


3345A

PARTS, OPERATION, AND MAINTENANCE MANUAL

WITH 2000 PARTS
INDEX AND 248

3200001-3210387
3610001-3610197
3620001-3620045
3370001-3370012



MA 30, 30 II
MA 40, 40 II
MA 50, 50 II

FORK LIFT TRUCKS

WHITE INDUSTRIAL DIVISION
WHITE MOTOR CORPORATION
MILWAUKEE, WISCONSIN

SUPPLEMENT TO MANUAL S-345A MA SERIES FORK LIFT TRUCKS

SUPPLEMENT INCLUDES CHANGES IN MAINTENANCE INSTRUCTIONS, SERIAL NUMBERS, AND REPAIR PARTS

REFER TO PAGE 1-33:

Change items 3 and 4 under paragraph C to read as follows:

3. Insert axle (50) in gear (31). Hold axle stationary and rotate cage. It must require a torque between 5 and 15 foot pounds to turn cage.
4. If torque required to rotate cage is over 15 foot pounds, reduce number of shims (use thinner ones) and repeat procedure in "2" and "3". If torque required is below 5 foot pounds, increase the number of shims and re-check torque.

THESE TORQUE SPECIFICATIONS ARE APPLICABLE TO DIFFERENTIAL CAGES THAT HAVE FOUR PINIONS.

REFER TO PAGE 1-39:

Add note:

CAUTION: THE PRESSURE REGULATOR VALVE (30A7200) USED ON LATER MODEL TRUCKS MUST NOT BE INSTALLED ON ANY TRUCK WITH A 2 PINION DIFFERENTIAL, OR TRUCKS THAT HAVE A 39A2240 REPAIR DIFFERENTIAL INSTALLED. EARLY TRUCKS WITH 2 PINION DIFFERENTIALS OR 39A2240 REPAIR DIFFERENTIALS CAN BE IDENTIFIED BY THE DESIGN OF THE DIFFERENTIAL CASE. THE DIFFERENTIAL CASE (36A-5180) USED ON EARLY MODEL TRUCKS DO NOT HAVE THE LARGE PLUG IN THE TOP OF THE CASE AS DO THE CASES (35A7810) USED ON LATER TRUCKS.


Discard test pressures given under Fig. 1-39 and use Fig. 1-38 and test pressures listed below it.

ADD TO SERVICING DIFFERENTIAL AND TRANSMISSION:

A set screw and lock nut have been added to adjust the position of the shaft for the reverse idler gear in the transmission. The set screw is located in the upper rear flange of the differential case.

If the set screw has been removed from the differential case during service work, apply Permatex or Locktite thread sealant to the threads in the hole and on the set screw before reinstalling the screw.

Turn in the screw until the idler shaft bottoms, then back out the screw 25 to 40 degrees (1/8 turn or less) and secure with the lock nut. This sets the proper end clearance on the reverse idler gear.



Before reinstalling the bearings (35A7752) for the drive axles, they must be repacked with grease. Use an automotive type, multi-purpose, lithium base grease, containing a moly-disulfide additive.

CASCADE TRIPLEX MAST

(See Figs. 2-37 and 2-38 in Manual S-345A.)

If the crosshead wear shoes (10, Fig. 2-37) become loose, it can cause failure of the interlocking latches and mating latch points. If the wear shoes are worn excessively, they must be replaced.

The side clearance between the wear shoes and mating channel members must be kept snug. This can be accomplished by using shims (13) between the shoes and shoe supports (14). Shims should be used on both sides of the crosshead to keep it square in the channels.

Check the side clearance every 150 hours of operation and lubricate the sliding channels, using a graphite base grease.

The bolts that secure the side rollers (6, Fig. 2-38) to the carriage may become loose after the lift truck has been in service for some time. This will allow the side roller to move out of position and can cause failure of the latches and mating latch points. Check these attaching bolts and nuts every 100 hours of operation to be sure they are tight.

Excessive side movement of the carriage can be removed with the adjusting screws (9). Loosen the lock nuts and tighten the four adjusting screws equally until the side play is reduced to a minimum.

Ref. No.	Part No.	DESCRIPTION	No. Pcs
		SERIAL NUMBER CHANGES IN S-345A	
		Refer to the following pages: 2-4, 2-5, 2-32, 2-36, 2-34, 2-73, 2-51, 2-86, and 2-69, and make the following changes: Change serial number on MA 30 from 28000126 to 29000111. Change serial number on MA 40 from 26100543 to 26100568. Change serial number on MA 50 from 26200185 to 26200169.	
		Refer to the following pages: 2-5, 2-6, 2-14, 2-34, 2-86, 2-79, 2-61, 2-86, and 2-62, and make the following changes: Change serial number on MA 30 from 29000126 to 29300112. Change serial number on MA 40 from 26100544 to 26100369. Change serial number on MA 50 from 26200186 to 26200170.	
		Refer to the following pages: 2-42, 2-44, 2-56, 2-64, and 2-65, and make the following changes: Change serial number on MA 30 from 28000145 to 28300121. Change serial number on MA 40 from 26100628 to 26100626. Change serial number on MA 50 from 26200205 to 2620024.	
		Refer to the following pages: 2-42, 2-44, 2-56, 2-66, and 2-70, and make the following changes: Change serial number on MA 30 II from 28000146 to 29000122. Change serial number on MA 40 II from 26100629 to 26100627. Change serial number on MA 50 II from 26200206 to 26200195.	
Page 2-9		Change Ref. No. 16 - F6001-802 to F6011-802 and F6001-301 to F6011-301 corr.	
Page 2-46		Add to description on 35A890 spool (Ref. No. 5), 1/2" O.D. x 2' long. Add to description on 35A7766 spring (Ref. No. 8), 1/2" O.D. x 1-11/16" long. Add to description on 35A375 spool (Ref. No. 19), x 2' long. Change description on 35A5177 block (Ref. No. 31 and 43), from 15/16" to 1-1/16". Change description on 35A5167 block (Ref. No. 32 and 40), from 5/8" to 3/4". Add to description on 35A7354 spring (Ref. No. 43), 2-11/64" long. Add to description on 35A7365 spring (Ref. No. 44), 1-13/16" long.	
Page 2-48		Omit Group II line and add the following: Group II Used on MA 30 Lift Trucks to No. 28000121, Inc. Used on MA 40 Lift Trucks to No. 26100626, Inc. Used on MA 50 Lift Trucks to No. 26200184, Inc. Change description on 35A590 spool (Ref. No. 6), from: 1-5/8" to 1/2" O.D. x 2". Add to description on 35A8027 spring (Ref. No. 48), 1/2" O.D. x 2-5/8" long. Add to description on 35A375 spool (Ref. No. 19), x 2' long. Add to description on 35A1248 spring (Ref. No. 23), 1-17/32" long. Add to description on 35A890 spring (Ref. No. 27), 2-1/8" long. Change description on 35A5177 block (Ref. No. 31 and 45), from 15/16" to 1-1/16". Change description on 35A5167 block (Ref. No. 32, 38, and 40) from 5/8" to 3/4". Add to description on 35A7354 spring (Ref. No. 43), 2-11/64" long. Add to description on 35A7365 spring (Ref. No. 44), 1-13/16" long.	

Rev. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-50, 2-51		Omit entire Group III and add new Group III.	
Page 2-56		Change 35A3730 nut following (Ref. No. 6) to GM120868 jam nut. Change 35A1890 nut following (Ref. No. 7) to 35A3742 jam nut.	
Page 2-64		Change 35A5453 stud to 35A5089 and length to 1-3/4". Change 35A6150 cap (Ref. No. 13) to 35A8244 (35A6150).	
Page 2-68		Add the following hardware to follow 35A7816 case: 35A4139 - Set Screw, slotted head, for idler shaft, 3/8" - 16 x 1" 35A1903 - Nut, hex., 3/8" - 16	1 1
Page 2-70		Add "O" ring to follow 35A8245 shaft: 35A5170 - "O" Ring - axle flange to housing Change 35A3680 bolt to 35A1164 bolt housing, 12 pt.	2
Page 2-74		Change 35A4254 clevis (Ref. No. 3) to 35A4278.	
Page 2-84		Change description on 35A8293 knob from tilt to lift.	
Page 2-86		Change 35A6139 hose (Ref. No. 28) to 35A9188 and size from 3/8" to 1/4" (35A6139). Change 35A6140 hose (Ref. No. 29) to 35A9189 and size from 3/8" to 1/4" (35A6140). NOTE: When replacing old hose, replace in pairs with new hoses.	
Page 2-91		Add roller pin 35A5523 for repairs as part of inner rail (Ref. No. 4) and carriage (Ref. No. 11). Change quantity on 35A3088 cap (Ref. No. 35) from 1 to 2. Change quantity on 35A8697 plunger (Ref. No. 33) from 1 to 2. Change quantity on 35A3696 spring (Ref. No. 43) from 1 to 2. Add to description on 35A3698, 35A3697, and 35A3696, on outer rail and carriage block.	
Page 2-11F		On cylinder assembly, MA 30 change 35A6740 thru 35A6769 to 35A7952 thru 35A7951. On cylinder assembly, MA 40-50, change 35A5232 thru 35A5261 to 35A7952 thru 35A7951. New cylinders have 3/4" lock nut.	

MOULIPT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pr.
		TRANSMISSION CONTROL VALVE AND REGULATOR	
		Group III. Used on Lift Trucks with Mechanical Inching. Used on MA 30 II Lift Trucks No. 26000122 and after. Used on MA 40 II Lift Trucks No. 26100627 and after. Used on MA 50 II Lift Trucks No. 26200165 and after.	
	38C1545	Valve - control, complete	1
		Includes the following 42 parts:	
1	35A591E	Body - valve	1
		50A8969 - Bolt, hex., 8/8" x 1-1/2"	2
		50A8372 - Bolt, hex., 3/8" x 1 3/4"	2
		*50A1829 - Star-o-seal, bolts, 3/8"	4
2	35A5248	Spool - directional, 3-7/32" long	1
3		50A4265 - Ball, steel, 3/16"	1
		50A4445 - Plug, pipe, hex. socket, 1/8" x 27	2
4	85A6386	Spring - spool ball, 23/32" long	1
5	10A18329	Seal - oil, lever spool, 3/4" I.D., 1/4" wide	2
6	85A090	Spool - inching, 1/2" O.D. x 2" long	1
7	85A699	Spring - centering, inching spool, 3/4" long	1
9	85A9227	Spring - inching spool, 1/2" O.D. x 1-5/8" long	1
9	85B5000	Inching Spool - assembly, complete, mechanical inching	1
15		50A196 - Snap ring, sleeve retainer	1
16	85A9306	Seal - inching spool in valve housing	1
18	85A37E	Spool - pressure reducer, 3/4" O.D. x 8" long	1
20	85A974	Spring - pressure spool, 1-3/4" long	1
21	35A1250	Valve - relief	1
22	85A1240	Piston - relief valve	1
23	35A1245	Spring - relief valve, 1-17/32" long	1
24	10A6329	"O" Ring - relief valve	2
25	35A398	Spool - priority valve, 15/16" long	1
26	85A991	Guide - priority valve	1
27	35A390	Spring - priority valve, 2-1/8" long	1
29	85A977	Valve - lube relief	1
29		50A426E - Ball, steel, 3/8"	1
30	10A12106	Spring - lube relief valve, 1" long	1
31	35A5177	Block - valve, 1-1/16" long	3
32	85A5187	Block - valve, 3/4" long	3
33	10A6329	"O" Ring - valve blocks, 9/16" I.D.	6
34	10A6330	Ring - snap, valve blocks	6
35	35A7887	Switch - neutral starting, with slip type terminals	1
36	35A7304	*Gasket - body to transmission case	1
37	35A9200	Body - pressure regulator valve	1
		50A1926 - Bolt, hex., 3/8" x 1 1/4"	1
		50A1927 - Bolt, hex., cad., 3/8" x 1 1/2"	1
		50A2249 - Bolt, hex., cad., 3/8" x 4-3/8"	1
		*50A1829 - Star-o-seal, bolts, 3/8"	3
		NOTE: Parts with single asterisk () are part of 35R23.	
38	85A090	Spool - pressure regulator	1
39	35A5187	Block - spool, 3/4" long	1
40	10A6329	"O" Ring - block	1
41	10A6330	Snap Ring - spool	1
42	35A7329	Piston - regulator valve	1
43	35A7384	Spring - piston, regulator valve, outer, 2-41/64" long	1
44	35A7855	Spring - piston to spool, inner, 1-13/16" long	1
45	35A5177	Block - piston, 1-1/16" long	1
46	10A6329	"O" Ring - piston, block	1
47	10A6330	Snap Ring - piston block	1
48	35A7336	Orifice - regulator valve	1
49	35A5187	Block - orifice, 3/4" long	1
50	10A6329	"O" Ring - orifice and block	2

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
TRANSMISSION CONTROL VALVE AND REGULATOR (Cont'd)			
51	10A6380	Snap Ring - block	1
52	35A7957	Screw - orifice	1
53	50A2879	Snap Ring - orifice	1
54	50A4265	Ball, steel, 5/16"	3
55	50A5031	Pin, dowel, 1/8" x 1/16"	1
56	50A4445	Plug, pipe, rtsk., 1/8"-27	2
57	50A2878	"O" Ring, regulator valve	5




FIG. 2-17B - TRANSMISSION CONTROL VALVE AND REGULATOR

Printed in U.S.A.

Technical Publications
10-4-66

SUPPLEMENT TO MANUAL S-345A

AND SUPPLEMENT C-280

FOR

MA SERIES FORK LIFT TRUCKS

INCLUDING MA 60

**WHITE
MOBILIFT**


WHITE INDUSTRIAL DIVISION

WHITE MOTOR CORPORATION

HOPKINS, MINNESOTA



This supplement covers changes and improvements that have been incorporated into the latest production of MA Series Lift Trucks, and includes the MA 60 Lift Truck. Use this supplement in conjunction with manual S-345A and Supplement C-269.

SPECIFICATIONS (MA60)

The capacity of the MA 60 Lift Truck is 6000 pounds at a 24-inch load center. A Continental engine, Model F163-802A supplies power for the lift truck. Specifications covering this engine are given below and reference must be made to these specs when performing an engine tune-up.

Governor Speed (No Load)	2650 RPM
Idle Speed	500 RPM
Converter Stall Speed	1000 RPM
Spark Plug Gap	Gasoline .325"
.....	L.P. Gas .615"
Breaker Point Gap020"
Timing Advance2° ATDC @ 500 RPM
.....	.8° BTDC @ 850 RPM
.....	1.4° BTDC @ 2400 RPM
Firing Order	1-3-4-2
Valve Clearance (Hot)	Intake .014"
.....	Exhaust .014"

HYDRAULIC SYSTEM RELIEF PRESSURES

REFER TO PAGE 1-5, FIG. 1-3 AND ADD;

POWER STEERING RELIEF (MA 60) 1200 ± 50 PSI

NOTE: LIFT SYSTEM RELIEF PRESSURE FOR MA 60 LIFT TRUCKS IS THE SAME AS FOR MA 80 (1000 PSI).

LUBRICATION

Refer to page 1-12, paragraph headings "HYDRAULIC OIL TANK" and "TRANSMISSION, DIFFERENTIAL, AND CONVERTER".

Delete Texaco 150E and insert Texaco Texamatic Fluid.

ZENITH CARBURETOR ADJUSTMENTS (MA60)

Refer to page 1-12; Carburetor adjustments given in paragraph 3-16 are satisfactory for Zenith gasoline carburetor used on MA 60 lift trucks. Fig. 1 shows Zenith carburetor.

GOVERNOR ADJUSTMENTS (MA 60)

Start engine and allow it to warm up to operating temperature. While engine is warming, back out surge (bumper) screw (3, fig. 1A) so it will have no effect.

IMPORTANT: BE SURE CARBURETOR IS PROPERLY ADJUSTED AND LINKAGE IS FREE OF BINDS BEFORE ADJUSTING GOVERNOR.



Fig. 1

1. Throttle stop screw
2. Idle adjusting needle

Depress accelerator to operate engine at full throttle, no-load. Turn nuts on speed adjusting screw (1, fig. 1A) to obtain a no-load speed of 2650 RPM. Shortening screw, placing more tension on spring, will increase engine speed.

If governor surges at no-load, turn in surge (bumper) screw (4, fig. 1A) one turn at a time until surge is eliminated. Do not turn screw in far enough to increase no-load speed more than a few RPM, if any.

Governor sensitivity (governor action between load and no-load RPM) is regulated by adjusting screw (3, fig. 1A) in flange bracket. Lengthening adjusting screw (moving speed adjusting screw forward) will alter pull on spring to broaden range of governor and produce more stable governor action. Shortening screw will narrow range and increase governor sensitivity. Maintain a dimension of 1-13/32" between centerline of speed adjusting screw and front edge of bracket for sensitivity adjusting screw for best results.




Fig. 1A

1. Speed adjusting screw
2. 1-13/32 inch
3. Sensitivity adjusting screw
4. Surge (bumper) screw

ENGINE TIMING

Follow procedure outlined in paragraph 3-19 on page 1-14 when timing engine, except use timing pointer and mark on crankshaft pulley. Fig. 2. A dab of white paint placed in pulley notch will make notch more legible under timing light.

Make a mark on pointer, 2 degrees AFTER top dead center. Operate engine at an idle speed of 500 rpm or less so automatic advance of distributor is completely retarded. Engine is in correct time when notch in pulley is lined up with mark on pointer that is 2° AFTER top dead center.




Fig. 2

1. Notch in pulley
2. Timing pointer

NOTE: FIG. 2 SHOWS TIMING POINTER WITH ENGINE REMOVED FROM LIFT TRUCK. POINTER IS LOCATED ON ALTERNATOR SIDE OF ENGINE.

REFER TO PAGE 1-29, PARAGRAPH 4-76C.

Insert the following timing advance for distributors used on MA 10 Lift Trucks with Model H113-8026 engines.

- 2° ATDC @ 500 RPM
- 6° BTDC @ 880 RPM
- 14° BTDC @ 2400 RPM

ALTERNATOR

The alternator and voltage regulator control the amount of electrical energy supplied to the battery and also maintain battery in fully charged condition.

IMPORTANT: IF IT BECOMES NECESSARY TO DISCONNECT WIRES FROM ALTERNATOR, BE SURE TO IDENTIFY WIRES ATTACHED TO "BAT" AND "GRD" TERMINALS SO THEY CAN BE RECONNECTED TO PROPER TERMINALS. IF WIRES ARE CROSSED WHEN RECONNECTED, JUST A MOMENTARY TOUCH TO ALTERNATOR TERMINALS COULD BE ENOUGH TO DAMAGE ALTERNATOR.

THE FOLLOWING PRECAUTIONS SHOULD BE OBSERVED TO PREVENT SERIOUS DAMAGE TO ELECTRICAL EQUIPMENT.

WHEN INSTALLING A BATTERY, MAKE ABSOLUTELY SURE THE GROUND POLARITY OF THE BATTERY AND THE ALTERNATOR ARE THE SAME. THE ELECTRICAL SYSTEM HAS A NEGATIVE GROUND.

WHEN CONNECTING A BOOSTER BATTERY, MAKE CERTAIN TO CONNECT THE NEGATIVE BATTERY TERMINALS TOGETHER AND THE POSITIVE BATTERY TERMINALS TOGETHER.

WHEN CONNECTING A CHARGER TO THE BATTERY, CONNECT THE CHARGER POSITIVE LEAD TO THE BATTERY POSITIVE TERMINAL AND THE CHARGER NEGATIVE LEAD TO THE BATTERY NEGATIVE TERMINAL.

DO NOT OPERATE THE ALTERNATOR ON OPEN CIRCUIT (NO BATTERY IN CIRCUIT). MAKE ABSOLUTELY CERTAIN ALL CONNECTIONS, INCLUDING BATTERY CABLES, ARE SECURE.

DO NOT SHORT ACROSS OR GROUND ANY OF THE TERMINALS ON THE ALTERNATOR OR REGULATOR.

DO NOT ATTEMPT TO POLARIZE THE ALTERNATOR.

If difficulty is experienced with the alternator or voltage regulator, see your local Delco-Remy dealer or Unired Motor Service as they have the facilities for repairing and testing this equipment.

A booklet covering general maintenance of Delco-Remy electrical systems is available from Delco-Remy, Anderson, Indiana. The number of this booklet is DR 5221 and the price is 25 cents.

Maintain proper tension on the fan and alternator drive belt by means of the adjusting bar. The belt has the correct tension when it deflects about 1/4 to 1/2 inch when approximately 10 pounds pressure is applied midway on the belt span.

STEERING GEAR (HYDRAULIC)

REFER TO PAGE 1-20, PARAGRAPH 4-30, a.
Add to follow paragraph "a":

Assemble worm to rack and align ball return guide holes with worm groove. Load 12 balls into guide hole nearest piston ring while slowly rotating worm counterclockwise to feed balls through circuit. Alternate black balls with standard balls.

Fill one ball return guide with remaining 6 balls. Place relief guide over balls and plug ends of guide with heavy grease to prevent balls from falling out when guide is installed in rack.

HYDRALIZER REPAIR

ADD TO PAGE 1-26, PARAGRAPH 4-39, REPAIR.

- d. Check condition of bushing (20) on piston (19). If original bushing is damaged or worn, it must be re-

placed. The outside diameter of bushing must be machined to a dimension of 4.996-4.997" after installation on piston.

ADJUSTING STEERING LINKAGE (MA60)

Park lift truck on level surface. Turn steering wheel to place steering housing in straight-ahead position and adjust tie rods if necessary, to place steer wheels in straight-ahead position. Detach booster cylinder from steering housing.

Turn steering wheel to extreme in both directions and adjust stop bolts on frame and steering fork to allow an 83 degree angle of inner steer wheel to side of frame (inner wheel as related to direction of turn).

With wheel held in 83 degree turn position, tighten stop bolts on center frame against steer housing arm and secure with lock nuts. Tighten stop bolts in steering fork against stop on frame, back out screw 1/4 to 1/2 turn and secure with lock nut.

NOTE: ADJUSTMENT OF STOP BOLTS ON STEERING FORKS MUST BE ACCOMPLISHED ON BOTH FORKS FOR EACH DIRECTION OF TURN.




Fig. 3

1. Stop bolts on center frame

Return steer wheels to straight-ahead position and adjust position of socket on steering booster so socket end can be installed in housing without moving housing from straight-ahead position. Recheck steering adjustments with drag link connected to be sure it allows full turn in both directions.

POWER STEERING HYDRAMOTOR (MA60)

REMOVAL AND DISASSEMBLY

Disconnect and cap oil lines connected to hydramotor. Identify lines so they can be properly reconnected. Disconnect transmission control rod by driving pin out of joint. Loosen hydramotor cover bolts sufficiently to allow hydramotor to escape support brackets. Remove entire assembly, including steering wheel and transmission shift lever.

Remove horn button assembly as described in paragraph 4-21 on page 1-22. Remove nut from steering shaft and remove steering wheel. Loosen nuts on column clamp and remove column, noting its position on steering assembly.

Loosen large nut on shaft near hydramotor, turning it until it is almost flush against hydramotor. Nut is staked so it will be tight at first. Loosen taper ring by tapping it toward hydramotor.




Fig. 4

1. Nut
2. Taper ring

Rotate taper ring until locking ball is exposed in hole. Tilt assembly so ball will fall out of hole. It may be necessary to tap taper ring lightly to dislodge ball. With ball removed, pull steering shaft off stub shaft.




Fig. 5

1. Ball

Remove large retaining ring that holds lower housing cover. Tap ring around until one end is near small hole in cover. Insert punch in hole, tap punch to dislodge ring and pry ring out with screwdriver. When ring reaches end-rotation lug, grasp ring firmly and pull it around and out from under lug.




Fig. 6

1. Retaining ring
2. Small hole for pencil.

Housing cover is spring-loaded and should come off when ring is removed. However, during operation, a small burr may be raised on main housing in contact with ring. If cover does not come off housing, tap mounting lugs with non-metallic mallet to loosen it.

Place bit in vise and remove cover by pulling it upward with a rotating motion. Remove spring from pressure plate. Remove "O" ring and back-up ring from groove in cover.




Fig. 7

1. Cover
2. Housing

Grasp pressure plate with both hands and carefully pull it off housing. Remove dowel pins.




Fig. 8

1. Pressure plate

Spread retaining ring for rotor and pry ring away from shaft with screwdriver.




Fig. 9

1. Removing rotor retaining ring
2. Dowel pins removed

Remove ring and rotor assembly by pulling upward on ring with slight rocking motion. If rotor sticks, rock ring and rotor until complete assembly can be removed.




Fig. 10

Slip ring out of ring and remove vanes. USE CAUTION when removing vanes as they are spring-loaded against ring.




Fig. 11

1. Ring
2. Vanes
3. Vane springs
4. Rotor

Tap end of drive shaft to dislodge bearing support from housing. Remove bearing support.

Withdraw drive shaft from housing. DO NOT USE FORCE TO REMOVE SHAFT. Spool and spool bore tolerances are very close and internal components may be damaged if spool is forced out of housing. If spool jams




Fig. 12

1. Bearing support
2. Tap end of shaft

In back, push assembly back into housing and again attempt removal.




Fig. 13

NOTE: COMPONENTS OF DRIVE SHAFT (ACTUATOR, SPOOL, STEER SHAFT, ETC.) ARE SELECTIVELY FITTED AND FACTORY BALANCED, SO FURTHER DISASSEMBLY IS NOT RECOMMENDED. IF ASSEMBLY IS FUNCTIONALLY DAMAGED, IT WILL BE NECESSARY TO REPLACE ENTIRE UNIT.

Remove seal retaining ring from housing and remove dust shield and oil seal.




Fig. 14

1. Retaining ring
2. Dust shield
3. Oil seal

REPAIR AND REASSEMBLY

Clean all parts in a petroleum base solvent and blow dry with compressed air. Inspect all parts for wear or damage. Use extreme care when handling parts to avoid nicking or scratching machined surfaces.

Renew all seals when reassembling unit. To remove rotor seal and back-up "O" ring from pressure plate and bearing support, pry parts out with a small screwdriver as shown in Figs. 15 and 16. Use a new "O" ring seal in groove around bearing support.




Fig. 15

1. Back-up "O" ring
2. Rotor seal in pressure plate

Check needle bearings in pressure plate and bearing support. Also, check condition of needle bearing in housing. Replace any bearing that is badly worn or damaged. When installing new needle bearings, always press against end of bearing on which number appears.

Install needle bearings in various components as follows:

Press needle bearing into pressure plate until it "bottoms".

Press needle bearing into bearing support until it is $.010-.020$ " under flush with surface of bearing support that is opposite rotor seal cavity.

Press needle bearing into housing until it is flush to $.020$ " under flush with surface of bearing bore in housing that is nearest small end of housing.




Fig. 16

1. Back-up "O" ring
2. Rotor seal in bearing support
3. Use new "O" ring in groove

Check all bearing surfaces on drive shaft and grub shaft for excessive wear. Check spool drive pin in actuator. If any components are worn or damaged, entire valve and housing assembly must be replaced.

Check fit of valve spool in housing bore. The spool must slide in freely without binding or catching. A small burr on spool or housing bore can usually be removed with a very fine hone. Extreme care must be taken not to cock or jam spool in housing bore when checking spool fit.

Check to be sure spool drive pin is properly engaged. This can be done by pulling spool away from actuator as shown in Fig. 17. If spool does not move axially away from actuator, pin is engaged. If, however, spool does move away from actuator, pin should be relocated in spool by letting spool come back against actuator and inserting pin into either one of two holes in base of spool.




Fig. 17

Check valve spool bore in housing for scoring or nicks. If any defects are found, it will be necessary to renew entire valve and housing assembly. If housing is in serviceable condition, renew oil and dust seals in housing. The spring-loaded lip of oil seal must face to inside of housing, lip on dust seal must face to outside.

Examine face of pressure plate for heavy score marks or other unusual wear patterns. In normal service, pressure plate face will have a polished surface with symmetrical shallow scratch marks resulting from contact with vanes, rotors, and vane springs. Discard pressure plate if it is badly worn or scored.

Check bore of rotor ring to see that it is not deeply scratched or grooved. A highly polished finish should be present on this surface. Slight irregularities in ring bore can be removed with crocus cloth.

Inspect vanes and rotor for excessive wear. The faces of rotor and all surfaces of vanes usually have a highly polished finish. A circular wear pattern from rotor seals may be present around splined hole.

IMPORTANT: IF ANY PARTS OF ROTOR SET ARE FOUND TO BE DEFECTIVE, THEY MUST BE REPLACED ONLY AS A COMPLETE SET AS SHOWN IN FIG. 19.




Fig. 18

Begin reassembly of hydraulic motor by clamping housing in a vise as shown in Fig. 19. Apply a film of grease to inside diameter of oil seal in housing. Insert drive shaft and valve spool assembly in housing from top. Push assembly into housing slowly and evenly with a slight oscillating motion until spool is seated.

CAUTION: BECAUSE OF EXTREMELY CLOSE TOLERANCES BETWEEN SPOOL AND HOUSING BORE, CARE MUST BE TAKEN WHEN INSTALLING VALVE SPOOL ASSEMBLY.

Place bearing support over end of drive shaft with rotor seal facing up. Push shaft upward until bearing is engaged on drive shaft.



Fig. 19

Apply a light film of grease to "O" ring seal around bearing support and push assembly downward into housing. Be careful not to cock bearing support when applying downward pressure as this could damage "O" ring. Push down on bearing support until it is bottomed.




Fig. 20

IMPORTANT: MAINTAIN CLEAN WORKING CONDITIONS TO AVOID GETTING ANY FOREIGN MATERIAL INTO UNIT. CAREFUL THOUGHT TO CLEANLINESS WHILE SERVICING COMPONENTS OF POWER STEERING SYSTEM WILL PREVENT FUTURE TROUBLE.

If rotor ring, rotor, and vanes are found to be in a re-usable condition, assemble components of rotor set before attempting to reinstall assembly to hydraulic unit.

Lay rotor ring on a clean, flat surface and place rotor in ring. Assemble vanes in rotor slots in each major diameter of rotor ring as shown in Fig. 21. Be sure rounded side of vanes are to outside (against the pump ring).




Fig. 21

1. Vanes installed in major diameter

Turn rotor 90 degrees and install remaining six vanes. To aid in installing last six vanes, compress vane springs with a screwdriver.

After all vane springs are engaged with vanes on one side of rotor, turn rotor and ring assembly over and engage springs to vanes on this side.

IMPORTANT: AFTER ALL VANES ARE INSTALLED, CHECK TO BE SURE ALL VANE SPRINGS ARE ENGAGED AND DO NOT PROTRUDE ABOVE SURFACE OF ROTOR.

Align marks made on the rotor ring and housing at disassembly and install ring and rotor assembly. If only one edge of rotor ring O.D. has a chamfer, install ring so chamfer is up, away from housing. The chamfer is most prominent in dowel pin area of ring.

Install dowel pins through ring and into housing. Install a new retaining ring for rotor. Spread ring with a snap ring pliers and work ring into groove with a screwdriver.

Install pressure plate on dowel pins and push plate down onto ring and rotor assembly. Special care must be taken so rotor seal does not drop out of its cavity when pressure plate is installed. Set pressure plate spring in place so it engages hub on pressure plate.




Fig. 22

1. Installing retaining ring
2. Dowel pins installed (1 shown)

Install a new "O" ring and back-up ring in housing cover. Stretch "O" ring before installing. Flat back-up ring must be installed so it is nearest open end of cover. Apply a coat of grease to back-up ring and seal to facilitate installing cover.




Fig. 23

1. "O" ring (inner)
2. Back-up ring

Carefully plane cover on unit, lifting up notch in cover with lug on housing. A slight binding of cover can be felt as cover seal engages O.D. of rotor ring. To start seal onto ring, rotate cover back and forth while exerting downward pressure. Keep notch and lug lined up.

CAUTION: BE SURE COVER DOES NOT COCK OR JAM DURING INSTALLATION AS THIS COULD RESULT IN DAMAGE TO SEAL.

Push cover down until pressure plate spring prevents it from being pushed any further. Remove unit from vise and place it in an arbor press. Handle unit carefully to prevent cover from slipping off housing.

Place cover retaining ring on housing, and place a sleeve on housing as shown in Fig. 24. Use a sleeve of sufficient length so that when unit on arbor press is brought down it will not contact drive shaft.

CAUTION: A SLEEVE MUST BE USED TO MOVE HOUSING DOWN INTO COVER. DO NOT APPLY PRESSURE TO SHAFT AS THIS WILL DISLodge INTERNAL COMPONENTS.




Fig. 24

1. Sleeve
2. Cover retaining ring

Apply pressure to housing to push it down into cover until retaining ring groove is exposed. Be sure housing is pushed squarely into cover. DO NOT USE FORCE. Light taps with a soft mallet, around edge of cover will aid in aligning housing and cover during installation.

Install cover retaining ring, placing one end of ring under anti-rotation lug to begin with. Work ring around cover until it is solidly seated in ring groove. Remove unit from press.

Place taper ring on steering shaft so holes for locking ball are aligned. Install nut on steering shaft so a few threads are engaged.

Install steering shaft on stub shaft so holes in shaft and taper ring are aligned with groove in stub shaft. Hole must not be located above flat on stub shaft since ball will not lock shaft in this position. Locate hole 90 degrees from flat on stub shaft.

Place lock ball in hole, allowing it to fall into place in stub shaft groove. If necessary, push ball into place with a punch. Rotate taper ring 1/4 turn so ball is locked in place.

Tighten steering shaft nut until taper ring is pushed up tightly on steering shaft (40-50 ft. lbs. torque). Stake nut to slat in steering shaft.

Reinstall steering column, placing clamp bolt 180 degrees from anti-rotation lug on hydramotor. Tighten nuts on column clamp to 10-15 ft. lbs.

Reinstall steering wheel and tighten nut to 25-40 ft. lbs. Reassemble horn button in reverse order of disassembly as described in paragraph 4-21 on page 1-22.

Install new "O" rings on elbows for hydraulic lines if there was evidence of oil leakage. When removing an elbow, note its position so it can be reinstalled in its original position.

Dip new "O" ring in hydraulic oil, or coat with Lubri-plate, and install on elbow. Be sure there are no twists in "O" ring after it is installed. Screw elbow part way into housing, then tuck "O" ring into recess in housing. Tighten elbow until it points in its original direction, then tighten down lock nut.

CAUTION: DO NOT ATTEMPT TO RELOCATE ELBOW AFTER LOCK NUT IS TIGHTENED, AS DOING SO WILL DAMAGE SEAL. IF IT IS NECESSARY TO REPOSITION ELBOW, FIRST LOOSEN LOCK NUT.

Reinstall hydramotor in its original position. Tighten pivot bolt to hold hydramotor in place and secure bolt with lock nut. Reconnect transmission control rod and reconnect oil lines to hydramotor.




Fig. 25

1. Tube to cylinder - right turn
2. Tube to cylinder - left turn
3. Pressure tube from pump
4. Return tube to pump
5. Latch for steer wheel position

Fig. 25 shows latch that holds steering wheel in one of two positions. Depress latch with foot to tilt steering wheel forward or back.

POWER STEERING BOOSTER (MA60)

REMOVAL (See figure on page 31 of supplement).

Disconnect and cap oil lines (25) attached to booster (19). Identify oil lines so they can be reconnected to original ports. Remove nut (12) and detach socket (11) from steering housing. Remove nut (19) from stud (18) and remove stud from frame bracket. Remove booster.

DISASSEMBLY (See figure on page 34 of supplement).

Remove socket from piston rod, noting its location on rod. Drain oil from booster by moving piston rod back and forth in booster.

Remove 3 slotted head screws and remove end plate (17). Remove rings (13 and 16). Pull out piston and rod assembly (1) to dislodge bearing (7) from housing.

Remove bearing from piston rod and remove items 8 through 15 from bearing. Remove "O" ring (14) and back-up ring (15) from bearing. Remove piston ring (6) and seal (5) from piston.

REPAIR AND REASSEMBLY

Clean all parts in solvent and inspect for wear or damage. Check piston and barrel bore to be sure they are not scratched or scored. Renew any faulty components.

Replace all seals and "O" rings during reassembly. Apply a coat of Lubriplate or clean hydraulic oil to all seals and "O" rings to facilitate installation and prevent seal or "O" ring damage.

Carefully install seal (5) in piston groove, checking to be sure seal was not cut or twisted. Install piston ring (6) in groove, on top of seal.

NOTE: IF NEW PISTON IS INSTALLED ON ROD, TIGHTEN PISTON ROD NUT TO 50 FT. LBS.

Install piston and rod assembly in tube, using care not to damage piston ring.

Install "O" ring (14) and back-up ring (15) on piston rod bearing so "O" ring (14) will enter cylinder tube first at assembly. Install assembly in tube and secure with ring (16).

Install "O" ring (8) over threads and notches in piston rod, being careful not to twist or cut ring. Tuck ring into place in bearing housing. Install back-up ring (9), retainer ring (10), seal retainer (11). Secure parts in bearing housing with ring (13). Reinstall cylinder end plate (17).

Reinstall socket on piston rod in approximately its original position. Reinstall booster in lift truck and reconnect hydraulic lines. Bleed air from cylinder. Check and adjust steering linkage as outlined on page 4 of this supplement.

BLEEDING POWER STEERING SYSTEM

Any time power steering system is opened for service, it will be necessary to bleed system to remove air. Be sure oil in hydraulic reservoir is up to specified level.

Start engine and run at idle speed. Rotate steering wheel as rapidly as possible to unseat control valve spool in hydramotor. Valve spool must be actuated off-center to start oil flowing from hydraulic pump to hydramotor.

Keep valve spool actuated by rotating steering wheel from one stop position to the other. Air will bleed out only at reservoir, therefore, rotate steering wheel rapidly from one stop position to the other to circulate oil repeatedly in both directions.

Oil in lines to steering cylinder does not flow in a circuit, but simply moves back and forth in lines. Oil pumped to cylinder with hydramotor during bleeding operation reaches a "dead end" at piston, so any air in these lines will be slow to move out of system. Large air bubbles in system will allow steering wheel to "free-spin" as air enters hydramotor; small bubbles will cause a spongy feel at steering wheel.

SERVICE BRAKES (BENDIX)

REMOVAL (See figure 2-23A.)

Jack up front of truck and remove drive wheel. Brake drum is an integral part of wheel center.

Remove two flat head screws from axle flange. Thread two 3/8" cap screws evenly and gradually into tapped holes in flange. This will force axle shaft out of housing.

Remove retainer ring (44) and pull bearing housing (40) with items 41 through 43 from housing (33).

DISASSEMBLY (See figure on page 37 of supplement)

Unhook shoe return springs (14 and 15) from wheel cylinder bolt (23) and remove springs.

Move lever (12) for automatic adjuster to obtain slack in cable (16). Unhook cable from cylinder bolt and adjuster lever. Remove lever and spring (13). Remove brake adjusting screw assembly (8 thru 11).

Press down on spring retainer (7) and turn it 90° to remove it from pin (4). Hold pin if necessary to keep it from turning. Remove spring (6) and inner retainer (5). Remove shoes (3).

Remove retainer (31) from parking brake cam (24) and remove cable guide (32) and retainer clip (30). Unhook cable (27) from parking brake lever (24). Levers may be removed by removing retainers (26).

IMPORTANT: IF PARKING BRAKE LEVER (82) OR CAM (28) IS TO BE REMOVED, MAKE A CHISEL MARK ON LEVER AND CAM SO PARTS CAN BE INSTALLED IN SAME RELATIVE POSITION.

Slip rubber dust cups from wheel cylinder body and withdraw pistons. Press in on edge of cup in cylinder to flip cup sideways and remove cups and springs.

To remove wheel cylinder body, disconnect oil line and remove mounting bolts and screws. Backing plate (2) can now be removed if desired.

REPAIR

Discard brake shoes with linings and rubber parts used in wheel cylinder. Check all springs for fatigue cracks. Examine fittings on ends of cables to be sure they are securely attached.

IMPORTANT: CHECK CABLE (16) FOR IDENTIFICATION MARK "A" STAMPED ON ONE EYELET. IF NO IDENTIFYING MARK CAN BE FOUND, AND BRAKE SHOES ARE TO BE REPLACED, A CABLE 35P2194, IDENTIFIED WITH AN "A" ON ONE EYELET, MUST BE USED.

Wipe wheel cylinder bore absolutely clean. Check bore for pits or corrosion. Remove any rough spots with fine crocus cloth.

REASSEMBLY

Reassemble in reverse order of disassembly. Tighten cap screws in backing plates to 115-120 ft. lbs. Tighten cap screws and allen head screws securing wheel cylinder to backing plate to 400-450 inch pounds.

Coat bores in wheel cylinder with clean brake fluid. Install new boots (in kit 35P2200) on pistons. Boots must be installed on pistons so they will engage grooves in cylinder housing when installed.

Coat rubber cups with clean brake fluid, and, with spring centered in cup, install spring and cup in cylinder. Use care to prevent damage to lip on cup.

Install piston in cylinder and slip box in place in groove around cylinder housing.

If parking brake lever and cam were removed, reinstall them, using marks made at disassembly to be sure they are properly reassembled.

Reinstall parking brake levers on pins in backing plate. Hang retainer clip for parking brake cable on parking brake cam, slip cable in groove in cable guide and install guide on cam. Secure with retainer ring. Attach cable to parking brake lever.

Apply a thin coat of light grease to area of backing plate that shoes rub on. Install brake shoes. Primary shoe does not have cable guide and attaches to forward

position on backing plate. Secure shoes with hold-down parts.

Install brake adjuster screw between shoes so that wheel is nearest secondary (rear) shoe. Attach adjuster cable to wheel cylinder bolt and place cable around guide on secondary shoe.

Reinstall spring between primary shoe and adjuster lever. Connect cable to adjuster lever then pull lever toward lower end of secondary shoe and hook lever in hole in secondary shoe. Install return springs at upper ends of shoes. Fig. 26 shows brake assembly installed.

NOTE: A SPECIAL TOOL FOR INSTALLING SHOE RETURN SPRINGS IS AVAILABLE FROM BENDIX CORPORATION, SOUTH BEND, INDIANA, UNDER THEIR PART NUMBER BPD41238F4.




Fig. 26

Reinstall bearing housing and axle in reverse order of disassembly. If bearing adjustment is not correct, refer to revised information found on page 18 of this supplement for procedures to follow for obtaining correct end play and bearing adjustment.

Bleed wheel cylinders after installation is complete. Be sure master cylinder is full before bleeding. Always use a bleeder hose to prevent brake fluid from running down back plate and entering brake drum. Apply foot pressure to brake pedal and hold pedal down while loosening bleed screw. Allow air to escape from wheel cylinder and line. Tighten bleed screw before releasing brake pedal. Replenish fluid in master cylinder if necessary.

Apply brake pedal and hold pressure in system. Check for signs of fluid leaks if pedal slowly travels to floor.

Operate lift truck at slow forward speed to determine that brakes stop truck evenly and quickly.

If pedal travels an excessive amount before braking action begins, it may be due to brake shoes not being adjusted to drums. A series of stops with lift truck travelling in reverse direction will help adjust brakes.

DRIVE WHEEL BEARINGS AND SEALS

THE FOLLOWING INSTRUCTIONS SUPERSEDE THOSE GIVEN IN MANUAL 5-345A REGARDING SERVICE OF DRIVE WHEEL BEARINGS AND SEALS.

DISASSEMBLY (See figure 3-22A.)

If a wheel hub must be removed to correct an oil leak, remove drive wheel and axle shaft. If red transmission fluid is noted in wheel hub, axle seal (38) is leaking and requires replacement. Hub seal (4) must be replaced if oil or grease is found on brake drum or outside of hub.

After drive wheel and axle shaft have been removed, drive outer bearing cone inward (away from bearing retaining ring) as far as it will go. Measure clearance between ring and bearing cone with feeler gage. If bearing-to-ring clearance is in excess of .002", a bearing adjustment will be necessary at reassembly. (The recommended end play for wheel bearing cones is zero to .002" loose-zero preferred).

Record measured clearance (if in excess of .002") between snap ring and bearing so, if reassembly is made with original bearing cones and retaining ring, a bearing spacer that is the measured amount thicker than original spacer will result in correct bearing adjustment.

Remove snap ring and wheel hub (bearing housing) containing bearings and seals.

REASSEMBLY

When reassembling seals for axle housing, apply sealant to seal bores. The recommended sealant to use is a sill-coke-rubber adhesive-sealer manufactured by either Dow-Corning, Inc. (RTV-732), or General Electric Corporation (KRV162). This sealant is generally available in hardware stores. It requires approximately 10 minutes to set after exposure to air.

Use sealant between axle flange and wheel hub on lift trucks that do not use an "O" ring at this location.

Apply a thin, continuous line of sealant on seal bore prior to pressing new seal 55A9620 into place. Install seal with lipped edge to inside, using a seal driver large enough to contact outside shell of seal. Use care to avoid cocking seal. Be sure seal is squarely seated against shoulder after installation, but do not apply excessive pressure as shell may buckle.

Install inner bearing cup in housing. Use original cup if possible to minimize bearing adjustment.

Prepare an assembly of wheel bearing cones, shim washer, and snap ring. If new components are being used, it will be necessary to determine correct shim washer to use between bearing cones to obtain a zero to .002" bearing end play.

To determine correct shim washer to use, measure distance between bearing shoulder and OUTER edge of snap ring groove in axle housing. Stack two bearing cones and snap ring and select shim washer so measurement over cones, shim washer, and retainer ring equals dimension obtained from axle housing.

A gauge (tool) for determining correct stack height of cones, shim, and ring can be made by filing a small rod so its length exactly equals distance between bearing shoulder and outer edge of snap ring groove in axle housing. Use gauge, together with straight edge, to determine correct stack height.

NOTE: A NEW GAUGE MUST BE MADE FOR EACH AXLE HOUSING THAT IS SERVICED.

After determining correct shim, pack bearing cones with an automotive-type, multi-purpose, lithium base grease, containing a moly-disulfide additive. Work grease into bearing so spaces around rollers are filled with grease.

Install hub on axle housing, being careful not to damage seal in hub. Install inner bearing cone, selected shim, outer cone, outer cup, and snap ring.

Install axle shaft less shims that are ordinarily used between axle flange and bearing housing. Install countersunk head screws and tighten until they are just snug. Rotate wheel hub several turns and measure space between axle flange and hub at both screws. Adjust screws so space between flange and hub at screws, and 90 degrees from each screw is equal. Tap axle shaft sharply several times and again rotate hub and retighten screws evenly. Repeat until no further take-up is obtained. Do not apply pressure with screws.

Wrap a stout string around outside of wheel nuts and attach a spring scale. Record pounds pull required to rotate hub.

Prepare a shim pack .002" thinner than space between axle flange and hub. Remove axle, install shim pack and axle, and tighten countersunk screws. Again obtain a rolling torque reading and vary shim pack as necessary so assembled rolling torque is 2 to 4 pounds greater than reading obtained without shims.

Remove axle shaft. Apply sealant to seal bore in axle housing and carefully install seal with lipped edge toward inside. Install collar with flat side toward seal and drive into bore until it contacts seal. The collar serves as a guide when axle shaft is installed to prevent damage to seal.

If no "O" ring is used between axle flange and wheel hub, coat flange on axle shaft that extends into wheel hub with same sealant specified for seal bores before axle is installed. Service axle with 2 countersunk screws.

ZENITH CARBURETOR (MA60)

REMOVAL AND DISASSEMBLY

Detach air cleaner hose from carburetor and remove air cleaner and mounting bracket. Flow divider must be removed from hydraulic pump before carburetor can be removed. Detach accelerator and governor linkages, choke cable, and fuel line, and remove carburetor from manifold.

Identify or mark relationship of carburetor components as carburetor is disassembled so parts can be reassembled in original position.

Disassembly of carburetor is complete upon removal of all attaching parts of each component.

REPAIR AND REASSEMBLY (See illustration on page 22 of supplement.)

Clean all parts in cleaning solution and dry, using compressed air. Carefully examine all parts for wear or damage.

NOTE: If throttle shaft bushings are found to be badly worn, carburetor throttle body should be taken to a Zenith Service Shop for installation of new bushings. Bushings must be line-bored after installation and economizer restriction passage and channel from body bore into throttle shaft bore must be redrilled.

Reassemble carburetor in reverse order of disassembly, using parts found in repair kit. Use marks made at disassembly to insure that various components are reinstalled in original position.

The float controls fuel level in carburetor bowl. After float is installed, turn throttle body upside down and measure distance from float bodies to machined surface on body (no gasket). The correct dimension is $1\frac{5}{32}$ " plus or minus $\frac{1}{32}$ ". If dimension is incorrect, bend float arms to obtain correct dimension.




Fig. 27

1. $1\frac{5}{32} \pm \frac{1}{32}$ "

Reassemble remaining carburetor components and re-install carburetor on engine. Adjust carburetor as explained in paragraph 2-16 on page 1-13 of Manual S-345A.

HYDRAULIC PUMP (MA60)

REMOVAL AND DISASSEMBLY (See figure on page 41.)

Drain hydraulic oil reservoir. Disconnect and cap oil lines connected to pump. Remove lower pump mounting bolt. Remove nut from long bolt that passes through pump and governor, allow pump to tip down and remove long bolt. Withdraw pump from engine.

Remove nut from pump shaft and remove gear (34) and Woodruff key. Remove screws securing adapter (9) to pump. Remove adapter and "O" ring (10).

Mark flow divider body (24) and pump so flow divider can be reinstalled in its original position. Remove flow divider and "O" rings (23).

Scratch a line on side of pump cover (9) gear plate (16), and body (2) so gear plate, if reusable, can be reinstalled in its original position. Loosen cover-to-body bolts a few turns and tap screws with a soft mallet to separate cover, plate, and body. Remove bolts and carefully lift off cover.

IMPORTANT: DO NOT PRY COVER OFF WITH A SCREWDRIVER OR OTHER SHARP INSTRUMENT AS THIS WILL DAMAGE MACHINED SURFACES OF GEAR PLATE AND COVER.

Remove wear plate (19), noting that bronze-placed side of plate is toward pump gears and that two small holes on one side of plate are toward small (pressure) port in cover.

Before removing gears (6 and 15), check clearance between gears and gear plate as shown in Fig. 28. If clearance exceeds .005 inch, a new gear plate must be used. Remove gears, gear plate, and wear plate (18).




Fig. 28

1. Clearance must not exceed .005"

Remove seals (20), back-up rings (22), and seals (21) from pump cover and body. Note position of back-up ring in relation to molded rubber seal. Also, notice that flat side of molded rubber seal is in bottom of groove in cover and body. Remove "O" rings (23) from pressure ports in cover and body.

Tap splined end of drive shaft (5) to dislodge bearing (7) and shaft assembly from body. Remove thrust washer (11). Disassemble bearing from shaft by removing one snap ring (8). Remove 4 screws in seal plate (12) and remove plate from body. Remove "O" ring (14).

Remove plugs from flow divider body to disassemble flow divider piston and spring, and components of power steering relief valve. Figs. 29 and 30.




Fig. 29

1. Spring
2. Flow divider piston
3. Plug with "O" ring




Fig. 30

1. Plug
2. Shims
3. Spring
4. Relief valve

REPAIR AND REASSEMBLY

Select a clean, dust-free area of shop for servicing and reassembling pump. Avoid handling pump parts with extremely dirty hands and do not use rags with excessive amounts of lint for wiping or cleaning pump parts. Keep pump parts immaculately clean during reassembly.

After thoroughly cleaning pump parts, carefully inspect them for wear or damage. Check condition of wear plates and replace them if they are warped or deformed, or worn excessively in gear travel area. (Wear plates will be worn more on pressure side -- side of plates with two small holes.)




Fig. 31

1. Worn areas on plates

Examine flow divider and relief valve parts. If relief valve or flow divider piston is grooved, scratched, or scored, they must be replaced. Use new springs if original ones are weak or broken. Replace entire flow divider assembly if bore for flow divider piston is damaged.

Check condition of drive and idler gears. If gears are worn, nicked, or otherwise damaged, recommended practice is to replace them as a set.

Check seal seating area on drive shaft. If seat is rough, it can possibly be cleaned up with crocus cloth, however, if seat area is badly grooved, it will be necessary to replace drive shaft.

Check condition of needle bearings in body and cover. These "blind" needle bearings are extremely difficult to remove without specialized pulling tools, so if there is evidence of bearing damage, install a new cover or body assembly with bearings installed.

If clearance between gears and gear plate, checked during disassembly, was not in excess of .005" as specified, and gear plate is to be re-used, check pressure areas of plate. If these areas are badly scored or discolored, replace gear plate.

Always replace all "O" rings, seals, and back-up rings when reassembling pump. Re-using original seals will often lead to leaks soon after overhaul. Dip "O" rings and seals in clean hydraulic oil when they are installed.




Fig. 32

1. Check for scoring in these areas

Install a new seal in seal plate, pressing seal into place from rear as shown in Fig. 33. Seal must be installed so spring-loaded lip is toward gears when seal plate is installed. Be careful when installing seal so as not to damage seal lip.




Fig. 33

1. Seal plate
2. Spring-loaded seal lip

Install a new "O" ring in body as shown in Fig. 34, and install seal plate and seal assembly. Tighten attaching screws securely.




Fig. 34

1. "O" ring for seal retainer plate

Install bearing on drive shaft, securing it with snap rings. Lay thrust washer in place on seal plate and reinstall shaft in body. Tap shaft with soft mallet, if necessary, to seat bearing in body.

Install molded rubber seal (21) in groove in pump body, with flat side of seal in groove bottom. Carefully lay back-up ring (22) in place on top of seal ring. Be sure back-up ring is completely seated around molded rubber ring and that there is no interference between seal ring and back-up ring. Fig. 35 shows a cross section view of molded seal ring and back-up ring in groove.

Install large, oval-shaped seal ring in pump body with flat side down. This oval-shaped ring that surrounds wear plate is molded in an L-shape as shown in Fig. 36.




Fig. 35

1. L-shaped seal
2. Metal back-up ring
3. Molded seal with flat side in groove
4. Wear plate

Install a new "O" ring around pressure port in pump body. (Pressure side of pump is area within molded seal and back-up ring.) Fig. 36 shows rings, molded rubber seals, back-up ring, and oval-shaped seal installed in pump cover. These parts are installed in body section in same way.




Fig. 36

1. L-shaped seal
2. Metal back-up ring
3. Molded seal
4. "O" ring around pressure port

Lay wear plate in place on body so bronze-plated side of plate will be toward gears, and two small holes (1/8") are located in area within molded seal and metal back-up ring. Wear plates must fit snugly in oval-shaped seal ring (plate should move just slightly from top to bottom).

IMPORTANT: IF NEW WEAR PLATES ARE BEING USED, RUB EDGES OF PLATES WITH A FINE STONE TO REMOVE ANY BURRS.

Reinstall dowel pins and install gear plate so word IN, stamped in side of plate, will be toward suction side of pump. This is side of pump opposite area within molded seal.




Fig. 37

1. Identification on gear plate

Apply a generous coat of Lubriplate to all surfaces of drive and idler gears and install gears. Lubriplate on gears will aid in initial prime of pump and provide lubrication until hydraulic oil is drawn into pump.

Apply Lubriplate to bronze-plated side of other wear plate and install plate with bronze-plated side against gears.

Install seals and back-up rings in cover as shown in Figs. 35 and 36 and install cover on pump. Use extreme caution when installing cover to body to be sure wear plate is properly seated within oval-shaped "O" ring. If plate is cocked so it does not lay within large seal, pump will not function at capacity.

Reinstall cover-to-body bolts. To avoid distorting cover, tighten bolts evenly, a little at a time, alternating from side to side. Torque bolts to 100-210 INCH pounds.

Install new "O" rings in pump cover and re-install flow divider body, aligning marks made at disassembly. Tighten flow divider attaching bolts to 17 ft. lbs.

Install new "O" ring for pump mounting adapter and re-install adapter. Reinstall pump, using a new gasket.

After pump is reinstalled, and before reconnecting oil lines, prime pump by pumping clean hydraulic oil into ports, using a pump-type oil can. Reconnect oil lines.

Power steering relief pressure is to be 1200 PSI, plus or minus 50 PSI. Relief pressure is regulated by using shims between plug and spring (See Fig. 30.) Fig. 38 shows location of plug for relief valve. To check steering relief pressure, install gage in small port in flow divider body.



Fig. 38

1. Plug for relief valve
2. Test port-power steering relief

WIRING HARNESS FUSES

The main wiring harness on lift trucks equipped with an alternator contains two 20 amp fuses and one 14 amp fuse. The 20 amp fuses serve as the main (primary) fuses for the entire wiring circuit and protect all the wiring whether the ignition switch is turned on or off. These fuses are contained in white cases and can be found near the starting motor solenoid. Check both these fuses when replacing.

NOTE: LIFT TRUCKS EQUIPPED WITH A GENERATOR USE TWO 14 AMP FUSES IN PRIMARY WIRING CIRCUIT.

The 14 amp fuse in the main wiring harness, is located up under the instrument panel and protects the ignition and instrument circuit.

The wiring harness (36A8207) for the horn circuit contains a 14 amp fuse to protect this circuit. This fuse can be found up under the instrument panel.

If the lift truck is equipped with lighting equipment, the lights are protected by a 14 amp fuse.

NOTE: WHEN IT BECOMES NECESSARY TO REPLACE A FUSE, USE ONLY AN SFF FUSE OF RECOMMENDED AMPERAGE.

SIMPLEX MAST

REMOVAL AND DISASSEMBLY (See illustration page 45 of supplement.)

Remove forks (42) by disengaging levers (44) and sliding forks to notch in lower carriage bar for removal.

Support mast assembly with hoist or other means to keep it from falling when detached. Disconnect hydraulic tubing from lift cylinder.

Drive out roll pins securing lift cylinder pins to mast. Thread a 3/8"-16 NC bolt into pins and pull out pins. Remove clamp blocks (2) and lift mast assembly up and away from truck. Place assembly on floor, with back of assembly down.

Remove pins (25) to detach chains and roll carriage assembly (13 or 17) out of bottom of mast assembly. Remove pin (26) to detach chain from anchor (27). Remove chains.

Loosen set screw (33) in piston head (32) and slide piston head away from cylinder. Remove bolt in cylinder base and remove cylinder. Remove shoes (34) and shims (35) from piston head and remove piston head.

Slide inner rail assembly (5) toward upper end of outer rail assembly (1) until first set of rollers (9) on inner rails are exposed. Raise upper end of inner rail sufficiently to allow removal of shoes (7) and shims (8) from upper end of outer rail.

Remove stop blocks (36) from back of outer rail assembly and slide inner rail assembly out of outer rail. Remove shoes (7) and shims (8) from inner rail assembly.

Remove snap ring (12) and remove roller assembly from pin. Remove snap ring (11) and remove bearing (10) from roller (9). If carriage is equipped with thrust rollers, remove pin (20) and roller (19). On carriages that have wear shoes, remove shoes (15) and shims (16).

To remove sheave (38) from piston head, drive roll pin into pin (41) just far enough to allow removal of pin. DO NOT drive roll pin in so far as to embed it in casting. Remove pin (41) and remove sheave (38). Drive roll pin out of sheave pin.

Unscrew pin (20) to remove thrust bearing (18) from carriage (17). Pin is staked at front so will turn hard at first. Loosen set screws before attempting to remove lower pins.

REPAIR AND REASSEMBLY (See illustration page 45 of supplement)

Examine all parts carefully for wear or damage and discard any unserviceable parts. Clean chains by soaking in kerosene or gasoline. Dry chains thoroughly and lubricate with No. 10 oil.

If roller pins (6, 14 or 18), welded to inner rails and carriage, require replacement, chisel off worn pin and grind off all remaining weld material to obtain a smooth surface. Clean up locating hole for roller so roller will enter hole and fit flat against rail. Weld roller in place, using low hydrogen welding rods.

Reassemble mast components in reverse order of disassembly. Apply a graphite base grease to sliding members when reassembling mast.

Stake thrust bearing pins (20) on front side of carriage, at both ends of slot in pin.

Use shims (3) under mast shoes (7) as required to obtain a minimum clearance between inner and outer rails. Use shims on both sides to keep rail assemblies square in relation to each other. Clearance should not exceed thickness of one shim, but rails must slide freely.

Maintain cylinder alignment by using shims (35) between piston head (32) and guide (34).

Begin lift chain adjustment by placing mast in vertical position. Move forks to extreme ends of fork bar and lower forks until cylinder is completely collapsed. There should be no slack in chains when cylinder is completely collapsed. Do not place a load on forks when adjusting chains.

Loosen jam nuts (30) and turn chain anchor rods (29) into anchors (27) approximately 1-1/4 inches (item 1, Fig. 37). Secure rods in anchors with jam nuts.

Adjust nuts (item 2, Fig. 37) on lower end of anchor rod to obtain a fork-to-floor clearance of 0 to 3/4 inch (item 3, Fig. 37). Make this adjustment on both sides. Keep nuts on lower end of anchor rod as near as possible to end so rods will not protrude below cylinder base.

Raise mast to maximum height and check to be sure a clearance of at least 1/8" exists between stop blocks (item 4, Fig. 37). If stop blocks are contacting each other, re-adjust nuts on lower end of anchor rod (lengthen chains) to obtain a clearance of at least 1/8 inch.

Attach tension scale (item 5, Fig. 38) and measure chain deflection with pull applied. Attach scale to other chain at same height, apply same pull, and measure deflection. Adjust nuts on lower end of anchor rod (under cylinder base) to equalize deflection with same pull applied.

Tighten nuts on lower end of anchor rod securely. Then, tighten lower nut (item 6, Fig. 38) down against base flange and back off 1/8 turn. Hold nut in this position and secure by tightening upper nut against lower nut. Chain anchor rod must not be locked solid in cylinder base, but must be free so it will tip slightly back and forth as mast is raised and lowered.

Raise mast to maximum height and recheck clearance between stops. Adjust as necessary.

SIMPLEX LIFT CYLINDER

REMOVAL AND DISASSEMBLY (See illustration on page 46.)

Raise forks until 8" block of wood can be inserted under carriage. Lower carriage onto block and detach lift




Fig. 39

1. Turn rods into anchors
2. Nuts on lower end of rods
3. Fork-to-floor clearance
4. 1/8" clearance between stops
5. Tension scale
6. Jam nuts (1/8 turn from tight)

chains from carriage. Extend lift cylinder, raising piston head a few inches. Secure piston head to top of mast with chain. Loosen set screw in piston head and contact lift cylinder.

Remove clamp (34, illustration page 45) to disconnect vent line. Disconnect hydraulic line from cylinder base. Remove bolt in cylinder base and lift cylinder up and out of mast.

Mark retainer (6) and shell (1) so retainer can be retightened to same position at reassembly. Remove retainer and "O" ring (7). Wiper ring (4) and garter spring (5) will come out with retainer.

Remove plunger (8) and spacer (9), if used. Remove snap ring (12) to remove piston (6) and packing (3). Remove "O" ring (10) and back-up ring (11) from groove in plunger bottom. Remove flow control parts (items 13, 14, 15, and 16) from cylinder inlet port.

REPAIR AND REASSEMBLY

Clean all parts and examine each one for scratches, pitting, wear, or other damage. Use new "O" rings, seals, packings, etc., found in repair kit during cylinder reassembly.

Dip all "O" rings, seals, and packings in clean hydraulic oil to facilitate assembly and to help prevent damage to these parts. Be sure "O" rings are not twisted during installation.

Install back-up ring (11) and "O" ring (10) in plunger groove. "O" ring must be nearest plunger bottom end. Install packing assembly (3) on piston (6) and install piston with packing, on plunger. Secure piston with snap ring (12).

Lubricate piston and packing generously with clean hydraulic oil and install plunger assembly in shell. Be careful not to damage packing while sliding it past threads in shell.

Install new wiper ring (4) with garter spring (5) in plunger retainer (6). Install new "O" ring (7) on retainer. Install spacer (9), if used, and reinstall retainer. Tighten retainer until mark made at disassembly is aligned with, or past, mark on shell.

Reinstall flow control parts in cylinder inlet port, in order shown in illustration on page 49.

Reinstall cylinder in mast in original position. Reinstall bolt through cylinder base and reconnect hydraulic pressure and vent lines. Start engine, extend cylinder, and reinstall piston head. Tighten set screw securely. Lower cylinder and reconnect lift chains to carriage.

CHANNEL PLUGS FOR CASCADE TRIPLEX MAST

(See page 5-26 of Manual S-340A)

The channel plug (5) must be kept properly adjusted to eliminate excessive movement of sliding members (channels). When properly adjusted, channels should fit snugly, yet be free to return to nested position without loading. Therefore, plugs must not be threaded in so far that they will cause binding.

When adjusting channel position with plugs, keep channels square in relation to each other to maintain alignment of latch points and latches. Latch points (capscrews) located on back of cylinder and carriage, must engage center of latch throat as carriage is raised. Be sure latches pivot freely.


Later production masts have a lock-type channel adjusting plug (35P2227). This plug has an Allenhead expanding lock screw for securing plug after channel position adjustment has been accomplished. This plug may be used to replace plugs (35P1356) in earlier masts.

The Allenhead screw should be tightened into channel plug AFTER correct position of plug has been determined. Do not allow lock screw to protrude on either side of plug or it may contact matching channel members.

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		<p>Repair Parts Section of Supplement to Parts, Operation, and Maintenance Manual S245A and Bulletin C-250.</p> <p>This supplement covers the MA 30 Lift Truck, Changes on MA 3E II, 40 II, and 50 II are also included.</p> <p>Refer to Crankcase Assembly, Cylinder Head and Gas Manifold. Group II.</p> <p>Add the following parts for MA 30 II, 40 II, 50 II with F163-8064 Continental Engine and MA 60 with F163-8026 engine.</p> <p>Used on MA 30 II Lift Trucks No. 28000211 and after.</p> <p>Used on MA 40 II Lift Trucks No. 2E100999 and after.</p> <p>Used on MA 50 II Lift Trucks No. 2E200279 and after.</p> <p>Used on MA 60 Lift Trucks No. 3E2E0001 and after.</p> <p>Cont. Mtrs.</p>	
17	35P2108	G8061B Tube - oil filler.....	1
20	35P2109	F430L-4130 Dipstick - oil gauge.....	1
22	35P2110	F600L-361 Support - dipstick.....	1
23	35P2128	F400A - Cylinder and Crankcase, with bearings, bushings, guides, inserts, pins and pins.....	1
		<p>Change 35P787 gasket - oil pan (ref. #66) to 35P2183 Continental Motors No. to F400B-267 on all F160 engines.</p>	
100	35P2115	*F490E-618 Manifold - intake and exhaust.....	1
124	35P2102	X-6978 Screw - cylinder head.....	4
130	35P2113	F110B-320 Housing - flywheel.....	1
	9154S	X-3942A Screw - flywheel pointer.....	1
	35P2114	*F600B-2640 Plug - timing hole.....	1
	35P2103	X-6791 Lifting Eye - motor.....	1
		*Note: Used on MA 60 Lift Trucks only.	
		<p>Refer to Camshaft, Valves, Oil Pump and Oil Filter Group.</p> <p>Add the following parts for MA 3E II, 40 II, 50 II with F163-8064 Continental Engine and MA 60 with F163-8026 engine.</p> <p>Used on MA 30 II Lift Trucks No. 28000211 and after.</p> <p>Used on MA 40 II Lift Trucks No. 2E100999 and after.</p> <p>Used on MA 50 II Lift Trucks No. 2E200279 and after.</p> <p>Used on MA 60 Lift Trucks No. 3E2E0001 and after.</p> <p>Cont. Mtrs.</p>	
1	35P2104	F401I-200 Camshaft.....	1
4	35P2105	F400H-404 Gear - timing, camshaft.....	1
8	35P2106	X-16021 Nut - gear to camshaft.....	1
13	35P2107	F400I-251 Guide - valve stem.....	5

Ref. No.	Part No.	DESCRIPTION	No. Per
Page 2-14 2-15		Refer to Crankshaft, Flywheel, Conn. Rods and Pistons Group III Add the following parts for MA 30 II, 40 II and 50 II Lift Trucks with F163-8384 Continental Engine. Used on MA 30 II Lift Trucks No. 29900211 and after. Used on MA 40 II Lift Trucks No. 26100999 and after. Used on MA 50 II Lift Trucks No. 26200270 and after. Cont. Mtrs.	
7	35P2237	F601C-239 Collar - pulley	1
8	35P2238	X-6785 Screw - crankshaft pulley retaining	1
34	35P2111	F601C-4350 Flywheel - with ring gear	1
35	35P2115	F244C-317 Ring Gear - flywheel	1
		Add the following parts for MA 60 Cont. Mtrs.	
5	35P2121	F401C-401 Pulley - fan drive	1
7	35P2122	X-14544 Washer - pulley	1
8	35P2121	X-6790 Screw - crankshaft pulley retaining	1
34	35P2111	F601C-4050 Flywheel - with ring gear	1
35	35P2112	F244C-317 Ring Gear - flywheel	1
	35P2249	F461B-308 Pointer - timing, on gear cover	1
Page 2-15		Refer to Air Cleaners - Dry Type, Group II Add the following parts for MA 60	
9-10	35A9156	Hose - air cleaner to carburetor, flex 2" I.D. x 15-1/2"	1
		35A4287 Clamp - 3950, 2"	2
	35A9563	Band - air cleaner and hose, 1" wide x 2" O.D.	1
		35A4219 Washer - plain, for bracket, 13/32" I.D., 13/16" O.D.	4
Page 2-16		Refer to Fuel Pump, Fuel Lines and Filter Gasline Group Add the following parts for MA 60	
	35A9147	Pump - fuel (Airtex Products No. 303048)	1
		Includes the following 2 parts	
	35P2129	K1 - pump, includes O-ring, seals, gaskets and valves	1
	35P2130	Gasket - pump retaining	1
		Add to below 35A9147 item	
	35A9147	* Tube - fuel pump to carburetor, curved, 5/16" O.D. x 14-1/16" long	1
	35A9148	* Hose - fuel pump to fuel tank, 3/16" I.D. x 16"	1
		Note: Used on MA 30 II Lift Trucks No. 28000211 and after. Used on MA 40 II Lift Trucks No. 26100999 and after. Used on MA 50 II Lift Trucks No. 26200270 and after. Used on MA 60 Lift Trucks No. 33200001 and after.	
Page 2-22		Add gasoline carburetor group for MA 60.	

Part No.	Part No.	DESCRIPTION	No. Req.
1	35A9142	13152 Carburetor - complete	1
2	10A9B17	C141-4-1 Gasket - flange	1
3	35P2168	C21-202 Plate - intake	1
4	3E7055	C11-9 Spring - idle needle	1
5	35P2169	C45-24 Needle - idle adjusting	1
6	----	812-13122 Body - throttle, upper part, order 30A3158 complete	1
7	10P177	C191-3 Plug - 1/8", fuel inlet	1
8	35P1415	C142-3 Seal - throttle shaft	2
9	35P1416	C142-57 Retainer - shaft seal	2
10	35P2172	T358-12 Screw - throttle stop	1
11	35P2163	C23-1578 Shaft - throttle and stop levers	1
12	35P2177	C35-22-16 Jet - idle	1
13	35P2172	C120-59 Axle - float	1
14	35P2171	C37-115 Assembly - float and hinge	1
15	35P2186	C25-15D17X2 Lever - float	1
16	35P2167	C117-71 Spring - return, float	1
17	35P2165	C25-103 Stop - float lever	2
18	0236H	T8310-13 Screw - stop	2
19	35P2164	C225-18C1X2 Lever - float	1
20	3E7054	T55-23 Valve - float, fuel valve seat	1
21	35P2180	C31-1-40 Valve and Seat - fuel	2
22	35P2173	C148-65 Gasket - bowl to body	1
23	----	83-120-2 Bowl - fuel, order 30A3158 complete	1
24	35P1422	C128-24 Plug - main jet passage	2
25	3E7064	T55-25 Jet - main - float, passage plug	1
26	35P2161	C52-7-27 Jet - main	1
27	3E7060	T55-24 Washer - float, main jet	1
28	35P2194	T31112-10 Bowl - bowl to body	4
29	10P177	C191-3 Plug - bowl drain	1
30	35P1425	C131-4X2 Retainer - choke shaft packing	1
31	35P1426	C130-60C Gasket - choke	1
32	35P1427	C140-53 Screw - choke bracket	2
33	35P1429	T358-7 Shaft - choke	1
34	35P1429	T358-7 Screw - choke lever return	1
35	35P1430	C118-6 Spring - choke lever return	1
36	35P1431	T358-8 Screw - bracket clip	1
37	35P1432	C110-7 Clip - bracket tube	1
38	35P1433	T31-58 Nut - clamp screw	1
39	C2734	C157-4 Washer - choke shaft packing	1
40	35P2176	C101-43 Plate - choke	1
41	35P1418	T3135-44 Screw - choke plate	2
42	35P1436	C817-1X1 Plug - choke shaft hole	1
43	3E7052	T55-4 Washer - float, discharge jet	1
44	35P2178	C62-10C-70 Jet - discharge	1
45	35P2179	C74-15-1E Jet - wall vent	1
46	35P2160	R38-71-23 Venturi	1
47	35P2162	C31-222 Tube - idle filter	1
48	35P1445	C3-70 Bushing - throttle shaft	2
49	10P189	C122-2 Lever - choke shaft	1
50	C644281	T2258 Nut - choke shaft	1
51	C612432	T41-10 Lockwasher - choke shaft nut	1
52	35P2182	C131-328 Kit - gasket parts in basket set	1
53	35P2182	R2157 Kit - gasket parts (parts in basket set)	2
54	10A9350	35A150 Nut - hex, 3/8"-18	2
55	----	35A150 Claws - clip, on carburetor end	1




Ref. No	Part No.	DESCRIPTION	No. Pcs
Page 2-24		Add governor group for MA 60	
		Naval Governor No.	
		GOVERNOR - MA 60	
	93P2116	----- Governor - complete (Cont. Mtrs. No. P4006-4480).....	1
		----- Includes the following 29 parts:	
		50A4210 - Washer, plain, 13/32" I.D., 13/16" O.D.	1
1	35P2241	50279A Body - assembly	"
		----- Includes the following 7 parts:	
2	92168	60081 Bearing - needle, lever shaft	1
3	15P77	51208-11 Bushing - lever shaft	1
4	92198	60027 Bushing - drive shaft	1
5	92206	60041 Washer - thrust, drive shaft	1
6	92178	60032-1A Seal - oil, lever shaft	1
10	95P2242	99289 Screw - bumper screw adjusting	1
11		50131-2 50A4932 - Nut, hex., 1/4"-28	1
7	35P2243	63606 Lever - governing, with shaft	1
8	35P859	56986 Fork - lever shaft	1
9	35P884	60306-1 Spring - bumper, lever shaft	1
12	35P866	5118-2 Base - with bushing	1
	35P857	60313-1 Bushing - base	1
13	35P895	62095C Shaft - drive, assembly	1
14		60042-12 GM145651 - Ball, steel, 3/4"	4
15	35P897	58799-F Race - lower	1
16	35P868	62488 Washer - thrust	1
17	35P890	60129A Plate - drive, assembly	1
	135419	50026-13 Washer - ball stop	1
18	15P100	60021 Bearing - thrust	1
19	15P101	60022 Base - lever fork	1
20	85P980	67020-8 Ring - snap	1
21	85P891	36893 Washer - retainer	1
22	15P103	60026-32 Washer - ball stop	A, R,
23	95P2248	51170B Race - upper	1
	35P2244	92064 Bracket - eye bolt	1
	35P2247	63081-1 Screw - self locking	1
		Continental Mtrs. No.	
	85P860	F1628-253 Deflector - oil	1
	35P2245	X-7599 Bolt - eye, mounts in bracket, 3/16"-24	2
		X-18198 50A4984 - Nut, hex., 1/16"-24	2
	85P2246	X-6864 Screw - governor spring to eye bolt, 1/4"-28	1
		X-18197 50A4982 - Nut, hex., 1/4"-28	2
	15P886	V1125208 Spring - governor	1
	35P859	F140V-200 Spacer - governor to gear cover	1
		X-6821 GM179847 - Screw, governor, 8/6"-16 x 2"	1
		X-6831 Screw - governor, 3/8"-16 x 4-3/4"	1
		X-18288 50A1045 - Nut, elastic stop, 3/8"-16	1
	91438	X-14184 Washer - copper, governor screw	1
	15P97	F140M-232 Gasket - spacer and governor	2
	92225	F4008-201 Plate - governor attaching	1
	92238	F4006-202 Gasket - governor plate	1
	85A9554	Red - carburetor to governor, 1/4" x 8-3/4"	1
		50A4201 - Washer, plain, 8/32" I.D., 5/8" O.D. ..	1
		50A8829 - Pin, cotter, 8/32" x 5/8"	1

Rel. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-29		Add water pump for MA 60 Comp. Mtrs.	
	35P2117	F401K-32E1 Pump - water, complete	
		Includes same parts as 35P984 pump except for the followings:	
8	35P2118	F401K-326 Body - water pump	1
12	35P2119	F401K-324 Hub - fan	1
23	10A12727	Belt - fan, 49" O.C., MA 60	1
23	35A9780	Belt - fan, 49" O.C., MA 30-40-50 with alternator	1
	10A9989	Pellet - sealant, for radiator	1
		Change 35P1387 thermostat (ref. #20) to 35P2239 and change Continental Motors No. to F601K302, 170° on all engines.	
Page 2-29		Refer to Alternator Group. Add the following parts for MA 60	
	-----	Alternator - less fan and pulley (Delco-Remy No. 1100771) use 35A9243 alternator for repairs	1
7	10A23146	Pulley - alternator, 3-1/8" O.D. (35A8254)	1
8	10A12727	Bolt - alternator, 49" O.C.	1
Page 2-30		Refer to Voltage Regulator, Generator, Starting Motor and Distributor Group. Add the following parts for MA 30 II, 40 II, 50 II and 60. Used on MA 30 II Lift Trucks No. 2800211 and after. Used on MA 40 II Lift Trucks No. 28100999 and after. Used on MA 50 II Lift Trucks No. 28200270 and after. Used on MA 60 Lift Trucks No. 33200001 and after.	
6	35A9146	Motor - starting (Delco-Remy 1127379)	1
		50A3866 Bolt - hex., 5/8" x 1-1/4"	3
		Make the following changes: Add note to 35A9341 adapter (ref. #6), for 35A9387. Change 35P1449 point set to Prestolite 13P-2040L. Change 35P1450 condenser to Prestolite 1B83042SS1. Change 35P1778 rotor to Prestolite 1AU-1016C. Cap - distributor, (Prestolite 1BT-10089)	1
10	35P2062	Cap - distributor, (Prestolite 1BT-10089)	1
	10R1191	Spark Plug - AC-C66 replaces 10R385-correction Add to 10A16817 Coil ref. #21, (Delco-Remy No. 1115043)	
Page 2-34		Refer to Battery, Battery Box, Cables and Wiring Harness Group. Add the following parts for MA 30 II, 40 II, 50 II and 60. Note: Used on MA 30 II Lift Trucks No. 2800211 and after. Used on MA 40 II Lift Trucks No. 28100999 and after. Used on MA 50 II Lift Trucks No. 28200270 and after. Used on MA 60 Lift Trucks No. 33200001 and after.	
	35A9361	Tray - battery	1
	35A7329	Hold-Down - battery	1
	35A9379	Bolt - hook, battery hold down, 1/4" x 7-1/8"	2
		50A1899 Nut - hex., 1/4" -20	2
		50A3762 Nut - wing, 1/4" -20	2
		50A4201 Washer - plain, 9/32" L., 5/8" O.D.	4
	35A9524	Harness - wiring, with 2-20 amp. and 1-14 amp. fuses	1
		GM120633 Fuse - harness, 20 amp.	2
		GM147865 Fuse - harness, 14 amp.	1
	35A9195	Wire - hornmaster to ground, 14 Ga. x 8"	1
	35A10442	Wire - horn harness, red 14 Ga. x 6" long	1
		Change 10P2047 battery -dry to type 24H, 55S4 Change 35A6192 harness to 35B6192 Includes the following part:	
	35A9681	Harness - generator, with 2-14 amp. fuses,	1

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-36		Refer to Instrument Panel and Instrument Group Change the following gauges, sending units and relay to non fungus treated 35A513 gauge ref. #2 to 35A214 35A512 gauge ref. #8 to 35A411 35A513 unit ref. #4 to 35A998 35A511 gauge ref. #5 to 35A412 35A520 unit ref. #8 to 35A933 35A516 relay ref. #12 to 35A405 Add new white face gauges	
2	35A7789	Gauge - ammeter	1
3	35A7787	Gauge - engine temperature	1
4	35A7789	Gauge - oil pressure	1
7	35A7736	Gauge - fuel, gasoline engine	1
		Change 35A8340 switch (ref. #6) to 10A18228	
	10F2703	Key - switch, set of 2, for 10A18228	1
Page 2-38		Refer to LP Gas Equipment Group. Change 35P519 coupling ref. #13 to ref. #12. Change D1173 coupling ref. #19 to 35P517 and ref. # to 18, D1173 Inter. Add new LP Gas group for MA 60.	
LP GAS EQUIPMENT - MA 60			
1	D118E	Tank - fuel, with fittings	1
		50A1900 - Nut, hex., 3/8"-16	4
		50A4210 - Washer, plain, 13/32" I.D., 13/16" O.D.	4
		50A366E Bolt - hex., 3/8"-16 x 7/8"	4
	36A9079	Plate - tank mounting, with studs	1
		50A106 - Bolt, rd. hd., 5/8"-11 x 2"	2
		50A1912 - Nut, hex., 5/8"-11	2
		50A4213 - Washer, plain, 11/16" I.D., 1-1/2" O.D.	4
		50A4209 - Washer, plain, 11/16" x 2-1/2" x 148 Dinch	A, 2
	35A9509	Spacer - mounting plate, U-shaped, 2" x 6" long	2
2	35P516	Strap - mounting, fuel tank, R.H.	1
2	35P518	Strap - mounting, fuel tank, L.H.	1
	35A7158	Groundset - hood	3
3	35P1088	Vaporizer - assembly, includes thermostat housing	1
	35P1085	Repair Kit - vaporizer (includes diaphragm, seat, seals and washers)	1
4	35P1084	Solenoid - 12 volt	1
5	35P1085	Regulator - Zenith Model C	1
		Includes the following 3 parts:	
6		GM16056 - Nipple, pipe, 1/4" N.P.T.	2
7		50A973 - Elbow, street, 1/4"	1
		GM10512 - Elbow, steel, 1/4" P.	1
		GM44825 - Adapter, tube, 1/4" N.P.T. x 3/8"	1
	35P1072	Valve - block and spring assembly	1
	35P1573	Screw - adjusting, fuel pressure	1
	35P1046	Orifice - fuel inlet	1
	35P1086	Repair Kit - regulator (includes diaphragm, gaskets and seals)	1
		GM213197 - Nut, hex., 3/4"-16	1
3	35P3030	Carburetor - LP gas (see breakdown on page 27)	1
	35P2331	Gasket - carburetor	1
8	35P515	Elbow - carburetor, 3/8" N.P.T. x 3/8" tube	1
10	86P514	Bulkhead - filter	1
		Includes the following 2 parts:	
11		GM144355 - Elbow, adapter, 1/4" N.P.T. x 3/8" tube, 90°	2
	35P1605	Element - filter	1
	35P1803	Spring - filter	2
		GM26700 - Washer, internal lock, 7/8"	1
12	35P515	Relief Valve	1

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
	35P2082	Plate - fuel pump cover	1
	35P2083	Gasket - plate	1
	35P530	Ball - plug, instrument gauge	1
	35P509	GM170438 - pipe, carb. gasoline tank	1
	35P509	Elbow - adapter, 3/8" N.P.T. x 3/8" tube, x 90°	1
	35P1088	3DA4740 Nut - box, jam, 7/16"-20	1
	35P1088	Bracket - hose, and clamp	1
	35P1089	Hose - water by-pass	1
	35P1600	Hose - carburetor to regulator, 26" long (35P1690)	1
	35P1081	Hose - filter to solenoid	1
	35P1667	Hose - filter to tank	1
	35P017	Coupling - hose to tank, male	1
	35A1701	"O" ring - coupling	1
	35P1769	Gasket - coupling	1
	35P519	Coupling - hose to tank, female	1
	35P520	Switch - vacuum	1
	35P1095	Wire - solenoid to pressure switch, 24" long	1
	35P1094	Wire - pressure switch to starter, 26" long	1
	35P1610	Gasket - thermostat housing	1
	35P2080	Carburetor - LF gas Includes the following 32 parts: LF Gas Carburetor - MA 60 LR Truck	1
	35P2141	Shaft - throttle	1
	35P2136	Body - carburetor, order 35P2080 assembly	1
	35P2136	Retainer - seat	1
	35P2180	Seal - throttle shaft, lever side	1
	35P2131	Washer - seal, lever side	1
	35P2152	Spring - metering disc	1
	35P2134	Washer - metering disc, plastic	1
	35P2146	Disc - gas metering	1
	35P2149	Plate - cover, metering valve	1
	35P2137	Stop - throttle	1
	35P2133	Screw - idle adjusting, #10-32 x 3/4"	1
	35P2127	Spring - idle adjusting screw	1
	35P2145	Screw - adjusting, idle stop, No. 10-32 x 3/4"	1
	35P2127	Spring - screw, throttle stop	1
	35P2147	Venturi - 1" I.D.	1
	35P2346	Screw - venturi retaining, No. 8-32 x 3/16"	1
	35P2140	Spoke - choke	1
	35P2349	Plate - choke shaft	1
	35P2129	Screw - plate, with lock washer, No. 6-32 x 1/4"	1
	35P1798	Plug - choke shaft	1
	35P1797	Gasket - ring	1
	35P1799	Bracket - choke cable	1
	35P2126	Washer - choke shaft	1
	35P2125	Screw - main load adjusting, 5/16"-18 x 1-1/8"	1
	35P2124	Spring - load adjusting screw	1
	35P1784	Lever - assembly, choke shaft GM170623 Screw - filter head, No. 8-32 x 3/16"	1
	35P1785	Spring - choke return	1
	35P2136	Lever - throttle and screw	1
	35P2144	Spoke - carburetor	1

Ref. No.	Part No.	DESCRIPTION	No. Pcs
Page 2-42		Refer to Transmission Case, Converter and Pump Group.	
		Add set screw and lock nut for reverse idler gear.	
		50A4189 Set Screw - hex. socket, 3/8"-16 x 1".....	1
		50A1800 Nut - hex, 3/8"-16.....	1
Page 2-44		Refer to Transmission Group.	
		Add the following parts for MA 30 II, 40 II, 50 II and 60.	
		Note: Used on MA 30 II Lift Trucks No. 28000211 and after.	
		Used on MA 40 II Lift Trucks No. 26100998 and after.	
		Used on MA 50 II Lift Trucks No. 28200270 and after.	
		Used on MA 60 Lift Trucks No. 33200001 and after.	
15	36A8448	**Gear - forward, with bushing.....	1
16	36A9448	**Gear - reverse, with bushing.....	1
27	35A9447	**Gear - forward, output shaft, 21 teeth.....	1
28	85A9450	**Gear - reverse, output shaft, 49 teeth.....	1
36	36A8449	**Gear - reverse idler, with bearings, 51 teeth.....	1
		** Caution: Do not order above gears when the letter "D" is stamped on the Differential Case beside the "Mobilift" in casting. Order replacement gears as they appear on page 2-44 of catalog 5343A.	
		Change 36A830 piston ref. #2 to 36A830 on all units. (35A830)	
Page 2-50		Refer to Transmission Controls, Filter and Oil Lines Group.	
		Add the following parts for MA 60	
1	35A9435	Rod - transmission control, upper, L shaped.....	1
		50A2824 Pin - roll, 1/4" x 1".....	2
2	35A9476	Knob - rod, transmission control.....	1
3	35A9434	Rod - transmission control, lower, 28-1/2" long.....	1
		50A2824 Pin - roll, 1/4" x 1".....	1
		50A2826 Pin - roll, 1/4" x 1-1/4".....	1
4	85A9444	Support - control lever.....	1
5	35A9488	Support - rod, upper, U-shaped.....	1
		50A3850 Bolt - hex., 1/4"-20 x 1-1/2".....	2
		50A1896 Nut - hex., 1/4"-20.....	2
6	35A9440	Support - bell crank and rod.....	1
7	36B8887	U-joint - assembly.....	1
		Includes the following 5 parts:	
8	35A9640	Shaft - U-joint, long.....	1
9	35A9641	Shaft - U-joint, short.....	1
10	85A9642	Tube - shaft.....	1
11	35A9641	U-joint - transmission control.....	2
12	35A9648	Pin - shafts and U-joints.....	6
13	35A9463	Skirt - steering column.....	1
		50A3896 Screw - machine, #10-24 x 3/8".....	3
		50A4241 Washer - internal lock.....	3
		50A247E Elbow - cooler outlet, 90°, to follow 50A4441 elbow.....	1



Page 2-5d

Refer to Hydraulic, Steering Wheels and Linkage Group.

Add the following parts for MA 60

Add the following stop bolts for 35A 5194 housing (ref. #35) on MA 60

30A 3680 Bolt - hex., 1/2" - 12 x 1-1/4"..... 2

50A 1911 Nut - hex., 1/2" - 13..... 2

36A 9075 Wheel - steer, with cushion tire..... 2

Includes the following 2 parts:

5 36A 9075 Wheel - steer, cushion tire..... 2

8 35A 9076 Tire - cushion, 6" x 10" x 15-1/2"..... 2

Add the following parts for MA Series Trucks with extreme service hydraulicizers

10 35A 9160 Retainer - bushing..... 2


13 35A 9167 Seal - oil, in cylinder..... 2

19 36A 9164 Piston - with bushing..... 2

Refer to 35A 6402 bushing (ref. #20) and add note: Machine O.D. of bushing to 4,996-4,997 after installation on piston.


Ref. No.	Part No.	DESCRIPTION	No. Per
Page 2-58		Refer to Hydra-Bizer, Steering Wheels and Linkage Group. Make note that 35A 5836 drag link (ref. #42) thru 35A5838 clamp (ref. #43), not used on MA 60.	
Page 2-59		Add new group for Power Steering and Cylinder for MA 60. Steering Motor and Lines	
1	35A 9308	Hydramotor - steering assembly, see breakdown on page 32	1
2	35A 9376	Pivot - steering motor to support	2
3		50A3748 Nut - hex. jam, 7/8"-8	2
4	35A 9760	Shaft - motor stop, 1/2" O.D. x 7-3/4" long	1
5		50A1827 Ring - snap (Trussar No. 5183-50)	2
6	35A 9518	Support - steering motor, R.H.	1
7	30A 9619	Support - steering motor, L.H.	1
		50A3669 Bolt - hex., 2/3"-16 x 1"	4
		50A1800 Nut - hex., 3/8"-16	4
8	35A 9619	Spring - lock button	1
		50A3647 Bolt - hex., 1/4"-20 x 7/8"	2
		50A1838 Nut - hex., 1/4"-20	2
		50A4201 Washer - flat, 9/32" I.D., 5/8" O.D.	2
9	35A 9520	Button - lock	1
		50A3700 Nut - hex., 3/16"-18	1
10	35A 9356	Cylinder - steering, see breakdown on page 34	1
11	35A 9356	Rocker - assembly	1
		Includes the following 4 parts:	
		50A3828 Pin - cotter, 1/8" x 1-1/4"	2
12		50A4983 Nut - hex. slotted, 9/16"-18	1
13	35P2154	Bolt - hex., 3/8"-24 x 1-1/2"	1
14		50A4938 Nut - hex., 3/8"-24	1
15	35P2151	Retainer - washer	1
16	35P2132	Cover - dust, socket	1
17	35P2153	Washer - cover retainer	2
18	35A 9057	Ball Stud - steering cylinder anchor	-
19		50A4983 Nut hex., slotted, 9/16"-18 NF	1
20	35A 9667	Tube - steering motor to cylinder, left turn port, 3/8", 13-7/8" to bend	1
21	35A 9366	Tube - steering motor to cylinder, right turn port, 3/8", 14-3/4" to bend	1
22	35A 9568	Tube - pump to steering motor	1
23	35A 9565	Tube and Hose - steering motor to tank	1
24		50A4736 Elbow - steering motor return port, 9/16"-18 x 45°	-
25	10A 16387	Hose - power steering pressure lines, 3/8" I.D. x 13-1/8"	7
26		50A4604 Elbow - steering ports, 9/16"-18 x 90°	2
27		50A4426 Connector - straight, steering motor left turn port, 9/16"-18	-
28		50A4423 Elbow - 9/16"-18 x 90°	-
29	10A 16405	"O" Ring - elbows	7
30		50A4421 Elbow - steering motor, 9/16"-18 x 45°	1
31		50A4413 Elbow - 90°, tube to tank	1
32	35A 9653	Support - tubes, 1" wide x 8-1/2" long	1
33	35A 9653	Bracket - tubes, 9" x 4-3/8"	1
34	35A 9851	Clamp - tubes, U-shaped, 1" wide x 8-3/8" long	2
		30A5510 Pad - tubes, foam rubber	2
		50A3649 Bolt - hex., 1/4"-20 x 1-1/4"	2
		50A1838 Nut - hex., 1/4"-20	2
		50A4201 Washer - flat, 9/32" I.D., 5/8" O.D.	2
35	35A 8188	Wheel - steering	-
36		GMJ14496 Nut - hex. jam, 1/2"-20	1
37	35P2238	Washer - steering shaft, 17/32" I.D. x 1" O.D.	1
38	35A 8142	Button - horn	1
39	35A 6141	Cover - horn button	1
40	35A 6444	Plate - base	1
		50A5834 Screw - rd. hd., No. 10 x 1/2"	2
41	35A 6443	Cup - contact	1
42	35A 6441	Spring - contact cup	1
43	35A 6445	Cup - contact	1


Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Steering Motor and Lines (Cont'd)			
44	35A 6442	Brush - contact in sleeve	2
45	35A 6439	Sleeve - contact brush	1
46	35A 6440	Spring - brush, in sleeve	1



Part No.	Description	No. Per
35A2966	Hydramotor Assembly - complete	1
	Includes parts Ref. Nos. 1 through 4:	
	Valve Assembly - (order 35A3967)	1
	Includes parts Ref. Nos. 5 through 10:	
	Hydramotor (order 35A3968)	1
	Includes the following parts:	
35P3928	Hearing - needle, drive shaft assembly	3
	Shaft Assembly - drive, lower (order 85A9366)	1
	Shaft Assembly - nut (order 85A9366)	1
	Actuator and Pin - assembly (order 85A9366)	1
	Pin - stub shaft to tension bar (order 85A9366)	1
	Spool - valve, select (order 85A9860)	1
	Spool - valve, select (order 85A9860)	1
	Spring - valve (order 35A9369)	1
	Seal - "O" ring, cover, 4-23/32" I.D.	1
	Seal - "O" ring, cover, 4-18/16" I.D.	1
	Seal - "O" ring, bearing support, 1-25/32" I.D.	1
	Seal - "O" ring, seal retaining	1
	Service Kit - stub shaft bearing and seals	1
	Includes the following 2 parts:	
10P2942	Service Kit - stub shaft seals	15
30P938	Bearing - needle, drive shaft assembly	3
10P2987	Support Assembly - hearing	16
	Includes the following parts:	
35P3928	Bearing - needle	17
35P2990	Rotor and Ring Assembly - includes vane	18
10P2947	Seal - rotor, 1-9/32" I.D.	19
10P2948	Seal - "O" ring, rotor	20
10P2949	Seal - retainer, rotor, 5/8" I.D.	21
10P2953	Pin - dowel, rotor ring, 1/4" x 2-1/4" long	22
35P2988	Plate - assembly, pressure	23
	Includes the following 4 parts:	
35P2989	Bushing - drive shaft	24
10P2933	Ball - steel, 7/32" dia.	25
10P2934	Plug - ball check	26
10P2935	Spring - ball check	27
10P2950	Spring - pressure plate	28
35P2988	Cover - lower housing	29
10P2952	Ring - retaining, lower housing cover	30
35P2989	Jacker - assembly, steering shaft	31
	Includes the following parts:	
35P2988	Bearing and Cable - assembly, upper	32
85P2991	Shaft - assembly, steering, upper	34
	GM114498 Nut - hex, jam, 1/2"-20	35
35P2322	Washer - steering shaft, 17/32" I.D., 1" O.D.	36
85P955	Seal - spring, upper housing	37
35P956	Spring - bearing, upper	38
35P2094	Nut - steering shaft, lower	39
35P2095	Ring - steering shaft	40
15P2098	Ball - upper shaft, 11/64" O.D.	41
35P2096	Clamp - jacker column	42
85P2096	Spacer - clamp, 5/16"-18 x 3"	43
35P2097	Seal - clamp, 5/16"-18 x 3"	44
	50A3730 Nut - steel, steering clamp, 5/16"-18	45
	50A4226 Washer - lock, 5/16"	46

STEERING MOTOR






1	Cylinder - hydraulic, complete *****	35A9855	1
1	30A4685 Piston - lubricator, ball stud housing, 1/4"-28 x 1/2".....		1
2	Piston - with rod, ring and seal.....	35P2072	2
	Includes the following 3 parts:		
1	Rod - cylinder *****	35P2099	2
1	Nut - hex, lock, 3/8"-24	35P2106	2
1	Piston - assembly.....	35P2073	1
	Includes the following 2 parts:		
1	Ring - piston	35P2075	5
1	Seal - piston	35P2074	6
1	Bearing - piston rod.....	35P2076	7
	Includes the following 8 parts:		
1	Seal - "O" ring	10A7799	8
1	Ring - back-up	35P189	9
1	Ring - retaining, msp	35P190	10
1	Ring - retaining	35P191	11
1	Seal - oil	35P192	12
1	Ring - retaining, msp	35P193	13
1	Seal - "O" ring	35P194	14
1	Ring - back-up	35P195	15
1	Ring - retaining.....	35P196	16
1	Plate - end	35P197	17
3	30A5893 screw - end plate, NO. 10-24 X 1/2".....		3
3	50A4287 Washer - lock, No. 10		3
1	Springs - ball seat.....	35P2077	18
1	Seal - ball	35P2078	19
2	Plug - adjusting, ball seat.....	35P2079	20
1	Tube - assembly, cast 35A9855 cylinder complete	*****	21

Power Steering Booster
Used on MA on LH Truck

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-68 2-70		Refer to Differential and Axle Group.	
		Add the following parts for MA 30 II, 40 II, 50 II and 60.	
		Note: Used on MA 30 II Lift Trucks No. 29000211 and after.	
		Used on MA 40 II Lift Trucks No. 26100999 and after.	
		Used on MA 50 II Lift Trucks No. 26200270 and after.	
		Used on MA 60 Lift Trucks No. 38200001 and after.	
1	35B7816	Case - differential, includes the following 3 parts:	1
86	35A9511	Seal - axle housing and differential case, outer end	1
89	35A9495	Collar - housing, seal retainer	1
4	35A9453	Shim - differential case to transmission case, .010	A.R.
4	35A9454	Shim - differential case to transmission case, .012	A.R.
4	35A9455	Shim - differential case to transmission case, .016	A.R.
4	35A9456	Shim - differential case to transmission case, .020	A.R.
5	35A9485	Shaft - bull pinion, 12 teeth	1
12	35A9459	Cap - bearing, pinion shaft, right hand 50A1440 Screw - cap, 12 pt. ctr. bore, 5/8"-16 x 1"	1 5
15	35A9458	Cap - bearing, pinion shaft, left hand 50A1440 Screw - cap, 12 pt. ctr. bore, 3/5"-16 x 12 50A1441 Screw - cap, 12 pt. ctr. bore, 3/8"-16 x 1-1/4"	1 3 2
15	35A9511	Cage - differential, with bushing and bull gear, 30 teeth	1
27	35A9451	Pinion - differential cage, 12 teeth 50A5170 "O" Ring - axle flange, 4-11/16" O.D.	4 2
31	35A9452	Gear - bevel, on axle, 28 teeth	2
85	35B8804	Housing - axle, left hand, includes the following parts: 50A1184 Screw - cap, 12 pt. ctr. bore	1 11
26	35A9511	Seal - axle housing and differential case, outer end	1
89	35A9495	Collar - housing, seal retainer	1
		Make the following changes for MA 30 II, 40 II and 50 II trucks: Change 35A7816 case ref. #1 to 35B7816, includes ref. #85 and 89. Add note to 35A7816 shaft (ref. #5) and 35A7806 cage, (ref. #18) when replacing use 35A9455 shaft (ref. #5) with 35A9511 cage (ref. #18) in sets only. 35A9511 cage has only 30 teeth. New shaft and cage used on MA 40 II Trucks No. 26100999 and after. Add new "O"-ring for axle shaft (ref. #30). 50A5170 "O" Ring - axle flange to housing, 4-11/16" O.D.	2
		Change 35A8384 housing (ref. #38) to 35B8354, includes ref. 38 and 39. Change 35A9626 seal (ref. #88) to 35A9511 (35A9626). Add note to 35A8591, 35A8295 and 35A8397 wheels (ref. #47).	
		Note: Used on MA 30-40 and 50 lift Trucks with 35A8774 and 35A1775 trucks with 1-1/2" x 10-1/2" linings.	
		Add the following wheel assemblies for trucks with 35A9108 and 35A9408 brakes with linings 2-1/4" x 10-1/4".	
	35A9522	Wheel - assembly, drive, MA 30 II, consists of the following 2 parts:	2
47	35A9522	Wheel - drive, MA 30 II	2
48	35A8980	Tire - cushion, 8" x 12-1/8" x 18", MA 30 II	2
	35A9521	Wheel - assembly, drive, MA 40 II, consists of the following 2 parts:	2
47	35A9521	Wheel - drive, MA 40 II	2
46	35A8987	Tire - cushion, 7" x 12-1/8" x 18", MA 40 II	2
	35A9523	Wheel - assembly, drive, MA 50 II, consists of the following 2 parts:	2
47	35A9523	Wheel - drive, MA 50 II	2
48	35A8988	Tire - cushion, 6" x 12" x 19", MA 50 II	2
	35A9524	Wheel - assembly, drive, MA 60, consists of the following 2 parts:	2
47	35A9524	Wheel - drive, MA 60	2
48	35A9683	Tire - cushion, 9" x 12-1/8" x 13" MA 60	2


Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-72		Refer to Brake Group. Add note to heading, with 1-1/2" x 10-1/2" shoes. Add new group for brakes with 2-1/4" x 10-1/4" shoes. Brakes - 2-1/4" x 10-1/4" shoes Used on MA 30 ft Lift Trucks No. 2800211 and after, Used on MA 40 ft Lift Trucks No. 2812099 and after, Used on MA 50 ft Lift Trucks No. 2820070 and after, Used on MA 60 Lift Trucks No. 3320000 and after.	
1	35A9109	Brake - complete, R.H., 10-1/4" x 2-1/4"	1
1	35A9109	Brake - complete, L.H., 10-1/4" x 2-1/4"	1
		Each includes the following 35 parts:	
		50A5553 Bolt - hex., 5/8"-18 x 1-1/4"	4
		50A5554 Bolt - hex., 5/8"-18 x 1"	2
		50A4500 Washer - plain, 5/8" I.D., 1-3/16" O.D.	2
2	35P2185	Plate - backing, R.H.	1
2	35P2184	Plate - backing, L.H.	1
3	35P2188	Kit - shoe with linings (enough for 1 truck)	1
		Caution: when replacing brake shoes on some units a new auto-adjusting cable 35P2184 must be used with an "A" stamped on one cycle.	
4	35P2209	Pin - hold down, brake shoe	4
5	35P2215	Cup - spring, shoe hold down	4
6	35P2210	Spring - hold down pin	4
7	35P2211	Cup - hold down pin	4
8	35P2191	Screw - brake adjusting, R.H.	1
9	35P2190	Screw - brake adjusting, L.H.	1
9	35P2193	Pivot Nut - screw, R.H.	1
9	35P2192	Pivot Nut - screw, L.H.	1
10	35P2215	Washer - adjusting screw	2
11	35P2206	Socket - adjusting screw	2
12	35P2205	Lever - automatic adjustment, R.H.	1
13	35P2204	Lever - automatic adjustment, L.H.	1
13	35P2203	Spring - automatic adjustment (std)	2
14	35P2208	Spring - shoe return, R.H. (Gray)	2
15	35P2207	Spring - shoe return, L.H. (Maroon)	2
16	35P2194	Cable - shoe, automatic adjustment	2
17	35P2183	Cylinder - wheel, 1-1/4" dia.	2
		Includes the following 8 parts:	
18	35P2199	Spring - cylinder	4
19	35P2200	Kit - cylinder, includes cups and boots (enough for 1 cylinder)	2
20	35P2187	Bolt - cylinder mounting, hex. head, 3/8"	4
		50A4244 Lockwasher - bolt, 3/8"	4
21	35P2199	Bolt - cylinder mounting, flat head, socket, 7/16"	4
22	35P2218	Lockwasher - bolt, 7/16" (Corless)	4
23	35P2201	Bolt - cylinder and anchor for shoe return springs	2
24	35P2195	Lever - parking brake	4
25	35P218E	Bolt - lever, parking brake	4
26	35P2210	Retainer - lever, parking brake	4
27	35P2196	Cable - parking brake	2
28	35P2197	Cam - cable, parking brake	2
29	35P2213	Sheave - cable, parking brake	2
30	35P2214	Retainer - cable, parking brake	2
31	35P2217	Retainer - sheave, parking brake	2
32	35P2202	Lever - brake control	2
		50A3888 Bolt - hex., 3/8"-18 x 1-1/2"	2
		50A1900 Nut - hex., 3/8"-18	2



Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-74		Refer to Brake Linkage and Master Cylinder Group. Change 50A4284 clevis (ref. #8) to 50A4279. Add the following parts for MA 30 II, MA 40 II, MA 50 II and MA 60 Lift Trucks with 35A9108 - 35A9109 brakes with 2-1/4" x 10-1/4" linings. Note: Used on MA 30 II Lift Trucks No. 28000211 and after. Used on MA 40 II Lift Trucks No. 28100339 and after. Used on MA 50 II Lift Trucks No. 28200270 and after. Used on MA 60 Lift Trucks No. 30260901 and after.	
14	35A9095	Cable - lever to right hand brake, 26" long.....	1
15	35A9050	Cable - lever to left hand brake, 37-3/4" long.....	1
22	35A9558	Pin - brake, right hand.....	1
23	35A9357	Tube - brake, left hand.....	1
	35A9354	Support - brake cable, right hand.....	1
	35A9353	Support - brake cable, left hand.....	1
		50A1921 Bolt - hex., 5/16"-18 N.F. x 7/8".....	4
Page 2-76		Add new group for Special Dual Stage Master Cylinder for MA 20, 40 and 50 Lift Trucks.	
	35R88	Kit - master cylinder, dual stage.....	1
		Includes the following 3 parts:	
	-----	Cylinder - assembly (Minnesota Automotive Inc. 703E).....	1
		50A2746 screw - flat head, socket, 3/8"-16 x 1".....	2
		50A366E Bolt - hex., 3/8"-18 x 7/8".....	3
	30P2001	Kit - cylinder repair, (includes seals, cups, gaskets, check valve, seat spring and etc.)	1
	35A3979	Adapter - cylinder.....	1
	35A2253	Clevis - bell crank and cylinder assembly.....	1
		50A4740 Nut - hex., jam 7/16"-20.....	1
		Add note to Master Cylinder 7/8", used on MA 60 Lift Truck.	

Ref No	Part No	DESCRIPTION	No. Pcs
Page 2-79 2-79		Refer to Hood, Panels and Seat Group. Change 35A9216 cowl (ref. #19) to 36A9216 on MA 30 II, 40 II and 60 II. Change 30A4998 nut to 35A9465. Add the following parts for MA 60 lift Truck.	
19	36A9405	Cowl - assembly, MA 60.....	1
23	35A9367	Panel - instrument, MA 60.....	
Page 2-83		Refer to Frame, Overhead Guard and Counterweight Group. Add the following parts for MA 60 Lift Trucks.	
3	35A921	Counterweight - MA 60.....	1
		35A5165 Bolt - hex., 3/4"-10 x 11", MA 60.....	
12	36A9406	Plate - floor, MA 60.....	1
		Add the following parts for MA 30 II, 40 II, 50 II and 60. Note: Used on MA 30 II Lift Trucks No. 28000211 and after. Used on MA 40 II Lift Trucks No. 28100989 and after. Used on MA 50 II Lift Trucks No. 26200270 and after. Used on MA 60 lift Trucks No. 33200001 and after.	
9	36A9110	Support - axle housing, right hand.....	1
10	36A9111	Support - axle housing, left hand.....	1
		30A1316 Screw - cap, 12 pt., 3/4"-10 x 2-3/4".....	8
		Add new breakdown for hydraulic pump on MA 60 Lift Truck.	


S.I. No.	Part No.	DESCRIPTION	Qty. Per
HYDRAULIC PUMP for MA 60			
1	35A3396	Pump - hydraulic, with flow divider, (Weستر No. 4YD59-0RB) Includes the following 21 parts: 50A1780 - Bolt, hex., 3/8"-16 x 3-1/4" 50A1781 - Bolt, hex., 3/8"-16 x 5-1/4" 50A1829 - Stat-o-seal, pump bulbs 50A1046 - Nut, hex., (Eaton) 3/8"-16 50A1782 - Nut, elastic stop, pump shaft, 3/8"-16	1
2	35P2226	Body - pump, with bearings	1
3	10P3074	Cover - pump, with bearings Each includes the following part:	1
4	35P207	Bearing - needle, body and cover	4
5	35P2231	Shaft - drive	1
6	35P2227	Gear - drive shaft	1
7	30A164	Bearing - ball, drive shaft	1
8		50A1789 Ring - bearing retainer	2
9	35P2230	Adapter - bearing GM14710 - Screw, adapter, No. E-33 x 1 *50A1744 "O" Ring - adapter	1
10		Washer - thrust, ball bearing	1
11	35P276	Retainer - bearing, with oil seal	1
12	33P288	Includes the following part:	
13	10P1772	*Seal - oil	1
	10P1966	Screw - retainer, No. 10-24 x 3/8"	4
14	10P2027	*"O" Ring - retainer, 1-15/16" O.D.	1
15	35P2225	Gear - idler	1
16	35P271	Plate - gear	1
17	33P2229	Pin - dowel, gear plate 50A3678 - Bolt, hex., cover to body, 3/8"-16 x 3"	2
18-19	10P2014	Plate - wear, pump body and cover	2
20	10P3077	*Seal - wear plate, outer, rubber	2
21	33P284	*Seal - wear plate, inner, rubber	2
22	10P3067	*Ring - back-up, wear plate seal	3
23	10P2021	*"O" Ring - body and cover, 5/8" I.D., 3/4" O.D.	2
24	33P2240	Flow divider - assembly Includes the following 8 parts: 50A4445 Plug - divider, hex. socket, 1/2"-27	1
25	35P289	Piston - flow divider	1
26	10P1592	Spring - piston	1
27	10P1590	Plug - piston and spring	1
28	35P1394	"O" Ring - piston plug	1
29	35P290	Valve - flow divider	1
30	10P1405	Spring - valve	1
31	35P295	Shim - valve spring	A. R.
32	33P292	Plug - valve spring	1
33	35P1291	*"O" Ring - flow divider to pump 50A3659 - Screw, flow divider to pump, 5/16"-18 x 1-8/4"	2
34	35P311	Gear - hydraulic pump, Continental Motors No. #400H-338 50A5007 Key - waircraft No. 5	1
35	35A706	*Gasket - hydraulic pump	1
	10A1193	*Kit - seals and gaskets	1
Note: Kit consists of items identified with a single asterisk()			



Rev. No.	Part No.	DESCRIPTION	Qty. Per		
Page 2-84		Refer to Mast Control Valve Group. Add note to 35A741 valve, and MA 80. Change description of 35A8292 knob (ref. #92) from tilt to lift.			
Page 2-96		Refer to Hydraulic Oil Lines and Fittings Group. Change 35A858T hose (ref. #54) to 35A9156 and length to 18". Add clip for lift cylinder tube 35A7865. Clip - tube.....	1		
	35A9539	Add the following parts for MA 80 Lift Trucks.			
4	35A9502	Tube - pump to strainer	1		
6		35A4418 Elbow - pump suction port, 1-5/16" x 90°	1		
10	35A9501	Tube - pump to control valve	1		
16		35A4425 Elbow - pump, 7/8" x 1/4, 90°	1		
	10A18285	"O" Ring - elbow to pump	1		
32	35A9814	Tube - control valve to lift cylinder.....	1		
Page 2-84		Refer to Tilt Cylinder Group. Add a single asterisk (*) to 33P300 packing (ref. #9). Change GM131643 bolt to 35A9561 and size to 1/2" - 18 x 1-1/2". Change GM120302 nut to 35A1900 and size to 1/2" - 12.			
Page 2-96		Refer to Upright for Triplex Tri-Free Lift (Cascade Viewmast) Group, Group I Add the following changes for upright due to different styles of lift chain used.			
12	35P2294	* Rod - lift, assembly	2		
12	35P1843	** Rod - lift, assembly	2		
13	35P1843	* Pin - rod and anchor	2		
13	35P2219	** Pin - rod and anchor	2		
13	35P2235	* Anchor - chain, outer channel	2		
15	35P1846	** Anchor - chain, outer channel	2		
		* Note: Used on uprights with AL-644 lift chain. ** Note: Used on uprights with BL-546 lift chain.			
		Chain for Lift - 3/8" Pitch BL-546			
M. P. H.	O. A. H. L.	Chain Length	M. P. H.	O. A. H. L.	Chain Length
135"	70"	164-3/8"	177"	62"	206-7/8"
187"	70"	164-3/4"	181"	82"	206-7/8"
140"	70"	164-3/8"	185"	82"	212-1/8"
145"	70"	164-3/8"	189"	88"	224-3/8"
149"	70"	170-3/8"	193"	88"	224-3/8"
153"	76"	182-1/8"	197"	88"	230-5/8"
157"	76"	182-1/8"	201"	88"	230-5/8"
161"	76"	188-3/8"	205"	94"	243-1/8"
165"	76"	188-3/8"	209"	94"	243-3/8"
168"	82"	200-5/8"	213"	94"	249-3/8"
173"	82"	206-7/8"	217"	94"	249-3/8"
Page 2-102		Refer to Cross Head for Upright (Cascade Viewmast), Group IV Add note to 35P1829 Cross Head, for BL-546 5/8" P. chain. 35P2233 Cross Head - upright, for AL-644 3/4" P. chain	1		
		Add note to 35P1885 support (ref. #14) for 35P2233 Cross Head. Add Simplex Mast.			

Rev. No.	Part No.	DESCRIPTION	No. Pcs.
Page 2-113		Refer to Decals, Paint and Hydraulic Fluid Group.	
		Change 35A8813 decal to 35A10198, White Mobilift, 4" x 12".	
		Change 35A9821 decal to 35A10186, White, 3/4" x 4-1/2".	
		Add the following new decals:	
	35A10199	Decal - R.H. side, 4-1/4" x 6" x 6-3/4".....	1
	35A10197	Decal - L.H. side, 4-1/4" x 6" x 6-3/4".....	1
	35A9876	Decal - capacity, MA 20 ll.....	1
	35A9875	Decal - capacity, MA 40 ll.....	1
	35A9874	Decal - capacity, MA 50 ll.....	1
	35A9873	Decal - capacity, MA 60.....	1
	10A92766	Decal - warning, negative ground, 2-1/2" x 8".....	1
	35A10194	Decal - G, for MA 60.....	2
	35A10188	Decal - Q, for MA 60.....	2
	35P2233	Decal - 10' of 2" black strip.....	1
		Refer to Bulletin C280 and make the following change on page 4:	
		Add to description of 35A7364 spring (ref. #43) for MA 30 ll, 40 ll, and 50 ll Lift Trucks, 20-1/2 coils.	
		Add new spring for MA 60 Lift Trucks:	
	35A9957	Spring - piston, regulator valve, outer, 2-11/16" long, 18 coils.....	1

Ref. No.	Part No.	DESCRIPTION	No. Pcs.	
		SIMPLEX MAST For MA 30 II, 40 II, 50 II and 60 Lift Trucks Group 1	MA 30 II	MA 60
			MA 40 II	
			MA 50 II	
1	-----	Rail - outer assembly, see chart on pages 50-51 Includes the following part:	1	1
2	3535034	Cap - bearing, outer rail pivot	2	2
3		50A1288 - Screw, bearing, cap, 12 pr., 5/8" x 11 x 2-1/2"	4	4
		50A4829 - Fitting, grease, 1/8" straight	2	2
4	35A5727	Washer - bearing cap	2	2
5	-----	Rail - inner assembly, see chart on pages 50-51 Includes the following part:	1	1
6	35A3323	Pin - rail	4	4
7	35A5558	Shoe - mast 50A1676 - Screw, hex. socket, 3/8" x 16 x 3/8"	6 12	6 12
8	35A5526	Slip - mast shoe	A.R.	A.C.
9	35A70E	Roller - mast and carriage	3	3
10	D317	Bearing - mast and carriage roller	3	-
10	35A9359	Bearing - mast and carriage roller	-	3
11		50A577 - Ring, snap, mast and carriage bearings, 3-5/32" I.D.	3	3
12		50A578 - Ring, snap, mast and carriage bearings, 1-3/8" I.D.	3	3
13	-----	Carriage - with wear plates, order from Mobilift Sales Department Includes the following 5 parts:	1	1
14	35A5323	Pin - carriage	4	4
15	35A5558	Shoe - carriage	4	-
15	35A9316	Shoe - carriage 50A1676 - Screw, hex. socket, 3/8" x 16 x 3/8"	- 3	4 3
16	35A5536	Slip - shoe, .031 thick	A.R.	A.R.
16	35A9099	Slip - shoe, .015 thick	A.R.	A.R.
16	35A9100	Slip - shoe, .010 thick	A.R.	A.R.
17	-----	Carriage - assembly, with side thrust rollers, Order from Mobilift Sales Dept. Includes the following part:	1	1
18	35A5323	Pin - carriage	4	4
19	35A5817	Bearing - thrust, carriage	4	4
20	35A5755	Pin - thrust bearing 50A413E - Set Screw, cup point, 3/8" x 16 x 5/8"	4 2	4 2
21	-----	Rack - load safety, order from Mobilift Sales Dept. GM271723 - Bolt, hex., 5/8" x 11 x 2"	1 6	1 6
22	35A5871	Bracket - mounting, load rack to carriage	2	2
23	-----	Chain - 3 x 4 lacing, see chart on page 50 for length of chain	2	2
23	-----	Chain - 4 x 6 lacing, see chart on page 51 for length of chain	2	2
24	35A6562	Anchor - chain, 2-1/2" long	2	-
24	35A9087	Anchor - chain, 3" long	-	2
25	35A5760	Pin - chain anchor, 3/4" x 2-1/8"	2	-
25	35A3973	Pin - chain anchor, 1" x 2-3/16"	-	2
26		50A1753 - Ring, retainer, anchor pin	2	-
26	20H5391	Ring - retainer, anchor pin	-	2
27	35A6562	Anchor - chain, 4-1/2" long	2	-
27	35A9066	Anchor - chain, 5" long	-	2
28	35A837	Pin - chain anchor, 5/16" x 1-1/8" 50A3319 - Pin, cotter, 3/32" x 1/2"	4 4	4 8
29	-----	Rod - chain anchor, see chart on pages 50-51	2	2
30		50A5161 - Nut, hex. jam, 3/4" - 16	8	6
31	-----	Cylinder - lift, see chart on pages 50-51 50A3671 - Bolt, hex., 3/8" x 16 x 2-1/4" 50A2742 - Nut, hex. jam, 3/8" - 16	1 1 1	1 1 1




QTY	DESCRIPTION	PART NO.	REF. NO.
1	Head - piston	35A9316	38
1	Pin - set screw, cup point, 3/8"-16 x 1/2"		38
1	Guide - piston head	35A9050	34
3	Washer - ball, hex., 1/8"-13 x 2"		
4	35A3633 - Bolt, hex., 1/8"-13 x 2"		
4	35A1811 - Nut, hex., 1/8"-13		
4	Spacer - guide, 2/16" x 1-1/4" x 3/8"	35A9208	35
2	Block - stop, outer rail, 1/2" x 2" x 2-7/8"	35A5520	36
2	Block - stop, outer rail, 1/2" x 2" x 2-7/8"		
4	Block - stop, outer rail, front	35A9370	37
4	Block - stop, outer rail, front		
2	35A0142 - screw, 1/2 pc. cr. hole (Nylon), 3/8"-16 x 1"		
4	Shave - chain, 5/16" dia.	35A9205	39
2	Shave - chain, 5/16" dia.		
2	Shave - chain, 5/16" dia.	35A9314	39
-	Each includes the following part:		
2	Pin - shove	35A9324	41
2	35A2880 - pin, roll, 1/4" x 1-1/4"		
2	35A3381 - Spring, grease, 1/4"-26 stainless		
2	Pin - Drive, order from Mobilite Sales Dept.		42
2	Includes the following 4 parts:		
2	Pin - left stop, 2-1/16" long	35A956	48
2	35A956		
2	Lower - stop pin	35A959	44
2	35A959		
2	Spring - stop pin	35A967	45
2	35A967		
2	35A2882 - pin, roll, 3/16" x 1"		46
2	35A2882 - pin, roll, 3/16" x 1"		46
2	Washer - lock lock, 1/16" x 21/32" I.D., 7/8" O.D.	35A9097	47
2	35A9097		
2	Tube - vent, 8/32" O.D.	35A9202	48
1	Flow - vent tube, see chart on pages 46-51		49
1	35A4303 - Clamping, hex., 3/8"		50
2	35A1566 - Fitting, hose, 1/4"-16		51
1	35A4338 - Reducer, vent line, 3/8" to 1/4"		52
1	35A4338 - Reducer, vent line, 3/8" to 1/4"		52
2	35A4902 - screw, rd. hd., 1/4"-20 x 1-1/4"		53
2	35A1698 - Nut, hex., 1/4"-20		53
2	35A1698 - Nut, hex., 1/4"-20		53
2	Spacer - strap, U-clip	35A1464	54

SIMPLEX MAST (Cont'd)

MA 80 II
MA 40 II
MA 50 II

No. Pcs.



Qty. No.	Part No.	DESCRIPTION	No. Per
Simplex Lift Cylinder Group II 3-1/4" Diameter, for MA 30 Lift Truck			
		*Cylinder - lift, complete.....	1
		Includes the following 8 parts:	
1		*Shell - cylinder, outer, 3-1/4" O.D.	1
2		*Plunger - cylinder, 2-1/4" O.D.	1
3		*Spacer - cylinder.....	A.R.
		*Note: Order above parts by M F H and O A H L.	
4	35P2068	**Ring - wiper, plunger.....	1
5	35P2067	**Spring - garter, wiper ring.....	1
6	35P2157	Retainer - plunger wiper ring.....	1
7	35P2068	**"O" ring - retainer, 2-3/4" I.D., 3" O.D.	1
8	35P2156	Piston.....	1
9	35P2069	**Packing - piston.....	1
10	35P2070	**"O" Ring - piston, inner, 1-3/4" I.D., 2" O.D.	1
11	35P2371	**Ring - back-up, "O" ring.....	1
12	35P2156	Ring - snap, piston retainer.....	1
	35R100	**Kit - cylinder.....	1
		Note: Kit consists of the above items identified by () asterisks.	
13	35A 7796	Spring - oil restrictor.....	1
14	35A 7796	Washer - perforated, oil restrictor.....	1
15	35A 7792	Spacer - oil restrictor.....	1
16	35A 7793	Hat - spacer.....	1
Simplex Lift Cylinder Group III 3-3/4" Diameter, for MA 40 II and 40 II Lift Trucks			
		*Cylinder - lift, complete.....	1
		Includes the following 8 parts:	
1		*Shell - cylinder, outer 3-3/4" O.D.	1
2		*Plunger - cylinder, 2-3/4" O.D.	1
3		*Spacer - cylinder.....	A.R.
		*Note: Order above parts by M F H and O A H L.	
4	35P940	**Ring - wiper, plunger.....	1
5	35P823	**Spring - garter, wiper ring.....	1
6	35P823	Retainer - plunger wiper ring.....	1
7	13A11647	**"O" Ring - retainer, 3-1/4" I.D., 3-1/2" O.D.	1
8	35P820	Piston.....	1
9	35P824	**Packing - piston.....	1
10	13A4729	**"O" Ring - piston, inner, 2-1/4" I.D., 2-1/2" O.D.	1
11	35P821	**Ring - back-up, "O" ring.....	1
12	35P823	Ring - snap, piston retainer.....	1
	35R101	**Kit - cylinder.....	1
		Note: Kit consists of the above items identified by () asterisks.	
13	35A 7792	Spring - oil restrictor.....	1
14	35P149	Washer - perforated, oil restrictor.....	1
15	35P148	Spacer - oil restrictor.....	1

Ref. No.	Part No.	DESCRIPTION	Qty.
		Simplex Lift Cylinder Group IV 4" Diameter for MA 60 Lift Trucks	
		*Cylinder - lift, complete.....	1
		Includes the following 9 parts:	
1		*Shell - cylinder, outer, 4" O.D.	1
2		*Plunger - cylinder, 3" O.D.	1
3		*Spacer - cylinder.....	A.R.
		*Note: Order above parts by M F H and O A H L.	
4	35P183	**Ring - wiper, plunger.....	1
5	85P192	**Spring - garter, wiper ring.....	1
6	35P172	retainer - plunger, wiper ring.....	1
7	35P181	**"O" Ring - retainer.....	1
9	35P168	Piston.....	1
3	85P176	**Packing - piston.....	1
10	35P174	**"O" Ring - piston, inner.....	1
11	85P175	**Ring - back-up, "O" ring.....	1
12	35P173	Ring - snap, piston retainer.....	1
	35R33	**Kit - cylinder.....	1
		Note: Kit consists of the above items identified by () asterisks.	
13	35A4902	Spring - oil restrictor.....	1
14	35A4900	Washer - perforated, oil restrictor.....	1
15	35A4931	Spacer - oil restrictor	1




CHART FOR SIMPLEX MAST

Used on MA 30 II, 40 II and 50 II Series Lift Trucks

Overall Height Lowered	Max. Fork Height	Outer Rail	Inner Rail	Cyl. Assy.		Chain Assy. 3/4" P. (BL634)			Chain Anchor		Vent Hose Length
				MA 30 II	50 II	Pitches	Length	Rod	Length		
63-1/2"	91"	36A 9210	36A 9240	35A 9402	35A 9171	35A 2650	81	60-3/4"	35A 9333-41-1/2"	35A 2776-86"	
65"	94"	36A 9211	36A 9241	35A 9403	35A 9172	35A 2652	83	63-3/4"	35A 9333-41-1/2"	35A 2777-87-1/2"	
66-1/2"	97"	36A 9212	36A 9242	35A 9404	35A 9173	35A 2654	88	66-3/4"	35A 9333-41-1/2"	35A 2778-89"	
68"	100"	36A 9213	36A 9243	35A 9405	35A 9174	35A 1706	96	69-3/4"	35A 9333-41-1/2"	35A 2779-90-1/2"	
69-1/2"	103"	36A 9214	36A 9244	35A 9406	35A 9175	35A 1708	97	72-3/4"	35A 9333-41-1/2"	35A 2780-92"	
71"	106"	36A 9215	36A 9245	35A 9407	35A 9176	35A 1710	101	75-3/4"	35A 9333-41-1/2"	35A 2781-93-1/2"	
72-1/2"	109"	36A 9216	35A 9246	35A 9408	35A 9177	35A 1706	93	69-3/4"	35A 9334-50-1/4"	35A 2782-95"	
74"	112"	36A 9217	36A 9247	35A 9409	35A 9178	35A 1708	97	72-3/4"	35A 9334-50-1/4"	35A 2783-96-1/2"	
75-1/2"	115"	36A 9218	36A 9248	35A 9410	35A 9179	35A 1710	102	75-3/4"	35A 9334-50-1/4"	35A 2784-98"	
77"	118"	36A 9219	36A 9249	35A 9411	35A 9180	35A 1712	105	78-3/4"	35A 9334-50-1/4"	35A 2785-99-1/2"	
78-1/2"	121"	36A 9220	36A 9250	35A 9412	35A 9181	35A 1714	109	81-3/4"	35A 9334-50-1/4"	35A 2786-92"	
80"	124"	36A 9221	36A 9251	35A 9413	35A 9182	35A 1716	113	84-3/4"	35A 9334-50-1/4"	35A 2787-92-1/2"	
81-1/2"	127"	36A 9222	36A 9252	35A 9414	35A 9183	35A 1712	105	78-3/4"	35A 9335-58-1/4"	35A 2788-94"	
83"	130"	36A 9223	36A 9253	35A 9415	35A 9184	35A 1714	100	81-3/4"	35A 9335-58-1/4"	35A 2789-95-1/2"	
84-1/2"	133"	36A 9224	36A 9254	35A 9416	35A 9185	35A 2716	113	84-3/4"	35A 9335-58-1/4"	35A 2790-97"	
86"	136"	36A 9225	36A 9255	35A 9417	35A 9186	35A 1716	117	87-3/4"	35A 9335-58-1/4"	35A 2791-98-1/2"	
87-1/2"	139"	36A 9226	36A 9256	35A 9418	35A 9187	35A 1718	119	84-3/4"	35A 9336-66-1/4"	35A 2792-98"	
89"	142"	36A 9227	36A 9257	35A 9419	35A 9188	35A 1716	117	87-3/4"	35A 9336-66-1/4"	35A 2793-61-1/2"	
90-1/2"	145"	36A 9228	36A 9258	35A 9420	35A 9189	35A 1720	121	90-3/4"	35A 9336-66-1/4"	35A 2794-83"	
93"	148"	36A 9229	36A 9259	35A 9421	35A 9190	35A 1722	135	93-3/4"	35A 9336-66-1/4"	35A 2795-65"	
94-1/2"	151"	36A 9230	36A 9260	35A 9422	35A 9191	35A 1722	125	98-3/4"	35A 9337-70-1/4"	35A 2796-66-1/2"	
96"	154"	36A 9231	36A 9261	35A 9423	35A 9192	35A 1724	129	98-3/4"	35A 9337-70-1/4"	35A 2797-68"	
97-1/2"	157"	36A 9232	36A 9262	35A 9424	35A 9193	35A 1726	133	99-3/4"	35A 9337-70-1/4"	35A 2798-69-1/2"	
99"	160"	36A 9233	36A 9263	35A 9425	35A 9194	35A 1728	137	102-3/4"	35A 9337-70-1/4"	35A 2799-71"	
100-1/2"	163"	36A 9234	36A 9264	35A 9426	35A 9195	35A 1726	133	99-3/4"	35A 9338-77-1/4"	35A 2800-73"	
102"	166"	36A 9235	36A 9265	35A 9427	35A 9196	35A 1728	137	102-3/4"	35A 9338-77-1/4"	35A 2801-74-1/2"	
103-1/2"	169"	36A 9236	36A 9266	35A 9428	35A 9197	35A 1730	141	105-3/4"	35A 9338-77-1/4"	35A 2802-76"	
105"	172"	36A 9237	36A 9267	35A 9429	35A 9198	35A 1732	145	108-3/4"	35A 9338-77-1/4"	35A 2803-77-1/2"	
106-1/2"	175"	36A 9238	36A 9268	35A 9430	35A 9199	35A 1730	141	105-3/4"	35A 9339-85-1/4"	35A 2804-79"	
109"	178"	36A 9239	36A 9269	35A 9431	35A 9275	35A 1732	145	108-3/4"	35A 9339-85-1/4"	35A 2805-81"	

Refer to page 48 for breakdown of cylinder assembly.

CHART FOR SIMPLEX MAST

Used on MA 60 Lift Trucks

Overall Height Lowered	Max. Fork Height	Chain Assy. - 3/4" P.						Chain Anchor		Vent Hose	
		Outer Rail	Inner Rail	Cyl. Assy.	(Bl. Gd)	Pitches	Length	Rod	Length	Hose	Length
68"	91"	36A8975	36A9005	35A9035	35A9348	81	60-3/4"	35A9078-44"		36A2776-36"	
69-1/2"	94"	36A8976	36A9005	35A9036	35A9350	85	63-3/4"	35A9078-44"		35A2777-37-1/2"	
71"	97"	36A8977	36A9007	35A9037	35A9352	89	66-3/4"	35A9078-44"		35A2778-39"	
72-1/2"	100"	36A8978	36A9008	35A9038	35A2064	93	69-3/4"	35A9078-44"		36A2779-40-1/2"	
74"	103"	36A8979	36A9009	35A9039	35A2066	97	72-3/4"	35A9078-44"		35A2780-42"	
75-1/2"	106"	36A8980	36A9010	35A9040	35A2063	91	66-1/4"	35A9077-51-1/2"		35A2781-48-1/2"	
77"	109"	36A8981	36A9011	35A9041	35A2065	95	71-1/4"	35A9077-51-1/2"		35A2782-45"	
78-1/2"	112"	36A8982	36A9012	35A9042	35A2087	99	74-1/4"	35A9077-51-1/2"		35A2783-46-1/2"	
80"	115"	36A8983	36A9013	35A9043	35A2069	103	77-1/4"	35A9077-51-1/2"		35A2784-49"	
81-1/2"	118"	36A8984	36A9014	35A9044	35A2071	107	80-1/4"	35A9077-51-1/2"		35A2785-48-1/2"	
83"	121"	36A8985	36A9015	35A9045	35A2073	111	83-1/4"	35A9077-51-1/2"		35A2786-51"	
84-1/2"	124"	36A8986	36A9016	35A9046	36A2066	109	77-1/4"	35A9079-60-1/2"		35A2787-52-1/2"	
86"	127"	36A8987	36A9017	35A9047	35A2071	107	80-1/4"	35A9079-60-1/2"		35A2788-54"	
87-1/2"	130"	36A8988	36A9018	35A9048	35A2078	111	83-1/4"	35A9079-60-1/2"		35A2789-55-1/2"	
90"	133"	36A8989	36A9019	35A9049	35A2075	115	86-1/4"	35A9079-60-1/2"		35A2790-57"	
91-1/2"	136"	36A8990	36A9020	35A9050	35A2077	119	89-1/4"	35A9079-60-1/2"		35A2791-59-1/2"	
93"	139"	36A8991	36A9021	35A9051	35A2073	123	92-1/4"	35A9079-60-1/2"		35A2792-60"	
94-1/2"	142"	36A8992	36A9022	35A9052	35A2081	127	95-1/4"	35A9079-60-1/2"		35A2793-61-1/2"	
96"	145"	36A8993	36A9023	35A9053	35A2083	131	98-1/4"	35A9079-60-1/2"		35A2794-63"	
98-1/2"	148"	36A8994	36A9024	35A9054	35A2072	129	98-1/4"	35A9080-70-1/2"		35A2795-65"	
100"	151"	36A8995	36A9025	35A9055	35A2081	127	95-1/4"	35A9080-70-1/2"		35A2796-65-1/2"	
101-1/2"	154"	36A8996	36A9026	35A9056	35A2083	131	98-1/4"	35A9080-70-1/2"		35A2797-68"	
103"	157"	36A8997	36A9027	35A9057	35A2085	135	101-1/4"	35A9080-70-1/2"		35A2799-69-1/2"	
104-1/2"	160"	36A8998	36A9028	35A9058	35A2087	139	104-1/4"	35A9080-70-1/2"		35A2799-71"	
107"	163"	36A8999	36A9029	35A9059	35A2089	143	107-1/4"	35A9080-70-1/2"		35A2800-73"	
108-1/2"	166"	36A9000	36A9030	35A9060	35A2085	145	107-1/4"	35A9081-79-1/2"		35A2801-74-1/2"	
110"	169"	36A9001	36A9031	35A9061	35A2087	149	104-1/4"	35A9081-79-1/2"		35A2802-76"	
111-1/2"	172"	36A9002	36A9032	35A9062	35A2069	143	107-1/4"	35A9081-79-1/2"		35A2803-77-1/2"	
112"	175"	36A9003	36A9033	35A9063	35A2091	147	110-1/4"	35A9081-79-1/2"		35A2804-78"	
114-1/2"	178"	36A9004	36A9034	35A9064	35A2089	143	107-1/4"	35A9347-87-1/2"		35A2805-81"	

Refer to page 40 for breakdown of cylinder assembly.

F O R E W O R D

This manual has been prepared as a guide for the owner and operator of a MA Series Fork Lift Truck. The contents of this manual are arranged in five sections which include complete operation and maintenance instructions, overhaul instructions, together with a list of all repair parts used on the lift trucks. In order to attain maximum life and efficiency from the lift truck, thoroughly read Chapters 1, 2, and 3 of the manual, and carefully follow all instructions.

A planned maintenance program, following the procedures outlined in this manual, is of vital importance in obtaining dependable service and long life from the lift truck, and should be initiated when the lift truck is new. The practice of preventative maintenance will reduce "down time" and repair cost.

Whenever lubrication and maintenance procedures are accomplished, record the number of hours of operation, as indicated on the hourmeter, so the interval for next performing these procedures will be known.

S P E C I F I C A T I O N S

	MA 30 MA 30 II	MA 40 MA 40 II	MA 50 MA 50 II
Capacity (At 24-inch load center)	3000 lbs	4000 lbs	5000 lbs
Tuck Point Rating	109, 500	146, 000	152, 500
Length (Less Forks).....	76-1/4"	81-1/2"	85"
Width	37"	38"	40"
Wheelbase	50'	52"	52"
Tread			
Drive	31"	31"	31"
Steer	32"	32"	32"
Turning Radius (Outside).....	68-3/4"	72"	75-1/4"
Speeds (MPH) (All Trucks)			
Forward	0 to 9.3	0 to 9.3	0 to 9.3
Reverse	0 to 9.5	0 to 9.3	0 to 9.5
Lift Speed (Manual Steering)			
No Load	126 fpm	---	---
Full Load	118 fpm	---	---
Lift Speed (Power Steering)			
No Load	107 fpm	86 fpm	86 fpm
Full Load	97 fpm	77 fpm	77 fpm
Lowering Speed			
No Load	87 fpm	63 fpm	63 fpm
Full Load	129 fpm	75 fpm	75 fpm
Mast Tilt (All Trucks)		10° Forward, 10° Rear	
Maximum Fork Spread	36"	36"	36"
Gradeability, Full Load	21.2%	28%	24%
Drawbar Pull	3140 lbs	3100 lbs	2080 lbs
Tires			
Drive	18 x 6 x 12-1/8	18 x 7 x 12-1/8	18 x 8 x 12-1/8
Steer	15-1/2 x 5 x 10	15-1/2 x 5 x 10	15-1/2 x 5 x 10
Fuel Capacity (Gasoline)	5 gal	8 gal	8 gal
Cooling System Capacity	11 qts	11 qts	11 qts
Transmission - Final Drive Capacity	15-3/4 qts	15-3/4 qts	16-3/4 qts

(Minneapolis-Moline, Inc. is constantly striving to improve its products and, therefore, reserves the right to change design, materials, and/or specifications without notice.)

E N G I N E S P E C I F I C A T I O N S

Make	Continental
Model	F162 or F163
Cylinders	4
Bore and Stroke	3-7/16 x 4-3/8
Piston Displacement	160 cu. in.
Firing Order	1-3-4-2
Governed Speed (No Load)	2800 rpm
Idle Speed	800 rpm
Horsepower @2400 rpm (Gasoline)	51
Crankcase Capacity w/Filter	4-1/2 qts

TABLE OF CONTENTS

CHAPTER 1.	INTRODUCTION	1-3
Section 1.	General Description	1-3
II.	Detailed Description	1-3
CHAPTER 2.	OPERATING INSTRUCTIONS	1-6
Section 1.	Preparation for Use	1-6
II.	Operating Instructions	1-7
III.	Principles of Operation	1-9
CHAPTER 3.	FIELD MAINTENANCE	1-10
Section 1.	Lubrication	1-14
II.	Preventive Maintenance Service	1-16
CHAPTER 4.	OVERHAUL (SHOP MAINTENANCE)	1-21
Section 1.	General	1-21
II.	Removal, Disassembly, Repair and Reassembly	1-21
4-7.	Battery, Lamp and Cables	1-21
4-11.	Fuel Pump, Fuel Lines and Filter	1-21
4-18.	Water Pump	1-21
4-21.	Horn Button	1-22
4-28.	Steering Gear (Hydraulic)	1-22
4-31.	Steering Gear (Manual)	1-23
4-38.	Hydraulic, Steering, Wheels and Linkage	1-24
4-41.	Head and Rear Lamps	1-24
4-49.	Instrument Panel and Instruments	1-26
4-51.	Adjuster Hoses, and Thermostat	1-26
4-56.	Muffler	1-26
4-60.	Generator	1-26
4-64.	Generator Voltage Regulator	1-28
4-70.	Starting Motor	1-28
4-75.	Lubricator	1-29
4-80.	Service Brakes and Rear Axle	1-30
4-85.	Brake Linkage and Master Cylinder	1-30
4-90.	Drive Axle and Differential (Two Pinion Cogs)	1-31
4-95.	Drive Axle and Differential (Four Pinion Cogs)	1-34
4-100.	Traction Control Valve (Hydraulic Inching)	1-38
4-105.	Traction Control Valve (Mechanical Inching)	1-38
4-110.	Adjusting Brake and Mechanical Inching Linkage	1-40
4-111.	Traction Control Case, Converter, and Pump	1-41
4-116.	Transmission	1-42
4-121.	Hydraulic Pump	1-45
4-128.	Master Control Valve	1-48
4-131.	TLN Cylinder	1-47
4-136.	Left Cylinder	1-47
4-141.	Master and Related Parts	1-48
4-145.	Overhaul	1-49
III.	Engine Repair and Overhaul	1-50
IV.	Optional Equipment	1-70
FUNCTIONAL PARTS LIST		

2-1 to 2-137 etc.




Fig. 1-1. Fork Lift Truck

Chapter 1
INTRODUCTION
Section I. General Description

1-1. SCOPE.

1-2. This manual provides instructions on the operation, maintenance, and overhaul of the MA Series Fork Lift Trucks. Most of the instructions apply to all models. Where differences do occur, they will be noted in the text or paragraph heading.

1-3. The lift truck is equipped with a Continental Engine, Model Number F162 or F163.

1-4. It is strongly recommended that all personnel concerned with the various phases of these lift trucks study this manual thoroughly, to gain knowledge and understanding of the equipment, before performing any procedures with the equipment.

1-5. GENERAL DESCRIPTION.

1-6. Due to its design and intended purpose the equipment will be referred to as "lift truck" or "truck" throughout this manual. Reference to either the right or left sides of the truck are made in respect to the normal direction of travel, which is forward.

1-7. The capacities of the lift trucks, at a 24 inch load center, are as follows: MA 30, 20 II - 3000 lbs; MA 40, 40 II - 4000 lbs; MA 50, 50 II - 5000 lbs.

1-8. The lift truck is a completely self-contained vehicle, its power train consisting of a four-cylinder gasoline engine, a hydraulic torque converter, and a multiple disc clutch and power shaft type transmission. All these assemblies are integrally mounted, forming one compact unit, which in turn drives the front axle differential and the drive wheels. A gear-type pump driven from the engine camshaft, supplies pressure to the hydraulic system. Electrical components of the truck utilize the current supplied from one 12-volt battery.

1-9. DUE TO ITS DESIGN AND INTENDED PURPOSE THE EQUIPMENT WILL BE REFERRED TO AS "LIFT TRUCK" OR "TRUCK" THROUGHOUT THIS MANUAL. REFERENCE TO EITHER THE RIGHT OR LEFT SIDES OF THE TRUCK ARE MADE IN RESPECT TO THE NORMAL DIRECTION OF TRAVEL, WHICH IS FORWARD.

Section II. Detailed Description

1-9. DETAILED DESCRIPTION.

1-10. ENGINE. The engine (4, figure 1-2) is a four-cylinder, four-cycle gasoline operated, I-head type. Its normal speed with no load is 2600 RPM. One complete stroke is required for intake, compression, power, and exhaust, thereby providing one power stroke per cylinder for each two revolutions of the crankshaft.

1-11. TORQUE CONVERTER. The torque converter (3, figure 1-2) is a compact, complete, sealed unit consisting of an impeller, turbine, and single-stage stator. The charging pump is coupled to the engine flywheel through the impeller hub. The oil from the pump charges the converter, and the torque is multiplied by the stator. The turbine is splined to the input shaft in the transmission.

1-12. TRANSMISSION. The transmission (2, figure 1-2) is a power shaft gear box equipped with a hydraulically actuated multiple disc clutch. The clutch is mounted on the input shaft, and controls the forward and reverse movement of the truck. The control valve receives pressure from an engine-driven hydraulic pump mounted on the transmission cover. The valve is controlled by the hand lever located on the steering column. An "inching" valve incorporated into the control valve, supplies only partial pressure to the clutch when it is activated by the inching pedal. This feature provides very slow ground speeds at full engine speed.

1-13. INCHING SYSTEM. The inching system is controlled by the combination inching-braking pedal (1, figure 1-6). The pedal activates a valve which supplies a restricted pressure to the clutch. The clutch is thus allowed to "slip", thereby delivering only partial power

to the drive wheels, with a resultant slow ground speed. The engine speed is not affected, so the lift mechanism can be operated at its normal speed.

1-14. DIFFERENTIAL AND DRIVE AXLE. Coupled to and driven by the transmission planet shaft (output), is the conventional automotive type differential. A common lubricant is used for the transmission, differential, and axles.

1-15. STEER WIZELS. Independent hydraulic suspension of the steer wheels eliminates the conventional pivoted rear axle. The load remains level on uneven surfaces. Coupled hydraulic cylinders give perfect cross-compensation. No strain due to surface variations is transmitted to the frame or power train, since this strain is absorbed in the cylinders.

1-16. HYDRAULIC SYSTEM. The hydraulic reservoir is an integral part of the main frame, on the right hand side. A gear type pump draws fluid from the tank, to a control valve, and to the hydraulic steering valve. Fluid under pressure is available at each of these components when the engine is running. Return lines complete the circuit when the hydraulic components are not in use. The system is controlled by hand levers located conveniently to the right of the operator.

1-17. HYDRAULIC STEERING SYSTEM. Steering of the truck is accomplished by an 17-inch diameter steering wheel, mounted on an automotive-type steering column. A hydraulic steering booster is incorporated into the steering column. (Optional on MA 30.) As the steering wheel is turned, hydraulic pressure assists in turning the rear wheels. The system can be steered manually in case of hydraulic pressure failure.




Fig. 1-2. Power train

- | | |
|-----------------|---------------------|
| 1. Differential | 3. Torque converter |
| 2. Transmission | 4. Engine |

1-18. **ELECTRICAL SYSTEM.** The electrical system consists of a 12-volt battery, starter, generator, distributor, coil, and voltage regulator. The battery is the basic source of electrical current; the generator maintains the battery in a charged condition; the voltage regulator governs the amount of voltage output into the electrical system. Head and tail lights are available as optional equipment.

1-19. **LIFT AND TILT ASSEMBLY.** The lift and tilt assembly consists of an upright, forks, a lift cylinder, and two tilt cylinders. The assembly is controlled by hand levers located to the right of the operator's seat. The truck is capable of lifting its rated load from ground level up to a specified height, depending on the mast assembly on the truck. The upright can be tilted from 6° forward of vertical to 16° to the rear of vertical. A restrictor valve in the system provides that the load will not drop at a rate of more than 50 feet per minute in case of hydraulic failure or damage to the lines.

1-20. **SERVICE AND PARKING BRAKES.** The service brakes are the floating shoe hydraulic type. Actuation permits the shoes to center themselves in the drum with equal effectiveness in either direction. The same brake shoes are utilized in a cable-operated parking brake.

1-21. FUEL SYSTEM.

a. **Gasoline.** An eight and one half gallon fuel tank is an integral part of the frame on the left hand side. It contains a "protected" safety filler cap. The fuel

suction line originates near the bottom of the tank, and emerges at the top of the tank, thereby preventing the loss of fuel should a fuel line be broken. A plug is provided at the tank bottom for fuel drainage and clearing. A fuel shut-off valve is installed in the line leading from the tank to the fuel pump.

b. **LP Gas.** The LP-Gas system consists of a replaceable fuel tank (33-1/2 In. capacity), a filter, an automatic fuel shut-off valve, a vaporizer, a pressure regulator, and the carburetor. The fuel is confined in the tank as a liquid under pressure. When the valve on the fuel tank is opened, and the ignition switch is turned on to open the solenoid shut-off valve, the liquid flows to the vaporizer where it is turned into a gas. The gas is then metered through the regulator, where the pressure is reduced, to the carburetor.

1-22. **COOLING SYSTEM.** Cooling of the engine is accomplished by a six-bladed pusher type fan, and a water circulating pressure system radiator. The lower portion of the radiator is designed with coils to cool the torque converter fluid.

1-23. **EXHAUST SYSTEM.** Engine exhaust vapors are vented over the exhaust manifold on the upper left side of the engine, down through a muffler and out of a tail pipe at the rear of the truck.

1-24. **SERVICING ACCESSIBILITY.** See figure 1-4. Raising the hood and propping it open provides easy access for servicing the air cleaner, distributor, generator, starter, battery, spark plugs, fan belt, voltage

regulator, engine oil supply and dipstick. The radiator, fuel tank, and hydraulic reservoir can be serviced without raising the hood. The transmission oil supply tube and dipstick, and the brake master cylinder are located under the "flip-up" floor plate. (Figure 1-5.)

1-25. WHEELS AND TIRES. The brake drums for the drive wheels are included in the wheel centers.

1-26. SEAT. The seat is adjustable forward and back. The seat release handle is located on the right side of the seat.




Fig. 1-3. Hydraulic flow diagram




Fig. 1-4. Servicing accessibility




Fig. 1-5. Floor plate raised

1. Air cleaner
2. Breather cap
3. Crankcase dipstick

1. Master cylinder
2. Transmission dip stick
3. Flip-up floor plate

Chapter 2
OPERATING INSTRUCTIONS
Section 1. Initial Preparation for Use

2-1. SERVICE UPON DELIVERY.

2-2. UNLOADING. Since the lift truck may be shipped from the factory in a number of ways, no attempt will be made to cover all methods of unloading procedures. The trucks were shipped from the factory in accordance with standard shipping procedures, and should be unloaded from their carriers in a safe, logical manner.

2-3. REMOVAL OF PROTECTIVE MATERIALS AND DISASSEMBLED COMPONENTS. Remove any protective tape, paper, or other packing. Remove any components that have been packaged separately and attached to the truck. Install these components according to the instructions in this manual.

2-4. VISUAL INSPECTION FOR SHIPPING DAMAGE. Although every attempt has been made at the factory to protect the equipment against damage during shipment it is possible for some damage to be incurred. It is necessary, therefore, that a careful visual inspection be made of the lift truck upon delivery and before placing it in operation. It is further recommended that a written record be maintained, which outlines the nature of the damage, and the urgency required in its correction.

2-5. SERVICE PRIOR TO USE. The following procedures are to be accomplished before operating the lift truck:

2-6. BATTERY.

a. If the battery is shipped without electrolyte, raise the hood, and remove the battery from the truck. Discard any vent plug seals. Fill all cells to the proper level with electrolyte. Allow the battery to stand for at least 20 minutes after filling.

WARNING

Electrolyte can burn or damage the eyes, skin, or clothing. Wear safety glasses to prevent damage to the eyes due to splashed electrolyte. If it is spilled on the skin or clothing, flush off immediately with a solution of baking soda and water, or some other neutralizing agent, then flush off with clean water.

b. Code date the battery according to the month and year. Stamp the code on the intercell connector nearest the negative terminal on the battery. The first number of the code indicates the month (1=January, 2=February, etc.), and the second number indicates the year (5-1966, 6-1966, etc.).

c. Give the battery a booster charge after it has been filled and dated. Fast charge for at least 10 minutes at the rate of 90 or 40 amps, or slow charge for at least 30 minutes at 10 amps.

d. If any electrolyte spilled on the battery flush it off with clean water. Dry the battery before installing.

e. The battery has a negative ground. Install it with the negative terminal toward the rear of the truck. Install the clamp and cables.

2-7. ELECTRICAL SYSTEM. Inspect wiring and connections. Actuate light switch and inspect the lights for proper response. Place ignition switch "on" and test for electrical current to their component. With switch on, test horn.

2-8. FUEL SYSTEM.

a. Gasoline. Open the fill cover of the fuel tank located on the left side of the lift truck. Fill as necessary with a good grade of regular gasoline. Close the tank cover, and padlock if desired. Wipe the tank free of dirt or fuel hose leakage, and inspect fuel line and engine-mounted accessories for signs of fuel leakage. Open shut-off valve in tank-to-pump fuel line.

b. LP Gas. Open the valve (2, figure 1-8) on the fuel tank slowly. An excess-flow valve, built into the fuel supply valve, will close, stopping the flow of fuel, if the valve is opened too fast. If the excess-flow valve closes, close the fuel supply valve and wait until a "click" is heard. This will indicate that the pressure has equalized on both sides of the excess-flow valve and the excess-flow valve has reopened.

c. To open the solenoid-type shut-off valve, turn the ignition switch to the "on" position. Check all fuel line connections for evidence of leaks. A leak will result in the formation of frost at the point of leakage.

2-9. HYDRAULIC SYSTEM. Remove the breather cap from the hydraulic tank located on the right side of the lift truck. Fill as necessary in accordance with the instructions given in figure 1-9. The capacity of the system is approximately 17 quarts (the capacity will vary, depending on the size of the lift cylinder). With the mast fully raised and in a vertical position, the oil should be up to the FULL mark on the dipstick.

2-10. LUBRICATION. The lift trucks are completely serviced prior to delivery with lubricants specified for ambient factory temperatures, and should require no further lubrication at point of delivery unless temperatures differ greatly from those at the factory. If such is the case, lubricate the truck in accordance with instructions in figure 1-9.

2-11. LIFT TRUCK BODY. Inspect all sheet metal and fabricated parts for distortion or damage. Tighten all screws and nuts, particularly those of the steering wheel column, instrument panel, and brake and accelerator pedals.

2-12. COOLING SYSTEM. Remove the radiator cap and inspect the coolant level. If weather is above freezing, add clean water until it covers the radiator core. For operation in sub-freezing temperatures, use a good grade of permanent anti-freeze. Inspect for coolant leakage at all connections.

Section II. Operating Instructions

2-13. STARTING THE LEFT TRUCK.

a. Position the forward-reverse shifting lever in neutral. A neutral starting switch prevents the engine from starting unless this lever is in neutral.

b. Turn the key for the combination ignition-starter switch (7, figure 1-7) all the way to the right to engage the starting motor. Release the key as soon as the engine starts. Do not engage the starting motor for more than 5 to 10 seconds at a time. If the engine fails to start on the first try, allow the engine and starting motor to come to a complete stop before making a second attempt. This will prevent damage to the starting motor housing, drive, and flywheel ring gear.

c. It may be necessary to use the choke (6, figure 1-6) to enrich the gas-air mixture when starting, especially during cold weather. Allow the engine to warm up gradually to its normal operating temperature (approx. 180° F.). Do not race the engine during the warm-up period.




Fig. 1-6. Controls

- | | |
|----------------------------|-----------------------|
| 1. Inching - Braking pedal | 4. Lift control lever |
| 2. Accelerator pedal | 5. Lift control lever |
| 3. Parking brake | 6. Choke button |

CAUTION

If, after starting the engine, there is very little or no oil pressure indicated on the oil pressure gauge, or if there is a sudden drop in oil pressure while operating the truck, stop the engine immediately and determine the cause. Correction usually consists of replenishing the crankcase oil supply. Located on the instrument panel is a red warning light (5, figure 1-7). This light will glow only when the temperature of the transmission lubricant is excessive. This indicates a plugged filter or screen, a restriction in the lines, or that the transmission oil supply is dangerously low and must be replenished before further lift truck operations.




Fig. 1-7. Instrument panel

- | | |
|-------------------------------------|-----------------------------|
| 1. Temperature gage | 6. Hourmeter |
| 2. Ammeter | 7. Ignition-starter switch |
| 3. Oil pressure gage | 8. Transmission shift lever |
| 4. Fuel gage - gasoline | |
| 5. Warning light trans. temperature | |

d. Release the parking brake and shift the forward-reverse lever to the position desired. Apply foot pressure to the accelerator pedal and steer the truck in the direction selected.

e. Refer to the Trouble Shooting Chart in Section III to correct any malfunction of the lift truck or its components under operating conditions.

2-14. LOADING PROCEDURE

a. Drive the truck squarely into position as near the center of weight of the load as possible.

b. Position the forks slightly below the level of the load and drive forward until the forks are completely under the load. If the depth of the load permits, drive forward until the load is against the back rest.

- c. Place the shift lever in neutral, apply the service brakes, accelerate the engine slightly, and pull back on the lift lever (4, figure 1-6) to raise the load.
- d. If the nature of the load permits, pull back on the tilt control lever (5, figure 1-3) to tilt the load to the rear to prevent it from slipping off the forks.
- e. For maximum safety and stability carry the load just high enough to clear obstacles or uneven terrain.

2-15. DRIVING

- a. Avoid sudden starting or stopping. Come to a complete stop, with engine at idle speed, before shifting direction.
- b. Reduce speed when making a turn.
- c. When carrying a load, the view straight ahead is obstructed to a certain degree so be alert for personnel or obstacles in the path of the truck.
- d. Watch the top of the load or mast assembly (whichever is higher) to avoid contact with overhead wires, rafters, lights, sprinklers, etc.

2-16. UNLOADING PROCEDURE

- a. Drive the truck into position for unloading, shift into neutral, and apply the service brakes.
- b. Move tilt control lever so mast is vertical.
- c. Push lift control lever forward until load is lowered to ground or at desired stacking height.
- d. Release brakes, shift into forward, and slowly move truck until load is in desired position.
- e. Shift into neutral and apply service brakes. Lower load until forks are clear of load. Release brakes and back away until forks are clear of load.
- f. Lower forks to normal position.

2-17. INCHING INSTRUCTIONS. The locking valve is controlled by the left hand pedal (1, figure 1-6) on the combination inching-brake pedal assembly. Depress the pedal slightly with the left foot; use just the portion of pedal travel before any braking action takes place. Depress the accelerator pedal with the right foot. Extremely slow ground speeds can be attained for operating in confined or dangerous areas, while the speed of the lift remains normal.

2-18. STOPPING THE TRUCK.

- a. Drive the truck to an area suitable for parking. Apply the brakes slowly and bring the truck to a gradual stop.

- b. Shift into neutral and apply the parking brake.
- c. Tilt the mast slightly forward, and lower the forks to the floor.

WARNING

Unless conditions prevent, always unload forks and lower them to surface, to avoid potential danger to personnel.

- d. Turn ignition switch to "OFF" position.

2-19. CHANGING LP-GAS TANKS. To change LP-gas tanks, close the fuel supply valve, disconnect the quick coupler, and release the clamps. Lift the tank out of the bracket. Install the new tank, being sure to place the aligning hole in the tank flange over the pin. Secure the tank with the clamps and connect the quick coupler.

IMPORTANT: LP-GAS TANKS MUST BE FILLED IN ACCORDANCE WITH ICC AND LOCAL REGULATIONS.




Fig. 1-6. LP-Gas tank

- 1. Gauge
- 2. Fuel valve
- 3. Quick coupler
- 4. Relief valve-filter

2-20. SAFETY PRECAUTIONS. The following safety precautions must always be observed:

- a. Driver must be thoroughly familiar with the lift truck, its capabilities and limitations, before attempting its operation. Never attempt operation of a lift truck known to be faulty.
- b. Provide adequate ventilation in operational area; avoid prolonged operation in enclosed areas.
- c. Constantly check for personnel and obstacles in path of truck and load, keep forks in view whenever possible.

- d. Transport load at lowest practical level, for maximum stability and visibility. Avoid sudden stops and starts, sharp turns, and excessive speed.
- e. Keep top of mast and load in view to avoid overhead wires, lights, cables, and other obstructions.
- f. Do not leave lift truck unattended with engine running or load elevated. Lower forks to surface, apply brakes, and turn off engine before leaving truck.
- g. Strap or otherwise secure load to carriage when descending grades steeper than 10 degrees from horizontal in a forward direction. Do not attempt operation of loaded lift truck on ascents or descents greater than the gradeability of the lift truck. See Specifications.
- h. Do not attempt to lift or transport loads that exceed the rated capacity of the truck.
- i. Always secure forks to notches in carriage with lock levers.

Section III. Principles of Operation

2-21. OIL PRESSURE GAGE. The oil pressure gage (2, figure 1-7) does not indicate the amount of oil in the crankcase; it indicates the pressure of the oil in the engine lubricating system. The gage electrically senses the oil pressure and reflects it on the gage dial. With the engine at normal operating temperature and speed, the oil pressure should be between 20 and 30 pounds.

2-22. ENGINE TEMPERATURE GAGE. This gage (1, figure 1-7) indicates the temperature of the cooling fluid. Engine operation under normal conditions should register approximately 180 degrees on the gage. Temperatures excessively higher or lower than 180 degrees indicates a dirty or restricted radiator, or loss of coolant. Do not operate the lift truck until these conditions are corrected.

2-23. IGNITION-STARTER SWITCH. The combination ignition-starter switch (3, figure 1-7) opens and closes the ignition circuit, and energizes the starting motor. Turning the ignition switch "on" also opens the solenoid valve in the LP-Gas system. The starting motor is put into operation by turning the ignition key all the way to the right. A neutral starting switch prevents electrical energy from reaching the starting motor unless the transmission shift lever is in neutral.

2-24. AMMETER. The ammeter (4, figure 1-7) indicates the activity of the electrical system. If the needle indicates a continuous discharge when the engine is operating above an idle speed, the trouble would probably be a loose or broken fan belt, a short in some wire or component of the electrical system, or a faulty generator or regulator. The gage needle should move slightly to the positive side of the "0" mark on the ammeter when the engine is running at full governed speed and the battery is fully charged.

2-25. HOURMETER. The hourmeter (6, figure 1-7) records the actual hours of engine operation. Its main

purpose is to be the determining factor as to when the lift truck components require lubrication or overhaul.

2-26. WARNING LIGHT. The red warning light (5, figure 1-7) senses the transmission oil temperature and glows only when the temperature is in excess of proper operating limits. This condition is usually remedied by bringing the transmission oil level to full.

2-27. FUEL GAGE.

a. GASOLINE. The fuel gage (3, figure 1-7) electrically senses and indicates the amount of fuel in the lift truck fuel tank.

b. LP-GAS. The gage (3, figure 1-8) indicates the amount of LP-gas in the tank.

2-28. CHOKE CONTROL. The choke control button (6, figure 1-8) is cable connected to the choke disc in the carburetor assembly. Pulling forward on the choke button closes the choke disc, thereby enriching the air and gas mixture and providing quicker starting of a cold engine. Push the choke button in as the engine warms up to operating temperature; if all carburetor settings are correct, the resulting fuel mixture will be correct for proper engine operation.

2-29. LIGHTING SYSTEM (OPTIONAL). Pulling outwardly on the light button closes the circuit to the lights, thereby energizing them from the current supplied by the battery. Returning button inwardly toward the panel opens the circuit, and renders the lights inoperative.

2-30. POWER TRAIN (ENGINE AND TRANSMISSION). With the ignition switch in the "ON" position, operation of the various components is achieved in the following sequence: Turning the ignition key all the way to the right energizes the starting motor which is pinion meshed with the engine flywheel ring gear teeth. As the ring gear is rotated by the starting motor, the crankshaft is forced to rotate. It is at this point that fuel vapors enter the piston chambers and are ignited by the electrical impulse delivered by the spark plugs. The synchronized firing order of the spark plugs produces a continuous source of driving energy for the crankshaft. The transmission is inter-connected to the engine by a torque converter and plate arrangement, and a multiple disc clutch in the transmission allows the operator a selection of either forward or reverse direction, and also a neutral position when no travel is desired. The transmission is in turn geared to the differential of the drive axle by means of a bevel pinion and ring gear.

2-31. HYDRAULIC SYSTEM. The hydraulic pump provides a constant flow of hydraulic fluid under pressure when the engine is running. The control levers direct the flow to the lift or tilt cylinders or to the hydraulically actuated attachments. Fluid is also supplied directly from the pump to the hydraulic steering unit. Return passages in the system provide a complete circuit for the fluid when the cylinders are not being utilized. Figure 1-3 shows the hydraulic oil circuit.

CHAPTER 3
FIELD MAINTENANCE

Section I. Lubrication

3-1. LUBRICATION INFORMATION.

- a. The lubrication chart (figure 1-9) illustrates lubrication points on the lift truck and prescribes approved lubricants, recommended intervals, and application procedures.
- b. In order that the lubricants can accomplish the protection for which they are intended, they must be kept free from dirt, dirt, water, or other contaminants.
- c. Wipe each lubrication fitting clean with a cloth before applying lubricant.
- d. Apply only the grade of lubricant specified for operation under the temperature ranges indicated.
- e. It is recommended automotive practice to operate the truck immediately after a complete lubrication change, in order to distribute the lubricant most effectively.
- f. Special or detailed instructions for servicing the lift truck components are outlined under "LUBRICATION NOTES".

Section II. Preventive Maintenance Services

3-2. PERIODIC IN-SERVICE MAINTENANCE.

3-3. GENERAL. The instructions contained in this section are intended to aid the operator in maintaining the lift truck in an efficient, trouble-free condition. It is the purpose of this section to acquaint the operator with the possibilities of equipment malfunction, the indications of malfunction, and the corrective measures to be taken. Thorough understanding of the instructions by the operator is required to prevent minor malfunctions from going unnoticed until a part or a system is damaged beyond repair, resulting in removing the lift truck from service for extended periods.

3-4. SPECIAL MAINTENANCE TOOLS. No special tools are required by operating personnel to maintain the lift truck in serviceable condition. Standard tools, commonly used by automotive mechanics, should be made available to the operator.

3-5. MAINTENANCE CHARTS. In addition to, and summarizing the procedures of this section, a Trouble Shooting Chart is presented to provide the operator with a ready reference as to typical troubles, the probable cause, and remedy procedures required.

3-6. ELECTRICAL SYSTEM. Disconnect battery ground cable before working on electrical components.

3-7. BATTERY. Battery "life" depends greatly upon proper care and thorough periodic inspections. The most important service in maintaining the battery, is to

inspect the electrolyte (liquid) level daily. Add distilled water until the tops of the plates are covered approximately 1/8 inch. If distilled water is not available, use clean rain water or regular drinking water that is low in mineral content. Since the water and the electrolyte in the battery will not mix until charged by the generator current, make a practice of operating the engine for a minimum of one hour after filling if the danger of freezing exists.

WARNING

If the battery electrolyte is accidentally spilled or comes in contact with skin or clothing, immediately apply baking soda or a similar neutralizing agent.

3-8. Use an accurate hydrometer to check the electrolyte specific gravity. When fully charged, the reading should be 1.240 to 1.260 at a liquid temperature of 50° F. Wide variations from this reading between the cells indicates a faulty battery, and requires replacement with a new battery.

WARNING

Since the batteries release highly flammable hydrogen gas when being charged, keep all forms of sparks or flame away from lift truck.

3-9. Wash batteries clean with solution 1/2 pound baking soda mixed with 1 quart of water, apply with a brush, and flush with clear water. Prevent solution from entering vent holes; make sure holes are open after cleaning. Apply a light film of petroleum jelly to the battery terminals and cable clamps to retard corrosion.

3-10. GENERATOR. In addition to maintaining the generator in a clean condition at all times, a more thorough inspection of the brushes and commutator should be accomplished every 500 hours of operation.

- a. To properly examine the generator components, remove the generator from the engine. Tag the wires from the field and armature terminals.
- b. A visual inspection of the brushes can be made through the openings in the commutator end frame. Do not pull the brushes against the spring tension by the leads or snap the brush arms against the brushes.
- c. To replace worn brushes, remove the commutator end cover. Replace the brush springs if they do not have sufficient tension to hold the brushes tight against the commutator. Keep the brush holders clean to prevent the brushes from sticking.
- d. Clean a dirty commutator, using a strip of No. 00 sandpaper, or a brush seating stone. Do not use emery cloth to clean the commutator. Remove dirt from between the commutator riser bars, being careful not to scratch the bars or mica. Blow out all dust and grit with compressed air.

LUBRICATION CHART




Fig. 1-9. Lubrication Chart (Part 1 of 2)

Brackets () after a lubrication point indicates the number of similar points to be lubricated.

*See "LUBRICATION NOTES" on following page.

LUBRICATION NOTES

ENGINE OIL: Check the oil level every 8 hours of operation. Drain and refill the crankcase every 50 operating hours and change the filter every 150 operating hours under normal service. The crankcase capacity is 4 quarts; the filter holds an additional quart. Clean the crankcase breather every 100 hours.

Engine Oil Viscosity (Use high grade MS oil).
32° F. and below - SAE 10W
32° F. to 60° F. - SAE 20W
60° F. and above - SAE 30

AIR CLEANER (OIL BATH): Service air cleaner every 50 operating hours or oftener as required. Remove and empty oil cup; scrape out sediment, and wash thoroughly. Refill cup to mark with same oil as in engine.

AIR CLEANER (DRY STRAINER): Remove element and shake out accumulated dirt every 50 hours of operation. Renew element every 500 hours or oftener under extreme dirt conditions. **DO NOT WASH AND REUSE ELEMENT.**

AIR CLEANER (DRY CYCLOPAC): Empty dust cup daily. Clean element by passing stream of air from inside to outside. **DO NOT USE AIR PRESSURE EXCEEDING 100 PSI AT NOZZLE.** Cleaning solutions are available for cleaning element. Follow manufacturer's instructions when using. Replace element after 10 washings, or annually, or if ruptured.

STEERING GEAR (MANUAL): Check oil level every 50 operating hours. Keep reservoir filled with SAE 90 gear lube. Use a high grade straight mineral oil.

MASTER CYLINDER: Check fluid level every 20 operating hours. Keep reservoir filled to within 1/4" from top. Keep vent hole in filler cap open at all times. Use Mopar SPECIAL high temperature fluid (SAE T093).

GENERATOR: Every 400 operating hours, add 8 to 10 drops SAE 10W engine oil to the reservoir oil cups.

DISTRIBUTOR: Every 400 hours place 3 or 4 drops SAE 10W oil in cup. Apply a trace of high quality ball bearing lubricant to breaker cam every 400 hours.

CRANKCASE VENT. VALVE: Remove and clean crankcase ventilator valve every 150 hours; replace every 400 hours. Reinstall with arrow pointing up.

HYDRAULIC OIL TANK: Check oil level every 50 hours. With the mast fully extended and not tilted, and the oil at operating temperature, the oil should be between the "F" and "L" marks on the dipstick. Drain and clean the tank and screen every 2000 operating hours. Use ATF

Type A, Suffix A, Texaco 1808 or Mobilfluid 200 oil. Clean the breather every 400 hours.

RADIATOR: Check daily. Refill as required. Add permanent type anti-freeze when air temperature is 32° F. or lower.

TRANSMISSION, DIFFERENTIAL, AND CONVERTER: Check oil level every 50 hours of operation. Check with engine idling, clutch disengaged, and oil at normal operating temperature. Maintain oil level between "F" and "L" marks on dipstick. Change oil and filter and clean screen in transmission every 400 operating hours. (Change filter and clean screen after first 10 hours.) Use ATF Type A, Suffix A Texaco 1808 or Mobilfluid 200 oil.

DRIVE AXLE BREATHER: Remove and clean breather every 400 hours; replace every 1000 hours.

LIFT CHAINS: Do not lubricate chains when operating under extremely dusty conditions.

MAST SHOES: Lubricate full length of rail where shoes rub. Replace shoes at approximately 1500 hours.

LATCH HOOKS: Disassemble and clean thoroughly every 300 operating hours.

HYDRALIZERS: Recharge hydralizers when distance from rear of frame to floor (when measured directly in front of steer wheels) varies from 4-1/4", plus 1/16", minus 1/4". Place lift truck on level floor with no load and recharge hydralizers as follows:

Jack up rear of lift truck, remove rear side panels, and remove the filler plugs from both hydralizers. Lower the lift truck to raise both wheels to their extreme height.

Pick a measuring point, preferably on the hydralizer piston. Raise the truck to lower the wheels 1-5/8 to 1-3/4 inches and hold in this position.

Fill both cylinders completely full with Mobil Delvac 5-220 DS oil and replace the filler plugs. Lower truck and loosen plugs to bleed all air out of cylinders. Tighten plugs when rear of frame is 4-1/4 ± 1/16" off the floor. (Measure frame height from floor directly in front of steer wheels.)

Approximately 1/3 quart of oil will be vented from the system. This will assure that there will be no air remaining in the system.

Fig. 1-8. Lubrication Chart (Part 2 of 2)

8-11. **GENERATOR AND FAN BELT.** Frequently inspect belt for proper tension; a loose or slipping belt will cause engine overheating and reduce generator charging rate and rpm of driven pulley. Check belt tension by pressing on belt midway between fan and crankshaft pulleys with a force of approximately 10 pounds. Proper belt deflection should be 5/8 inch. Adjust belt tension by loosening

generator mounting bolts and adjusting bar cap screw, pull outwardly on generator until correct tension is applied, then tighten nuts and cap screw. **DO NOT USE A DRY BAR TO PLACE TENSION ON BELT.**

9-12. **STARTING MOTOR.** Service starting motor, brushes, and commutator in similar manner as generator.

- If the starting motor drive pinion fails to engage the engine flywheel ring gear, it indicates a sticking or broken drive assembly.
- Disconnect the negative cable from the battery and remove and tag all wires from the starting motor solenoid. Remove the bolts that secure the starting motor to the engine and withdraw the motor.
- Clean the drive pinion and shaft with kerosene. Check the starter drive assembly for damage. If the drive assembly is faulty, tag the motor for repair, and install a new starting motor.
- Clean the solenoid terminals and make proper connections of the wires. Reconnect the ground cable to the battery.




Fig. 1-10. Fan belt

3-13. DISTRIBUTOR. Every 250 hours of operation, clean the distributor cap inside and out, without removing the spark plug or coil wires. Inspect the cap for cracks or chips. Clean the rotor contact point. Examine the contact points and replace if burned or pitted. Adjust the point gap to .020 inch.

3-14. VALVE TAPPET CLEARANCE. Remove the valve chamber cover and check, and adjust if necessary, the tappets every 500 hours of operation. Adjust the tappets for both the intake and exhaust valves to .014 inch clearance. Operate the engine at idle speed and at normal operating temperature when adjusting the tappets.



Fig. 1-11. Adjusting tappets

3-15. SPARK PLUGS. Every 250 hours of operation, remove and clean the spark plugs. Clean the area around the plug ports before removing the plugs. Reset the spark plug gap to .035 inch. Use the same gap setting for both gasoline and LP gas engines. Tighten the plugs to 35 foot pounds torque when they are reinstalled.

3-16. CARBURETOR (GASOLINE). Inspect all linkages for rough edges, paint, or blading. Check all line connections for leaks. If the engine fails to start, or does not operate properly, make the following carburetor adjustments.

- Screw in the idle adjusting needle (2, figure 1-12) until it just starts to seat. DO NOT USE FORCE. Then, open the needle two full turns.
- Make certain the throttle stop screw (1, figure 1-12) is holding the throttle disc slightly open.
- Start the engine and allow it to warm up at an idle speed of approximately 500 RPM. When the engine reaches normal operating temperature (approximately 180°), release the accelerator pedal and allow the engine to idle.
- Adjust the throttle stop screw to obtain an engine idle speed of approximately 500 RPM.
- Back out the idle adjusting needle until the engine speed drops from an over-lean gas mixture. Then, turn the screw in JUST FAR ENOUGH until the engine runs smoothly and steadily.




Fig. 1-12. Gasoline carburetor

- Throttle stop screw
- Idle adjusting needle

3-17. LP GAS CARBURETOR.

- Adjust throttle stop screw (1, figure 1-13) so it just touches stop pin, then, turn in screw one additional turn to assure that throttle disc will be held slightly open. Accelerator pedal and linkage must be at absolute idle position when adjusting throttle stop screw.

b. Turn in idle adjusting screw (2, figure 1-13) until it just seats. Then back out screw three complete turns.

c. Turn in main load screw (3, figure 1-13) until it just seats. Then back out screw three complete turns.

d. Start the engine and run it until it reaches normal operating temperature. Check choke position to see that it is completely open.

e. Adjust the throttle stop screw to obtain an engine idle speed of 500 RPM.

f. Set the idle adjusting screw to obtain a smooth idle. If a vacuum gage is used, set idle adjusting screw to obtain peak intake manifold vacuum.

g. The main load screw should be adjusted with the engine under load. A simulated load can be placed on the engine by shorting out all spark plugs except the plug for No. 1 cylinder. Operate the engine at full throttle and turn in the main load screw a fraction of a turn at a time until the carburetor throttle is most nearly closed by the governor. For utmost economy, run in the main load screw an additional 1/4 turn, and secure with the lock nut.




Fig. 1-13. LP Gas Carburetor

1. Throttle stop screw
2. Idle adjusting screw
3. Main load screw

h. See paragraphs 4-187 and 4-198 for instructions on adjusting vaporizer and regulator.

NOTE: FIG. 1-13 SHOWS THE AIR CLEANER REMOVED FOR ILLUSTRATIVE PURPOSES. KEEP THE AIR CLEANER INSTALLED.

3-18. GOVERNOR. To adjust the governed engine speed, proceed as follows:

a. Start the engine and allow it to warm up to operating temperature. While the engine is warming up, back out the surge adjusting screw (3, figure 1-14) so it will have no effect.

b. Back out the speed adjustment locking screw (2, figure 1-14) so it will not interfere with the speed adjustment.

c. Turn speed adjusting screw (1, figure 1-14) to provide a no-load speed of 2600 RPM. Tighten locking screw (2, figure 1-14) against stop to maintain this position.

d. If the governor surges, turn in the surge adjusting screw (3, figure 1-14) one turn at a time until the surge is eliminated. Do not turn the screw in far enough to increase the engine speed more than a few RPM, if any.

e. Be sure all lock nuts are tight to maintain the governor settings.




Fig. 1-14. Governor

1. Speed adjusting screw
2. Locking screw - speed adjustment
3. Surge adjusting screw

3-19. ENGINE TIMING.

a. Turn the engine over until the "DC" mark on the flywheel is visible in the timing opening. Place a chalk or paint line on the "DC" mark so it will be more legible under the timing light.

b. Attach the battery leads of the timing light to their respective terminals on the battery. Clip the secondary lead of the timing light to the No. 1 spark plug. Leave the spark plug wire on the plug.

c. Start the engine and run at an idle speed of 500 RPM or less, so the automatic advance of the distributor is completely retarded. **THIS IS IMPORTANT TO OBTAIN CORRECT ENGINE TIMING!**

d. Direct the timing light at the timing opening and note the position of the timing mark in relation to the pointer as the light flashes. The timing mark should line up with the pointer.

e. To advance the timing, turn the distributor body clockwise. To retard timing, turn distributor body counterclockwise.

f. When timing is correct, tighten the distributor clamp securely. Then, readjust the timing with the light.




Fig. 2-15. Timing opening

1. Timing pointer

3-29. COOLING SYSTEM. The cooling system plays an important role in the life and efficiency of an internal combustion engine. Overheating not only causes the engine to knock and lose power, but also results in damage to bearings and other moving parts of the engine.

a. Overcooling, although less sudden in effect than overheating, may be equally dangerous to the engine. Low engine temperatures cause the formation of sludge which interferes with proper lubrication; it also creates harmful acids which attack engine parts.

WARNING

Be careful when removing radiator cap when engine is hot. Turn cap slowly to vent position and allow steam pressure to escape before removing.

b. A pressure-type cooling system raises the boiling point of the coolant and permits the engine to operate at higher temperatures without coolant loss. A pressure-type system will not function properly unless it is absolutely airtight; consequently, the system must be kept in good condition. Air in the system will also force coolant out of the overflow pipe, reduce the rate of heat transfer, and accelerate rusting within the system.

c. The cooling system has 2 drains -- the radiator drain, located at the lower side of the bottom tank; and a drain for the engine block (2, figure 1-18). Whenever the system is drained, it should be done at the end of a day's run when any foreign material is in suspension and will be removed with the coolant. To insure complete draining, open all drains and remove the radiator cap.



Fig. 1-18. Drain locations

1. Radiator drain
2. Block drain

d. The type of coolant used in the radiator (18, fig to 2-9) depends on climatic conditions. If there is no danger of freezing, use a solution of clean, soft water and rust inhibitor; however, if the truck will be exposed to freezing temperatures, use a permanent type anti-freeze.

e. Avoid the use of water having a high mineral content or containing other impurities. Water containing minerals or other foreign material will form deposits throughout the cooling system. These deposits, in addition to restricting the proper flow of coolant, act as an insulator to prevent the effective transfer of heat. Clean rain water and a rust inhibitor is a good coolant solution.

f. If the danger of freezing exists, fill the cooling system with a permanent type anti-freeze solution. Follow the recommendation of the anti-freeze manufacturer to obtain a solution that will give the desired protection for the lowest anticipated temperature. After filling the radiator, run the engine until it reaches normal operating temperature and the thermostat opens. This will establish circulation through the radiator and engine blocks to insure proper mixing of the anti-freeze and water. If the solution is not thoroughly mixed, slush ice may form. Slush ice will stop circulation, causing overheating and subsequent loss of coolant. Another reason for running the engine is to release any air trapped in the engine water jacket by the closed thermostat. When the thermostat opens, the trapped air is released and the water passages fill with coolant. Eliminating trapped air lowers the coolant level of the radiator, and more water must be added to fill it to the proper level.

g. As mentioned previously, rust inhibitors should always be used in a radiator to protect it against corrosion. Most high-quality anti-freeze solutions are compounded with a rust inhibitor or corrosion deterrent. Do not add a rust inhibitor to these solutions as the chemical reaction may damage the system. Maintain full strength corrosion pro-

tection in the coolant system at all times. Corrosion inhibitors tend to lose their effectiveness with use, and we recommend draining the system and renewing the inhibitor every 6 months. In a system that was clean originally, the appearance of rust in the radiator, or in the solution, is an indication that the inhibitor is weakened or exhausted completely. Whenever the cooling system shows signs of rust, the coolant should be drained, the system flushed, and the radiator refilled with fresh coolant containing an inhibitor.

b. After the anti-freeze solution is drained in the spring, it is recommended that the cooling system be flushed thoroughly, cleaned if necessary, and a suitable rust inhibitor added to a summer filling of fresh water. In areas where anti-freeze is not required, add rust inhibitor to a fresh filling of water both spring and fall.

NOTE

Flush the system thoroughly before and after the use of anti-freeze solutions.

1. Efficient operation of the cooling system requires an occasional cleaning -- particularly at seasonal changes when anti-freeze solution is added or drained. The proper method of cleaning depends on the condition of the system. The exterior of the radiator should also be cleaned regularly. Dirt, insects, or other foreign material will clog the radiator fins and reduce cooling efficiency. Clean the fins with forced air or water. Straighten any bent fins noticed during the cleaning operation, but be careful not to kink the tubes or break the bond between the fins and tubes.

j. To check the thermostat, first clean it, and then suspend it in a container of clean water along with a thermometer. Heat the water and check the opening and closing temperatures. If the valve fails to open at 20° or more above the rated opening temperature (180°) or fails to close at 10° to 15° below this temperature, the thermostat should be replaced.




Fig. 1-17. Testing thermostat

1. Thermometer
2. Thermostat

k. When replacing thermostat in water outlet elbow, be sure thermostat seat and adapter counterbore are clean.

l. Assemble thermostat and adapter in housing as shown in Fig. 1-18, and install on engine, using new gasket.




Fig. 1-18

1. Thermostat
2. Adapter

3-21. STORING THE LIFT TRUCK. If the lift truck is to be stored for an extended period of time, the following steps should be taken to prevent unnecessary deterioration and to insure top performance when the lift truck is returned to service.

a. Drain the crankcase, filter, and transmission. Install new filters, and refill the units with the specified grade of fresh oil.

b. Thoroughly lubricate the lift truck, and service the air cleaner and breathers according to the instructions given in this manual. Drive the lift truck for a short distance to distribute the fresh lubricants.

c. Drain and flush the cooling system. Leave the radiator and bluck drains open to prevent the collection of condensation.

d. Drain the gasoline tank, filter, and carburetor. Make certain the system is completely drained as any fuel remaining in the system will oxidize and form gummy deposits. Leave the shut-off valve and the carburetor drain open. Clean the fuel filter. If the truck has an LP-Gas system, close the fuel valve, remove the tank, and store it in a safety rack.

e. Remove the spark plugs and pour a liberal amount of engine oil into each cylinder. Turn the engine over several times to distribute a protective oil film on the pistons and cylinder walls.

f. Remove the battery and store it in a cool, dry place where it will not freeze. Keep the battery fully charged.

and maintain the proper electrolyte level. A run-down battery will deteriorate rapidly when stored. If the terminals and the top of the battery appear corroded, clean them with a stiff brush and a solution of baking soda and water. Make certain the vent holes in the filler caps are open.

g. Drain and flush the hydraulic system. Remove the strainer from the hydraulic tank and clean. Replace the screen and fill the tank to the specified level in accordance with the lubrication chart. Operate the hydraulic controls for several minutes to distribute the new fluid throughout the system. Contract the cylinders during storage.

h. Thoroughly clean the lift truck. Check for worn or damaged parts, and make any necessary repairs, replacements or adjustments. Touch up any areas where the paint has worn or rubbed off.

i. Store the lift truck in a dry building; however, if it cannot be stored inside, cover it with a tarpaulin.

3-22. TROUBLE SHOOTING. Trouble shooting can be applied to any part of the lift truck that is not functioning properly and follows the same pattern.

a. First, confirm the suspected condition before proceeding with any tests.

b. Next, determine and recognize the possible causes.

c. Finally isolate the cause (or causes) by performing a series of quick tests to eliminate the others.

d. A good rule to follow in locating trouble is to never make more than one adjustment at a time - then locate the trouble by a process of elimination.

e. Operators handling the same lift truck every day, soon develop a sense of impending trouble when abnormal operation occurs. Immediate attention to these danger signals can prevent major failures, insure dependable operation, and increase the life of the lift truck.

f. Some of the normal complaints encountered in routine operation, and their probable causes, are listed on the following pages.

TABLE 1

TROUBLE SHOOTING

A. STARTING MOTOR - WILL NOT CRANK ENGINE:

1. Weak or dead battery.
2. Poor ground connection.
3. Faulty starting switch or relay.
4. Defective starting motor.
5. Internal engine seizure - turn engine manually to determine cause.

B. ENGINE CRANKS - BUT DOES NOT START:

Disconnect one spark plug wire, turn ignition on with starter cranking engine and feel end of wire 1/8" from cylinder head - norm spark.

1. NO SPARK:
 - a. If ammeter shows no discharge it indicates an open primary circuit due to:
 1. Points not closing.
 2. Open primary wires.
 3. Defective ignition switch.
 4. Faulty coil.
 - b. Normal ammeter reading (2.5 amps) this indicates that primary circuit is OK, trouble may be in secondary circuit due to:
 1. Broken or grounded high tension wire from coil to distributor.
 2. Wet high tension wires.
 3. Faulty distributor cap or rotor.
 4. Broken secondary winding of coil.
 - c. Excessive ammeter reading (over 5 amps) indicates a "short" in the primary winding which may be due to:
 1. Shorted or grounded primary winding.
 2. Distributor or magnet points not opening.
 3. Grounded breaker point arm.
 4. Defective condenser.
2. WEAK SPARK - may be caused by:
 - a. Loose ignition wiring connections.
 - b. Burned or pitted distributor points.
 - c. Wet spark plug wires.
 - d. Defective condenser.
 - e. Cracked distributor cap.
 - f. Weak ignition coil.
3. GOOD SPARK AT EACH PLUG - indicates that ignition system is OK and trouble is in fuel system - which may be due to:
 - a. No gas in carburetor - which may be due to:
 1. No gas in tank.
 2. Clogged filter or lines.
 3. Faulty fuel pump.
 4. Leaky fuel line from tank.
 5. Plugged vent in fuel tank cap.
 - b. Gas in carburetor - which may be flooded due to:
 1. Too much choking - plugs are wet.
 2. Wrong float level.
 3. Choke not operating correctly.
 4. Water in gas.

C. ENGINE RUNS WITH CONTINUOUS MIS-FIRING: One lug

1. Uneven compression.
2. Wet or deteriorated high tension wires.
3. Cracked distributor cap.
4. Faulty spark plugs - if spark plug porcelain is white when removed, use colder plug - if light brown OK - if black or oily use hotter plug.

D. ENGINE RUNS UNEVENLY

1. At idling speed - which may be due to:
 - a. Too wide spark plug gaps.
 - b. Poor carburetor idle adjustment.
 - c. Wrong float level.
 - d. Carburetor or intake manifold air leaks.
 - e. Leaky cylinder head gasket.
2. At high speed - may be due to:
 - a. Wide breaker points.
 - b. Weak distributor breaker arm spring.
 - c. Weak valve springs.
 - d. Spark plug of wrong type or incorrect gap.

E. ENGINE RUNS IMPROPERLY

1. Back-firing into manifold - indicates too rich a fuel mixture: the carburetor indicates a too lean a mixture - may be due to:
 - a. Late ignition timing.
 - b. Clogged air cleaner.
 - c. Fuel line restrictions.
 - d. Clogged carburetor jets.
 - e. Sticking valves.
 - f. Weak or broken valve springs.
2. Excessive ping (detonation) results in damaged pistons and bearings and is caused by pre-ignition or using inferior grade of gas.
3. Engine idles too fast - indicates improper throttle adjustment or weak throttle return springs.
4. Engine dies when idling - which indicates incorrect speed or mixture adjustment; clogged idling circuit in carburetor or wrong choke adjustment, or air leaks in intake manifold.
5. Engine "stumbles" on acceleration - which may be due to defective accelerator pump or air in fuel lines.
6. Defective spark plugs.

F. LACK OF POWER - which may be due to:

1. Poor compression.
2. Wrong timing.
3. Throttle control not opening fully.
4. Air leak in fuel system.
5. Restriction in air cleaner - should have vacuum less than 10" water.
6. Exhaust line obstruction - should have back pressure of not more than 20" water.
7. Poor fuel.
8. Piston rings sticking or worn.

G. **POOR COMPRESSION** - check with compression gage - if irregular, seal the piston with a teaspoonful of engine oil poured through the spark plug hole, and take a second reading; if pressure does not increase this will indicate that poor seating of valves are at fault. Poor compression may be due to:

1. Valves holding open - no tappet clearance.
2. Leaky cylinder head gasket.
3. Broken or weak valve springs.
4. Burned or sticking valves.
5. Badly worn, broken or stuck piston rings.
6. Wrong valve timing.

H. **OVERHEATING**

1. Lack of water in radiator.
2. Fan belts slipping.
3. Thermostat sticking or inoperative.
4. Radiator clogged or leaky.
5. Late ignition timing.
6. Back pressure in exhaust line.
7. Defective water pump.
8. Overloading of engine.

I. **LOW OIL PRESSURE**

1. Low oil level.
2. Oil pressure gauge or line faulty.
3. Oil too light - diluted.
4. Strainer screen plugged.
5. Dirt in relief valve or broken spring.
6. Worn bearings.
7. Worn or damaged oil pump gears.
8. Worn cam bushings.

J. **HIGH OIL PRESSURE** - should not exceed recommended pressure except when engine is starting up cold. Abnormally high oil pressure is not desirable because it increases oil consumption - possible causes of high oil pressures are:

1. Engine oil too heavy.
2. Stuck relief valve.
3. Obstruction in distributing line.
4. Faulty oil pressure gauge.

K. **HIGH OIL CONSUMPTION**

1. Oil leaks.
2. Too high oil level.
3. Incorrect grade of oil used.
4. Clogged crankcase breather.
5. Oil pressure too high - stuck relief valve.
6. Piston rings run tight, due to too smooth cylinder bore finish or glazed condition.
7. Worn, broken or stuck piston rings and clogged oil control rings.
8. Worn piston and sleeves.
9. Worn bearings.
10. Worn valve guides.

(Manifold may be removed for visual inspection.)

L. **ENGINE KNOCKS AND OTHER NOISES**

1. Operating knocks - which may be due to:
 - a. Fire-ignition - most common cause is due to wrong type plugs which are too hot.
 - b. Carbon - noticeable when engine is accelerated while hot - clean head and pistons.
 - c. Timing - early timing causes knocks similar to carbon - but may tend to kick back when starting.
 - d. Fuel - detonation knock caused by poor gas.
 - e. Overloads - particularly at lower operating speeds.
2. Mechanical Knocks - result from wear, abuse or improper adjustments - which may be due to:
 - a. Crankshaft and main bearings:
 1. Worn or burned-out main bearings - a heavy, dull knock when accelerating under load. Locate by shutting out plugs on both sides of the bad bearings.
 2. Crankshaft end-play - excessive end-play is indicated by intermittent knocks which come and go when the load is released and engaged.
 - b. Connecting rod bearings:
 1. Worn or burned-out bearings - the worst condition, a light pood or metallic knock, is noted at idling and to about 2/3 maximum speed. Bad bearings can be determined by shutting out plugs.
 - c. Pistons and wrist-pins:
 1. Loose wrist pins - noise doubles when the correct plug is shutted out - most noticeable at idling speed.
 2. Piston loose in cylinder - "Piston-Slap" is noted by metallic knocking at low speed under load; but disappears at high speed - also most noticeable when starting cold - test by shutting out plugs.
 - d. Broken piston ring or pin - sharp clicking noise that won't shut out.
 - e. Valves:
 1. Burned valves and seats - engine rattles, especially at low speeds, or acceleration under load.
 2. Weak or broken valve springs - missing at low or high speeds when under load.
 3. Sticking valves - loss of power and popping sound when bad.
 4. Tappet noise - excessive clearances cause noise when cold - which diminishes at normal operating temperature.
 - f. Crankshaft - noise due to loose bearings or end play - usually occurs at half engine speed.
 - g. Timing gear noise - loose or worn gears rattle or knock - tight gears hum.
3. Vibration originating at engine - the most common source of vibration originating in or on the engine, as distinguished from causes created outside the engine are as follows:
 - a. Misfiring
 - b. Misalignment of engine

- c. Bent or off-center coupling.
- d. Engine loose on bed and type of mountings.
- e. Out of balance condition of flywheel and clutch assembly.

M. SLIPPAGE IN DRIVE SYSTEM

- 1. Faulty clutch.
- 2. Faulty pump.
- 3. Low oil level.
- 4. Defective torque converter.

N. LIFT TRUCK OPERATES IN ONE DIRECTION BUT NOT IN THE OTHER

- 1. Defective clutch.

O. DRIVE SYSTEM NOISY

- 1. Low oil level.
- 2. Worn or broken gear or shaft.

P. SYSTEM WILL NOT LIFT, LIFTS TOO SLOWLY, OR STICKS WHEN LOWERING

- 1. Leaks in system.
- 2. Defective control valve.
- 3. Defective hydraulic pump.
- 4. Defective lift cylinder.
- 5. Dirty plunger assembly.
- 6. Low hydraulic pressure.

Q. LOW HYDRAULIC PRESSURE

- 1. Defective pump.
- 2. Leaks in system.
- 3. Defective valve.

R. EXCESSIVE HYDRAULIC PRESSURE

- 1. Defective valve.

S. SYSTEM LIFTS, BUT WILL NOT LOWER LOAD

- 1. Defective valve.

T. EXCESSIVE NOISE OR HAMMERING

- 1. Defective pump.
- 2. Air in system.

U. SERVICE BRAKES NOT EFFECTIVE

- 1. Worn brake lining.
- 2. Insufficient brake fluid.
- 3. Broken or loose line.
- 4. Faulty brake cylinder.

V. SPONGY BRAKE ACTION

- 1. Air in system.

W. BRAKES GRAB

- 1. Dirt in brake drum.
- 2. Defective lining.
- 3. Scored brake drum.
- 4. Brake fluid on lining.

CHAPTER 4
OVERHAUL (SHOP MAINTENANCE)

Section I. General

4-1. GENERAL.

4-2. This chapter consists of instructions relating to the removal, disassembly, repair and reassembly of the components of the truck.

4-3. The overhaul procedures for the engine are contained in Section III.

4-4. No special tools are required to overhaul the equipment. Tools and testing devices required are those commonly employed at a shop having overhaul facilities. Assuring that only skilled automotive mechanics will perform the procedures described in this manual, obvious and elementary instructions have been purposely omitted.

4-5. An attempt has been made, whenever possible to treat the assemblies in their logical order of accessibility sequence. For complete disassembly, refer to the Table of Contents, locate the assembly desired, and note its page number. Repeat for each assembly.

4-6. Unless otherwise indicated, all bolts should be torqued to the following values:

5/16 inch	10-15 ft. lbs.
3/8 inch	20-25 ft. lbs.
7/16 inch	33-39 ft. lbs.
1/2 inch	53-68 ft. lbs.
9/16 inch	75-85 ft. lbs.
5/8 inch	105-115 ft. lbs.
3/4 inch	180-210 ft. lbs.

Section II. Removal, Disassembly, Repair and Reassembly

4-7. BATTERY, CLAMP, AND CABLES. (See figure 2-12 or 2-12A).

4-8. REMOVAL AND DISASSEMBLY.

- a. Raise hood and prop it open with overcenter hinge.
- b. Remove cables and hold down (2). Remove battery from box. Remove box (1).

4-9. REPAIR.

- a. Clean battery and other parts with stiff brush and baking soda and water solution. When foaming stops, flush battery with clean water. Use care not to get solution into vent holes.
- b. Inspect and test battery. Inspect cables and other parts. Replace battery if damaged, or if test indicates poor condition. Replace all damaged or corroded parts.

4-10. REASSEMBLY. Reassembly is accomplished in reverse order of disassembly.

4-11. FUEL PUMP, FUEL LINES, AND FILTER. (See figure 2-6).

4-12. REMOVAL.

- a. Close the shut-off valve at the tank. Disconnect the fuel lines and remove pump (1). Remove fuel filter assembly and tank unit from truck.

4-13. DISASSEMBLY. (See figure 2-6).

- a. Loosen bail nut (13) and remove bowl (10), gasket (15), and screen (12).
- b. Remove cover (5). Remove screw and retainer (16).

Remove valve and cage assemblies (14) and gaskets (13).

- c. Remove diaphragm (2) and spring (3).
- d. Remove washer (8), pin (7), rocker arm (6), and spring (3).

4-14. REPAIR.

- a. Clean all parts thoroughly and examine carefully. Look especially for worn linkage and worn valves and seats.
- b. If diaphragm (2) is stiff or brittle, it should be replaced, even if it is not punctured.
- c. To test pump, install gage between pump and carburetor. Pressure should be 1-1/2 to 3-1/4 PSI at 1800 RPM.

4-15. REASSEMBLY. (See figure 2-6).

- a. Reassemble in reverse order of disassembly. Use new gaskets.
- b. When fuel pump is attached to engine, care must be taken that rocker arm (6) is not installed under cam.

4-16. WATER PUMP.

4-17. REMOVAL. (See figure 2-9).

- a. Drain radiator and remove hoses from pump. Disconnect hose (16) from nipple (9) in pump (8).
- b. Remove fan (23) by removing four cap screws.
- c. Loosen generator enough so fan belt can be slacked off enough to slide over pulley on hub (12).
- d. Remove nuts and lock washers holding pump body to block and remove pump assembly.

4-18. **DISASSEMBLY.** (See figure 2-3). Disassembly must be in the following sequence in order to prevent damage to the pump.

- a. Remove hub (12) from shaft.
- b. Remove countersunk screws (1), holding cover (2), and remove cover and gasket (3).
- c. Use puller to remove impeller (4), taking precautions to prevent damage to the casing.
- d. Remove seal (5) and water shudder (6).
- e. Remove lock ring (11) holding bearing and shaft assembly in body, after which shaft (10) can be forced OUT THROUGH THE FRONT with an arbor press or lead hammer.

CAUTION: DO NOT ATTEMPT TO DRIVE THE SHAFT OUT THROUGH THE REAR OF THE HOUSING. TO DO SO WOULD DAMAGE THE HOUSING BEYOND REPAIR.

4-19. **REPAIR.**

- a. Replace all worn or failed parts.
- b. Seal contact surface must be smooth and flat. If bushing is slightly worn or grooved, it may be refaced and polished for further use. If it is excessively worn or grooved, it should be replaced.

4-20. **REASSEMBLY.** (See figure 2-9). Reassemble in reverse order of disassembly.

- a. A light film of lubricant applied to the face of the seal will facilitate seating and sealing.
- b. Use thick soapuds on both seal and shaft when assembling, in order to prevent damage to the seal.
- c. Use a new gasket when mounting the pump on the engine.
- d. Torque the mounting bolts to 25 to 30 foot-lbs.
- e. Install the belt and adjust tension to have 1/2 inch deflection on the long side. Do not use a bar to pull out the generator, this could cause damage to bearings.

4-21. **HORN BUTTON.** (See figure 2-21).

4-22. **REMOVAL.** (See figure 2-21). Removal and disassembly are accomplished at the same time as follows:

- a. Disconnect battery ground wire. Disconnect horn button wire at horn relay.
- b. Remove cover (36) and button (35). Remove cap (38), spring (40), and cap (41). Remove screws (39) and lift out plate (37).
- c. Remove brushes (42), spring (44), and sleeve (43).

4-23. **DISASSEMBLY.** Disassembly has been accomplished with completion of removal steps.

4-24. **REPAIR.**

- a. Clean and inspect parts. Check wire and insulating ground (25). Replace damaged or worn parts. Check compressor of spring (40). Spring must prevent contact unless button is pressed.

4-25. **REASSEMBLY.** (See figure 2-21). Reassemble in reverse order of disassembly.

4-26. **STEERING GEAR (HYDRAULIC).**

4-27. **REMOVAL.** (See figure 2-21).

- a. Turn steel wheels to straight-ahead position. Disconnect accelerator pedal linkage and remove the floor plate.
- b. Disconnect horn wire and hydraulic tubing from steering gear housing. Disconnect drag link from steering arm.
- c. Remove clamp (22, figure 2-25), and shift lever clamps. Remove bolts holding gear housing to frame and lift out entire assembly.

4-28. **DISASSEMBLY.**

- a. Drain out as much hydraulic oil as possible. Turn steering wheel back and forth several times to assist draining.
- b. Mark worm and coupling flange (20) so they can be reinstalled in the same position. Remove flange from stub shaft.
- c. Loosen adjuster plug lock nut (16). Remove adjuster plug assembly (14) with a spanner. Remove the retainer, spacer, thrust bearing, and the races.
- d. Remove valve assembly (10) by grasping the stub shaft and pulling the assembly out of the housing.

NOTE

The valve parts are selectively fitted and hydraulically balanced. None of the valve parts (10) are serviced individually except for the seal rings (30), which are included in a service kit (35P941) and the valve spool spring (11). Do not disassemble the valve. If replacement of any part (other than 30 and 11) is necessary, replace the entire valve assembly.

- e. Rotate end plug retainer ring at base end of housing until one end is over hole in housing. Insert punch through hole to spring ring enough to allow removal of end. Turn shaft to force plug (13) out of housing.
- f. Pull out plug (9) with channel-lock pliers. Remove assembly (7) from housing, being extremely careful that steel

balls do not fall out.

g. Remove snap ring and seals (30) and cover (17). Tap cross shaft out of housing.

4-29. REPAIR. (See figure 2-21).

- a. Discard all seals which show signs of leakage.
- b. Discard needle bearings, thrust bearings, shafts, gears, etc., which show excessive wear. Worm and rack (5) must be replaced as a matched assembly.
- c. Clean all parts in a solvent. Make sure all the parts are clean.
- d. Be sure that openings in guide (7) are not damaged, so balls can enter and leave freely.

4-30. REASSEMBLY. (See figure 2-21).

- a. Reassemble in reverse order of disassembly, lining up all marks, so parts are installed in same relative positions.
- b. Tighten adjuster plug up snug, then back off 1/8 turn and measure valve assembly drag. Adjust thrust bearing so that pre-load is 1 to 3 inch-pounds in excess of valve assembly drag. Tighten lock nut. Total thrust bearing adjustment and seal drag not to exceed 6 inch-pounds.
- c. Selective fit worm, rack, and balls to give a pre-load of 1-1/2 to 4-1/2 inch-pounds measured on center of worm. Pre-load is altered by using smaller or larger balls.
- d. With gear on center, adjust pitman shaft thrust screw so that pre-load is 4 to 8 inch-pounds in excess of total pre-load and drag. Readings are to be made through arc not exceeding 30 degrees, with gear arc center. Tighten lock nut. Total over-center load not to exceed 10 inch-pounds.

e. Torque bolts and screws as follows:

Adjuster plug lock nut.....	50-85 foot-pounds
Flange assembly pinch bolt.....	20-25 foot-pounds
Lash adjuster nut.....	35-38 foot-pounds
Side cover bolts (3/8-16).....	30-35 foot-pounds
Return guide clamp screws (1/4-28).....	9-12 foot-pounds

f. If air becomes trapped in the system due to the disassembly, this air must be bled out. Fill the hydraulic reservoir to the proper level. Start the engine and turn the steering wheel through its full travel two or three times, to allow the air to escape. Check the hydraulic oil level again and replenish as necessary.

NOTE

If air becomes trapped in the system, the pump may be noisy until the air clears up. This may take some time, since air trapped in oil does not bleed out rapidly.

g. To reset the steering after the mechanism has been completely disassembled, position the steer wheels in the straight-ahead position. Position the steering arm (31) at the center of its travel. Adjust the length of drag link to fit between steering arm and hole in steering housing (33, figure 2-19). Adjust tie rods and drag link to allow 83 degree angle of inside wheel to frame.

NOTE

Do not turn the wheels under hydraulic power to their limit until the steering stops have been installed.

h. Power steering relief pressure is to be 1100 PSI, plus or minus 50 PSI. See paragraph 4-125.

4-31. STEERING GEAR (MANUAL).

4-32. REMOVAL. (See figure 2-20.)

- a. Turn steer wheels to straight ahead position. Disconnect accelerator pedal linkage and remove floor plate.
- b. Disconnect horn wire. Detach drag link from steering arm.
- c. Remove shift lever clamps, steering column clamp (20, figure 2-25), and bolts which hold gear housing to frame. Lift assembly out of truck.

4-33. DISASSEMBLY. (See figure 2-20.)

- a. Remove horn button components as described in paragraph 4-22. Remove steering wheel.
- b. Mark steering arm (24) and sector shaft (17) so they can be reassembled in same position. Remove nut (19) and pull arm off sector shaft.
- c. Loosen nut (20) on lash adjusting screw (22) and turn screw sufficiently to remove load from wormshaft bearings.
- d. Loosen lock nut (16) and unscrew worm bearing adjuster (15) a few turns.
- e. Remove three cap screws which secure cover (20) to housing. Allow lubricant to drain.
- f. Pull side cover (20) from housing, withdrawing sector and shaft assembly at the same time. Turn wormshaft as necessary to allow sector to pass through opening in housing. Remove parking (18) from housing.
- g. Remove worm bearing adjuster (15), lock nut (16), re-gather with bearing components (5, 9, and 10) from housing.

CAUTION: TO AVOID DAMAGING THE ENDS OF THE BALL GUIDES (12) DURING DISASSEMBLY, DO NOT ALLOW THE BALL BLOCK (14) TO ROTATE TO THE END OF THE WORM.

k. Carefully withdraw wormshaft (4) and ball block assembly from housing.

i. Recommended procedure is not to disassemble ball block assembly if there is no indication of binding or tight fit when block is rotated on worm shaft.

j. To disassemble ball block, remove clamp (13) and withdraw ball guides (12) from block. Turn block upside down and rotate wormshaft until all balls have dropped out. Pull block off wormshaft.

4-34. REPAIR.

a. Wash all parts in solvent and dry thoroughly.

b. Carefully examine all parts for excessive wear or damage.

c. Check ball guides for damage at ends. Replace if damaged.

d. Discard seals and gaskets which show signs of leakage.

4-35. REASSEMBLY. (See figure 2-20) Reassemble in reverse order of disassembly.

a. Assemble ball block and wormshaft by placing block on shaft with ball guide holes up. Assemble 20 balls into each ball circuit. Be sure each circuit is completely full.

b. Reinstall wormshaft and ball block assembly, being sure grooves in block are properly positioned to engage sector. Turn wormshaft to place ball block in center of worm. Reinstall bearing adjuster and lock nut.

c. Check end clearance of lash adjusting screw (22) in sector shaft (17). Use shims (33P546 kit) as necessary to obtain an end clearance no greater than .002" between screw head and shaft.




Fig. 1-19. Sector shaft

1. Sector shaft
2. .002" maximum clearance
3. Use shims here
4. Lash adjuster screw

d. Draw sector shaft into cover with lash adjusting screw. Slide sector shaft and cover into housing, being sure center tooth of sector engages center groove in ball block. Tighten bolts in side cover to 25 - 35 foot pounds.

e. Tighten bearing adjuster to remove all end play from wormshaft. Tighten lock nut to 75 - 100 foot pounds.

f. Reinstall steering wheel and tighten wheel attaching nut to 35 - 40 foot pounds.

g. Turn steering wheel to determine center of wheel travel. Hold wheel in centered position and remove all lash between sector and worm nut. Tighten adjuster lock nut to 15 - 27 foot pounds.

h. Check pull required to rotate steering wheel through center position. Pull required should be from 1 to 2 pounds. Readjust bearing adjuster and lash adjuster screw to obtain proper pull.

i. Reinstall steering arm on sector shaft. Refill gear housing with lubricant and reinstall assembly in truck.

j. To reset steering mechanism after it has been completely disassembled, first be sure steer wheels are in straight-ahead position. Position steering arms (24) at center of travel. Adjust length of drag link so socket (47, figure 2-18) will fit freely in hole in steering housing (30, figure 2-12). Adjust tie rods and steering stop bolts (figure 1-22) to allow an 83 degree angle of inside wheel to frame (inside wheel in relation to direction of turn).

4-36. HYDRAULIZER, STEERING WHEELS, AND LINKAGE.

4-37. REMOVAL. (See figure 2-19).

a. Remove the counterweight. (See figure 1-63).

b. Jack up rear of lift truck. Remove hub cap (8). Remove nuts, and remove wheel and bearings.

c. Disconnect tie rod sockets (30) from steering forks (1 and 2). Remove dust cover (32).

d. Remove connecting tube (29) between cylinders (13 and 14). Remove side panels (16, 17, figure 2-25).

e. Remove four bolts holding each assembly to frame and remove cylinder and fork assembly.

4-38. DISASSEMBLY. (See figure 2-19).

a. Straighten edges of retaining ring (17) and remove retainer (18). Pull piston and fork out of cylinder (19).

b. Remove piston head (27) by using three 3/8" pusher bolts; turn them in evenly and gradually. Remove nut (8) from fork spindle and remove piston assembly (items 19 through 28).

c. Remove cap (41) and nut (36). Remove steering housing (37) with bearings.

4-39. REPAIR.

a. Examine all bearings and seals carefully. Discard any that are unserviceable.

b. If dust seals (22 and 24) are brittle or damaged, replace them with new.

c. Examine the inside cylinder walls carefully for pits or grooves; smooth any roughness with emery paper. If the walls are grooved so deeply that they will not clean up easily, use a new cylinder.

4-40. REASSEMBLY. (See figure 2-19.) Reassemble in reverse order of disassembly. Tighten cylinder mounting bolts to 210 ft. lbs. Apply coat of clean oil to piston, cylinder wall, and seals at assembly.

a. Tighten elastic nut (3) to apply preload to bearings (22 and 24) to obtain a rolling torque of 30 to 40 inch pounds on piston (16). Wrap a string around piston, attach a spring scale and tighten nut to obtain a scale reading of 14 to 18 pounds. (Since radius of piston is 2.249 to 2.251 inches, a pull of 14 to 18 pounds is equivalent to a rolling torque of 32 to 40 inch pounds.)

b. With piston (16) and related components reinstalled in cylinder, engage tangs of lock ring (17) in notches in ring (16). Tighten retaining ring securely and bend back edge of lock ring up against cylinder. Bend front edge down to avoid interference with frame.

c. Tighten the castellated nut (36) on steering spindle to snug up bearings (27 and 29) so there is no end play.

d. Tighten castellated nut on axle spindle to snug up bearings (9 and 11) until there is a slight amount of bearing drag, then back the nut off one notch and secure with the cotter key.

e. Recharge hydraulicers as follows: Place lift truck on level floor with no load. Jack up rear of truck, remove rear side panels, and remove filler plugs from both hydraulicers. Fig. 1-20. Lower lift truck to raise both wheels to their extreme height.

f. Pick a measuring point, preferably on hydraulicer piston. Raise truck to lower wheels 1-3/8 to 1-3/4" and hold in this position.

g. Fill both cylinders completely full with Mobil Delvac S-220 DS oil and replace the filler plugs.

h. Lower truck and loosen plugs to bleed all air out of cylinders. Tighten plugs when rear of frame is 4-1/4 ± 1/16" off the floor. (Measure frame height from floor directly in front of steer wheels.)

i. Approximately 1/3 quart of oil will be vented from the system. This will assure that there will be no air remaining in the system.




Fig. 1-20. Hydraulicer.

j. Filler plug

j. Truck must be on level surface to set steering. Disconnect drag link and tie rods. Set steering housing (35) so center of housing is parallel with truck (NO TOE-IN). Connect tie rods and secure. (Note: They should be close to the same length.) Tie rod clamps must be positioned to avoid interference with steering forks.

k. Center steering wheel and connect drag link. Adjust drag link length to allow full turn in both directions.




Fig. 1-21. Steer wheel adjustment

1. Drag link
2. Tie rods
3. Clamps

l. Turn wheels to extreme in both directions and adjust stop bolts (against both stops) to allow 33° angle of inner steer wheel with frame (inner wheel in relation to direction of turn). STOPS MUST BE ADJUSTED SO STEERING GEAR DOES NOT BOTTOM IN EITHER DIRECTION.



Fig. 1-22. Steering steps

1. Steps

4-41. HEAD AND REAR LAMPS (OPTIONAL). (See figure 2-12A).

4-42. REMOVAL.

- a. Disconnect battery ground wire.
- b. Disconnect lead wires to lamps and remove lamps.

4-43. DISASSEMBLY. (See figure 2-13A).

- a. Remove retainer (13). Pull sealed beam unit (12) out of shell.
- b. Remove lens retainer (25) and remove lens (24).

4-44. REPAIR. Inspect and replace all defective parts.

4-45. REASSEMBLY. (See figure 2-12A). Reassemble in reverse order of disassembly.

4-46. INSTRUMENT PANEL AND INSTRUMENTS.

4-47. REMOVAL. (See figure 2-13).

- a. Remove clips holding panel to steering column support, and shift lever clamps.
- b. Disconnect battery ground cable. Disconnect controls for transmission valve.
- c. Remove bolts holding panel (1) to cowi assembly. Lift out panel assembly.
- d. Disconnect and tag wires from instruments.

4-48. DISASSEMBLY. (See figure 2-13). Disassembly is complete upon removing switches and gages from the panel, and removing the sending units.

4-49. Repair is limited to checking condition and performance of switches, gages, sending units, and components. Inspect wiring for broken conductors, corrosion, and damaged insulation. Discard all unserviceable parts and replace with new parts.

4-50. REASSEMBLY. Reassemble in reverse order of disassembly.

4-51. RADIATOR, HOSES, AND THERMOSTAT.

4-52. REMOVAL. (See figure 2-8).

- a. Remove counterweight. (See figure 1-53).
- b. Remove radiator cap and open radiator and block drains.
- c. Remove upper and lower hoses (20 and 21).
- d. Remove bolts (31) holding radiator to frame and carefully lift out radiator.
- e. Remove thermostat housing (26), thermostat (24), and adaptor (25).

4-53. DISASSEMBLY. Disassembly is complete upon removal of components from truck.

4-54. REPAIR. Inspect radiator and hoses. Test the thermostat as outlined in Chapter 3. Discard unserviceable parts. Repair minor ruptures in radiator, discard if damage is excessive.

4-55. REASSEMBLY. (See figure 2-9).

- a. Reassemble in reverse order of disassembly. Tighten radiator mounting bolts (31) to obtain a dimension of $11/32"$, plus or minus $1/32"$, between inside edges of radiator mounting flange and frame bracket. This will just slightly compress radiator mounting pads (33) to provide cushioning mount for radiator.
- b. Close radiator and block drains. Refill cooling system and check for leaks.

4-56. MUFFLER.

4-57. REMOVAL AND DISASSEMBLY. (See figure 2-9).

- a. Remove counterweight. (See figure 1-54).
- b. Remove clamps (2 and 4) and remove muffler (1) and exhaust pipe (3).

4-58. REPAIR. Inspect and discard any parts that show excessive rust or deterioration. Muffler restriction should not exceed 20" water or $1-1/2"$ mercury.

4-59. REASSEMBLY. Reassemble in reverse order of disassembly. Align pipe (3) so it does not contact other parts of the lift truck.

4-60. GENERATOR. Field service of the generator is limited to maintenance procedures which include replacing worn brushes, bearings, and cleaning the commutator.

4-61. REMOVAL.

- a. Disconnect ground cable from battery. Disconnect and tag wires from field and armature terminals on generator.
- b. Remove cap screw from belt tightener bar, push generator toward engine, and slip belt out of pulley.




Fig. 1-23. Wiring Diagram

- | | | |
|------------------------------|---|--|
| 1. Distributor | 9. Starter | 18. Battery |
| 2. Water temp. sending unit | 10. Coil | 10. Ignition-starter switch |
| 3. Spark plugs | 11. Pressure switch | 20. Hourmeter |
| 4. Oil pressure sending unit | 12. Neutral starting switch | 21. Transmission oil temp. warning light |
| 5. Voltage regulator | 13. Transmission oil temp. sending unit | 22. Ammeter |
| 6. Generator | 14. Horn button | 23. Oil gage |
| 7. Fuel tank unit | 15. Horn | 24. Fuel gage |
| 8. Solenoid | 16. Horn relay | 25. Temperature gage |
| | 17. Fuse (15 amp.) | |

c. Remove two generator mounting bolts and lift generator up and away from engine.

4-62. DISASSEMBLY.

a. Disassembly of the generator should be accomplished only as far as necessary to make repair or replacement of defective parts.

b. Remove the drive belts and lockwashers. Tap off the commutator end cover to gain access to the brushes, holders, arms and springs.

c. Tap drive end frame to loosen and carefully withdraw frame and armature assembly from field frame.

d. To remove ball bearing in drive end cover, remove pulley, fan, and Woodruff Key, and pull end frame off armature shaft. Remove thru screws which secure bearing retainer plate to frame. Remove bearing and other components.

e. Remove screws which secure brush leads to supports, and remove brushes.

4-63. REPAIR. Major overhaul of the generator should be performed by an authorized electrical equipment service station which has the facilities for properly overhauling and testing the generator.

a. Clean all parts in an approved solvent. Do not soak

field frame or armature in solvent. Clean brush holders, brush arms, and inside of field frame with a cloth dampened with solvent. Dry all parts thoroughly with clean, dry compressed air.

b. Check condition of ball bearing, and bushing in commutator end cover. The entire commutator end cover must be replaced if the bushing is worn or damaged.

c. Clean the commutator portion of the armature, using a strip of No. 00 sandpaper, or a brush seating stone. Do not use emery cloth to clean the commutator. Remove dirt and grit from between commutator riser bars, being careful not to scratch the bars or mica.

4-64. REASSEMBLY.

a. Install new brushes in the holders, attaching the brush leads to the supports. After the armature is installed, check the tension of the brush springs to be sure they have sufficient tension to hold the brushes tight against the commutator.

b. Reassemble the roller bearing and components to the drive end cover. Slip armature shaft through bearing and cover, and reinstall fan and drive pulley.

c. Carefully install armature through field frame, being careful not to damage brushes. Check brush spring tension with armature in place.

d. Reinstall commutator end cover, securing both end covers with thru bolts.

e. Install generator on engine, install drive belt and adjust to proper tension. Reconnect battery ground cable.

f. Before reconnecting voltage regulator-to-generator wires, polarize generator by momentarily connecting a jumper wire between the "B" terminals on the regulator and the "A" terminal on the generator.

g. Reconnect the armature and field wires to their proper terminals on the generator.

h. Start the engine, operate at fast idle, and check generator output on ammeter. Generator output will depend on condition of battery and voltage regulator.

i. If the ammeter needle indicates to the right (discharge) side of the gage, the generator should be removed and replaced with a new one. Don't forget to polarize a new generator to the electrical system.

j. It is recommended automotive practice to replace the voltage regulator any time a new generator is installed.

4-65. GENERATOR VOLTAGE REGULATOR

4-66. REMOVAL. Disconnect ground cable from battery. Disconnect and tag wires from regulator terminals. Remove regulator from bracket.

4-67. DISASSEMBLY.

a. Remove regulator cover and gasket.

4-68. REPAIR. Field repair of the voltage regulator is limited to cleaning contact points and adjusting point gap.

a. Use a spoon or riffler file to clean the contact points. File points very lightly. Do not use emery cloth or sandpaper to clean the points. If the contact points are badly burned or otherwise damaged, replace the regulator with a new one.

CAUTION: DO NOT CLOSE CONTACT RELAY POINTS BY HAND WITH THE BATTERY CONNECTED. DOING SO WOULD PLACE A HIGH CURRENT THROUGH RELAY UNITS AND CAUSE SERIOUS DAMAGE.

b. Adjust air gap of voltage regulator and current regulator to .070 inch. Press down on armature arm and adjust air gap by means of the adjusting screws.

c. Adjust air gap of output relay to .020 inch. Press down on armature arm until points just close, then raise or lower arm as required by loosening screws in back of relay. Adjust relay point opening to .020 inch by bending upper armature stop.

d. Generator Regulator Settings:

Output Relay closing voltage -- 11.5 to 13.5 volts
Voltage Regulator closing voltage -- 13.3 to 14.3 volts
Current regulator setting -- 23 to 27 amps.

e. If regulator adjustments cannot be accomplished to obtain satisfactory performance, discard regulator and replace with a new one.

4-69. REASSEMBLY.

a. Reinstall cover and gasket.

b. Reinstall regulator and reconnect wires. Polarize generator before starting the engine by momentarily connecting a jumper wire between "GEN" and "BAT" terminals on regulator. Failure to polarize the generator may result in serious damage to components of the electrical system.

4-70. STARTING MOTOR. Field service of the starting motor is limited to maintenance procedures, which include replacing the brushes, cleaning or replacing the starting motor drive, and cleaning the commutator.

4-71. REMOVAL.

a. Disconnect ground cable from battery. Disconnect and tag wires from magnetic switch.

b. Remove starting motor mounting bolts and withdraw starting motor from flywheel housing.

4-72. DISASSEMBLY.

- a. Disassembly of the starting motor should be accomplished only as far as necessary to make repair or replacement of defective parts.
- b. Remove thru bolts and tap commutator end frame off field frame to expose brushes, holders, arms, and springs.
- c. Remove brush lead screws, pull brush holder attaching pins, and remove brushes, holders, and springs.
- d. Remove belt through shift lever and remove drive end housing. Withdraw armature and drive assembly from housing.

4-73. REPAIR.

- a. Clean all parts thoroughly and inspect closely for damage.
- b. Inspect brushes for wear, oil soaked condition, or other damage. Replace brushes if they are worn to less than half of original length when compared to a new one.
- c. Check motor drive for broken springs, broken or stripped pinion teeth. Check fit of motor drive on armature shaft. Discard motor drive if damaged.
- d. Clean dirt from between commutator riser bars, being careful not to scratch or damage the mica.

4-74. REASSEMBLY. Reassemble in reverse order of disassembly.

- a. Apply a light coat of engine oil to bearing surfaces of armature during reassembly.
- b. Check tension of brush springs, and also check to see that brushes seat properly on commutator. Replace springs if tension is insufficient to hold brushes against commutator.
- c. Seat brushes to commutator by wrapping a strip of No. 80 flintpaper around commutator and slowly turning commutator until brush surface assumes curvature of commutator.
- d. Reinstall starting motor and reconnect wires to magnetic switch.

4-75. DISTRIBUTOR.

4-76. REMOVAL.

- a. Disconnect battery ground cable. Disconnect high and low tension leads. Disconnect spark plug wires.
- b. Remove distributor cap. Note position of rotor and

mark distributor housing with spot of bluing so cam can be recalled with rotor in same position when reassembling. Remove distributor hold-down clamps and remove distributor.

- c. Do not turn over engine while distributor is removed.

4-77. DISASSEMBLY.

- a. Lift off rotor and remove distributor plate. Remove condenser and breaker front assembly.
- b. Remove breaker plate. Remove snap ring from shaft and lift off cam. Remove spacer, springs, and weights.
- c. Drive out roll pin from collar at bottom end of shaft and remove collar and thrust washers.
- d. Remove drive shaft from housing.

4-78. REPAIR.

- a. Clean parts in solvent and dry carefully.
- b. Inspect all parts carefully for excessive wear, cracks, corrosion, or deterioration. Replace unserviceable parts with new ones, particularly the points, condenser, rotor, or distributor cap.
- c. If a Distributoscope is available, the advance should be as follows:

9° TDC at 300 RPM
8° TDC at 600 RPM
13° TDC at 2400 RPM

4-79. REASSEMBLY.

- a. Reassemble in reverse order of disassembly.
- b. Mount distributor on engine, aligning it so cam and rotor will return to spot marked during disassembly.
- c. Adjust breaker point gap to .020 inch. Bend the stationary arm so points are properly aligned as well as gapped.
- d. Apply a light film of ball bearing lubricant to the breaker cam. Apply a drop of light engine oil to the breaker arm hinge. Lubricate the shaft with engine oil through the oil cup.
- e. Time the engine according to instructions in paragraph 3-19.




Fig. 1-24. Distributor

1. Points - .020" gap
2. Stationary arm

4-80. SERVICE BRAKES AND REAR AXLES.

4-81. REMOVAL. (See Figure 2-52A.)

- a. Jack up the front of the truck.
- b. Remove the drive wheel. The brake drum is an integral part of the wheel center.
- c. Remove two flat head screws from axle flange. Thread two 3/8" cap screws evenly and gradually into tapped holes in flange. This will force shaft out of housing.
- d. Remove retainer ring (44) and pull bearing housing (40) with stems 41 through 43 from housing (38).

4-82. DISASSEMBLY. (See figure 2-23).

- a. Remove springs (10 and 11).
- b. Press down on spring retainers (6), hold it from turning, turn hold-down pin (7) 1/4 turn and remove spring (8) and retainers (6). Remove shoe (9).
- c. Disconnect parking brake cable from link (5 or 6).
- d. Disconnect hydraulic line and remove wheel cylinder (14) from backing plate (1 or 2). Remove backing plate.
- e. Remove push rods (13), boots (18), pistons (17), cups (16), and spring (15), from cylinder.

4-83. REPAIR. (See figure 2-23).

- a. Discard worn linings, and weak or broken springs.
- b. Examine cylinder and components carefully. If cylinder bore is pitted or grooved, hone it to a smooth finish. If considerable metal must be removed before the bore will clean up, use a new cylinder.

c. If pistons are scored, or if the bores are brittle or cracked, install new parts.

d. Check pawls for brake shoes, 2 in each backing plate, to be sure they have not become stuck or frozen. The pawls must not turn with less than 150 inch pounds torque applied to the nut, but must turn when no more than 250 inch pounds are applied.

4-84. REASSEMBLY. (See figure 2-23).

- a. Reassemble in reverse order of disassembly. Tighten cap screws in backing plates to 115-120 ft.-lbs.
- b. Dip cylinder parts in clean brake fluid to facilitate assembly.
- c. Brakes are self-adjusting, so no mechanical adjustments are necessary. However, be sure shoes are in proper position (fully retracted) so drum can be installed.
- d. If there has been no evidence of seal leakage, excessive end play or worn or damaged axle bearings, these parts may be reinstalled in reverse order of disassembly with the original number of bearing housing shims. If any of the above conditions exist, see paragraph 4-84 for the procedures to check correct end play and bearing adjustment.

e. When installation is complete, loosen bleed screw (18) and depress pedal until air is removed from the system. Re-adjust fluid in master cylinder (see figure 1-2) as necessary.




Fig. 1-25. Bleed screw

1. Bleed screw

4-85. BRAKE LINKAGE AND MASTER CYLINDER. (See figure 2-24).

4-86. REMOVAL.

- a. Flip up rear section of floor plate. Disconnect accelerator pedal linkage and remove front section of floor plate.
- b. Disconnect cables (14 and 15) from brakes and lever.

c. Remove tubing from cylinder, and remove pedal assembly, cylinder, and support as a unit.

4-87. DISASSEMBLY.

a. Remove pins (16) and remove linkage.

IMPORTANT

Do not turn or adjust clevises (8 and 9) unless they are damaged and must be replaced. The length of this assembly is set at the factory and determines the travel of the piston in the master cylinder. This piston travel affects the braking action and inching. If it is absolutely necessary to disassemble the clevises, they must be reset as explained in paragraph 4-110.




Fig. 1-26. Master cylinder assembly

1. Cylinder
2. Clevises

b. Remove roll pins and remove shafts (4 and 6).

c. Remove cylinder (20) from support (5).

d. See figure 2-24A. Remove internal components of cylinder.

4-88. REPAIR.

a. Replace bushings (3) if they are excessively worn or scored.

b. Discard tubing showing signs of leakage. Discard frayed or damaged cables.

c. Examine bore of cylinder carefully for pits or grooves. If minor defects are present, hone carefully. If hone does not clean up without removing considerable metal, use a new cylinder. Install repair kit anytime the cylinder is disassembled and honed. Dry parts in clean brake fluid to facilitate assembly.

4-89. REASSEMBLY. (See figure 2-24).

a. Reassemble in reverse order of disassembly.

b. If the clevises (8 and 9) have been disassembled, reassemble the pedal, support and master cylinder assembly. Install assembly on lift truck. Connect all tubing. Replenish fluid in cylinder.

c. Loosen bleed screws (figure 1-26) and bleed both brakes. Replenish fluid as necessary.

d. The procedure for adjusting brake linkage and linkage for mechanical inching is described in paragraph 4-110, on page 1-40.

e. When brake linkage is properly adjusted, engage hand brake and pump up brakes with pedal. Remove cover (17) from master cylinder (20). Release hand brake and release brake pedal. A definite "sting" of fluid must be seen entering the fluid chamber when the brake pedal is released.

4-89. DRIVE AXLES AND DIFFERENTIAL (TWO PINION CAGE) - See figure 1-22).

4-91. REMOVAL.

a. Remove the upright and lock assembly. (See paragraphs 4-142 and following).

b. Drain the differential. Block up the front end of the truck. Support the transmission case. Disconnect tubing and linkages.




Fig. 1-27. Removing differential

c. Remove the bolts holding the differential to the transmission, and the axle support housing to the frame. Roll the assembly forward out of the truck. (See figure 1-27.)

NOTE: In figure 1-27, the drive wheels and some of the cowling has been removed to more clearly illustrate the parts involved. These parts do not have to be removed to remove the differential.

4-92. DISASSEMBLY. (See figure 2-24).

a. Remove drive wheels and tires (47). Remove two flat head screws in flange of shaft (23). Screw two 3/8-16 bolts evenly and gradually into tapped holes in flange, to force axle shaft out of housing.

b. Remove retaining ring (42) and remove bearing housing assembly (37). Remove brake assembly.

- c. Remove bearing caps (10 and 15) and shims (12, 13, 14, 17, 18, and 19). Remove bull pinion and ring gear assembly (5) with bearing cones (6 and 8).
- d. Support differential cage (20) and remove axle housing (32) and shims (34, 35, and 36). Remove cage assembly.
- e. Remove right hand cage (5a) from cage (20), with cone (24), thrust washer (31), and bevel gear (30).
- f. Pull roll pin and remove shaft (27), pinions (28), bevel gear (30) and thrust washers (28 and 31).

4-83. REPAIR. Clean all parts thoroughly and examine carefully. Discard any worn or damaged parts.

4-84. REASSEMBLY. (See figure 1-22.)

- a. Do not use Permatex on gaskets.
- b. Torque bolts and nuts to differential following chart on page 1-21. Torque counterbore cap screws in cage as follows:

3/8 inch	30-40 foot pounds
5/8 inch	150-175 foot pounds
- c. Reassemble differential cage (20) and its components as follows:

1. Use .032" thick thrust washers (31) behind bevel gears (30) when assembling. Torque six cap screws to 36 to 40 foot-pounds.
2. Insert axle (29) into gear (30). Holding the axle stationary, it must require a torque between 15 and 50 foot-pounds to turn the cage.
3. If the torque required to rotate the cage is over 50 foot-pounds, remove the .032" thick washers, and insert .080" thick washers and repeat the above procedure. If the torque required is below 15 foot-pounds, use .035" thick washers.
4. Washers of the same thickness must be used to keep the assembly symmetrical about the drive pin (27).




Fig. 1-28. (1 of 2) Differential

1. Bevel gears
 2. .032" shims
 3. Axles
- c. When torque requirements of differential cage have been met, install assembly in case.

- e. Install axle housing (32) USING NO SHIMS. Tighten the housing bolts just enough to hold the assembly in place. Wrap a string around the portion of the cage next to the tooth (2, figure 1-28); attach a spring scale to the string; record the number of pounds pull required to rotate the assembly. Then remove the housing and install the proper shims (34, 35, 36) so it requires 2 to 4 pounds MORE PULL than it did with no shims. (This amounts to 5 to 10 inch pounds NET rolling torque.)




Fig. 1-28 (2 of 2) Differential

1. Place string here for step "e"
2. Place string here for step "g"
- f. Install the ring gear and bull pinion assembly (5) with its components (Items 6 through 19). Use shims (17, 18, 19) and (12, 13, 14) under caps (10 and 15). Torque cap screws in caps to 30 to 40 foot-pounds.
- g. Wrap a string around the center portion of the shaft (2, figure 1-28). Add or remove shims under the caps so it will require a total pull of 4 to 8 pounds MORE PULL than it did with no shims to rotate the entire assembly. This will also obtain a NET rolling torque of 5 to 10 inch pounds on the upper shaft. See figure 1-28.




Fig. 1-29. Measuring height of pinion

1. Measure from end of shaft to finished surface of case.
- a. To determine the proper amount of shims (3) between the transmission and differential cages (for proper ring gear and pinion contact), proceed as follows: Measure the distance from the end of the pinion shaft to the fin-

ished surface of the transmission case. Record this dimension. (Fig. 1-30.)

i. Measure from finished surface of differential case to finished surface of cap (20). Record this dimension. (Fig. 1-30.)




Fig. 1-30. Differential

1. Finished surface of case

2. Shoulder on cap (early trucks)

3. Shoulder on cap (late trucks)

4. Measure from finished surface of case to shoulder of cap

EXAMPLE:

Dimension from paragraph h (Table A) 1.447
 Shims (Table A, Column 2)019
 Dimension from paragraph i (Table B) 2.077
 Shims (Table B, Column 2) + .002
 Total Shims required020

Table A

Column 1	Column 2
1.434	.009
1.436	.009
1.438	.007
1.437	.008
1.438	.009
1.439	.010
1.440	.011
1.441	.012
1.442	.013
1.443	.014
1.444	.015
1.445	.016
1.446	.017
1.447	.018
1.448	.019
1.449	.020

Table B

Column 1	Column 2
2.074	+ .005
2.075	+ .004
2.076	+ .003
2.077	+ .002
2.078	+ .001
2.079	.000

NOTE: Shims are available in the following thicknesses; 35A3385 -- .002"; 35A3386 -- .003"; 35A3387 -- .004".

IMPORTANT

Be sure the contact point of the gage is on the portion of the cap shown in figure 1-30.

j. Refer to Table A. Look up the dimension obtained in paragraph h in Column 1; obtain the shims required from Column 2.

k. Refer to Table B. Look up the dimension obtained in paragraph i in Column 1; read from Column 2 the amount of shims to be used.

l. Remove axle housing (32) and shims. Attach a dial indicator to the case, with the contact point on one of the bull pinion teeth.

m. Attach another indicator to transmission case, with contact point in one of the notches in the lock nut on the end of the pinion shaft.

n. Turn pinion shaft (5) to read backlash, also watch indicator on bull pinion teeth to be sure bull pinion is not turning. Backlash is to be .004 to .008 inch.

o. If reading is greater than .006, remove shims (17, 18, or 19) from under cap (16), and place shims of the same thickness under cap (10).

IMPORTANT

The correct number of shims has been determined (in paragraph 4-94). This same thickness of shims must be used to maintain the correct milling torque. If shims are removed from one side, shims of the same thickness must be installed on the other side.

p. If reading is less than .001, remove shims (12, 13, or 14) from under cap (15), and add shims of the same thickness under cap (15).

q. Reinstall housing (92) and shims.

r. Install seal (36) in bearing housing (97), with lipped edge toward case. Place bearing housing (97) on axle housing. Install caps and cones (40 and 41) and secure with retainer ring (42).

IMPORTANT: Cones (40), shim (43), and retainer (42) must be considered an assembly with dimension shown in Fig. 1-31. Select shim (43) of the proper thickness to obtain the given dimension.




Fig. 1-31. Bearing cones

1. Retainer
2. Cones
3. Shim
4. 1.932 to 1.930 inches

s. Place "O" ring (39) in groove in axle shaft (29). Install axle shaft (29), using shims (43, 44, 45) to obtain .004 to .008 inch end play.

t. Install drive wheel (47) and torque wheel nuts to 20 to 120 foot pounds. Reinstall entire assembly on truck.

4-95. DRIVE AXLES AND DIFFERENTIAL. (HUB PINION CAGE - See figure 2-22A.)

4-96. REMOVAL.

- a. Remove mast assembly. (See paragraph 4-142 and following.)
- b. Turn steering wheel to full left position to move steering arm and drag hub to rear and out of way.
- c. Drain differential. Place blocks under both sides of frame and under transmission.
- d. Disconnect linkage for mechanical locking and remove support plate with parts attached. Disconnect brake lines from wheel cylinders and disconnect parking brake cables. See Fig. 1-27.
- e. Remove bolts securing axle support to transmission case and frame side members. Remove bolts holding differential to transmission. Roll differential-axle assembly forward and away from truck.

4-97. DISASSEMBLY. (See figure 2-22A.)

- a. Remove drive wheels and tires. Remove two flat head screws in axle flange (30). Screw two 3/8" - 16 nuts evenly and gradually into tapped holes in flange to pull axle out of housing. Note quantity of shims between axle flange and housing (40).
- b. Remove ring (46) from housing (35) and remove bearing housing assembly (40).
- c. Remove bearing caps (12 and 13), together with shims (14 and 17) from either side of case. Remove bull pinion (5) and ring gear (6) assembly with bearings (8 and 10).
- d. Support differential cage (18) and remove axle housing (35) together with brake assembly and axle housing support. Lift out differential cage assembly.
- e. Remove cover (22) from cage (18). Remove bevel gear (31), together with thrust bearing (33), bearing race (32), and shim (34).
- f. Remove shaft (cross) (25), bevel pinion (27), and input washers (28). Remove other bevel gear (21), bearing (33), race (32) and shim (34).

4-98. REPAIR.

- a. Clean all parts thoroughly and examine carefully. Discard all worn or damaged parts.
- b. Renew bushings in cage and cover if they are worn. Press in new bushings to position shown in Fig. 1-32. Renew bushings to obtain inside diameter indicated in Fig. 1-32.




Fig. 1-32. Bushing in cage and cover

1. Cover
2. 1/32 inch (both bushings)
3. .004 to .008" (both bushings)
4. Cage

4-99. REASSEMBLY. (See figure 2-22A.)

- a. Do not use Fernotex on gaskets.
- b. Torque bolts and nuts in differential following chart on page 1-21. Torque 3/8" screws in cage to 35 ft. lbs. if threads are oiled; 45 ft. lbs. for dry threads. Torque 7/16" cap screws in ring gear to 50 ft. lbs. if threads are oiled; 75 ft. lbs. for dry threads. Secure cap screws with lock wire after proper torque value has been obtained.
- c. Reassemble differential cage (18) and its components as follows:
 1. Install two .005" thick shims (34) between the bearing races (22) and cage (18) and cover (22) when reassembling. Be sure extended portion of bevel pinion thrust washers (29) engage in slots as pinions are installed.
 2. Tighten eight cap screws in cage cover to torque value specified in paragraph "b".
 3. Insert axle (30) in gear (31). Hold axle stationary and rotate cage. It must require a torque between 15 and 60 foot pounds to turn cage.
 4. If torque required to rotate cage is over 60 foot pounds, reduce number of shims (use thinner ones) and repeat procedure in "2" and "3". If torque required is below 15 foot pounds, increase the number of shims and recheck torque.

IMPORTANT: KEEP SHIM PACK EQUAL ON BOTH SIDES OF BEVEL GEARS (31) TO MAINTAIN SYMMETRICAL POSITION.




Fig. 1-33. Differential Cage

1. Bearings, races, and shims
2. Thrust washers
3. Axles

d. After correct torque requirements of differential cage have been determined, install assembly in case.

e. Install axle housing (35), USING NO SHIMS. Tighten housing bolts just enough to hold differential cage assembly in place. Wrap a string around cage, next to teeth (1, figure 1-36-2) and attach a spring scale. Record pounds of pull required to rotate cage assembly. Then remove housing and install necessary shims (37) so it requires 2 to 4 pounds MORE PULL to rotate cage than it did with no shims. (This amounts to 5 to 10 inch pounds NET rolling torque.) Retain "O" ring (36) the second time housing is installed.

f. Install ring gear and bul. pinion assembly (5 and 6), with all components (items 3 through 10). Use shims (17 and 14) under caps (12 and 13). Torque cap screws in bearing caps to 30 to 40 foot pounds.

g. Wrap a string around shaft, at point midway between bul. gear and ring gear (2, figure 1-28-2). Add or remove shims under bearing caps (12 and 13) so it will require a total pull of 4 to 6 pounds MORE PULL than it did with no shims, to secure entire assembly. This will also obtain a NET rolling torque of 5 to 10 inch pounds on upper shaft.

h. To determine correct amount of shims (4) between transmission and differential cases (for proper ring gear and pinion contact), proceed as follows:

1. Measure distance from end of pinion shaft to finished surface on transmission case. RECORD THIS DIMENSION, Fig. 1-28.
2. Measure distance from finished surface of differential case to finished surface of bearing cap (12). RECORD THIS DIMENSION, Fig. 1-29.
3. Refer to Table A, Column 1. Look up dimension obtained in item 1; obtain necessary shims required from Column 2.
4. Refer to Table B, Column 1. Look up dimension obtained in item 2; obtain necessary shims required from Column 2.

Table A		Table B	
Column 1	Column 2	Column 1	Column 2
1.476	.005	2.074	+.005
1.477	.006	2.075	+.004
1.478	.007	2.076	+.003
1.479	.008	2.077	+.002
1.480	.009	2.078	+.001
1.481	.010	2.079	.000
1.482	.011		
1.483	.012		
1.484	.013		
1.485	.014		
1.486	.015		
1.487	.016		
1.488	.017		
1.489	.018		
1.490	.019		
1.491	.020		

EXAMPLE:

Dimension from Item 1 (Table A)	1.430
Shims indicated Table A, Column 2009
Dimension from Item 2 (Table B)	2.077
Shims indicated Table B, Column 2	+.002
TOTAL SHIMS REQUIRED	.011

NOTE: Shims are available in the following thicknesses: 35A8843 = .002", 35A8844 = .003", 35A8845 = .005".

i. To check backlash between ring gear and pinion, it will be necessary to reassemble differential to transmission. Use shim pack as determined in paragraph "h" and secure differential to transmission with 6 or 8 bolts.

j. Remove plug (51) from top of differential case and mount a dial indicator on ring gear. Hold pinion from turning and check backlash. The backlash must be .008 to .011 inch.




Fig. 2-34. Checking backlash

1. Remove plug to mount indicator

k. If indicator reading is greater than .011", remove shims (17) from under cap (18), and place shims of same thickness under cap (12).

l. If indicator reading is less than .006", remove shims (14) from under cap (12), and add shims of same thickness under cap (18).

IMPORTANT: THE CORRECT NUMBER OF SHIMS HAS BEEN DETERMINED IN PARAGRAPHS "E" AND "G". IF SHIMS ARE REMOVED FROM ONE SIDE, SHIMS OF SAME THICKNESS MUST BE INSTALLED ON OTHER SIDE TO MAINTAIN CORRECT ROLLING TORQUE.

m. Install seal (41) in housing (40), with lipped edge toward bearings. Carefully install bearing housing (47) on axle housing. Install cups and cones (42 and 43) and secure with retainer ring (44).

n. After bearing housing (40) and bearing are installed and secured on housing (35), use a soft driver and drive against inner race of outer bearing to move bearing away from retainer ring as far as it will go. **BE CAREFUL NOT TO DAMAGE BEARING.**

o. Measure distance between retainer and bearing, using a feeler gage. If dimension obtained is .018" or less, bearing adjustment is satisfactory and does not have to be changed.

p. If dimension between retainer and bearing is .018" or more, it will be necessary to install a shim between the two axle bearings.

q. Remove retainer and pull hub off housing far enough so outer bearing can be removed. **BE CAREFUL NOT TO DAMAGE OIL SEAL IN INNER END OF HUB.** Install a shim (45) of the proper thickness that will bring dimension between bearing and retainer down to a clearance of less than .018". Use shims to bring clearance down to a minimum, yet allow installation of retainer ring.

r. Press seal (38) into bearing housing (40) with lipped edge toward inside. Install retainer (37) with flat side against seal.

s. Apply vaseline to lips of seal (38), and carefully install axle shaft (30), using shims (46) to obtain .004 to .006 inch end play. Secure axle with two flat head screws.

t. Install drive wheel and secure wheel nuts to 90 to 120 foot pounds.

u. Install remaining bolts that secure differential to transmission and tighten all bolts securely. Tighten bolts holding axle supports to transmission and frame sides to 170 to 200 foot lbs.

v. Reconnect all disconnected linkages and lines. Reinstall removed components in reverse order of disassembly.

4-100. TRANSMISSION CONTROL VALVE (HYDRAULIC ENGAGING)

4-101. REMOVAL. (See figure 2-17).

a. Remove the left hand drive wheel. Remove the drag link and turn the steering arm all the way forward. Disconnect control lever cable assembly by removing pins shown in figure 2-18. Disconnect wires from neutral starting switch (35). Disconnect tubing.

b. Remove the pressure regulator valve assembly (27), control valve assembly (1), and gasket (36) from the case. Use care to avoid losing ball (3) and spring (4).

4-102. DISASSEMBLY. (See figure 2-17).

a. Remove snap ring (34). Thread a 1/4"-20 UNC bolt into valve block (81), and pull out the block and "O" ring. Remove valve (28) with "O" ring, and spring and ball (29 and 30).

b. Remove main system relief (items 21 through 24), priority valve (items 25, 26 and 27), and pressure reducing valve (19 and 20), in the same manner as in "a" above.

c. Remove snap ring (15) and remove inching spring plug (14). Remove seat plug (17), spring (7), and check disc (18) from the plug.

d. Remove spring (13) and inching piston (9), with quad ring (10) and seal (11).

e. Remove snap ring (34) from opposite end of inching part, thread a 1/4"-20 UNC bolt into block (30) and pull out block and "O" ring (33). Remove inching spool (6) and springs (7 and 8).

f. Remove snap ring and block from directional spool part, as outlined above. Push spool (2) through seals (5) and out of valve body. Remove seals if there is evidence of leakage.

g. Remove snap ring (41), thread a 1/4"-20 UNC bolt into block (39), pull out block, "O" ring, spool (38), and spring (44).

h. Remove snap ring (47) and block (43) and "O" ring (46) in same manner as above. Remove piston (42) and spring (43).

i. Remove snap ring (51), block (49), and "O" ring (50) in same manner. Remove orifice assembly (48). Remove snap ring (53), screen (52), pin (55), and ball (54).

4-103. REPAIR. (See figure 2-17).

a. Discard "O" rings, seals, quad rings, and gaskets which show signs of leakage. Discard damaged tubing, and fittings. Discard weak or broken springs.

b. Inspect valves and spools carefully; discard any that are scratched or pitted. If the polished surfaces inside the valve body are pitted or scratched, try to clean them up with a light honing. If the blemishes are so deep that it requires removal of considerable metal to remove them, discard the entire valve body.

c. Clean all parts thoroughly in solvent. Be sure filter disc (18) and screen (52) are clean.

4-104. REASSEMBLY. (See figure 2-17).

a. Reassemble in reverse order of disassembly.

b. Dip all parts EXCEPT INCHING SPOOL (6) in clean hydraulic fluid to facilitate assembly, and to help prevent damage to parts during installation. Inching spool may be dipped in graphite.

IMPORTANT

There are three grooves in the center section of the inching piston (9). The quad rings (10)

must be installed in the outer grooves. The center groove must be kept clear for an oil passage. Install seal (11) and washer (12) in large groove, with grooved side of seal toward quad rings.




Fig. 1-35. Inching piston

1. Quad rings
2. Seal -- Lip end toward quad rings
3. Washer

c. Insert directional spool (2) in body. Then slip seals over spool -- DO NOT PUSH SPOOL THROUGH SEALS. The lip end of the inner seal must face in, the lip end of the outer seal must face out.

d. Install assembled valve to case, with gasket (36) and ball and spring (3 and 4) in position.

e. Torque the mounting bolts evenly and gradually to 20 to 25 foot-pounds, in the sequence shown in figure 1-36.




Fig. 1-36. Torque sequence and test parts

1. through 7. Torquing sequence
8. Lube pressure -- 15 to 25 psi
9. Pump pressure -- 90 to 120 psi
10. Converter pressure -- 48 to 68 psi
11. Clutch pressure -- 55 to 65 psi
12. Power piston pressure -- 55 to 60 psi

f. Connect links to spool and reattach control cable. Adjust clevises shown in figures 1-37 and 1-38, to allow full detent position for spool, yet prevent spool from bottoming in valve or pulling too far out. Adjust set screw to keep spool from being withdrawn beyond the detent position.



Fig. 1-27. Clevis and set screw

1. Clevis
2. Set screw




Fig. 1-28. Adjusting clevis

1. Clevis
- b. Change transmission oil filter cartridge (see figure 1-8).
- c. Connect all lines and start engine. Operate truck through several cycles of forward, reverse, and latching.
- d. Check pressures as follows:
 1. Warm up truck until transmission oil temperature reaches 170° to 180°.
 2. Place substantial load on forks.
 3. Engage service brakes, shift into forward, and operate the engine at approximately 1400 RPM (converter at stall).
 4. Fig. 1-30 shows pressures and check ports. Check both forward and reverse clutches.

4-105. TRANSMISSION CONTROL VALVE. (MECHANICAL LATCHING.)

4-106. REMOVAL. (See figure 2-17A or 2-17B.)

- a. Remove left hand drive wheel. Turn steering wheel to full left position so steering arm and drag link will not be in way. Disconnect links (3 and 14, figure 2-18A)

or links (3 and 14, figure 2-18B) from valve spools. Disconnect wires from neutral starting switch and disconnect tubing.

- b. Remove regulator valve assembly (37, figure 2-17A), control valve assembly (1) and gasket (36). Be careful not to lose ball (3) and spring (4) as valve assembly is removed.

4-107. DISASSEMBLY. (See figure 2-17A or 2-17B.)

- a. Remove snap rings (41, 47, and 51) from regulator valve. Thread a 1/4"-20 NC bolt into blocks (32, 45, and 48) and carefully pull out blocks and "O" rings.
- b. Remove pressure regulator spool (38) and spring (44). Remove piston (42) and spring (43). Remove orifice (43) and related components from bore in top of valve. Remove snap ring (53) to disassemble orifice assembly.
- c. Remove snap ring (24), thread a 1/4"-20 NC bolt into block (31), and pull out block and "O" ring. Remove tube relief valve (29) with "O" ring, and ball (29) and spring (30).
- d. Remove main system relief valve (items 2, through 24), priority valve (items 23, 26, and 27), and pressure reducing valve (19 and 20), in same manner as described in paragraph "c".
- e. To remove seal (16), punch 2 small holes in seal back, install 2 small metal screws and pry seal out of valve. Discard seal. Remove snap ring (10) and remove spool (9). The internal components of spool (9) are not serviceable items, so if any are broken or damaged, renew complete assembly.
- f. Remove snap ring (39) from opposite end of latching spool port, thread a 1/4"-20 NC bolt into block (22) and carefully pull out block and "O" ring. Remove spring (7), spool (6), and spring (8).
- g. Remove snap ring and block from directional spool port as outlined in paragraph "f". Push spool (2) through seal (6) and out of valve body. Remove seals if there is evidence of leakage.

4-108. REPAIR. (See figure 2-17A or 2-17B.)

- a. Clean all parts in suitable solvent. Inspect valves and spools carefully; discard any that are scratched, pitted, or badly discolored. If polished surfaces inside valve body are pitted or scratched, try to clean by light honing. If blemishes are so deep that it requires removal of considerable metal to remove them, discard the entire valve body.
- b. Discard "O" rings, seals, and gaskets that showed signs of leakage. Discard damaged tubing and fittings. Discard weak or broken springs.

4-109. REASSEMBLY. (See figure 2-17.) Reassemble in reverse order of disassembly.

d. Dip all parts EXCEPT INCHING SPOOL (6) in clean hydraulic fluid to facilitate assembly, and to help prevent damage to parts during installation. Coat inching spool with graphite at assembly.

e. Install directional spool (2) in body. Be sure 3 detent grooves are toward ported side of valve body so as to properly engage detent ball (3).

f. Slip seals (5) over spool, with lip end of inner seal facing in; lip end of outer seal facing out. DO NOT PUSH SPOOL THROUGH SEALS.

g. Apply a light film of 150 AA Lubriplate to inching spool (9), and install spool in body. Install snap ring (10). Carefully slide seal (16) over spool and install in body. (NOTE: An 11/16" socket makes a good seal installing tool.)

h. Install assembled valve to case, with gasket (36), and ball and spring (3 and 4) in position. Install regulator valve (27, figure 2-17A) if used.

i. Use new O-rings (50A1829) on attaching bolts. Torque bolts evenly and gradually to 20-25 ft. lbs. in sequence shown in Fig. 1-39.




Fig. 1-39. Torque Sequence & Test Ports

1. through 7. Torquing sequence
8. Lube pressure -- 15 to 25 psi
9. Pump pressure -- 90 to 110 psi
10. Converter pressure -- 45 to 60 psi
11. Clutch pressure -- 80 to 100 psi

g. Connect links to inching and directional spools. For lift trucks equipped with cables for controlling directional spool, as illustrated in Fig. 2-13A, adjust clevises, shown in Figs. 1-38 and 1-40, to allow full detent position for spool, yet prevent spool from withdrawing in valve or pulling out too far. Adjust set screw (Fig. 1-40) to keep spool from being withdrawn beyond detent position.



Fig. 1-40. Cable control for directional spool

1. Cable
2. Set screw
3. Adjusting clevis

h. For lift trucks equipped with directional spool control linkage as illustrated in Fig. 2-13B, adjust position of spool in valve with connector (7). Maintain spool position as described in previous paragraph (g). The set screw used with cable type control (Fig. 1-40) to regulate spool position is not used with lever type control (Fig. 1-41).




Fig. 1-41. Lever control for directional spool

1. Lever
2. Adjusting connector

i. Check location of lever (4, figure 2-13B) in relation to lug for lower end of lever (1) on support (11). If ball joint (5) is used, with nut on top of lever (4), a dimension of 5/16" must be maintained between upper edge of lever (4) and bottom edge of lug. Fig. 1-42.

j. If ball joint (8) is used, with nut on bottom side of lever (4), a dimension of 1-1/8" must be maintained between the lever and lug. Fig. 1-42.

k. If the dimension is incorrect, loosen the cap screws in hub (3, figure 2-18B) and slide the hub up or down on the steering column until the correct dimension is obtained. Tighten cap screws in hub securely.




Fig. 1-42. Lever location

1. Hand lever
2. $5/16$ inch (see paragraph "l")
or
2. $1-1/8$ inch (see paragraph "j")
3. Lever on end of rod
4. Lug on support plate

l. Reconnect oil line to top of valve. Install new oil in transmission and change oil filter. See Lubrication Chart and notes on pages 1-11 and 1-13.

m. Start engine and operate truck through several cycles of forward, reverse, and inching. Operate truck long enough to warm transmission oil to 170 to 190 degrees. Check transmission operating pressures as follows:

1. Place substantial load on forks.
2. Engage service brakes, shift into forward, and operate engine at approximately 1400 rpm (converter at stall).
3. Fig. 1-39 shows pressures and check ports. Check both forward and reverse clutches.

4-110. ADJUSTING BRAKE AND MECHANICAL INCHING LINKAGE

a. Release parking brake lever. Remove pin from brake linkage clevis so master cylinder will be disconnected from brake pedal. Check position of pedal to be sure it is at rest against stop (3, figure 1-43).

b. Loosen jam nut securing inching adjustment turnbuckle and adjust turnbuckle so inching spool is bottomed

in valve housing -- DO NOT apply pressure on spool, placing undue strain on link, or pedal will be pulled away from stop. Recheck pedal position to be sure it is against stop.

IMPORTANT: IF SPOOL IS NOT BOTTOMED, IT WILL CAUSE CLUTCH SLIPPAGE, RESULTING IN DELAY OF CLUTCH ENGAGEMENT.




Fig. 1-49. Brake and inching linkage

1. Clevis pin
2. Brake linkage clevis
3. Pedal against stop bar
4. Jam nut
5. Inching adjustment turnbuckle

c. Stand at left side of truck, and, while watching inching spool, push brake pedal down by hand. Pedal should travel approximately $1/8$ inch before inching spool moves. Readjust position of turnbuckle, if necessary, but do not apply pressure to spool with turnbuckle or pull brake pedal away from stop. Secure turnbuckle with jam nut.

d. Reconnect brake linkage adjusting clevis. Install pressure gage in clutch pressure port (11, figure 1-89). Start engine, apply brakes, and check clutch pressure on gage. Adjust brake linkage clevis as necessary to obtain 10 psi clutch pressure with brakes applied and transmission control lever engaged. Check in both forward and reverse. This clutch pressure is satisfactory for average operating conditions.

e. If conditions exist, such as having to stop or change directions on severe ramps or inclines, brake linkage should be adjusted to more overlap between brakes and inching range. This is accomplished by lengthening linkage to master cylinder by means of the clevis (2, figure 1-48). Lengthening the brake linkage will raise the clutch pressure above 10 psi and will, in effect, raise the full-applied brake pedal position so that it is within the inching range of pedal travel.

IMPORTANT: DO NOT ALTER ADJUSTMENT OF INCHING TURNBUCKLE IN AN ATTEMPT TO OBTAIN ADDITIONAL OVERLAP OF BRAKES TO INCHING RANGE AS IMPROPER ADJUSTMENT WILL CAUSE DELAY IN CLUTCH ENGAGEMENT, OR UNDUE STRAIN ON LINKAGE.




Fig. 1-44. Brake and inching linkage

1. Parking brake disengaged
2. Locking adjustment turnbuckle
3. Brake linkage clevis
4. Inching spool

4-111. TRANSMISSION CASE, CONVERTER, AND PUMP.
(See figure 2-15).

4-112. REMOVAL.

- a. Remove fork and mast assembly. (See paragraphs 4-142 and following).
- b. Block up front end of lift truck. Disconnect all wires, tubing, linkages, etc. that are connected from the brakes, transmission, differential, and control valve, to other components of the truck. Remove the bolts holding the transmission supports to the frame.
- c. Disconnect the steering arm from the drag link. Disconnect all wires, cables, tubes to instruments on panel. Remove front cowling, instrument panel, and steering assembly as a unit.
- d. Remove floor plates. Remove parking brake lever from frame -- leave cable connected. Disconnect tubing from master cylinder and remove pedals, supports, and master cylinder as an assembly.
- e. Remove the clip holding the tilt cylinder tubing at the right side of the transmission; lift the tubing and secure it out of the way.



Fig. 1-45. Converter drive plate

f. Remove bolts holding converter drive plate to engine flywheel. Turn engine over to remove each bolt in turn, through opening shown in figure 1-45.

g. Remove belts holding bell housing (1E) to flywheel housing. Remove bolts holding transmission supports to the frame.

h. Roll the entire transmission and differential assembly away from the truck.

4-113. DISASSEMBLY. (See figure 2-15).

- a. Remove drive plate (27) and converter (26). Remove bearing cap (13) and "O" ring (13).
- b. Straighten out the two bear tabs on washer (3, figure 1-46), and remove the two lock nuts (2, figure 1-46).




Fig. 1-46. Transmission removed

1. Pump
 2. Lock nuts
 3. Washer
 4. Bearing
- c. Remove pump (30) from bell housing (16). Remove seal (23) from pump. Remove bell housing (16) from case. Bearing (30, figure 2-16) will come out with housing.
 - d. Remove dip stick (5), tube (7), and "O" ring (8).
 - e. Remove manifold (4) and shim (6).
 - f. Remove flange (3) and gasket (15). Remove bolt (11) and withdraw tube (12), element (13) and gasket (14).

4-114. REPAIR.

- a. Discard defective seals, "O" rings, and gaskets.
- b. Discard defective converter and pump.
- c. Thoroughly clean sump filter components. Reassemble in original order and tighten bolt (11) to 70-75 inch pounds.

d. Examine bore of manifold (4) carefully. If it is grooved or pitted, clean it up with a light honing. If the blemishes are so deep that it requires considerable honing to clean up, discard the manifold and use a new one.

4-115. REASSEMBLY. (See figure 2-10).

- a. Reassemble in reverse order of disassembly.
- b. Use new seals and gaskets.
- c. When reinstalling lock nuts on pinion shaft adjust per paragraphs 4-120 u, v, and w, page 1-45.
- d. Install components previously removed, following instructions under the appropriate headings in this manual.

4-116. TRANSMISSION. (See figure 2-16).

4-117. REMOVAL.

- a. Removal of the entire assembly is accomplished as explained in paragraph 4-112.
- b. Remove bolts holding transmission case to differential case.
- c. Remove control valve as explained in paragraph 4-101.

4-118. DISASSEMBLY. (See figure 2-16).

a. Remove the bearing cap over the end of the pinion shaft. Remove the pump. Straighten out bent tabs of lock washer (35) and remove nuts (34).




Fig. 1-47. Pinion shaft removal

1. Pump
 2. Bearing cap removed
 3. Straighten out tabs and remove nuts
- b. Remove ball bearing from transmission case. Bearing cone and cup (30 and 31) will come off with ease.
 - c. Remove shaft (32). Turn case over so open side is up. Set it on blocks high enough so pinion and manifold are clear of bench.
 - d. Remove snap ring (29) and remove gear (27).

e. Lift the entire clutch assembly out of the case.

f. Remove snap rings (29) and gear (27). Remove pinion shaft (26) from case. Remove cone and cup (32 and 33). Remove gear (27) and thrust washers (39).

g. Remove retainer ring (25). Remove retainer (24) with ring (23) and collector ring (21) with "O" ring (22).

h. Remove bearing (23) from shaft. Remove thrust washer (19), gears (15 and 16), and thrust washer (15). Mark shaft in relation to the housing and remove shaft (12). (Drive shaft from splined end, use a soft driver).

i. Remove retainer ring (7) and remove back-up ring (5), and friction plates and backing plates (3 and 4). Keep the parts for each side of the assembly separate.

j. To remove the piston (8) it will be necessary to compress spring (9) and remove snap ring (11).

NOTE

An adaptor similar to the one shown in figure 1-48 may be made from a length of 3-1/2 inch pipe. Cut approximately a 3 inch slice out of one side and weld a strap across one end.




Fig. 1-48. Compressing spring

1. Adaptor
2. Spring retainer
3. Snap ring

k. Turn the housing over, hold it square with the bench, and drop it down flat on the bench to dislodge the piston and ring. Remove the rings (6 and 8) from the piston and hub.

l. Repeat the above procedure to disassemble the other side of the clutch housing.




Fig. 1-49. Sealing rings

1. Piston ring
2. Oil seal ring

m. Remove oil seal rings (13) and quad rings (14) from shaft.

n. Remove manifold (4, figure 2-15) from case.

4-118. REPAIR.

a. Clean all parts thoroughly and examine them carefully. Make sure the oil passages in the shaft and pistons are clear. Discard any worn or damaged parts.

b. We recommend using new quad rings (14) each time the unit is disassembled. The oil seal rings (13) should be replaced only if they are worn or damaged. Check the ball plugs in the end of the shaft. Drive tight with a hammer and punch if necessary.

c. Examine bushings (17) on gears -- if they are damaged, press them out, and press in new ones.

d. Examine all bearings -- discard any that are unserviceable.

4-120. REASSEMBLY. (See figure 2-16).

NOTE

Unless otherwise indicated, torque 5/16 inch bolts to 15 foot pounds, and 3/8 inch bolts to 35 foot pounds. Do not use Permatex on gaskets.

a. Assemble in reverse order of disassembly.

b. Coat the quad rings (14) with a light film of clean chassis lubricant and install them in the grooves in the shaft. Coat the oil seal rings with chassis lubricant.

c. Install oil seal ring (8) in hub and piston ring (6) in piston. Coat the rings lightly with clean chassis lube.




Fig. 1-50. Input shaft

1. Oil seal rings
2. Quad rings

d. Note the position of the bleed hole in the piston, and the lube hole in the splined portion of the hub. Mark the unsplined hub in line with the lube hole. The piston must be installed with the bleed hole 90 degrees from the lube hole. (When the opposite piston is installed, the bleed hole must be 90 degrees from the lube hole in the opposite direction, so the bleed holes are 180 degrees apart).




Fig. 1-51. Piston and housing

1. Bleed hole, 90° from lube hole
2. Lube hole
3. Mark on unsplined hub

e. Start the piston very carefully on the hub -- tap it gently all around the edge to allow the ring to enter its bore without damage. Be sure the piston is fully seated all the way around.

f. Place spring (9) and retainer (10) on piston, compress spring, and secure with snap ring (11). (See figure 1-48).




Fig. 1-52. Installing piston

- l. Tap gently all the way around
- g. Install the friction plates (3) and backing plates (4).

IMPORTANT

A friction plate (with internal teeth) must be used at both ends of the clutch pack. Install the plates alternately, using 3 friction plates and 2 backing plates in each clutch pack.

- h. Install the back-up ring (5) and secure the pack with the retainer ring (7). Make sure the ring is firmly seated in the groove.

1. Install the other clutch pack in the housing, locating the bleed hole 180 degrees from the bleed hole in the other piston.

- j. If new parts are being used, note the position of the tube hole in the splined portion of the hub, and place a mark on the unsplined hub, in line with the hole. (The shaft must be inserted from the unsplined end of the hub). See figure 1-53.




Fig. 1-53. Shaft installed

1. Oil holes in line with mark
2. Mark in line with tube hole in hub

- k. Insert the splined end of the shaft into the unsplined hub of the housing. Push the shaft gently in place (to avoid damaging the quad rings), with the oil holes in the shaft in line with the mark previously made. Be sure the shaft splines are fully engaged in the hub splines.

- l. Place a round thrust washer (18) over each end of the shaft. Place 28 tooth gear (15) over splined end of shaft; place 27 tooth gear (16) over opposite end of shaft.

- m. Place a notched thrust washer (19) over each end of the shaft. Press bearings (20) onto the shaft.

- n. Examine the piston ring in the retainer and the "O" ring in the collector ring. If they are worn or damaged, they should be replaced. Coat with a light film of chassis lube.




Fig. 1-54. Collector ring and retainer

1. "O" ring in collector ring
2. Piston ring in retainer

- o. Install the retainer and piston ring on the shaft; and secure with retainer ring (25).




Fig. 1-55. Retainer installed

1. Retainer with piston ring
2. Retainer ring

- p. Carefully install collector ring (21) over retainer (24). Side of collector ring with "O" ring must be against ball bearing.

- q. Set the case in an upright position. Install gear (30), with a thrust washer (59) on each side of it, and install shaft (38). Secure this assembly with a nut, spacer, and large washer as shown in figure 1-56. Install bearing cone and cup (32 and 33) if they have been removed, and install piston shaft (26). Install manifold and shim (1 and 5, figure 2-13).




Fig. 1-56. Reassembling transmission

1. Pinion shaft and bearing
 2. Idler gear shaft -- secured with nut, spacer, and large washer
- r. Tip the case over and back on the blocks. Install 48 tooth gear (28) on pinion shaft, with long hub toward center of case. Secure with snap ring (29).

s. Coat oil seal rings with a light film of chassis lube. Lower clutch assembly in place, using care so oil seal rings are not damaged as they move into the manifold. Install snap ring (25), gear (27), and other snap ring (26) on pinion shaft. Long hub of gear must face the center of the case.

t. Install bell housing and gasket. Torque mounting bolts to 35 foot pounds. Stake retainer (24) to small keyway in shaft.




Fig. 1-57. Staking retainer

1. Collector ring
 2. Stake retainer to keyway
- u. Pinion shaft bearing adjustment:

1. Determine pinion shaft rolling torque with zero bearing preload.
2. Install adjusting nut (34) with beveled side out, and tighten until rolling torque is INCREASED by 33 to 40 inch pounds.
3. Mount a dial indicator on the machined face of the transmission case, as near as possible to the gear end of the pinion shaft.

4. Place the dial indicator point on the face of the pinion shaft. Do not readjust or relocate dial indicator base or pointer during the tests.
5. Support the transmission assembly on the surface of the bell housing, and apply a 5000 pound load on the gear end of the pinion shaft with an arbor press or other suitable device. Axial movement of the pinion shaft must not exceed .002 inch.
6. Turn the unit over and support it on the transmission housing mounting face. Apply a 5000 pound load to the threaded end of the pinion shaft. Axial movement must not exceed .003 inch.
7. Install lockwasher. Install second nut (34) with beveled side toward first nut. Tighten second nut to 60 to 80 ft-lbs. torque and bend at least one tang of the washer into a slot in each nut.
8. Recheck the total rolling torque to be sure it is correct after tightening the outer nut.

v. See paragraphs 4-94 or 4-98, and following, for ring gear and pinion adjustment. See paragraphs 4-104 or 4-109, and following for installing control valve. Install remaining components in reverse order of disassembly.

NOTE: When installing converter, it must turn freely when transmission case is bolted to crankcase, but before drive plate is bolted to flywheel.

4-121. HYDRAULIC PUMP. (See figure 2-27).

4-122. REMOVAL.

a. Drain hydraulic reservoir. Disconnect hydraulic lines from pump. Disconnect governor linkage. Remove four bolts holding radiator to frame -- it is not necessary to remove radiator hoses.

b. Remove the nut from the long bolt which passes completely through the upper side of the governor and pump. Loosen the lower bolt which passes through the governor and is threaded into the pump body, until the threads are clear of the pump.

c. Raise radiator enough so long upper bolt can be pulled back far enough to clear pump. Remove pump -- bolts can be left in far enough to hold governor in place.

4-123. DISASSEMBLY. (See figure 2-27).

- a. Remove the elastic stop nut and remove gear (32) and woodruff key.
- b. Remove bolts (4 and 5) and separate rear cover (3 or 3A), body (2), and front cover (7). Remove seal (9), gasket (10), spacer (11), and gasket (12).
- c. Remove bearings (15) and gears (13 and 14). Remove seal (8) from front cover.
- d. If lift truck has power steering, remove flow divider valve assembly (16) and "O" rings (29, 30, and 31).

4-124. REPAIR.

- a. Clean all parts thoroughly and examine them carefully.
- b. Discard any damaged seals, gaskets, and "O" rings.
- c. Place bearings on gear shafts -- if there is excessive play, install new components.
- d. Discard gears with cracks or broken or chipped teeth.

4-125. REASSEMBLY. (See Figure 2-27).

- a. Assemble in reverse order of disassembly.
- b. When installing seal (3), place a light coating of No. 3 Permatex in hole of cover (7). Install seal with lip to inside and stake tightly to cover.
- c. Torque mounting bolts (4 and 5) to 28 to 32 foot pounds.
- d. Power steering relief pressure is to be 1100 PSI, plus or minus 50 PSI. Adjust pressure by turning adjusting screw (1, figure 1-53). Turn screw in to increase pressure. When desired pressure is attained, stake screw to cartridge, at both ends of slot.




Fig. 1-53. Power steering pressure adjustment

1. Adjusting screw

4-126. MAST CONTROL VALVE. (See figure 2-23).

4-127. REMOVAL.

- a. Disconnect hydraulic lines and linkages. Cap ends of lines to prevent the entry of dirt or other foreign material.
- b. Remove valve body from support plate.

4-128. DISASSEMBLY. (See figure 2-23).

- a. Remove ball check plug (11), O' ring (22), and check valve plunger (13).
- b. Remove cup (22), gasket (21), shim (20), washer (19), spring and guide (16 and 17). Remove ball (18). Remove valve seat (14), "O" ring (15), and plunger (13).

- c. Remove rubber bonnet (13), strap ring (9), and disc (8).
- d. Remove bolt (10), lock washer (7), stop collar (3), centering spring (5), and stop washer (4).
- e. Push spool into housing from front of valve (control handle end) until front seal (2) is exposed, then remove front seal. Pull spool out of housing from front end, being very careful that neither spool nor bore is damaged. Remove rear seal (2).

4-129. REPAIR.

- a. Clean the seal grooves thoroughly.
- b. Install new seals, "O" rings, and gasket (21).
- c. Examine all parts carefully and replace any damaged components. If a spool or the valve body is damaged, the entire assembly must be replaced.

4-130. REASSEMBLY. (See figure 2-23). Reassemble in reverse order of disassembly.

- a. Wash all parts thoroughly in a mild solvent.
- b. The spools MUST be installed in the ports from which they were removed (the spool with 2 grooves must be installed in the port nearest the inlet side of the valve.) Install the spool from the front of the valve, until the spool end reaches the rear seal groove.
- c. Dip new seal in clean hydraulic fluid and place seal in seat groove, with the "U" cup of the seal toward the valve body. Straighten the seal by running a smooth rod around the exposed surface of the seal until it fits perfectly.
- d. Push the spool further into the valve body with a rotating movement, to ease the spool through the rear seal. Push the spool in just far enough to expose the front seal groove. Dip new seal in clean hydraulic fluid and install front seal with the "U" cup toward the valve body and straighten seal as explained previously.
- e. Push spool gently forward with a rotating motion to ease the spool through the front seal. Position spool with 1/4 inch of polished surface of the spool exposed at the front of valve.

- f. Install new rubber bonnet (13).
- g. Install check valve assembly with new "O" ring (12). Tighten plug (11) to 30 foot pounds.
- h. Install relief valve assembly, with new "O" ring (16). Tighten valve seat (14) securely. Install ball (18), guide (17), and spring (16). Use sufficient washers (19) or shims (20), or both, to obtain the relief pressure specified in Fig. 1-3. Each washer (19) affects the pressure approximately 300 psi; each shim (20) affects the pressure approximately 50 psi. Remove the front plate and the pipe plug from either tee shown in figure 1-29, install a gage and check the pressure.

i. Install new gasket (21). Tighten cap (22) to 45 foot pounds.



Fig. 1-59. Power system test ports

1. Test ports

4-131. TILT CYLINDERS. (See figure 2-30).

4-132. REMOVAL.

a. Tilt mast forward and place logs on floor. Secure mast with hoist or other means to keep it from tipping. Remove hydraulic hoses.

b. Remove socket head set screw from rear pin and drive out roll pin from front pin.

c. Thread a 3/8-16 UNC-2B bolt into the end of each pin to assist in pulling out the pins. Remove the cylinder to the front.




Fig. 1-60. Removing tilt cylinder

1. Roll pin
2. Set screw

4-133. DISASSEMBLY. (See figure 2-30).

a. Drain cylinder by moving rod back and forth.

b. Unscrew threaded washer (18). Pull piston rod (10) and internal parts out of shell (3 or 4).

c. Remove nut (11). Pull remaining components off rod.

4-134. REPAIR.

a. Replace all parts contained in cylinder repair kit (55R32). See page 2-80.

b. Examine bushings (22) or bearings (23). If they are badly worn, they should be replaced.

c. If piston halves (5 and 6) or bore of shell (3 or 4) are badly scored, install new parts.

4-135. REASSEMBLY. (See figure 2-30).

a. Reassemble in reverse order of disassembly. Dip all "O" rings and packing in clean hydraulic oil to facilitate installation. Install all parts from piston end of rod.

b. If a new cylinder is installed, or if the rod ends (21) have been removed, loosen the clamp bolt in rod end. Place a punch through the hole in the rod, and align cylinders to square up the mast.




Fig. 1-61. Aligning cylinders

1. Insert punch here

4-136. LIFT CYLINDER. (See figures 2-82 or 2-33).

4-137. REMOVAL.

a. Lower links to ground. Disconnect lift chains and hydraulic lines.

b. Remove set screw and remove piston head (26, figure 2-31) from mast. Remove the cap screw through the lug at the base of the cylinder. Lift the cylinder up and out.

4-138. DISASSEMBLY. (See figures 2-32 or 2-33).

a. Remove retainer (17), with "O" ring (18), wiper ring (19), and garter spring (16).

b. Remove plunger (8) and spacer (32). Remove snap ring (23) to remove piston (18), packing (20), "O" ring (21), and back-up ring (22).

c. Remove retainer (9), with "O" ring (10), wiper ring

(7), and garter spring (8). Remove bottom head screw (3) and seal (4).

d. Loosen lock nut (20) and unscrew cylinder head (27). Remove "O" ring (28) and back-up ring (28). If cylinder has lock nut (23) that is 3/4" thick, remove nylon ring (29). This nylon ring is not used on cylinders having lock nut 1/2" thick.

e. The intermediate tube (3) and its components may then be removed through the bottom of the cylinder as assembly. Use extreme care in this removal to avoid scratching or scoring the other sealing surfaces.

f. Remove snap ring (26). Push bearing (24) onto the tube far enough to expose retainer ring (25). Remove retainer ring and bearing.

g. Remove bushing (11), with packing (14), "O" ring (12), and back-up ring (13).

NOTE: Packing (14) may be serviced without disassembling the entire cylinder as follows: Remove retainer (8) and remove the packing with a small screwdriver or similar tool. Use extreme care so as not to mar the sealing or outer surface of the intermediate tube.

h. Remove spring (30), washer (24), and spacer (5c). When disassembling a 4 inch cylinder, also remove hat-shaped oil restrictor (38, figure 2-32).

4-139. REPAIR.

a. Examine all parts carefully for scratches, pitting, wear or other damage.

b. Replace items identified by an asterisk (*) on pages 2-92 or 2-94, depending on cylinder diameter.

4-140. REASSEMBLY. (See figures 2-32 or 2-33.) Reassemble in reverse order of disassembly.

a. Dip new "O" rings, seals, and packing in clean hydraulic oil to facilitate assembly and to help prevent damage to these parts.

b. Coat the full length of plunger (8) with a film of Lubriplate No. 110, or equal.

c. Install cylinder on mast assembly, with protrusion on bottom of cylinder in guide hole in base of mast. Install cap screw through flange on cylinder head (27) into tapped hole in base of outer rail assembly (1, figure 2-31). Allow a minimum 1/8" clearance between bottom of cap screw head and flange. Secure with jam nut.

d. Install piston head (24, figure 2-31), secure with set screw, and bolt head to mast.

e. Reinstall hydraulic lines. Secure vent hose with strap and spacer. Install lift chains and adjust per instructions in paragraph 4-145.

f. Check hydraulic fluid level in tank and replenish as necessary. Strap engine and run at idle speed. Pull back

oil lift control lever to fill the cylinder. Cycle the cylinder several times by raising and lowering the mast assembly.

g. Bleed the system as follows: Raise the mast high enough to expose the bleed screw. Loosen the screw to allow the air to escape. Raise and lower the mast until pure fluid -- WITH NO BUBBLES -- is being forced out around the bleed screw, then, tighten the screw. DO NOT RAISE THE MAST ABOVE THE FREE LIFT POSITION WHILE BLEEDING. Replenish the fluid in the tank if necessary.




Fig 1-62. Bleeding lift cylinder

1. Bleed screw

4-141. MAST AND RELATED PARTS. (See figure 2-31).

4-142. REMOVAL.

a. Remove forks (31) and safety rack (14). Disconnect hydraulic oil and vent lines.

b. Disconnect tilt cylinders from mast as described in paragraph 4-132.

c. Remove bearing caps (2) and bushing (3). Move the mast away from the truck and lay it down on its bank.

4-143. REASSEMBLY. (See figure 2-31.)

a. Remove lift cylinder as described in paragraph 4-137.

b. Remove snap rings and anchor pins (18). Slide inner rail assembly (4) toward top of outer rail assembly (1) enough to clear carriage assembly (11). Lift carriage away from rails.

c. Remove stop blocks (26). Slide the inner rail toward the top of the outer rail until only the lower set of mast rollers (7) are engaged in the outer rail. Rotate inner rail upward, support in raised position, and remove shoes and films (3 and 4) from upper end of mast. Slide inner rail from outer rail.

6. Remove roller assemblies from carriage and inner rail. Remove snap ring (10), and remove roller (7) from shaft. Remove snap ring (8) and bearing (6) from roller.

7. Remove cross bearing pin (13) and bearing (12).

8. Drive roll pin into pin (36) just far enough to allow removal of pin. DO NOT DRIVE ROLL PIN IN FAR ENOUGH TO IMBED IT IN THE CASTING. Remove pin, sleeve (27 and 28), and bearing (29).

9. Remove cap (36), plunger (37), and spring (40). Remove latch (35), bushing (38), and pin (37).

4-144. REPAIR. Examine all parts carefully for wear or damage, particularly bushings and bearings. Discard all unserviceable parts.

4-145. REASSEMBLY. Reassemble in reverse order of disassembly.

a. Stake cross bearing pins (13) from front side of carriage, at both ends of slot in pin.

b. Use shims (6) under mast shoes (5) to obtain minimum clearance between inner and outer rails.

c. To adjust lift chains, first move forks to the extreme ends of fork bar and lower forks until lift cylinder is completely collapsed. Adjusting is to be done with no load on forks. Move the upright to a vertical position.




Fig. 1-63. Adjusting lift chains

1. Turn rod into anchor
2. Spherical nuts
3. 1/8" clearance required
4. Tension scale
5. Fork to floor -- 0 to 3/4"

d. Turn rod into chain anchors approximately 1-1/4 inches (at 1, figure 1-63). Adjust spherical nuts (2, figure 1-63) for fork-to-floor clearance of 0 to 3/4 inch (both sides).

e. Raise upright to its fullest height and check to insure a clearance at 3, figure 1-63. If stop blocks are touching, readjust spherical nuts to obtain a clearance of at least 1/8 inch.

f. Attach tension scale as shown (4, figure 1-63) and measure deflection in chain. Attach the scale to the other chain at the same height, apply the same pull, and measure the deflection. Adjust spherical nuts to equalize deflection with the same pull applied. Tighten jam nuts securely.

g. Check again for clearance at (3) with upright fully extended. Adjust as necessary.

4-146. COUNTERWEIGHT.

4-147. REMOVAL, DISASSEMBLY, AND REPAIR. (See figure 1-64).

a. Remove overhead guard. Remove bolt at bottom of counterweight. Disconnect tall light wires.

b. Insert a suitable hook or eye bolt through the hole in the counterweight and secure with large flat washers and nut.

c. Use a suitable hoist and lift the counterweight straight up and off the truck.



Fig. 1-64. Removing counterweight

4-148. REASSEMBLY. Assembly consists of replacing the counterweight on truck.

Section III. Engine Repair and Overhaul

4-149. GENERAL.

a. This section includes instructions for repairs and overhaul of the component units of the engine.

b. Provide a clean place to work and clean the engine exterior before you start disassembling -- dirt causes engine failures. Many shop tools have been developed to save time and assure good workmanship; these should be included in your equipment.

4-150. CARBURETOR. (See figure 2-7).

a. Loosen screw (41) and pull the choke cable out of sleeve (40).

b. Remove the air intake hose, the fuel line, and the linkage. Remove the cap screws that hold the carburetor to the manifold.

c. Disassembly of the carburetor is complete upon removal of all attaching parts of each component. The following steps outline the various troubles and which components cause them.

d. Some factors other than faulty carburetor operation that could contribute to improper operation of the engine are as follows: Faulty ignition system, incorrect timing, air cleaner restrictions, or air leaks. Check for and correct any of these conditions that may exist.

e. If the engine is not idling properly, check the gasket between the manifold and cylinder head and the gasket between the carburetor and manifold. Air leaks at these points will cause erratic idling.

f. The principal parts subject to wear in the carburetor are the throttle shaft (8) and the float valve and seat assembly (22).

g. Wear of the throttle shaft results in more air entering the carburetor than is necessary. This condition results in too lean a gas mixture when the engine is idling. To compensate for the increased air supply, it is usually necessary to increase the idle gas mixture; this in turn affects fuel economy. In addition, this excess air is unfiltered, and could cause serious damage to the engine.

h. Excessive wear of the float valve and seat will result in too high a fuel level in the carburetor bowl. This high fuel level causes excessive fuel consumption, crankcase oil dilution, and difficulty in maintaining satisfactory adjustment of the carburetor.

i. If the fuel level is too low, the engine will not respond quickly, and it will be very difficult to maintain a satisfactory carburetor adjustment. A sticking float valve or float arm could cause a low fuel level.

j. Inspect all parts taken from the carburetor. Replace any that are damaged or worn excessively. Discard all

gaskets, the choke shaft packing (32), and the throttle shaft packing (9).

k. Use a cleaning solution, and thoroughly clean the throttle body (1), the fuel bowl (17), and all parts being used again.

l. Assemble the carburetor in reverse order of disassembly.

m. The float (20) controls the fuel level in the carburetor bowl. Attach the float to the throttle body (1) and turn the throttle body upside down. Measure the distance of the float from the milled surface of the throttle body. This distance should be 1/4 inch. If necessary, bend the float arms in either direction to obtain the correct dimension.

n. Secure carburetor to manifold, and make hose, tube, cable, and linkage connections. Adjust carburetor as explained in paragraph 2-16.

4-151. GOVERNOR. (See figure 2-8).

a. To remove the governor, first disconnect the linkage.

b. Remove the fan and the four bolts holding the radiator. Raise the radiator high enough to allow removal of the governor mounting bolts.

c. Remove drive plate (17) and base (12). Remove weight and shaft assembly.

d. Remove snap ring (20) and remove washers (21 and 22), base (19), thrust bearing (18), and upper race (23).

e. Drive groove pin out of fork (8), and remove lever (7), fork (8), and spring (3).

f. Examine all parts carefully and discard any that are unserviceable. Races (18 and 23) must slide freely on shaft.

g. When balls (14) are to the bottom of the slots, there must be .230 to .240 inch space allowed for movement of upper race (23). Snap ring (20) acts as a stop. Use washers (22) as required.

h. Lubrication is supplied the governor by splash from the gear train through the holes in the governor base (12). Make sure the governor parts are being well supplied with oil.

i. When governor is installed, adjust engine speed as explained in paragraph 5-19.

4-152. CYLINDER HEAD.

a. The cylinder head is an important part of the engine assembly since it contains the complete combustion chamber and cooled passage for water flow. Remove the cylinder head in the following sequence:

1. Drain water from engine and disconnect radiator hose.
2. Loosen and remove the nuts holding the cylinder head to the block.
3. Lift the cylinder head off the engine and carry to a clean bench for further disassembly.

b. Remove all carbon from combustion areas using a scraper and wire brush.




Fig. 1-65. Cleaning carbon from combustion chamber

c. Clean the cylinder head thoroughly with a solvent or degreasing solution and blow it off with air pressure.

d. Make sure that gasket contact surfaces on the head and block are clean, smooth and flat.

e. Check flatness with straight edge and feeler gauge in three positions lengthwise and five crosswise. The maximum permissible is .004 in the center lengthwise, gradually decreasing towards the ends, or .003 crosswise or in localized low spots.



Fig. 1-66. Checking cylinder head flatness lengthwise, (.004 max.)

4-168. VALVE REMOVAL.

a. With a valve spring lifter, compress the springs and remove the locks or pins from the valve stems which are in a closed position. Close the other valves by rotating the crankshaft and remove the locks (or pins) from these valves in the same manner. Remove all valves and place



Fig. 1-67. Checking cylinder head flatness crosswise, (.003 max.)

in order in a rack, with holes numbered for both intake and exhaust valves so they will not be mixed in handling.



Fig. 1-68. Valve removal



Fig. 1-69. Valves in rack

4-169. VALVE GUIDES

a. Clean the valve stem guides, removing lacquer or other deposits by running a valve guide cleaner or wire brush through the guides.

b. Check guides for wear by using "Go and No-Go" plug gage or a telescope gage and 1" micrometer. Nominal diameter of guide hole is .3432-.3422 for both intake and exhaust valves. Replace all guides that are worn ball-mounted and have increased .0016" or more in diameter. Remove all guides when necessary by driving them out from the combustion chamber side with a driver slightly smaller than the outside diameter of the valve guide.




Fig. 1-70. Removing valve guides

c. Using a suitable driver, replace worn guides as required, from the combustion side, and locate so top of guide is 1-15/32 inches below face of block (both intake and exhaust valve guides).




Fig. 1-71. Valve guide locations

d. Ream new valve stem guides to required size, using a straight center ground to correct size and having a pilot which will properly locate it and keep it from wandering from the original reamed hole.

CAUTION

When replacing guides that are ferrox coated do not ream since these are all pre-reamed before being ferrox coated - any further reaming will remove the coating.

4-155. VALVE SEAT INSERTS

a. The exhaust valve seat insert is held in place by a shrink fit.

b. Inspect all exhaust valve inserts in the block and replace any that are loose, cracked or otherwise damaged. Use puller for removing faulty insert as shown in illustration.




Fig. 1-72. Removing exhaust valve seat insert

c. When required to replace with new insert, clean and counterbore for .010 larger insert using counterbore tool with correct firing pilot.

d. When machining the counterbore, be sure to go deep enough with the tool to clean up the bottom so that the insert will have full contact to carry away the heat.

e. We do not recommend installing new inserts having the same outside diameter as the one removed. The following chart shows the dimensions of Standard Inserts and counterbores. See figure 1-73.

Outside Dia. of Insert (A).....	1.3485-1.3475
Inside Dia. of Ctrbore (B).....	1.3445-1.3435




Fig. 1-73. Insert and counterbore

f. When OVERSIZE inserts are used, dimensions of the insert and counterbore increase proportionately (.010, .020, .030 -- depending on the oversize).

g. New insert installation should have a press fit. Chill insert in container with dry ice for 20 minutes before assembling.

h. Insert may then be installed in the counterbore using a piloted driver, tapping in place with very light hammer blows, without the possibility of shearing the side walls. This assures it being seated firmly on the bottom of the counterbore.



Fig. 1-74. Installing valve seat insert with driver

4-166. VALVE SEATS

a. Grind intake valve seats at a 30° angle, exhaust valve seats at a 45° angle. Before removing the arbor, indicate the seats. Total indicator reading of the run-out must not exceed .002". Use a pilot having a solid stem with a long taper, as all valve seats must be ground concentric and square with either new or worn valve stem guide holes,




Fig. 1-75. Grinding valve seat



Fig. 1-76. Indicating valve seat

4-167. VALVES

a. Inspect valves for condition and replace any that are "nicked", cracked or burned, also any on which valve stems are bent or worn more than .002" over the maximum allowable limits. Reface or replace all valves.

VALVE SPECIFICATIONS

	Intake	Exhaust
Stem Diameter	.3414-.3461	.3386-.3477
Clearance Limits	.0026-.0068	.0055-.0097
Desired Clearance in Guide	.0015	.0045
Seat Angle	30°	45°




Fig. 1-77. Allowable head thickness of refaced valves

b. All valves having less than 50% margin thickness (outer edge of valve head) after refacing has been completed must be replaced. To check this dimension, compare the refaced valve with a new valve.




Fig. 1-78. Checking valve face in "V" blocks

c. Check all refaced or new valves in V-blocks with indicator to determine if the contact face is true with the stem within .002. If not, repeat the refacing operation.

d. After the valves and seats have been refaced and re-ground, coat the seat lightly with Prussian blue and drop the valve into position, oscillating it slightly to transfer the blue pattern to the valve face. This should show a




Fig. 1-79. Method of narrowing valve seats

contact width of $1/16$ " to $3/32$ " and should fall well within the width of the valve face, leaving at least $1/64$ " on either side where the blue does not show. If the contact is over $3/32$ " wide, the seat in the head may be narrowed by using a 15° stone to reduce the outside diameter or using a 60° or 75° stone to increase the inside diameter.




Fig. 1-80. Valve position in block

e. Never allow valves to set down inside the seat.

f. After the narrowed-down seat is brought within specifications, the seat should be retouched lightly with the original stone to remove burrs or feathered edge.

A poor valve grinding job cannot be corrected by valve lapping.

g. Coat the valve stem with a light film of engine oil.

4-159. VALVE SPRINGS

a. Check all valve springs on a spring tester (Fig. 1-81) to make sure they meet specifications regarding weight and length. Springs, when compressed to "valve open" or "valve closed" length, must fall within specifications shown below when new, and must not show more than 10% loss to re-use.

VALVE SPRING SPECIFICATIONS

Outside diameter	$32/32$ "
Length - valve closed	$1-45/64$ "
Load - valve closed	47 to 53 lbs.
Wear limits - min. load	42 lbs.
Length - valve open	$1-27/64$ "
Load - valve open	96 to 104 lbs.
Wear limits - min. load	86 lbs.

b. Reassemble the valves and springs in the block with the retainer and retainer lock.

4-159. CYLINDER BLOCK

a. Checking bore wear.

1. Clean the ring of carbon from around the top of the cylinder bore formed above the travel of the top ring.




Fig. 1-81. Valve spring tester

2. Determine the original diameter of the cylinder barrel by checking this unworn area with a pair of inside micrometers at intervals of approximately 45° .




Fig. 1-82. Measuring original bore diameter above ring travel.

3. Check in same manner the top of the ring travel area approximately $1/4"$ below the shoulder.

4. The maximum difference in the above checks, indicates the amount of cylinder bore wear. If less than .008, re-ringing will be suitable, if over .008 re-boring is recommended.

h. Preparing cylinder walls for re-ringing or re-boring.

1. Ridge ream the cylinders to remove the un-worn area at the top so that the new rings when assembled will not bump and distort both themselves and the piston lands.



Fig. 1-83. Ridge reaming top of cylinder bore

2. Several good makes of ridge reamers are available which will ream the top of the bore in direct relation to the worn area so that should the worn area be off center slightly there will be no partial ridge remaining.

3. Drain the crankcase and remove the oil pan.

4. Remove the cap screws holding the connecting rod caps to the rod. KEEP THE CAP AND BOLTS IN NUMERICAL ORDER SO THAT WHEN THE PISTONS AND RODS ARE REMOVED FROM THE ENGINE, THE CAP CAN BE REASSEMBLED AND KEPT WITH ITS MATING PART.

5. Push the pistons and connecting rods up through the top of the cylinder, carrying with them all the carbon and metal chips left from the cleaning and ridge reaming operation. WHEN DOING THIS, EVERY PRECAUTION MUST BE TAKEN TO PREVENT DAMAGE TO CYLINDER BORES BY THE SHARP CORNERS AND ROUGH EDGES OF THE CONNECTING RODS AND BOLTS.

6. It is important to remove the glaze on the cylinder bores by using a glaze breaker in order to assure quick seating of the new piston rings. If the cylinder glaze is not removed, you will have no assurance as to when the rings will begin to function properly and control the oil.

7. The following step by step procedure is recommended:

- A. Cover the entire crankshaft with a clean, slightly oily cloth to prevent abrasives and dirt from getting on the crankshaft.
- B. Remove the excess carbon deposits from the top of the cylinder wall before beginning the glaze breaking operation. (This is to prevent loading the stones).
- C. Surface hone each cylinder several times; move the glaze breaker up and down in the cylinder rapidly to produce a 45 degree cross




Fig. 1-84. Removing cylinder wall glaze.

hatch pattern similar to that illustrated.

D. Clean the loose abrasives from the stones by using kerosene and a wire brush. (Do not use thinner to clean the stones because of the explosion hazard). Dry the glaze breaker before moving to the next cylinder.

E. The most desirable cylinder finish is 30 - 40 micro inches with this finish the asperities in the surface tend to keep the supply of lubrication between the mating parts. This finish can be obtained by using 220 grit stones on the glaze breaker.

F. Clean all bores thoroughly with a clean oiled rag to pick up all the small particles of dirt that may be embedded in the walls. Follow this with a clean cloth to make certain the walls are CLEAN.




Fig. 1-85. Desirable cross hatch pattern obtained with a glaze breaker.

4-100. PISTONS

a. Check the pistons for excessive ring groove wear, and replace any that exceed the allowable limits in the Limits and Clearance Data Chart, page 1-86.

b. The cylinder walls and pistons must be perfectly clean and dry when fitting pistons to the cylinder bores. Pistons should be fitted with the block and pistons at room temperature (68° - 76° F).

PISTON FIT ON STANDARD PISTONS WITH 5 TO 10 POUND PULL003"

c. Check the piston fit in the bore, using a half-inch wide strip of .003" feeler stock, the feeler being attached to a small scale of approximately 15 pounds capacity.



Fig. 1-86. Checking piston fit in bore.

d. When the correct fit is obtained you must be able to withdraw the feeler with a pull of 5-10 pounds on the scale, with the feeler inserted between the piston and the cylinder midway between the piston pin bosses where the diameter of the piston is the greatest. Check the fit of the piston when it is approximately 2" down in the cylinder bore in an inverted position.

4-101. PISTON PINS.

a. Check the bushing in the upper end of the connecting rod for wear. If worn and you are using the original pistons with a service set of rings, an oversize piston pin may be obtained in .003 or .005" oversize.

b. The piston pin hole in the piston and the bushing in the connecting rod may be bored to increase their diameter to obtain the desired fit as shown in the Limits and Clearance Chart, page 1-86.

Note that while the chart specifies a light push fit of the pin in the piston, there is a definite clearance of the piston pin in the connecting rod.

4-102. CONNECTING ROD.

a. Replace the bushing in the connecting rod if new pistons are used. Using an arbor press, press out the old bushing and press in the new one - after which the bushing must be bored to obtain the correct fit of the pin in the bushings as shown in Limits and Clearance Chart, page 1-86.




Fig. 1-87. Pressing in piston pin bushing

b. If there is an excess of stock in the piston pin bushing, it may bereamed first, then honed. In any event, the final operation should be done with a hone to obtain the desired fit with better than 75% bearing area on the pin.

4-163. PISTON AND CONNECTING ROD ASSEMBLY.

a. Assemble the pistons on the connecting rod by first heating them in some form of oven or in hot water to a minimum temperature of 100° F. When heated, the piston pin will enter the piston very easily and can be tapped through the connecting rod and into place without disrocting the piston.




Fig. 1-88. Checking connecting rod for twist

b. The snap rings must be assembled in the grooves, making sure they are fully seated in place.

c. The piston pin hole in the connecting rod must be parallel to and in plane with, the large bore in the best-lag end of the connecting rod.

d. This may be checked on a fixture with the piston pin assembled in the rod before assembling the piston; but regardless of this preliminary check, the completed piston and rod assembly must be rechecked and there must not be more than .002" twist or out of squareness checked over a spread of approximately 4 inches. The connecting rod can be bent or twisted to meet this specification.




Fig. 1-89. Chucking connecting rod for alignment

e. Pistons are cam and taper ground, and this must be taken into consideration when checking alignment of the assembly, since the diameter in line with the piston pin would be less at the top of the skirt than at the bottom.

4-164. PISTON RINGS.

a. Check the piston rings in the cylinders for gap.

b. To do this, insert a piston in the cylinder bore in an inverted position and then insert each ring one at a time about 2" down in the bore and bring the bottom edge of the piston up against the ring to square it up in the cylinder bore.

c. Check the gap between the ends of the ring with a feeler gauge in accordance with specifications shown in the Limits and Clearance chart. If any of the rings do not have enough gap, they may be filed either in a ring filing fixture or by clamping the file in a vise and holding the two ends against opposite sides of the file.




Fig. 1-90. Checking connecting rod assembly for alignment




Fig. 1-91. Filing piston ring to increase gap

4-165. RECOMMENDED METHOD OF INSTALLING PISTON RINGS.

a. Grip the connecting rod in a vise with lead lined jaws to hold the piston firmly and roll each of the straight side rings in its groove to be sure there are no burrs or other interference with the free action of the ring in the groove.




Fig. 1-92. Installing rings with ring expander tool

b. Hold the ring tool with recess side up and place the ring in with the bottom side up. Start with the lowest ring first.

c. Some piston rings are taper faced. These are clearly marked "TOP" on the side to be up when assembled on piston.




Fig. 1-93. Install tapered rings with "top" side up

d. Position ring in the tool so the expanding fingers will fully engage both ends.

e. Apply pressure on handles so ring is completely expanded. Pass the expanded ring and tool recessed side down over the piston to the proper groove.

f. Check ring side clearance at various positions with a feeler as shown in Fig. 1-94, in accordance with tolerances shown on Limits & Clearance Chart, page 1-68.

4-193. CRANKSHAFT AND MAIN BEARINGS.

a. Using a puller, remove pulley from crankshaft.



Fig. 1-94. Checking ring clearance in groove

- b. Take out screws and remove gear cover.
- c. Drop the oil pump, by removing nut or cap screws holding pump to center main bearing cap.




Fig. 1-95. Removing crank gear

- d. Remove each main bearing cap, one at a time, and inspect the bearing and crankshaft journals.
- e. If there is any indication of flaking out, scoring or actual wear, they must be replaced.

4-367. BEARINGS.

a. Tri-metal bearings when new, are smooth and highly polished. However, a VERY FEW HOURS OF OPERATION WILL CHANGE THEIR APPEARANCE COMPLETELY. The bearing surface becomes a leaden gray in color and develops minute cracks, almost cellular in appearance as indicated in figure 1-96, which follow the pattern of

the matrix. THIS APPEARANCE IS A NATURAL CHARACTERISTIC OF THIS TYPE BEARING AND IN NO WAY INDICATES FAILURE.



Fig. 1-96. Appearance of a good bearing




Fig. 1-97. Bearing damage due to corrosion




Fig. 1-98. Scoted bearing due to dirt or lack of oil

b. If the visual inspection appears satisfactory, the bearings should be removed and checked for thickness with a ball micrometer.

c. To remove the upper half of the bearing shell use a special tool obtainable at most parts houses, which is a pin with an angled head. It may be inserted in the oil hole of the crankshaft and as the crankshaft is turned in a clockwise direction, the head of this pin picks up the bearing shell and forces it out of the bore in the block.



Fig. 1-99. Removing main bearing

d. The thickness of the bearing shells is given in the Limits and Clearance Chart, page 1-69, and if this thickness has been reduced more than .0005 beyond the maximum allowable tolerance, the bearing shell must be replaced.



Fig. 1-100. Measuring bearing thickness

e. If visual inspection of the crankshaft shows no indication of excessive wear or scoring, the clearance of the leader should be checked.

f. Check each bearing, one at a time by using a piece of Plastigage of a diameter specified to check certain clearances.

g. By placing this Plastigage in the bearing and rightening it in place, the width of the Plastigage, after cranking, determines the bearing clearance as shown in Fig. 1-101.



Fig. 1-101. Checking bearing clearance with Plastigage

CAUTION

When using this method DO NOT TURN the crankshaft, as that would destroy the Plastigage.



Fig. 1-102. Checking bearing clearance with feeler stock.

h. An alternative method is to use a piece of 1/2" feeler stock (the thickness of which should be equivalent to the maximum clearance permissible in the bearing) lengthwise, in the bearing shell, on a film of oil. Assemble the bearing cap and tighten the screws, forcing them to the specifications, - then try to turn the crankshaft by hand to determine whether or not you can feel a drag.

i. If a definite drag is felt and the piece of feeler stock is equivalent to, but no more in thickness than the maximum clearance specified, you may be sure that neither the crankshaft nor bearing are worn excessively as far as clearance is concerned.

j. When using new bearings and the crankshaft is not worn, checking with a piece of feeler stock as outlined above should lock up the crankshaft, making it possible to turn only by use of a bar or wrench.

k. If crankshaft is scored, or worn enough so that new bearings will not fit with the required clearance, it should be removed and reground.

l. Standard crankshaft may be reground to decrease the diameter a maximum of .040.

m. Before shaft is reground, it must be checked for straightness and straightened if necessary to be within .002 Indicator reading. When reground, the fillet radii must be within dimensional limits and must be perfectly blended into thrust and bearing surfaces.

CRANKSHAFT FILLET RADIUS

$3/32" \pm 1/64"$ Radius on all crankpins and mains (except test pin).

$1/8" \pm 1/64"$ Radius on test main.




Fig. 1-105. Crankshaft fillet radii

n. Connecting rod bearings and crank pins may be checked in the same manner with one exception: instead of trying to turn the crankshaft when the connecting rod bearing is tightened on it with a piece of feeler gauge assembled, try to move the connecting rod from side to side.




Fig. 1-106. Replacing bearing

a. With new bearing shells and feeler stock equivalent to the specified clearance in thickness, if the crank pin is not worn, you will quite probably have to use a hammer tap to move the rod from side to side, indicating that the clearance is well within the specified range.



Fig. 1-105. Clearing rod bearing with feeler stock.

4-106. CAMSHAFT.

a. Using a puller, remove the cam and crank gears.




Fig. 1-106. Removing cam gear with puller

1. Crankshaft gear

b. Remove the screws holding the crankshaft thrust plate to the front of the cylinder block, which makes it possible to pull the crankshaft toward out of the bearings.

c. Unless engine is lying on its side, tappets must be removed or lifted before camshaft can be pulled.

d. Remove tappet chamber covers.

e. Tappets can then be lifted out and lined up in sequence, for installation in the same location unless inspection shows that they require replacement.

f. Before pulling the camshaft completely, check the clearance of the bearing journals in the bushing. To do this use strips of feeler stock $1/4"$ wide with edges dressed with a stone to eliminate any burrs or feathered edges.

g. If clearance is equal to or greater than the amount indicated under wear limits, check the diameter of the camshaft journals to determine the next step. Excess wear at these positions require replacement of the shaft.

h. If wear is found to be in the bushings instead, these must be replaced, using precision service bushings, available for their purpose, which require no reaming, only care in assembly, to line up oil holes, and not to damage the bushings as they are being pressed in.

4-169. TAPPETS.




Fig. 1-107. Valve tappet wear comparison

a. Inspect each tappet carefully. Two or more small pits on the contact face is acceptable; more than that calls for replacement of the tappet.

b. Check the outside diameter with micrometers to determine if replacement is necessary because of wear.

c. Tappet guides or guide bushings may be checked for wear with a plug gauge or preferably with a telescope gauge and micrometer.

d. If guide bushings are used, they may be replaced and standard tappets used. If bushings are not used, the tappet bore may be reamed oversize, and oversize tappets installed.

e. When reassembling, adjust tappet clearance to .014" on both intake and exhaust valves.

CAUTION

When installing camshaft, use special care to prevent camshaft bumping and loosening expansion plug, to cause an oil leak.

4-170. TIMING GEARS.

a. Timing gears and timing gear fits must be checked carefully while the engine is being overhauled. To check the fit, use a screw driver to force the mating

teeth as far apart as possible and check this clearance with a feeler gauge. If this clearance is .002" or greater, or if the gear teeth are badly scuffed and worn, the gear must be replaced. Timing gears must be replaced in pairs.



Fig. 1-108. Checking timing gear backlash

b. Gears marked same as the original as far as sizes are concerned, should be used as replacements.

c. Examine the camshaft thrust plate carefully for scoring and wear and if any indication of either shows, a new thrust plate should be assembled without question.




Fig. 1-109. Checking camshaft end play

d. Assemble the cam gear to the camshaft by driving or pressing it on, at the same time holding the camshaft forward with a suitable bar through the fuel pump opening in the block so there is no possibility of the camshaft bumping the expansion plug at the rear end and forcing it out of position, thus causing an oil leak.

e. Check camshaft end play as shown in Fig. 1-109. End play should be .005 to .009 inch.

f. Inspect crankshaft thrust washers for wear and scoring. Replace if necessary before reassembling gear.

g. Drive the crank gear on the shaft making sure that the marked teeth on the cam gear straddle the marked tooth on the crank gear, which assures you of the crankshaft and camshaft being in time.



Fig. 1-110. Gear scoring marks

h. Check for clearance with the above gears assembled in place, since it may be possible that it is not within specifications. Repeat the operation previously outlined. Using a screwdriver pry the teeth as far apart as possible and check the clearance with a feeler gauge. If a .0015" feeler will not enter the gap the clearance is not excessive.




Fig. 1-111. Checking gear fit

i. To be certain that there is enough clearance, hold your finger at the junction of the two gears and with a light hammer tap the rim of the cam gear and note if there is vibration felt at this point.

j. If there is vibration and a .0015" feeler gauge will not enter the gap between the two gear teeth, the gear fit is within specifications.




Fig. 1-112. Torquing cam gear nut

4-171. CRANKSHAFT END PLAY.

a. Check crankshaft end play before replacing gear cover. End play must be .003 to .004". Add or remove shims so end play falls within specifications. Crank gear must be tightened firmly against shim pack when checking end play.




Fig. 1-113. Crankshaft shims, thrust washers

b. The crankshaft thrust on later engines is controlled by flanged center main bearings, which require no shims. Check end play, using a feeler gauge. If end play exceeds .006", replace flanged center main bearings. End play should be between .002 and .006".

4-172. ASSEMBLING OIL SEALS IN FILLER BLOCK AND OIL GUARD.

a. Tube type oil seals.

1. First, remove the filler block and oil guard, the latter

being the semi-circular die casting which fits in the cylinder block just to the rear of the rear bearing bore. Clean out the grooves thoroughly and clean the outer surface of this oil guard so as to remove all dried cement and grease.

2. Jute packing for crankshaft seal as it is received is approximately one-third larger in diameter than the width of the groove. To fit the grooves in the filler block, this must be crushed in a vise or flattened with a hammer on a flat surface so the jute packing is narrow enough to fit into the grooves.

3. Next, press it into the grooves of both the filler block and the oil guard. Then, using a piston pin, a smooth hammer handle or some other instrument with a rounded surface, tap this packing into the groove so that it is seated firmly and expanded so that it seizes the sides.



Fig. 1-114. Top half of rear seal

4. In its present condition the packing will protrude from the grooves at either end in varying amounts. With a sharp knife, or razor blade, cut this off flush, making the cut parallel to the surface of the casting.




Fig. 1-115. Lower half of rear seal

1. Trim jute seal flush
2. Neoprene seal

Then slip it into place, either around the crankshaft, if the engine is still assembled, or directly into the groove if the crankshaft is out.

5. Neoprene oil seal.

1. To replace neoprene seal, thoroughly clean all cement, dirt, and oil from the contacting surface of the filler block. To hold seal in place for assembly, use only a small spot of non-hardening cement in the center of the contacting surface, before inserting seal in groove. No other cement is required.




Fig. 1-116. Installing neoprene seal in rear block

1. Cement here

2. Neoprene seal on boat filler block is installed in the same manner.




Fig. 1-117. Installing neoprene seal in front block

1. Cement here

3. When replacing gear cover, cement gasket to gear cover with a quick drying gasket cement and reassemble to engine block.




Fig. 1-118. Seals in place

1. Neoprene seals

4-173. OIL PUMP.

a. The oil pump is assembled to the reaper main bearing, held in position vertically against a retained nut by studs.

b. The extended portion of the body acts as a pilot, fitting closely in a reamed hole in the main bearing web, maintaining definite relationship between the camshaft and the oil pump drive shaft.




Fig. 1-119. Oil pump removal

c. A gear assembled to the upper end of this shaft is driven by a mating gear cut on the camshaft and drives the oil pump gear which is assembled to the lower end of the pump shaft.

d. The pump shaft is carried in two bronze bushings assembled in the cast iron housing, which is also a part of the oil distributing system, transmitting oil to the drilled passages.

e. The gear type pump has a capacity well in excess of that required by the engine.

f. When the pump is removed, examine the drive gear carefully for wear, inspecting the gear on the camshaft at the same time. If scored or worn badly, both the camshaft and the gear on the pump must be replaced.

g. Examine the pick-up screen for clogging or damage.

h. Remove the cover, being careful not to damage the lead gasket which acts as a spacer as well as a gasket to seal the joint.

i. Examine the gears and pump body for any sign of wear indicating lack of clearance. The gears should have from .001 to .003 clearance in the chamber and should make no contact with the walls.




Fig. 1-120. Checking gear clearance in body

j. Inspect the cover and face of the gears for excessive wear or scoring. With the gasket assembled to the body there should be .0015-.003 clearance between the gears and the cover.



Fig. 1-121. Checking end clearance

k. Worn or scored gears can be replaced, as can a worn cover. If the body shows wear in the chamber, it can be replaced, but in a case like this a new pump would be the most economical.

l. Engine oil pressure must be maintained to specification for satisfactory engine life.

m. Pressure relief is located externally on the right-hand side, near the oil pan flange at the center. Pressure is controlled by a plunger and spring, the latter specifically for a certain range. The only adjustment variation is either to change springs or assemble or remove washers from behind the present spring. Up to four washers are permissible.




Fig. 1-122. Oil pressure relief valve

1. Washer to adjust pressure

IMPORTANT

A 1/8" thick flat spacer washer is used between the oil pump mounting lug and the center main bearing cap. When re-assembling, be sure that this washer is placed on the oil pump mounting stud before the oil pump is installed in place. Failure to do this will cause interference between oil pump and crankshaft and will not allow the distributor drive to mesh correctly.

NOTE

When replacing the drive pinion (19, figure 5-2), it is necessary to line up the hole in the new pinion with the hole in the shaft and drill through the other half of the pinion before pinning it in place.

4-174. FLYWHEEL AND FLYWHEEL BROSING.

a. The flywheel is machined and balanced so that the clutch face and locating counterbore will run true with its axis.

b. To be sure that the crankshaft flange has not been

spring or otherwise damaged or that the counterbore in the flywheel, which locates it on the crankshaft, is not damaged, mount an indicator on the flywheel housing and check the flywheel for runout. Caution: When checking runout, remove spark plugs to allow engine to be turned over freely.

c. The indicator should be set up so that it contacts the clutch face or the vertical surface of the clutch counterbore, then turn the flywheel at least one full revolution, at the same time holding against the crankshaft to offset the possibility of end play.




Fig. 1-123. Checking flywheel runout

d. Excessive runout of the flywheel, in either position, is probably caused by dirt in, or damage to counterbore locating the flywheel on the crankshaft flange.

e. Re-locate the indicator to check the inside diameter of the counterbore. In both cases the maximum indicator reading must not be more than .004.




Fig. 1-124. Checking flywheel counterbore

f. When assembled, mount the indicator on the flywheel so that it contacts the housing face and turn the crankshaft, at the same time holding against it to counteract end play. The maximum indicator reading must not exceed .008.




Fig. 1-125. Checking housing face

g. Re-locate the indicator to contact the housing bore and check this in the same manner. The same runout limits prevail.




Fig. 1-126. Checking housing bore

h. If more than one engine is being rebuilt at a time, the housing should be identified with its original cylinder block and should be reassembled to that block in the rebuilding process.

4-175. REASSEMBLING ENGINE.

a. In the foregoing, we have outlined procedures for checking, repairing, or replacing the many wearing parts in the engine.

b. In most cases, the instructions have covered the re-

assembly of parts or subassemblies made up of several parts.

c. When reassembling pistons and connecting rods, use a good ring compressor and oil the bores thoroughly. A hammer handle may be used to bump the pistons out of the ring compressor into the cylinder bores.

d. Once more, we call attention to the care demanded to prevent connecting rods damaging the cylinder bore finish and at the same time as they are assembled over the crank pin, locate them carefully in order to protect the bearing surfaces.

e. Always lubricate the bearings with clean engine oil when assembling, and tighten them to the torque specified. Use lockwires, cotter pins or lockwashers as required to prevent nuts and screws from loosening.

f. Clean cylinder head and block surfaces thoroughly before installing gasket. Tighten all cylinder heads or cap screws evenly and torque in following sequence to the recommended torque.

g. Before assembling the oil pan with new gaskets make certain that gasket surfaces are flat and clean. Tighten screws in accordance with limits prescribed in torque chart ** to avoid looseness or overstraining.

h. Tighten all cylinder head stud nuts evenly and gradually to 33 to 75 foot-pounds, in the sequence shown in Fig. 1-127.




Fig. 1-127. Cylinder head torque sequence

i. When engine is completely assembled and filled with proper oil, set tappets on both intake and exhaust to .014".



Fig. 1-128. Adjusting tappets

TABLE II
TORQUE SPECIFICATIONS (FOOT-POUNDS)

Cylinder head stud nuts	70-75
Main bearing caps	85-95
Connecting rod caps	40-45
Flywheel	25-30
Manifolds	25-30
Gear cover, water pump, rear end plate	25-30
Oil pan	12-16
Flywheel housing	50-55
Camshaft nut	65-70

TABLE III
LIMITS AND CLEARANCE DATA

PISTON

Cylinder Diameter	3.4395-3.4375
Piston Pin Hole Diameter8594-.8592
Ring Groove Width	
No. 11285-.1275
No. 21285-.1275
No. 31285-.1275
No. 4250-.252
Fit in Cylinder Bore0037 Feeler, 5-10 lb. pull

PISTON RINGS

Ring Width	
No. 1124-.123
No. 2124-.123
No. 3124-.122
No. 4249-.2485
Gap clearance (all rings)017-.007
Side clearance	
No. 10053-.0033
No. 20055-.0035
No. 30033-.0033
No. 40045-.003

PISTON PIN

Length	2.878-2.868
Diameter8593-.8591
Pin Bushing Diameter (finished)8597-.8595
Pin Clearance in Bushing0006-.0002
Desired Pin Clearance0034
Pin Fit in Piston	Light push

VALVE GUIDE (INT. and EXH.)

Length	3-5/16
Outside Diameter6575-.6565
Stem hole Diameter3432-.3422
Max. Wear Limit-Stem Hole3447
Distance - Valve Seat Face to Guide Top	1-15/32

INTAKE VALVE

Seat Angle	39 degrees
Stem Diameter8414-.8406
Stem Clearance Limits0026-.0008
Desired Stem Clearance0015

TABLE III (Continued)

EXHAUST VALVE	
Seat Angle	45 degrees
Stem Diameter	.9385-.9371
Stem Clearance Limit	.0025-.0021
Desired Stem Clearance	.0045
VALVE SPRINGS	
Outside Diameter	.9172
Length	
Valve Open	1-.27/34
Valve Closed	1-.45/64
Load	
Valve Open	88-104 lbs
Valve Closed	47-58 lbs
CAMSHAFT	
Reading Journal Diameters	
No. 1	1.8725-1.8715
No. 2	1.7455-1.7457
No. 3	1.2475-1.2465
No. 4	.8985-.8980
Upper Diameter	
Upper Hole Diameter	1.2005-1.0050
End Play	.009-.005
CAMSHAFT BUSHINGS	
Inside Diameter	
No. 1	1.8755-1.8745
No. 2	1.7502-1.7495
No. 3	1.2505-1.2485
Clearance Limits	.004-.002
CONNECTING RODS	
Pushing Hole Diameter	.814-.918
Bearing Hole Diameter	2.0620-2.0615 (F. 57), 2.2875-2.1353 (F. 63)
Side Play	
Positive	.030-.006
Desired	.008
CONNECTING ROD BEARINGS	
Thickness	.06190-.06165
Clearance	.0002-.2022
Desired Clearance	.001
MAIN BEARINGS	
Thickness	.09315-.09290 (F. 62), .09250-.09275 (F. 63)
Bearing Bore Diameter	2.4378-2.4365 (F. 62), 2.5615-2.5622 (F. 63)
Clearance	.0024-.0032 (F. 62), .0028-.0035 (F. 63)
Desired Clearance	.002 (F. 62), .0015 (F. 63)
CAMSHAFT	
End Play	.009-.008 (F. 62), .007-.006 (F. 63)
Diameter - Main Journals	2.250-2.2490 (F. 62), 2.3744-2.3752 (F. 63)
Diameter - Rod Journals	1.9375-1.9365 (F. 62), 2.0019-2.0027 (F. 63)

Section IV. Optional Equipment

4-176. LP GAS EQUIPMENT.

a. Remove bolts securing rear hood section to hood. Remove overhead guard if lift truck is so equipped. Remove rear hood section. Disconnect battery ground cable.

b. Drain cooling system. Remove water bypass hose between water pump and thermostat housing. Remove pipe nipple from water pump.

c. Detach upper radiator hose from thermostat housing and remove thermostat housing, thermostat and adapter.

d. Disconnect choke, throttle, and governor linkages, air cleaner hose, and fuel line from carburetor. Remove carburetor.

e. Remove fuel pump, fuel lines, and fuel shut-off valve. Install cover and gasket over fuel pump opening in crankcase. Install a 1/8 inch pipe plug in shut-off valve opening in fuel tank.

f. Remove filler assembly from fuel tank and install pipe cap.

g. Disconnect wires from fuel gage, remove gage, and install plug in panel. Wrap wire ends with electrical tape.

h. Disconnect wires from hourmeter pressure switch and remove switch. Install new switch with 3 terminals.

i. Install new carburetor, using new gasket provided, and reconnect choke, throttle, and governor linkages. Check choke linkage to be sure choke disc operates properly. Reconnect air cleaner hose.

j. Use an approved pipe joint sealing compound on all pipe threaded fittings. Make sure all line connections are securely tightened.

k. Install elbow in water pump, and install thermostat housing assembly with thermostat and adapter on engine. Connect water bypass hose attached to thermostat housing to elbow in water pump.

l. Install filter and relief valve assembly in rear hood section. See Fig. 129. Connect 18 inch hose to filter bottom. (This hose connects to solenoid valve.)

m. Install rear hood section on counterweight. Use 5 inch bolts provided to attach hood section if lift truck does not have an overhead guard. On trucks with overhead guard, rear legs of guard secure rear hood section to counterweight.

n. Install fuel tank supports on rear hood section with toggle clamps to rear. Tank support with tank aligning pin must be installed on the right hand side. Install tank in supports.

o. Install 20 inch hose with coupling half attached, in filter. Install other half of coupling on tank outlet valve.




Fig. 129. Tank, supports, and hose

1. Coupling
2. 20 inch hose
3. Relief valve - filter

p. Install hose from filter bottom in solenoid valve.

q. Install 54 inch hose between regulator and elbow on carburetor. Install clip assembly on long leg, shown in Fig. 130, to support fuel line.




Fig. 130. LP Gas equipment

1. 54" hose
2. Hose support clip
3. Regulator assembly
4. Solenoid

r. Reconnect battery cable and turn on ignition. Test two purple and white wires to determine which one is "hot".

s. Turn ignition off and connect "hot" purple and white wire to "NO" terminal on pressure switch.

t. Connect other purple and white wire, and 24 inch wire supplied in kit, to "C" terminal on pressure switch. Connect 24 inch wire to terminal on side of solenoid valve.

u. Connect 26 inch wire to "NC" terminal on pressure switch and "S" terminal on starting motor solenoid.

v. Install rubber grommets in rear of front hood. If any interference is encountered between hood and solenoid valve when hood is closed, tip solenoid to one side.

w. Open fuel supply valve on tank and turn on ignition switch to open solenoid valve. Apply soap suds to all fuel line connections to check for leaks. Be sure all fuel leaks are eliminated before attempting to start the engine.

x. Close radiator and block drains, and refill cooling system.

y. Adjust carburetor, following instructions given in paragraph 3-17, on page 1-14.

4-177. SERVICING LP GAS REGULATOR.

4-178. REMOVAL.

a. Close fuel valve on tank. Disconnect fuel line from bottom of regulator and unscrew regulator from vaporizer.

4-179. DISASSEMBLY.

a. Unscrew diaphragm assemblies. Remove fuel pressure adjusting screw and two set screws from either side of body.

b. Remove fuel inlet orifice. **HANDLE INLET ORIFICE WITH EXTREME CARE**, as slightest nick or scratch across seating surface will cause fuel leaks. Keep sharp edge of seating surface well protected while it is removed.




Fig. 131

1. Pressure adjusting screw
2. Set screw removed (both sides)
3. Inlet orifice

c. Withdraw valve assembly from body as shown in Fig. 132.




Fig. 132

1. Valve being removed
2. Inlet orifice removed




Fig. 133

1. Orifice seating surface

d. Remove and discard valve seat from valve as shown in Fig. 134. The original seat may be turned over and reused, however, it is recommended that a new one (found in repair kit) be used.




Fig. 134

1. Valve seat

4-180. REPAIR.

- a. Clean all parts, except diaphragm assemblies, in carburetor cleaning fluid.
- b. Inspect all parts for wear or damage. Renew "O" ring on fuel pressure adjusting screw.
- c. A repair parts kit (SSP1086) is available for regulator and it is recommended that the parts in the kit be used at reassembly. The kit contains the parts shown below:

- 2 - Diaphragm assemblies
- 2 - Gaskets for diaphragms
- 1 - Seat for regulating valve
- 1 - Seal for fuel adjusting screw

- d. Individual repair items, not included in kit, are available to complete regulator service. These items are as follows:

- SSP1872 Regulating valve assembly
- SSP1873 Fuel pressure adjusting screw
- SSP1865 Fuel inlet orifice

4-181. REASSEMBLY.

- a. Install new valve assembly in body, holding body as shown in Fig. 139. Leaf springs must be straight and parallel. Tap body lightly as tips of blades drop into slots. The springs are visible through set screw holes shown in Fig. 136.
- b. Install fuel inlet orifice and tighten. Apply Lubriplate to "O" ring and threads on fuel pressure adjusting screw and carefully turn it in with fingers.



Fig. 135

1. Pressure regulating screw
2. Inlet orifice

IMPORTANT: BE SURE VALVE ROD ENTERS HOLE IN THE ADJUSTING SCREW DURING ASSEMBLY. IF A RESISTANCE IS FELT AT ANY POINT WHILE INSTALLING SCREW, STOP TURNING AND ALIGN ROD.

- c. With valve rod in place in screw, turn screw down until it is flush with end of body.




Fig. 136

1. Set screw holes
2. Mark on orifice and body

- d. Install set screws for leaf springs, BUT DO NOT TIGHTEN. Make a mark on center of one of "flats" on inlet orifice as shown in Fig. 136. Loosen orifice distance of half of a flat (one-twelfth turn) and tighten set screws against leaf springs. DO NOT OVERTIGHTEN SET SCREWS. Retighten orifice. The leaf springs are now properly adjusted.

- e. Work the leaf springs with finger and thumb a few times and watch valve to see that it moves back and forth (opens and closes). The leaf springs can be aligned with a screwdriver so diaphragm plungers will contact them on center.

- f. Install new gaskets on diaphragm covers and install covers.




Fig. 137

1. Gasket

- g. Fig. 139 shows a cross section of regulator.




Fig. 138

4-182. SERVICING LP-GAS VAPORIZER.

4-183. REMOVAL.

a. Drain cooling system. Disconnect upper radiator hose and by-pass hose from thermostat-vaporizer housing. Disconnect wire and fuel line from solenoid valve. Remove bolts holding thermostat housing to engine.

4-184. DISASSEMBLY.

a. Mark vaporizer and thermostat housing in some way so they can be reassembled in their original position.

b. To separate vaporizer from the thermostat housing, loosen tie bolt two or three turns and lightly tap bolt and vaporizer head until water seal ("O" ring) works free. Remove and discard "O" ring.




Fig. 139

1. Tie bolt
2. Water seal here

c. To remove inlet orifice, first turn adjusting bonnet down all the way to compress diaphragm spring and push square piston away from orifice. Remove inlet bushing and aluminum washer. Insert a 1/4"-20 bolt in inlet orifice and pull orifice straight out. Take special care not to scratch orifice lip.




Fig. 140

1. 1/4"-20 bolt
2. Inlet orifice
3. Adjusting bonnet
4. Inlet bushing and washer

CAUTION: ORIFICE AND SEAT WILL BE DAMAGED IF DIAPHRAGM IS NOT PUSHED TO BOTTOM WHILE REMOVING ORIFICE. THE ORIFICE HAS A KEYWAY AND MUST NOT BE TURNED OR TWISTED.

d. Remove adjusting bonnet and diaphragm spring. Mark cover and body. Remove six screws and lift off diaphragm cover. Lift out diaphragm and round piston. Remove screw from center of diaphragm. Discard "O" ring and diaphragm if cracked, dry, swollen, or spongy.




Fig. 141

1. "O" ring
2. Diaphragm
3. Cover
4. Adjusting bonnet

e. Turn vaporizer over to remove square piston seat retainer, cap, and spring. Inspect seat carefully for hardness, cuts, imbedded foreign materials, or wear. Clean out pin hole vents in body and cover.




Fig. 143

1. Piston seat retainer
2. Pin hole vent

f. Place vaporizer in a vise and, using a 1-1/4 inch socket, remove large plug. Remove bellows and "O" ring. Discard the "O" ring.




Fig. 140

1. Bellows
2. "O" ring
3. Plug

4-185. REPAIR.

a. Clean all parts to be reused and dry with compressed air.

b. A repair kit (35P1395) is available and should be installed to assure satisfactory performance after vaporizer is reassembled and adjusted.

4-186. REASSEMBLY.

a. Fig. 144 illustrates components to vaporizer. Refer to illustration when reassembling.




Fig. 144

- | | |
|---------------------|---------------------|
| 1. Adjusting bonnet | 10. Button |
| 2. Lock nut | 11. Spring |
| 3. Spring | 12. 1/8" plug |
| 4. Cover | 13. Fibre gasket |
| 5. Kerahet | 14. Inlet orifice |
| 6. Diaphragm | 15. Aluminum washer |
| 7. "O" ring | 16. Inlet bushing |
| 8. Piston | 17. Fibre gasket |
| 9. Seat retainer | 18. Plug |

b. Install new "O" ring (found in kit) on bellows, see Fig. 140, apply Lubriplate to "O" ring, and assemble bellows to body. Coat fibre gasket for large plug with oil and install plug, tightening it to 50 ft. lbs. torque.

c. Assemble new diaphragm to new piston with "O" ring, leaving center screw loose. Flange on diaphragm retainer must be away from diaphragm.

d. Temporarily install inlet orifice, using a 1/4"-20 bolt, being sure keyway in orifice is lined up with dowel pin in body. Apply a coat of oil to piston and "O" ring, then install piston in housing so it straddles inlet orifice (Fig. 145). Turn diaphragm as necessary to align holes near edge with six holes in body. Tighten center screw and remove diaphragm and piston assembly and inlet orifice.




Fig. 145

1. Align screw holes
2. Piston straddles orifice
3. Diaphragm center screw

e. Place spring button on small spring and install these parts in square piston. Install assembly in body. See Fig. 142.

f. Reinstall diaphragm and piston assembly as described in paragraph "d". Be sure piston straddles inlet opening as indicated in Fig. 145. Install diaphragm cover, aligning marks made at disassembly. Reinstall diaphragm spring and adjusting bonnet.

g. Turn adjusting bonnet all the way in and install inlet orifice, using a 1/4"-20 bolt as before. Tap bolt LIGHTLY with a hammer, if necessary.

h. Remove 1/4" bolt and install aluminum washer and inlet bushing. Tighten inlet bushing to 45 ft. lbs. Screw out adjusting bonnet several turns.

CAUTION: EXCESSIVE TORQUE ON THE INLET BUSHING CAN SHEAR DOWEL PIN, ALLOWING INLET ORIFICE TO ROTATE AND SEAT IMPROPERLY.

i. Install a new "U" ring (water seal) on body and install body in thermostat housing, aligning marks made at disassembly. Install tie bolt and tighten securely.

j. The vaporizer pressure must be readjusted after servicing. See "ADJUSTING VAPORIZER".

4-187. ADJUSTING VAPORIZER,

a. Install a pressure gage that will give accurate low pressure readings, in vaporizer OUTLET port. Remove 1/8" pipe plug from side of vaporizer body.

b. Connect an air hose, that will apply 60 to 75 psi, to INLET PORT. The pressure applied to vaporizer INLET must not fall below 60 psi.

c. Place thumb over 1/8" plug hole and apply air pressure to unit. Set pressure adjusting bonnet to obtain a reading of 10 psi with no flow. Remove thumb from port. The reading on gage should now be 6 to 7 psi with full flow.

d. Check the pressure several times by covering and uncovering port. The pressure should return to 10 psi, plus or minus 1 psi, each time port is covered, and drop to 6 - 7 psi when port is uncovered.

NOTE: TO OBTAIN AN ACCURATE GAGE READING, IT MAY BE NECESSARY TO UNSCREW GAGE TO BLEED OFF SOME OF THE AIR.

e. A steady reading on gage in both full flow and no flow ranges indicates that vaporizer valve is operating satisfactorily. If the pressure reading tends to creep up, it indicates that valve is leaking. Low pressure during the flow test means that valve is failing to open properly.




Fig. 146

1. Low pressure gage
2. Adjusting bonnet
3. Plug removed from back side
4. Apply air at 60 - 75 psi here

4-188. ADJUSTING REGULATOR.

- With vaporizer adjustments completed, and correct outlet pressure obtained, as described previously, connect INLET port of regulator to vaporizer OUTLET port, Fig. 147.
- Connect an air hose, capable of applying 80 - 75 psi, to vaporizer INLET port. Place a soap film over fuel OUTLET port in regulator as indicated in Fig. 147.
- Turn in the pressure adjusting screw for regulator to just seat it. Apply air pressure to vaporizer and slowly back out regulator pressure adjusting screw until soap bubble shows a slight air flow. (Flow will be indicated by slowly expanding bubble.) At this point, turn in adjusting screw $8/4$ to 1 turn.




Fig. 147

- Soap bubble here
 - Pressure regulator screw this end
 - Regulator
 - Puff here to open valve
 - Vaporizer
 - Apply air at 80 - 75 psi here
- d. A slight suction applied to regulator outlet, or a light puff applied to diaphragm should cause air to flow through outlet a moment, then shut off tight again.

4-189. SERVICING LP-GAS CARBURETOR.

4-190. REMOVAL.

- Disconnect fuel line, choke wire, throttle control rods, and air cleaner hose. Remove carburetor and gasket.

4-191. DISASSEMBLY. (See Fig. 2-14A.)

- Mark throttle plate (3) and choke plate (14) in relation to main body so plates can be reinstalled in their original position. Remove screws (4 and 13) and plates.
- Remove throttle shaft and lever assembly (2). Remove retainers (6) and seals (9) from both sides of body.
- Remove choke return spring (23) and remove choke shaft (13) and lever assembly (22). Remove plug (16) and gasket (17).

NOTE: UNLESS CHOKE AND THROTTLE SHAFTS, OR LEVERS, REQUIRE REPLACEMENT, DO NOT DISTURB LEVER POSITION ON SHAFT. MARK LEVER POSITION IF ANY ARE REMOVED FROM SHAFTS.

- Mark position of choke cable bracket (18) and remove nut (13) and bracket.

- Remove venturi retaining screw (12) and withdraw venturi from body.

- Remove idle adjusting needle (7) and spring (5). Loosen nut (22) and remove main load adjusting screw (21) and nut.

4-192. REPAIR.

- Thoroughly clean all parts in carburetor cleaning solution. Rinse parts in clean solvent and blow dry with compressed air. Blow out all internal passages with compressed air. DO NOT USE WIRE OR A DRILL TO CLEAN THE JETS.
- Carefully inspect throttle and choke shafts for wear or damage. Replace shafts if worn excessively. Replace needle valve if grooved, scratched, or otherwise damaged.

4-193. REASSEMBLY. (See Fig. 2-14A.)

- Attach choke cable bracket (18) to body in original position as marked, using nut (13). Tighten the nut securely.
- Reinstall choke shaft (13), gasket (17) and plug (16). Reinstall choke plate (14) in original position as marked at disassembly. Leave screws (13) loose and close the choke. Tighten the screws with the plate in the best closing position.
- Reinstall main load adjusting screw (21) and nut (22) in body. Turn screw in all the way against seat, then back out two turns.
- Reinstall venturi (11) in carburetor throttle bore with side hole in line with hole in main body. Install screw (12) to secure venturi.

e. Install throttle shaft seals (5) and retainer (6) in body. Install throttle shaft assembly (2) through seals and reinsert throttle plate (3) in original position as marked at disassembly. Leave screws (4) loose, close throttle and align plate for best closing position, then tighten screws.

NOTE: THROTTLE STOP SCREW MUST CONTACT STOP PIN WITH THROTTLE PLATE IN CLOSED POSITION.

t. Reinstall the carburetor on the engine, using a new gasket between carburetor and manifold. Reconnect the fuel line, choke wire, throttle control rods, and air cleaner hose. Adjust the carburetor as explained in paragraph 3-17.

4-104. BULKHEAD FILTER ELEMENT. Close valve on fuel tank and run engine until it stops. This will relieve pressure in fuel line.

a. Disconnect fuel line from elbow in filter and remove elbow. Remove filter element and spring. Wash element in solvent and blow dry.

b. Reassemble components in reverse order of disassembly. Retighten fuel lines securely.

4-106. POSITIVE CRANKCASE VENTILATION.

a. Remove necessary engine components to facilitate removal of valve chamber cover. Remove valve chamber cover.

b. Install new valve chamber cover with port for vent valve toward rear of engine (port away from fan end of engine). Reinstall engine components removed.




Fig. 148. Positive crankcase ventilation

- | | |
|----------------|--------------------|
| 1. Gasket | 6. Coupling |
| 2. Valve cover | 7. Elbows |
| 3. Gaskets | 8. Tube |
| 4. Nipple | 9. Intake manifold |
| 5. Valve | |

c. Remove pipe plug (upper) from intake manifold and install elbow.

d. Install 1" nipple in valve chamber cover and install valve on nipple. Install pipe coupling and elbow on valve. Install tube between elbows.

e. Remove breather cap from oil filler tube and install new breather cap furnished.

IMPORTANT: REMOVE, DISASSEMBLE, AND THOROUGHLY CLEAN THE VALVE IN SOLVENT EACH 100 HOURS OF ENGINE OPERATION.

4-108. AUXILIARY VALVE AND HOSE REELS.

a. Use extreme care when installing hydraulic equipment to avoid getting any foreign material into system.

b. Remove left hand knock-out plugs in cowl when installing a single spool valve and left hand hose reel (Fig. 149). Remove all four plugs when installing a double spool valve and two reels.

c. Three new 13/32 inch holes must be drilled in cowl for mounting auxiliary valve. Fig. 149 shows dimensions for locating the mounting holes for single and double spool valves.




Fig. 149. Valve mounting holes

- | |
|--|
| 1. Valve mounting holes - single spool |
| 2. Valve mounting holes - double spool |
| 3. 3-3/16" from top |
| 4. 11-35/16" from edge |
| 5. 4-1/8" (single spool valve) |
| 6. 6-3/8" (double spool valve) |
| 7. 1-11/16" |
| 8. 5-3/4" |

- d. Install control levers on valve and install elbows. Figs. 152 and 153 show the correct elbow positions.
- e. Install valve, using pipe spacers between valve and cowl as shown in Figs. 152 and 153.
- f. Remove floor plate. Cut a notch in plate as shown in Fig. 150 to allow clearance for new hydraulic tubes for auxiliary valve.




Fig. 150. Floor plate

1. 7/8 inch
2. 2-3/4 inches
3. 2-7/8 inches

g. Remove large plug from side of main hydraulic control valve and pipe plug from return line extension in reservoir. Install a straight connector in return line extension and a elbow in valve port.

h. Slip the hydraulic pressure and return lines into place. Tighten line connections securely. Reinstall floor plate.




Fig. 151. Line connectors

1. Elbow in valve port
2. Straight connector
3. Pressure line
4. Return line




Fig. 152. Single spool valve

1. Single spool valve
2. Pipe spacers (3)
3. Pressure line
4. Return line




Fig. 153. Double spool valve

1. Double spool valve
2. Pipe spacers (3)
3. Pressure line elbow
4. Return line elbow

i. Drill two 17/32 inch holes in cowl, as shown in Fig. 154, for mounting hose reel. Drill holes in both sides of cowl if two hose reels are to be installed.

j. A new hole must be drilled and tapped in backside of upper carriage bar for mounting junction block. Drill a 5/16" hole, 3/4" deep, in back of bar, at location shown in Fig. 154, depending on height of upright on lift truck. Tap hole to 3/8"-16 N.C. thread, 5/8" deep.

NOTE: DRILL AND TAP ONLY THE MOUNTING HOLE APPLICABLE TO THE HEIGHT OF UPRIGHT ON THE LIFT TRUCK.




Fig. 154. Reel and block mounting holes

1. Reel mounting holes - $17/32$ "
2. 4 inches
3. 2 inches
4. $15/16$ inch
5. $3/8$ "-18 NC tapped hole (backside of bar)
6. $7/8$ " from top of bar
7. $15-5/8$ " from center - 91 to 145° MFH
8. $16-7/16$ " from center - 148 to 178° MFH

k. If the lift truck has an overhead guard, it will be necessary to modify the front supports for the guard before the reels are installed. Cut off the mounting plates on the front legs. Weld new mounting plates to legs, using dimensions shown in Fig. 155 to locate. Bend legs back at point shown so bolt holes in plates line up with holes in frame. (See Fig. 157.)

l. Attach the reel to the cowl and install the hydraulic tubes between valve and reel as shown in Fig. 156. Tighten line connections securely.

m. Install the junction block as shown in Fig. 157.




Fig. 155. Overhead guard support

1. $12-5/16$ inches
2. New mounting plate
3. $1-1/4$ inches




Fig. 156. L.H. hose reel

1. Hydraulic tubes
2. Reel mounting bolts
3. L.H. hose reel
4. Elbows in valve

n. Assemble the hose couplings to the hoses. Attach the hoses to the connections on the reel. Pre-load

spring in hose reel by turning reel against spring tension three turns. Attach hoses to junction block, being sure all twist is removed from hoses.




Fig. 157. R.H. reel and junction block

1. R.H. hose reel
2. Junction block
3. Overhead guard mg. plate

d. Install the necessary hydraulic hoses between the junction block and hydraulic equipment to complete the installation. Relief valve pressure of auxiliary valve is 1700 PSI.

4-197. HEAD LIGHT.

a. Measure up 38 inches from bottom of outer right hand rail and weld light bracket to back side of rail. See figure 158.

b. Drill a 7/16" hole in instrument panel, in the position shown in Fig. 158, for the light switch. Install switch.

c. Assemble light, together with 8" wire, to handle. Install handle and bearing assembly on bracket, securing other end of 8" wire to bracket with bearing attaching screw.

d. Connect 6" wire between "hot" terminal on ignition switch and terminal on light switch. Attach 36" wire with fuse to other terminal on light switch.




Fig. 158. Light mounting bracket

1. 15-7/16 inches
5. 1-5/8 inches
3. 7/16" hole for switch
4. 3/4" from inner edge
5. 38" from bottom of channel

e. Connect 71" wire to terminal on head light. Secure 71" wire to mast with clips and connect to 36" wire from light switch.

4-199. STOP LIGHT.

a. Remove 1/3" pipe plug from top front of brake master cylinder and install stop light switch.

b. Install light and bracket assembly. If lift truck has an overhead guard, remove nut from left hand rear leg and install light assembly. Use bolt provided for attaching light if truck does not have an overhead guard.

c. Connect 80" wire between wire on stop light and terminal on stop light switch. Connect 38" wire to other stop light switch terminal.

d. Connect 36" wire with fuse to positive terminal on ammeter and connect to 80" wire from stop light switch.

4-199. LOAD SAFETY RACK.

a. Weld safety rack brackets to backside of run carriage bar, using dimensions shown in Fig. 159 to locate.

b. Attach safety rack to brackets with bolts provided.

4-200. OVERHEAD GUARD.

a. Set overhead guard in place on truck, and secure front plates to frame. Secure rear guard support legs to counterweight.

b. If lift truck has hose reels installed, it will be necessary to modify front support legs to obtain necessary clearance. See Fig. 160.




Fig. 159. Rack mounting brackets

1. $14\text{-}3/8$ inches
2. $3\text{-}9/16$ inches

CHAPTER 2

FUNCTIONAL PARTS LIST



MINNEAPOLIS-MOLINE, INC.

F O R E W O R D

This catalog contains a complete list of parts for the MA Series Fork Lift Trucks. To assist in determining the part numbers and descriptions, the parts in this catalog are grouped according to their location on the Lift Truck. Reference numbers only are shown in each illustration. These numbers correspond to those in the reference number column in the list of parts which precedes each "exploded view".

TYPICAL PARTS ARE SHOWN, AND MAY NOT ALWAYS BE IDENTICAL WITH CURRENT PARTS. REFER TO THE TEXT.

To further assist in locating repair parts, the part numbers are arranged in numerical sequence and indexed on pages 2-127 thru 2-137.

Component parts of assemblies are listed following the assembly itself and are identified as being part of the assembly by this notation following the description:

Consists of the following parts:

or

Includes the following parts:

Part numbers only make up an assembly. Hardware items are not to be included.

Parts such as standard bolts, nuts, screws, washers, etc., are indented and listed under the respective individual parts with which they are used.

"Right or Left" is determined by facing the man from the Mobilift seat.

When in need of repair parts always order the parts from your Mobilift dealer nearest you. All parts orders should plainly specify your name, post office address and whether shipment is to go by parcel post, express, or freight.

Before returning repair parts it is necessary to secure written permission from the company authorizing the return of such parts. In the returning of repair parts be sure the package is tagged with your name and address. Prepay transportation charges.

Claims of shortage or breakage should be made to the transportation company on receipt of goods.

It is the policy of Minneapolis-Moline, Inc. to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements in the design or construction of parts at any time without incurring the obligation to install such changes on products previously delivered.

MOBILIFT - MA SERIES LIFT TRUCKS

PARTS GROUP INDEX

	Page		Page
Alternator	2-29	Lamps	2-34
Air Cleaner	2-17 thru 2-18	Lift Cylinder (Duplex)	2-92 thru 2-94
Auxiliary Valves	2-132	Lift Cylinders (Knickerbocker).....	2-106 thru 2-116
Battery	2-33 thru 2-34	Lift Cylinders (Viewmast).....	2-98 thru 2-106
Battery Box	2-32 thru 2-34	Lifting Forks	2-119
Brakes	2-72	Load Safety Rack	2-119
Brake Linkage	2-74	LP-Gas Equipment	2-35
Cables	2-32 thru 2-34	Mast.....	2-99 thru 2-116
Camshaft	2-6	Master Cylinder	2-74 thru 2-76
Carburetor, Gasoline Engine	2-25	Muffler	2-18
Carburetor, LP Gas Engine	2-40	Oil Filter, Engine	2-8
Clutch Control	2-36	Oil Filter, Transmission.....	2-32 thru 2-36
Coil, Ignition.....	2-30	Oil Pump	2-8
Connecting Rod	2-11 thru 2-14	Overload Guard	2-31
Control Valve, Lift and Tilt	2-84	Pistons	2-10 thru 2-14
Control Valve, Transmission and Regulator	2-46 thru 2-56	Piston Rings	2-10 thru 2-14
Converter	2-42	Positive Crankcase Breather.....	2-82
Cooling System	2-21	Radiator.....	2-26
Counterweight	2-29	Seat	2-79
Crankcase	2-4 thru 2-6	Sheave Take-Up for Hoses.....	2-124 thru 2-126
Crankshaft	2-10 thru 2-14	Spark Plug	2-30
Cylinder Block and Head	2-4 thru 2-6	Starting Motor	2-30
Decals	2-119	Steering Gear	2-68 thru 2-82
Differential	2-64 thru 2-70	Steering Linkage	2-58
Distributor	2-30	Tilt Cylinder	2-36
Drive Axle and Wheels	2-64 thru 2-70	Thermostat	2-48
Duplex Mast and Lift Cylinders.....	2-96 thru 2-94	Transmission	2-44
Fan	2-26	Transmission Case	2-42
Flywheel	2-10 thru 2-14	Transmission Controls	2-46 thru 2-56
Foot Accelerator	2-28	Triplex Mast (Knickerbocker).....	2-104 thru 2-116
Forks and Fork Extensions	2-119	Triplex Viewmast (Cascade)	2-98 thru 2-119
Frame	2-29	Valves	2-3
Fuel Filter	2-20	Variable Parts Chart (Duplex Mast)	2-118
Fuel Pump	2-29	Variable Parts Chart (Triplex Mast)	2-119
Gas Manifold	2-5 thru 2-7	Voltage Regulator	2-30
Gasket Sets	2-5 thru 2-7	Water Pump	2-36
Generator	2-30	Wheels, Drive	2-68 thru 2-70
Governor	2-24	Wheels, Steering.....	2-32
Hood	2-78	Wires	2-32 thru 2-34
Horn	2-36	Wiring Harness	2-35 thru 2-34
Hose Reels.....	2-120	NUMERICAL INDEX	2-127 thru 2-137
Hydra-Lixer and Wheels	2-66		
Hydraulic Oil Lines	2-84		
Hydraulic Pump	2-82		
Ignition System	2-30		
Instrument Panel	2-21		

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION		No. Pcs.
		Continental Motors	CRANKCASE ASSEMBLY, CYLINDER HEAD AND GAS MANIFOLD	
			GROUP 1 - FOR MODEL F162 ENGINES	
			Used on MA 30 Lift Trucks to No. 28000125 Inc.	
			Used on MA 40 Lift Trucks to No. 28100543 Inc.	
			Used on MA 50 Lift Trucks to No. 28200135 Inc.	
12	35P778	F401A-302	Head - cylinder	1
		X-1014G	GM103874 - Plug, pipe, cyl. hd., 1/2"	1
16	35P988	20CL-2020	*Cap - oil filler tube	1
		10A10431	**Cap - oil filler tube	1
17	35P862	20CL-2910	*Tube - oil filler	1
17	35P918	F102L-350	**Tube - oil filler	1
18	91188	X-1013	Valve - drain, cylinder block	1
18	35P779	F400A-330	Gasket - cylinder head	1
20	35P780	F500L-2090	Dipstick (oil gauge)	1
21	90978	X404L-210	Felt - dipstick	1
22	35P731	Y400L-256	Support - dipstick	1
23	35P1022	F400A-48712-A	Cylinder and Crankcase - with bearings, bushings, guides, inserts, plugs and pins	1
	92205	X-2286	Plug - expansion, camshaft bushing, rear, 1-1/2"	1
		X-2267	GM172548 - Plug, expansion, 1-1/8"	1
		X-2202	GM172570 - Plug, expansion, 1-3/8"	2
		X-101	GM103868 - Plug, pipe, (drain) 1/4"	2
			*NOTE: Used on motors to No. 287584 Inc.	
			**NOTE: Used on motor No. 287585 and after.	
24	91475	87C-200	Ring - dowel, gear cover to crankcase	1
25	35P783	F400B-225	Gasket - end plate to cylinder	1
28	35P784	F400B-368	Plate - end, crankcase	1
28	35P783	F400B-333	Gasket - gear cover to end plate	1
32	35P788	F400B-522	Cover - gear, with oil seal	1
33	15P662	X-1535	Seal - oil, gear cover	1
34	91135	X-4200	Stud - gear cover to cylinder, 3/8"-16 x 1-11/16"	1
36	91435	X-1802-C	Nut - gear cover stud, 3/8"-16	2
	35P1759	X-4528	Stud - gear cover to cylinder, 3/8"-16 x 1-7/8"	1
40		X-3225	GM179840 - Bolt, hex., 3/8"-16 x 1-1/8"	2
		X-228	GM114806 - Washer, lock, external, 8/8"	2
		X-1803-H	GM271500 - Nut, hex., 7/16"-14	1
41	91436	X-14134	Washer - copper, cover screw, 3/8" I.D., 5/8" O.D. ...	2
48	91115	D600B-208	Ring - dowel, end plate to crankcase	1
66	35P787	F400B-442	Gasket - oil pan	2
67	90948	D600B-340	Block - filler, front	1
68		X-3924	GM179817 - Bolt, filler block, 5/16"-18 x 7/8"	2
		X-297A	GM115348 - Washer, int. lock, 5/16"	2
70	15P570A	F400B-255	Gasket - front and rear filter blocks	2
71	35P789	F400B-4480	Pat. - oil	1
72	91585	W40-108	Gasket - drain plug	1
73	15P282	2285-221	Plug - drain oil pan (Magnetic)	1
74	35P976	X-3896	Screw - oil pan to crankcase	14
76		X-2953	GM179828 - Bolt, hex., filler block, 5/16"-18 x 2-5/8"	2
78	90856	D600B-406	Block - filler, rear	1
79	35P789	T-427B-201	Seal - rear filler block	1
80	90875	D600B-303	Guard - oil	1
	15P467	F400B-251	Felt - rear bearing oil guard	-
81	91775	158L-211	Valve - relief, oil pressure	1
82	91793	X-14324	Washer - relief valve	1
83	91785	F400L-223	Spring - relief valve	1
84	91813	X-866	Gasket - relief valve	1
85	91805	41AX-200	Plug - relief valve	1
	35P1766	F600A-3090	Baffle - tappet drain	2
86	35P012	X-4004	Stud - cover	2

MOELLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.		DESCRIPTION	No. Pcs
		Continental Motors	CRANKCASE ASSEMBLY, CYLINDER HEAD AND GAS MANIFOLD (Cont'd)	
97	31025	X-334	Gasket - cover stud	2
98	35P919	X-18327	Nut - cover stud	2
99	35P793	F124A-201	Gasket - valve chamber cover	1
92	35P381	F400A-3000	Cover - valve chamber	1
93	91135	X-4900	Stud - manifold, 3/8"-16 x 1-11/16"	6
84	35P920	X-14323	Washer - manifold stud, 13/32" L.D., 3/4" O.D.	4
94	35P921	X-14141	Washer - manifold stud, 13/32" L.D., 7/8" O.D.	3
95		X-18278	GM271535 - Nut, manifold stud (brass)	7
96	35P913	X-4206	Stud - manifold, 3/8"-10 x 2-5/8"	1
98		X-100	50A034 - Plug, pipe, 3/8"	1
		X-111	GM103880 - Plug, pipe, 1/4"	1
99	35P793	F400E-303	Gasket - manifold	1
100	35P794	F182E-415	Manifold - intake and exhaust	1
124	35P909	X-4723	Stud - cylinder head, 7/16"-20 x 5-1/2"	13
124	35P910	X-4726	Stud - cylinder head, 7/16"-14 x 4-1/4" (Nylon)	2
125	35P911	3X-X-1408	Washer - cylinder head stud, 7/16"	15
126		3X-X-1908-B	GM451404 - Nut, cylinder head stud, 7/16"-20	15
130	35P852	F600B-415	Housing - flywheel	1
		X-5798	GM100798 - Bolt, hex., 1/4"-20 x 5/8"	2
	35P860	X-5841	Lifting Eye - motor	1
	36R40	F162D-120	Gasket Set - engine overhaul	-
	36R41	F162D-109	Gasket Set - valve grinding	-




Fig. 2-1 - CRANKCASE ASSEMBLY, CYLINDER HEAD AND GAS MANIFOLD

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.		DESCRIPTION	No. Per
		Geothermal Motors	CRANKCASE ASSEMBLY, CYLINDER HEAD AND GAS MANIFOLD GROUP II - FOR MODEL F183 ENGINES Used on MA 30 Lift Trucks No. 25000126 and after. Used on MA 40 Lift Trucks No. 26100544 and after. Used on MA 30 Lift Trucks No. 25200186 and after.	
12	36F1938	F401A-600	Head - cylinder	1
		X-101-B	GM102874 - Plug, pipe, cyl. hd., 1/2"	1
16	10A1040	-----	Cap - oil filler tube	1
17	35P913	F162L-350	Tube - oil filler	1
18	91185	X-1015	Valve - drain, cylinder block	1
19	35P773	F400A-330	Gasket - cylinder head	1
20	36P790	F400L-2080	Dipstick (oil gauge)	1
21	90973	K404L-210	Felt - dipstick	1
22	36P781	Y400L-208	Support - dipstick	1
23	35P1972	F163A-40010-A	Cylinder and Crankcase - with bearings, bushings, guides, inserts, plugs, and pins	1
	99333	X-2204	Plug - expansion, camshaft bushing, rear, 1-1/2"	1
		X-2207	GM172548 - Plug, expansion, 1-1/8"	1
		X-2202	GM172570 - Plug, expansion, 1-3/8"	2
		X-101	GM103366 - Plug, pipe, (craft) 1/4"	2
24	91478	8TC-200	Ring - dowel, gear cover to crankcase	1
25	15P458	F244B-301	Gasket - end plate to cylinder	1
26	35P1553	F400B-531	Plate - end, crankcase	1
28	35P745	F400B-553	Gasket - gear cover to end plate	1
32	35P72E	F400B-3221	Cover - gear, with oil seal	1
33	15P502	X-1555	Seal - oil, gear cover	1
34	91135	X-4030	Stud - gear cover to cylinder, 3/8"-16 x 1-11/16"	1
36	91433	X-1302-G	Nut - gear cover stud, 3/8"-16	2
	35P1753	X-4228	Stud - gear cover to cylinder, 2/8"-16 x 1-7/8"	1
40		X-8295	GM173840 - Bolt, hex., 3/8"-16 x 1-1/8"	2
		X-220	GM114636 - Washer, lock, external, 3/8"	2
		X-1303-H	GM271530 - Nut, hex., 7/16"-14	1
41	91433	X-14134	Washer - copper, cover screw, 3/8" I.D., 5/8" O.D.	2
45	35P1934	8TC-215	Ring - dowel, end plate to crankcase	1
46	35P787	F400B-442	Gasket - oil pan	2
47	30845	D600B-340	Block - filler, front	1
49		X-3934	GM179817 - Bolt, filler block, 5/16"-18 x 7/8"	2
		X-297A	GM110546 - Washer, int. lock, 5/16"	2
70	15P0106	F400B-255	Gasket - front and rear filler blocks	2
71	35P723	F400B-4460	Pan - oil	1
72	91583	W40-106	Gasket - drain plug	1
73	15P282	2203-221	Plug - drain oil pan (Magnetic)	1
74	35P016	X-3806	Screw - oil pan to crankcase	14
76		X-2356	GM179828 - Bolt, hex., filler block, 5/16"-18 x 2-5/8"	2
78	36F1931	D400B-432	Block - filler, rear	1
79	35P769	T457B-201	Seal - rear filler block	1
80	35P1932	F400B-390	Guard - oil	1
	15P437	F400B-251	Felt - rear bearing oil guard	1
81	91775	16SL-211	Valve - relief, oil pressure	1
82	91766	X-14324	Washer - relief valve	1
83	91768	F400L-223	Spring - relief valve	1
84	91515	X-038E	Gasket - relief valve	1
85	91806	4LAX-200	Plug - relief valve	1
	36F1766	F600A-3990	Ball - tappet drain	2
86	35P912	X-4026	Stud - cover	2
87	91025	X-334	Gasket - cover stud	2
88	35P913	X-15227	Nut - cover stud	2
89	35P783	F134A-201	Gasket - valve chamber cover	1

MOBILIFT - MA SERIES LIFT TRUCKS

Kit No.	Part No.	DESCRIPTION	No. Pcs.	
	Commental Meters	CRANKCASE ASSEMBLY, CYLINDER HEAD AND GAS MANIFOLD (Cont'd)		
93	35P981	F430A-3960	Cover - valve chamber	1
97	91135	X-4263	Stud - manifold, 3/8"-16 x 1-11/16"	6
94	35P920	X-14023	Washer - manifold stud, 13/32" I.D., 5/4" O.D.	4
94	35P921	X-14141	Washer - manifold stud, 13/32" I.D., 7/8" O.D.	3
95		X-15276	GM271586 - Nut, manifold stud (Brass)	7
9E	35P913	X-4259	Stud - manifold, 3/8"-16 x 3-6/8"	1
9E		X-103	50A354 - Plug, pipe, 1/8"	1
		X-101	GM103886 - Plug, pipe, 1/4"	1
99	35P795	F400E-303	Gasket - manifold	1
130	35P791	F102E-415	Manifold - intake and exhaust	1
124	35P1934	X-6894	Stud - cylinder head, 7/16"-14 x 2-7/8"	11
124	35P1935	X-6884	Stud - cylinder head, 7/16"-14	4
125	35P911	OX-X-1402	Washer - cylinder head stud, 7/16"	15
126		3X-X-1802-E	GM451464 - Nut, cylinder head stud, 7/16"-20	15
180	35P852	F800B-412	Housing - flywheel	1
		X-5799	GM179793 - Bolt, hex., 1/4"-20 x 5/8"	2
	35P863	X-5641	Lifting Eye - motor	1
	35P1728	F103U-114	Gasket Set - engine overhaul	1
	35H41	F162D-109	Gasket Set - valve grinding	1




Fig. 2-1 - CRANKCASE ASSEMBLY, CYLINDER HEAD AND GAS MANIFOLD

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs.	
		Continental Motors		
		CAMSHAFT, VALVES, OIL PUMP AND OIL FILTER		
1	35P818	F4001-422	Camshaft	1
2		X-2293	GM179814 - Screw, thrust plate, 5/16" x 5/8" ...	2
		X-2297-A	GM115546 - Washer, lock, 5/16"	2
3	15P456	Y4001-238	Plate - thrust, camshaft	1
4	35P813	F400H-406	Gear - timing camshaft	1
5		X-506	GM106750 - Key, Woodruff, No. 6	1
6		X-1848E	GM219197 - Nut, gear to camshaft, 3/4"-16	1
7	35P812	F400-G222	Bushing - camshaft, front	1
8	909150	X400G-231	Bushing - camshaft, center	1
9	909252	X400G-232	Bushing - camshaft, rear	1
10	35P849	F600I-2520	Tappet - (valve lifter)	8
11	15P402	F400I-202	+Retainer - valve spring, intake valve	4
11	35P1867	F600I-200	+Retainer - valve spring, intake valve	4
12	15P461	Y400I-215	Spring - valve, intake and exhaust	6
13	35P816	F400I-233	Guide - valve stem	6
14	35P979	PL40A-218	Insert - exhaust valve, OLV O.S.	4
15	15P463	Y400I-206	+Lock - retainer, valve spring	8
15	35P1953	CVT-3234	+Lock - retainer, valve spring	8
16	86P979	F400I-335	+Valve - exhaust, 45° seat, positive rock	4
16	35P1936	F600I-353	+Valve - exhaust, 45° seat, positive rock	4
18	95915	F800I-228	+Valve - intake	4
18	86P1936	F600I-302	+Valve - intake	4
	15P464	Z120I-3000	+Roto Cap - assembly, exhaust valve	4
	86P1939	F600I-301	+Roto Cap - assembly, exhaust valve	4
			+Used on MA Series Trucks with F162 Continental Engine. MA 30 Lift Trucks to No. 28000125 Inc. MA 40 Lift Trucks to No. 26100543 Inc. MA 50 Lift Trucks to No. 26200135 Inc. +Used on MA Series Trucks with F163 Continental Engine. MA 30 Lift Trucks No. 28000126 and after. MA 40 Lift Trucks No. 26100544 and after. MA 50 Lift Trucks No. 26200136 and after.	
	15P465	Z120I-335	Lock - valve spring seat	8
17	35P817	F600I-4131	Oil pump - assembly, includes parts identified with an asterisk (*)	1
	15P290	Z-14264	Washer - oil pump mounting lug, 3/8"	1
18	80938	F400I-210	Bushing - oil pump shaft, in crankcase	1
19	35P653	F600A-205	*Pinion - drive shaft, upper end	3
20	35P977	X-17095	*Pin - gear to shaft	2
21	91639	D600I-274	*Bushing - oil pump, in housing	1
22	91625	F21E1-204	*Shaft - oil pump	1
23		X-584	*GM106749 - Key, Woodruff, No. 3	1
24	16246	F600H-217	*Gear - driver, oil pump	1
25	16247	F600H-218	*Gear - idler	1
26	91695	90L-212	*Stud - idler gear	1
27	91636	D600I-204	*Ring - snap, drive gear	1
28	91715	C400L-231	*Gasket - oil pump cover	1
29	15P48	F400I-280	*Cover - oil pump	1
30	91735	17E1-204	*Gasket - cover to frame	1
31	91725	17E1-300	*Frame - oil pump strainer	1
		X-5798	*GM179798 - Bolt, hex., 1/4"-20 x 5/8"	6
32	91745	C400I-229	*Sparer - frame to screen	1
33	91755	D600I-2120	*Screen - assembly, oil pump	1
34	16P280	Z-20040	Stud - oil pump body to bearing cap	1
35	91435	X-18926	Nut - oil pump stud	1
36	36A6593	-----	Filter - oil, spin on	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		Continental Motors	
		CAMSHAFT, VALVES, OIL PUMP AND OIL FILTER (Cont'd)	
37	85A6158	Base - filter	1
		GM180122 - Bolt, hex., 3/8"-16 x 1"	2
		GM120376 - Nut, hex., 3/8"-16	2
38	90A6264	Hose - with couplings, filter to engine, 21" long	2
39		GM454146 - Tee, pipe, 1/4", 3 way	1
39	80A8214	Tee - pipe, 1/4", 4 way	1
40		50A4399 - Elbow, 1/4"-18 NPT to 1/2"-20 NF	2
41		GM119322 - Bushing, reducer, 1/4" to 1/8"	1
42	35A8321	Connector - orifice, tee to crankcase	1




Fig. 2-2 - CAMSHAFT, VALVES AND OIL PUMP

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.		DESCRIPTION	No. Pcs
		Continental Motors	CRANKSHAFT, FLYWHEEL, CONN. RODS AND PISTONS GROUP I - FOR MODEL F182 ENGINES Used on Continental Motors to No. 30.237 etc.	
1	35P795	F400C-3000	Crankshaft - with bushing	1
2	91318	1ELG-202	Bushing - crankshaft	1
3	35P790	D200C-204	Washer - thrust crankshaft	1
4	13P276	6TG-101	Pin - thrust washer, 5/32" x 1/2"	3
5	91265	10EC-204	Shim - thrust, crankshaft, .002	A.R.
6	91275	10EC-205	Shim - thrust, crankshaft, .008	A.R.
7	35P797	F600C-205	Plate - thrust, crankshaft	1
8	35P814	F600B-317	Gear - timing	1
9	13P58	X-534	Key - timing gear and fan pulley	5
10	91238	A600C-204	Thrower - oil	1
12	35P956	F102K-336	Pulley - fan drive	1
13	91245	C400K-217	Plug - keyway, fan pulley	1
14	35P758	8UC-205	Washer - jaw to crankshaft	1
15	91308	D600-0-201	Jaw - starting	1
16	35P799	F400B-343	Cup - bearing, front	1
17	35P300	F600C-3491	Bearing - crankshaft, front, (pair) standard	1
18	35P833	F600G-3491-.020	Bearing - crankshaft, front, (pair) .020 undersize	1
19	35P904	F600G-3491-.040	Bearing - crankshaft, front, (pair) .040 undersize	1
20	35P801	F400B-350	Cup - bearing, center	1
21	35P902	F400G-3111	Bearing - crankshaft, center, (pair) standard	1
21	35P335	F400G-3111-.020	Bearing - crankshaft, center, (pair) .020 undersize	1
21	35P556	F400C-3111-.040	Bearing - crankshaft, center, (pair) .040 undersize	1
22	35P802	F400B-343	Cup - bearing, rear	1
23	35P904	F600G-3471	Bearing - crankshaft, rear, (pair) standard	1
23	35P327	F600G-3471-.020	Bearing - crankshaft, rear, (pair) .020 undersize	1
23	35P906	F600G-3471-.040	Bearing - crankshaft, rear, (pair) .040 undersize	1
24	35P915	X-14455	Washer - bearing cap screws	3
25	15P277	X-2086	Screw - front and rear bearing cap, 1/2"-13 x 2-5/8"	4
27	70618	X-3511	Screw - center bearing cap, 1/2"-13 x 3-1/4"	2
29	35P903	F400D-3021	Rod - connecting, with bearings, No. 1 and 3 pistons	2
29	35P804	F400D-3031	Rod - connecting, with bearings, No. 2 and 4 pistons	2
30	35P907	F600G-341	Bearing - connecting rod, (half) 1 and 3 cyl., standard	4
30	35P909	F600G-341-.020	Bearing - connecting rod, (half) 1 and 3 cyl., .020 undersize	4
30	35P910	F600G-341-.040	Bearing - connecting rod, (half) 1 and 3 cyl., .040 undersize	4
30	35P908	F600G-342	Bearing - connecting rod, (half) 2 and 4 cyl., standard	4
30	35P901	F600G-342-.020	Bearing - connecting rod, (half) 2 and 4 cyl., .020 undersize	4
30	35P902	F600G-342-.040	Bearing - connecting rod, (half) 2 and 4 cyl., .040 undersize	4
31	911982	F400G-211	Bushing - piston pin	4
32	90385	C600D-206	Bolt - connecting rod	8
33	90368	X-18193	Nut - connecting rod bolt	8
34		X-901	GM103373 - Cover, 3/32" x 3/4"	8
35	15P279	X-7011	Ring - piston pin retainer	8
36	13P451	11EA-200	Pin - piston, standard	4
36	35P905	11EA-200-.003	Pin - piston, .003 oversize	4
36	35P905	11EA-200-.005	Pin - piston, .005 oversize	4
37	35P909	F162A-2461-E	Piston - with pin and retainers, standard	4
37	35P908	F162A-2461-E-.020	Piston - with pin and retainers, .020 oversize	4
37	35P904	F162A-2461-E-.040	Piston - with pin and retainers, .040 oversize	4
38	35P1064	F162T-208	Rings - piston, complete re-ring set, standard	1
38	35P1065	F162T-208-.020	Rings - piston, complete re-ring set, .020 oversize	1
38	35P1066	F162T-208-.040	Rings - piston, complete re-ring set, .040 oversize	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs.
		Continental Motors	
		CRANKSHAFT, FLYWHEEL, CONNECTING RODS AND PISTONS (Cont'd)	
40	35P914	Bolt - flywheel to crankshaft	6
41		GM115548 - Washer, Int. lock, 3/8"	6
42	91908	Nut - flywheel bolt	6
43	35P830	Flywheel - with ring gear	1
44	35P851	Ring Gear - flywheel	1
	91945	Screw - drive, flywheel pointer	1




Fig. 2-3 - CRANKSHAFT, FLYWHEEL, CONN. RODS AND PISTONS

MORILLIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No Pcs.	
		Continental Motors CRANKSHAFT, FLYWHEEL, CONN. RODS AND PISTONS GROUP II - FOR MODEL F102 ENGINES Used on Continental Motors No. 30123E and after.		
1	35P795	F400C-5906	Crankshaft - with bushing	1
2	91215	13LG-202	Bushing - crankshaft	1
3	35P796	D46BC-204	Washer - thrust crankshaft	1
4	15P276	6TC-101	Pin - thrust washer, 5/32" x 1/2"	3
5	91245	13EC-204	Shim - thrust, crankshaft, .002	A.R.
6	91275	13EC-205	Shim - thrust, crankshaft, .008	A.R.
7	35P797	F600C-205	Plate - thrust, crankshaft	1
8	35P814	F600H-217	Gear - timing	1
9	15P58	X-384	Key - timing gear and fan pulley	2
10	91285	A600C-204	Thrower - oil	1
12	35P858	F182K-388	Pulley - fan drive	1
13	91345	C400K-217	Plug - keyway, fan pulley	1
14	35P798	6LC-202	Washer - jaw to crankshaft	1
15	91305	D60C-0-201	Jaw - starting	1
15	35P799	F400B-048	Cap - bearing, front	1
19	35P1740	F400G-3421	Bearing - crankshaft, front, (pair) standard	1
19	35P1741	F400G-3421-.020	Bearing - crankshaft, front, (pair) .020 undersize	1
19	35P1742	F400G-3421-.040	Bearing - crankshaft, front, (pair) .040 undersize	1
20	35P811	F400B-250	Cap - bearing, center	1
21	35P1743	F400G-3441	Bearing - crankshaft, center, (pair) standard	1
21	35P895	F400G-3441-.020	Bearing - crankshaft, center, (pair) .020 undersize	1
21	35P896	F400G-3441-.040	Bearing - crankshaft, center, (pair) .040 undersize	1
22	35P863	F400B-249	Cap - bearing, rear	1
23	35P1744	F400G-3461	Bearing - crankshaft, rear, (pair) standard	1
23	35P1747	F400G-3461-.020	Bearing - crankshaft, rear, (pair) .020 undersize	1
23	35P1748	F400G-3461-.040	Bearing - crankshaft, rear, (pair) .040 undersize	1
24	35P018	X-14465	Washer - bearing cap screws	6
25	15P277	X-2988	Screw - front and rear bearing cap, 1/2"-13 x 2-5/8"	4
27	90815	X-3511	Screw - center bearing cap, 1/2"-13 x 2-1/4"	2
29	35P1757	F400D-5023	Rod - connecting, with bushing, No. 1 and 3 pistons	2
29	35P1758	F400D-3033	Rod - connecting, with bushing, No. 2 and 4 pistons	2
			Includes the following 3 parts:	
31	91195J	F400C-211	Bushing - piston pin	4
32	90396	C800D-206	Bolt - connecting rod	8
33	00385	X-12168	Nut - connecting rod bolt	8
34		X-091	GM103370 - Cotter, 3/32" x 3/4"	8
30	35P1749	F400G-340	Bearing - connecting rod, (half) 1 and 3 cyl. standard	4
30	35P1750	F400G-340-.020	Bearing - connecting rod, (half) 1 and 3 cyl. .020 under- size	4
30	35P1751	F400G-340-.040	Bearing - connecting rod, (half) 1 and 3 cyl. .040 under- size	4
30	35P1752	F400G-341	Bearing - connecting rod, (half) 2 and 4 cyl. standard	4
30	35P1753	F400G-341-.020	Bearing - connecting rod, (half) 2 and 4 cyl. .020 under- size	4
30	35P1754	F400G-341-.040	Bearing - connecting rod, (half) 2 and 4 cyl. .040 under- size	4
35	15P279	X-7311	Ring - piston pin retainer	8
36	15P451	11EA-200	Pin - piston, standard	4
36	35P905	11EA-200-.002	Pin - piston, .002 oversize	4
36	35P906	11EA-200-.005	Pin - piston, .005 oversize	4
37	35P809	F182A-2461-E	Piston - with pin and retainers, standard	4
37	35P905	F182A-2461-E- .020	Piston - with pin and retainers, .020 oversize	4
37	35P906	F182A-2461-E- .040	Piston - with pin and retainers, .040 oversize	4
38	35P1364	F182T-208	Rings - piston, complete re-ring set, standard	1
38	35P1365	F182T-208-.020	Rings - piston, complete re-ring set, .020 oversize	1
38	35P1366	F182T-208-.040	Rings - piston, complete re-ring set, .040 oversize	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs	
		Continental Motors		
		CRANKSHAFT, FLYWHEEL, CONNECTING RODS AND PISTONS (Cont'd)		
40	35P-970	F162A-247	Spacer - dng. piston top groove	4
41	35P914	C400C-206	Bolt - flywheel to crankshaft	8
42		X-297	GM115549 - Washer, Int. Lock, 3/8"	8
43	91305	X-23287	Nut - flywheel bolt	8
44	35P850	F600C-4500	Flywheel - with ring gear	1
	35P851	F400C-577	Ring Gear - flywheel	1
	8194S	X-9D43-A	Screw - drive, flywheel pointer	1




Fig. 2-3 - CRANKSHAFT, FLYWHEEL, CONN. RODS AND PISTONS

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No		DESCRIPTION	Qty. Per
		Continental Motors	CRANKSHAFT, FLYWHEEL, CONN., RODS AND PISTONS	
			GROUP III - FOR MODEL F163 ENGINES	
			Used on MA 30 Lift Trucks No. 28000186 and after.	
			Used on MA 40 Lift Trucks No. 28100344 and after.	
			Used on MA 50 Lift Trucks No. 28200186 and after.	
1	35P1937	F400G-3031	Crankshaft	1
2	35P814	F600H-317	Gear - timing	1
3	35P193E	X-675	Key - timing gear	1
4	91285	A300C-204	Thrower - oil	1
5	35P856	F1E2K-366	Pulley - fan drive	1
6	91348	C400K-217	Plug - keyway, fan pulley	1
7	35P1975	X-14295	Washer - pulley to crankshaft	1
9	35P197C	X-653E	Screw - crankcase, pulley retaining	1
9	35P1925	F600B-470	Cap - bearing, front	1
10	13P469	F600G-3911	Bearing - crankshaft, front (pair), standard	1
10	15P653	F600G-8911-.320	Bearing - crankshaft, front (pair), .320 undersize	1
10	15P654	F600G-3911-.340	Bearing - crankshaft, front (pair), .340 undersize	1
11	35P1926	F400B-359	Cap - bearing, center	1
12	35P1940	F400B-3281	Bearing - crankshaft, center (pair), standard	1
12	35P1941	F400G-8281-.320	Bearing - crankshaft, center (pair), .020 undersize	1
12	35P1942	F400G-3281-.340	Bearing - crankshaft, center (pair), .040 undersize	1
13	35P1927	F400B-301	Cap - bearing, rear	1
14	35P1943	F400G-3351	Bearing - crankshaft, rear (pair), standard	1
14	35P1944	F400G-8351-.320	Bearing - crankshaft, rear (pair), .320 undersize	1
14	35P1945	F400G-3351-.340	Bearing - crankshaft, rear (pair), .040 undersize	1
16	93135	F600B-242	Dowel - bearing, cap, front	2
16	15P53	F600B-247	Dowel - bearing, cap, center and rear	4
17	35P1929	X-6503	Bolt - place, bearing cap, front and rear, 1/2"-18 x 2-1/2" long	4
18	35P1930	X-8920	Bolt - place, bearing cap, center, 1/2"-18 x 3-1/4"	2
19	35P1933	F226D-4002	Rod - connecting, with bushing, No. 1 and 3 pistons	2
19	35P1939	F226D-3002	Rod - connecting, with bushing, No. 2 and 4 pistons	2
			Each includes the following 3 parts:	
20	911652	F400G-211	Bushing - piston pin	4
21	90335	C600D-20E	Bolt - connecting rod	5
22	90338	X-15138	Nut - connecting rod bolt	8
23		X-601	GM 103378 - Cover, 3/32" x 5/4"	6
24	15P472	F600G-389	Bearing - connecting rod (half), 1 and 3 cyl., standard	4
24	35P1948	F600G-389-.020	Bearing - connecting rod (half), 1 and 3 cyl., .020 undersize	4
24	35P1947	F600G-389-.040	Bearing - connecting rod (half), 1 and 3 cyl., .040 undersize	4
25	15P473	F600G-390	Bearing - connecting rod (half), 2 and 4 cyl., standard	4
25	35P1946	F600G-390-.020	Bearing - connecting rod (half), 2 and 4 cyl., .020 undersize	4
25	35P1949	F600G-390-.040	Bearing - connecting rod (half), 2 and 4 cyl., .040 undersize	4
26	35P1950	F245A-40H-E	Piston - with pin and retainers, standard	4
26	35P1951	F245A-40H-E-.020	Piston - with pin and retainers, .020 oversize	4
26	35P1952	F245A-40H-E-.340	Piston - with pin and retainers, .040 oversize	4
27	35P1909	X-7109	Ring - piston pin retainer	5
28	35P19E6	F600A-214	Pin - piston, standard	4
28	35P19E7	F600A-214-.009	Pin - piston, .009 oversize	4
28	35P19E8	F600A-214-.005	Pin - piston, .005 oversize	4
29	35P1971	F244A-333	Spacer - ring, piston top groove	4
30	35P1964	F162T-235	Rings - piston, complete re-ring set, standard	1
30	35P1965	F162T-208-.020	Rings - piston, complete re-ring set, .020 oversize	1
30	35P1966	F162T-208-.040	Rings - piston, complete re-ring set, .040 oversize	1

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION		No. Pcs
		Continental Motors	CRANKSHAFT, FLYWHEEL, CONN. RODS AND PISTONS (Cont'd)	
81	35P914	C400C-206	Bolt - flywheel to crankshaft	6
82		X-287	GM115549 - Washer, int. lock, 3/8"	6
83	91005	X-18237	Nut - flywheel hub	6
84	35P830	F630C-4500	Flywheel - with ring gear	1
85	25P851	F400C-377	Ring Gear - flywheel	1
	91046	X-3048-A	Screw - drive, flywheel pinover	1




FIG. 8-3A - CRANKSHAFT, FLYWHEEL, CONN. RODS AND PISTONS

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs
MUFFLER			
1	35A5236	Muffler	1
2	35A5556	Clamp - muffler to frame (35A5335)	1
		50A3666 - Bolt, hex., 3/8" x 1"	2
3	35A5306	Pipe - exhaust	1
4		50A1746 - Clamp, 1-7/8" Dia.	2
5	35A5256	Elbow - on exhaust manifold	1
6	10A3072	Stud - elbow, in manifold, 3/8" x 1-3/8"	2
		50A1090 - Nut, hex., seaz-proof, 3/8" x 16	2
		50A4226 - Washer, lock, 3/8"	2
7	10A8616	Gasket - elbow to manifold	1
	35A9105	*Muffler	1
		* 50A4190 - screw, No. 6 x 3/8"	1
		*NOTE: Used on trucks G5 or LP5 equipped.	




Fig. 2-4 - MUFFLER

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Per
		AIR CLEANER Group I Used on Trucks with Wet Type Air Cleaner.	
1	85A8270	Air Cleaner	1
		Consists of the following 4 parts:	
2	35P888	Cleaner - upper half	1
3	35P887	Oil Cup	1
4	35P886	Gasket - oil cup to upper half	1
5	35P889	Gasket - oil cup to support	1
6	85A8287	Elbow - support, air cleaner	1
		GM186124 - Bolt, hex., cad., 3/8"-16 x 1-1/4"	1
		GM120377 - Nut, hex., cad., 3/8"-16	1
7	85A8289	Stud - air cleaner to support	1
		GM126177 - Nut, wing, 1/4"-20	1
8	92968	Washer - copper, air cleaner stud, 5/16", Continental Motor No. X-14:82	1
9	35A8294	Hose - air cleaner to carburetor	1
10	35A8296	Tube - connecting hoses	1
11	35A8295	Hose - elbow to tube	1
		GM105483 - Clamp, hose, 2-3/8"	1
		GM145479 - Clamp, hose, 1-7/8"	3




Fig. 2-5 AIR CLEANER - WET TYPE

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per
<p>AIR CLEANERS - DRY TYPE</p> <p>Group II</p> <p>Used on Trucks with Dry Type Air Cleaner.</p>			
1	10A1B004	Air Cleaner - regular	1
<p>Consists of the following 8 parts:</p>			
1	10P1R73	Filter - oil cleaner	1
1	10P1R74	Cover - air cleaner	1
1	02M120240	Nut, wing, 10-32 N.F.	1
1	35A8119	Bracket - air cleaner, L-shaped	1
2	50A3666	Bolt, hex, 3/8" - 18 x 1"	2
2	50A1B00	Nut, hex, 3/8" - 18	2
1	50A2730	Nut, hex, 5/16" - 18	1
2	50A9101	Hose - reducer, air cleaner to elbow, 1-7/8" to 1-1/2" x 3-3/8" long	2
1	50A4283	Clamp, hose, top, 3-1/4"	1
1	50A4285	Clamp, hose, bottom, 1-7/8"	1
1	50A4284	Hose - air cleaner to carmanock, L-shaped, 1-1/2" O.D.	1
1	50A4282	Clamp, hose, 7/8"	1
2	50A4281	Air Cleaner - complete, 3-1/4" O.D. (Special)	2
<p>Includes the following 3 parts:</p>			
1	35P1601	Filter - element	1
1	10P2880	Nut - wing, with gasket	1
1	10P831	Clamp - assembly, cup	1
1	35P1602	Baffle - air cleaner	1
1	35P1604	Cup - air cleaner	1
1	10P2704	Cleaning Compound - filter element, 4 pound box	1
1	35A8806	Bracket - air cleaner	1
4	50A867	Bolt, hex, 5/16" - 18 x 1-1/4"	4
4	50A3730	Nut, hex, 5/16" - 18	4
2	35A8215	Band - air cleaner	2
1	35A8235	Flare - reducer, air cleaner to elbow, 45°, 2" I.D. to 1-1/2" I.D.	1
1	50A4280	Clamp, hose, 2-3/8"	1




Fig. 2-SA AIR CLEANERS - DRY TYPE

Mobilift - MA Series Lift Trucks

Ref. No.	Part No.	DESCRIPTION	No. Per
		FUEL PUMP, FUEL LINES AND FILLER - GASOLINE	
1	35P1030	Pump - fuel Includes the following 16 parts: GM103865 - Plug, pipe, 1/8"	1
2	35P870	Diaphragm and pull rod	1
3	35P877	Spring - diaphragm	1
4	35P871	Body - fuel pump	1
5	35P872	Cover and plug assembly - top	1
6	35P873	Rocker Arm	1
7	35P870	Pin - rocker arm	1
8	35P879	Washer - rocker arm pin	1
9	35P878	Spring - rocker arm	1
10	35P874	Bowl - brass	1
11	10P25	Gasket - bowl	1
12	15P24	Screen - bowl	1
13	10P347	Nail - assembly, fuel bowl	1
14	10P1869	Valve and cage	3
15	10P1862	Gasket - valve and cage	2
16	10P1866	Retainer - valve and cage	1
17	35P875	Lock - connecting	1
18	91085	Gasket - fuel pump to crankcase, Continental Motors No. 16EV-201	1
19	91075	Stud - fuel pump, 5/16"-16 x 1-3/8", Continental Motors No. X-1954-B GM120376 - Nut, hex., 5/16"-12, Continental Motors No. X-1801-E	2
	91083	Cover - fuel pump opening (for LP-Gas units only)	1
	35A5321	Tube - fuel pump to carburetor 30A4398 - Elbow, fuel tube, 5/16"-90°	1
20	35A179	Hose - fuel pump to fuel tank, 10-1/2" long	1
21		30A193 - Valve, shut-off, 1/8" NPT, in fuel tank	1
22	35A5387	Unit - tank, fuel gauge 30A5033 - Screw, round head, end., No. 10-32 x 7/16"	1
23	10A6918	Gasket - tank unit	1
	35A178	Filler - fuel tank, assembly Includes the following 9 parts:	1
24	35P56	Cap - filler	1
25	35P48F	Pin - filler cap	1
26	35P56	Arm - filler cap	1
27	35P48T	Pin - arm to cap	1
28	35P57	Spring - arm	1
29	35P58	Catch - arm	1
30	35P469	Pin - catch	1
31	35P59	Flange - screen	1
32	35P60	Screen - assembly	1
	35A9099	*Shield - gas tank filler	1
	35A7596	*Seal - gas tank filler *GM2994038 - Boot, gas tank sending unit	1
		*NOTE: Used on trucks G5 or LPS equipped.	




Fig. 2-6 - FUEL PUMP AND FUEL FILLER

MOBLIFT - MA SEALS LIFT TRUCKS

Qty.	Part No.	DESCRIPTION	No. Per.
1	50A5135	Capilator - (See the Model T8X82), Consists of the following 42 parts:	
1	35P775	Body - front, upper half	1
2	35P781	Lever - throttle	2
2	35P782	Shaft - throttle	2
4	EE9324	Disc - throttle	4
5	TOP750	Spring - throttle stop screw	5
7	GM10714 - screw, fluster head, No. 6-32 x 3/8"	Spring - throttle stop screw	7
8	TOP750	Spring - throttle stop screw	8
9	10P927	Retainer - throttle shaft parking	9
10	10P778	Cap - throttle shaft	10
11	10P929	Pin - throttle stop	11
12	35P765	Spring - governor lever	12
18	35P772	Clevis - assembly, inner	18
13	35P773	Clevis - assembly, outer	13
14	GM11048 - screw, fluster head, No. 11-24 x 7/8"	Clevis - assembly, outer	14
15	GM12081 - Nut, clevis screw, 10-24	Washer - clevis assembly	15
17	35P767	Washer - clevis assembly	17
18	35P767	Washer - clevis assembly	18
19	GM10674 - screw, fluster head, No. 12-24 x 5/8"	Cap - fuel tank to body	19
20	10P920	Fuel and lever - assembly	20
21	10P921	Shaft - fuel lever	21
22	35P997	Valve - float, with seat and gasket (matched)	22
23	10P747	Cap - float seat	23
24	10P841	Washer - 35/32" dia. throat	24
25	35P769	Needle - idle adjusting needle	25
26	10P751	Spring - idle adjusting needle	26
27	35P770	Nozzle - main assembly	27
28	EE9328	Cap - main nozzle	28
28	35P771	Jet - power	28
29	10P947	Plug - nozzle opening	29
31	35P766	Shaft - choke assembly	31
32	10P922	Retainer - choke shaft parking	32
33	10P926	Retainer - choke shaft parking	33
34	10P752	Disc - choke	34
35	EE9520	Spring - choke disc	35
36	35P766	Bracket - choke, assembly	36
37	10P756	GM11393 - screw, fluster head, No. 6-32 x 3/8"	37
38	10P756	Cup - choke bracket	38
39	GM11389 - screw, fluster head, No. 6-32 x 5/16"	Cup - choke bracket	39
40	10P756	GM11389 - screw, fluster head, No. 6-32 x 5/16"	40
41	GM11389 - screw, fluster head, No. 6-32 x 5/16"	Swivel - choke lever	41
42	10P774	Center - choke swivel	42
43	35P764	Spring - choke return	43
44	10P919	Pin - bowl drain	44
45	35P774	Pin - throttle body	45
46	10P948	Pin - idle drill	46
1	35P768	Cap - capilator (includes parts with a single asterisk)	1
1	35P772	Repair kit - capilator (includes parts with a double asterisk)	1
1	10A7713	Cap - capilator to manifold	1
2	EE130	Good - capilator to manifold, 5/16"-18 x 1-1/4"	2
2	50A3700 - Nut, hex, 5/16"-18	50A3700 - Nut, hex, 5/16"-18	2
3	50A4203 - Washer, flat, 11/32" I.D., 11/16" O.D.	50A4203 - Washer, flat, 11/32" I.D., 11/16" O.D.	3
1	50A1787 - Clevis, clip, no carburetor and	50A1787 - Clevis, clip, no carburetor and	1




Fig. 8-7 - CARBURETOR

MOHLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per
		Govt Governor No.	
		GOVERNOR	
	85P857	50345A Governor - complete	2
		Includes the following 22 parts:	
		50A4210 - Washer, plain, 13/32" I.D., 13/16" O.D.	1
1	35P881	51875-AB1 Body - assembly, with bushings, bearing and seal	1
2	92186	56031 Bearing - needle, lever shaft	1
3	15P77	51209-11 Bushing - lever shaft	1
4	92196	50027 Bushing - drive shaft	1
5	82205	50041 Washer - thrust, drive shaft	1
6	92175	50032-1A Seal - oil, lever shaft	2
7	35P862	55036-A Lever - governing, with shaft	1
8	35P883	56988 Fork - lever shaft	1
9	35P884	50306-1 Spring - bumper, lever shaft	1
10	92296	51842 Screw - bumper screw adjusting	2
11		50131-2 GM103024 - Nut, hex., 1/4"-28	1
12	35P886	51184-B Base - with bushing	1
	35P967	50313-1 Bushing - base	1
13	35P885	52095-C Shaft - drive, assembly	1
14		50042-12 GM145651 - Ball, steel, 3/4"	4
15	35P887	50794-B Race - lower	1
16	35P866	52456 Washer - thrust	1
17	35P869	59129A Plate - drive, assembly	1
18	35P100	50021 Bearing - thrust	1
19	35P101	50022 Base - lever fork	1
20	35P890	57029-3 Ring - snap	1
21	35P891	56998 Washer - retainer	1
22	15P103	50026-32 Washer - ball stop	A.R.
23	35P892	55260-A Race - upper	1
	35A5294	----- Rod - carburetor to governor, 1/4" x 6-1/8"	1
		----- 50A4201 - Washer, plain, 3/32" I.D., 5/8" O.D.	1
		----- 50A3829 - Pin, cotter, 3/32" x 5/8"	1
		Continental Motors No.	
	35P652	F140V-200 Spacer - governor to gear cover	1
		X-5821 GM179847 - Screw, governor, 5/8"-16 x 2"	1
		X-0581 GM450517 - Screw, governor, 5/8"-16 x 4-3/4"	1
		X-13282 50A1045 - Nut, elastic stop, 3/8"-16	1
	91496	X14154 Washer - copper, governor screw	1
	15P97	F140M-232 Gasket - spacer and governor	2
	32826	M600S-306 Lever - governor speed change	1
		X-602 GM107761 - Pin, cotter, 1/16" x 5/8"	1
	92685	X-10944 Stud - speed change lever, 5/16"-26 x 1-7/8"	1
		X-18210 GM102644 - Nut, hex., 3/16"-24	1
	92285	F400S-201 Plate - governor attaching	1
	32255	F400S-202 Gasket - governor plate	1
	32345	X-3665 Screw - speed adjusting	2
		X-16137 GM114492 - Nut, hex., 1/4"-28	2
	35P960	F162S-213 Deflector - oil	1
	35P1018	H405S-301 Spring - governor	1
	92315	Y400S-227 Screw - governor adjusting	1
		X-16137 GM114492 - Nut, hex., 1/4"-28	2




Fig. 2-8 - GOVERNOR

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs
		Continental Motors	
		COOLING SYSTEM	
	35P384	F228K-3722	Pump - water, complete
			Consists of the following 14 parts:
	9241S	X-102	Pipe Plug - 3/8"
1	15P175	X-3734	Screw - cover to body
2	15P174	F400K-892	Cover - water pump
3	15P173	F400K-891	*Gasket - water pump cover
4	35P1930	F401K-317	Impeller - with insert (15P168)
5	35P1931	QA 200K-3040	*Seal - water pump (15P163)
	85P955	K 000K-220	Gasket - water pump seal
6	15P172	F430K-291	*Shedder - water
7	15P171	X-7022	*Ring - seat bearing
8	35P1324	F228K-372	Body - water pump
9	16P170	X-22517	Nipple - hose, 3/8" pipe, gasoline engine
10	15P167	F228K-2230	*Shaft - water pump
11	85P1932	X-7096	*Retainer - seal (15P170)
12	35P258	F140K-369	Hub - fan
	36P1938	F400K-820	*Kit - water pump repair, includes items with an asterisk*
13		X-3838	GM179848 - Bolt, hex., 3/8"-16 x 2-1/4"
14	91436	X-14134	Washer - copper, water pump to cylinder
15	9241S	F400K-340	Gasket - water pump to cylinder
16	15P178	X-2441	Hose - water pump, gasoline engine (for F162 engine) ..
16	15P502	X-2443	Hose - water pump, gasoline engine (for F163 engine) ..
17		X-2378	GM13333 - Clamp, hose, 1"
		X-2364	50A2374 - Nipple, pipe, 3/8" x 1-1/4", gas engine ..
		X-5062	GM114128 - Elbow, pipe, 3/8"-90°, gasoline engine ..
18	35A 5889		Radiator - with pressure cap
			Includes the following 2 parts:
			50A 4430 - Valve, drain, 1/4" N.P.T.
	85P1763		Oil Cooler - radiator
19	35P280		Cap - pressure, 7#
20	35A 5844		Hose - radiator, inlet
21	33A 5345		Hose - radiator, outlet
			50A 4236 - Clamp, hose, 2-1/8" dia.
			50A 4236 - Clamp, hose, 1-7/8" dia.
22	85A 5896		Fan
			50A 3656 - Bolt, hex., 5/16"-16 x 1"
			50A 422E - Washer, lock, 5/16"
			Belt - fan
23	83A 6148		Thermostat - 180°
24	35P1037	GD157K-204	Adapter - thermostat
25	9275S	F218K-202	Housing - thermostat, gasoline engine
26	85P777	F400K-429	GM11313 - Elbow, street, 3/8", gasoline engine ..
27		X-12181	GM103666 - Plug, lock, 1/4"
28	9276S	C400K-215	Gasket - housing to cylinder head, gasoline engine ..
29	15P304	X-18337	Stud - thermostat housing, 5/16"-16 x 2"
		X-1801E	GM182834 - Nut, hex., 5/16"-16
30	35A 5337		Cushion - radiator, 5/16"-I.D., 1-3/8" O.D., 2/8" thick
31	35A 5888		Bolt - attaching radiator, 5/16"-16 x 1"
			50A 4202 - Washer, plain, 11/32" I.D., 11/16" O.D.




Fig. 2-9 - COOLING SYSTEM

MORILLIP - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
FOOT ACCELERATOR			
1	35A5889	Pedal - accelerator	1
		50A4972 - Nut, hex., 1/4"-28	1
2	35A7142	Bracket - foot pad to mount bracket	1
3	35A6480	Pin - bracket, 3/8" x 1-18/16"	1
4		50A1813 - Ring, snap, 3/8"	2
5	35A6896	Bracket - on floor plate	1
6	35A5890	Eyebolt - bracket on spring (on early models)	1
		50A1900 - Nut, hex., 3/8"-16	2
		50A2664 - Bolt, hex., 3/8"-16 x 3/4"	1
7	35A6389	Spring - eyebolt to rod (on early models)	1
7A	10A307	Spring - rod to hood support (on late models)	1
8	35A7075	Rod - throttle, pedal to carburetor	1
		50A5001 - Nut, hex., No. 10-32	1
9		50A4278 - Clevis, adjusting, No. 10-32	1
10		50A3965 - Pin, clevis, 8/16"	1
		50A3216 - Pin, cotter, 1/16" x 1/2"	1
11		50A1797 - Clip, bracket	1




Fig. 2-10 - FOOT ACCELERATOR

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		ALTERNATOR - 12 Volt, 32 Amp.	
1	35A8253	Alternator - less fan and pulley (Delco Remy No. 1100723)	1
2	35A8272	Bracket - alternator	1
		50A1926 - Bolt, hex., 3/8" - 16 x 3-1/4"	1
3	35A8568	Bracket - coil	1
		50A3849 - Bolt, hex., 1/4" - 20 x 1"	1
		50A1699 - Nut, hex., 1/4" - 20	1
		GM2977484 - Terminal	1
		GM2964093 - Boot	1
		GM120614 - Nut, hex., No. 10-32	1
		50A8753 - Nut, hex., No. 12-24	1
4	35A8802	Strip - alternator adjusting	1
5	35A8252	Harness - alternator	1
6	35A8249	Fan - alternator, 5-1/4" O.D.	1
7	35A8254	Pulley - alternator, 3-1/8" O.D.	1
8	35A8786	Belt - alternator	1
9	35A8243	Regulator - for alternator (Delco-Remy No. 1113507)	1




FIG. 2-10A - ALTERNATOR

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		VOLTAGE REGULATOR, GENERATOR, STARTING MOTOR AND DISTRIBUTOR	
1	35A6137 35A7733	Regulator - voltage (Delco-Remy No. 1119600), regulat	1
		Regulator - voltage (Delco-Remy No. 1119165), GS or LPS equipped	1
		GM56637 - R-Boot, regulator, 2" long, GS or LPS equipped	3
		GM180020 - Bolt, hex., 1/4"-20 x 3/4"	3
2	10A21339 35A6257	Generator - less fan and pulley (Delco-Remy No. 1103420), regular	1
		Generator - less fan and pulley (Delco-Remy No. 1102340), GS or LPS	1
		GM2064033 - Boot, generator, GS or LPS equipped	3
		GM124645 - Key, Woodruff, No. 5, alloy	1
	35A5134	Pulley and Fan - assembly, generator drive	1
3	36A5173 36A6206	Bracket - generator support, regulat	1
		Bracket - generator support, GS or LPS equipped	1
		50A3864 - Bolt, hex., 3/8"-16 x 3/4"	2
		50A3880 - Bolt, hex., 5/16"-18 x 1"	1
		50A3859 - Bolt, hex., 5/16"-18 x 1-3/4"	1
		50A3739 - Nut, hex., 5/16"-18	2
4	35A5171	Bar - generator adjusting	1
		50A3864 - Bolt, hex., 3/8"-16 x 3/4"	1
		50A3855 - Bolt, hex., 5/16"-18 x 3/4"	1
5	36A6067	Motor - starting (Delco-Remy No. 1107884)	1
		50A3871 - Bolt, hex., 3/8"-16 x 2-1/4"	2
		50A1909 - Nut, hex., 3/8"-18	1
		50A0755 - Nut, machine, No. 8-32	2
		GM2566377 - Boot, starter wire, GS or LPS equipped	2
6	35A5541	Adapter - starting motor	1
7	36A5130	Distributor - assembly (Aucolite Co. No. 1B1-4702)	1
		Includes the following 3 parts:	
	35P1449	Point Set - distributor (Aucolite Co. No. 1-47)	1
	35P1450	Condenser - distributor (Aucolite Co. No. 2-32)	1
	35P1772	Retor - distributor (Aucolite Co. No. 4-23)	1
8	35P202	Shaft - distributor drive (Continental Motors No. F400M-279)	1
	35P203	Clamp - distributor hold-down (for F162 engine Cont. Mtrs. No. F400M-278)	2
	Q2465	Stud - clamp (for F162 engine Cont. Mtrs. No. X-19096), 3/8"-16 x 1"	2
	35P1905	Clamp - distributor hold-down (for F163 engine Cont. Mtrs. No. F400M-257)	1
	35P1904	Stud - clamp (for F163 engine Cont. Mtrs. No. X-19002) 3/8"-16 x 1-3/8"	1
		50A1023 - Nut, hex., (Griseo) Cont. Mtrs. No. X-18337, 3/8"-16	2-1
	35P202	Clamp - distributor hold-down (Continental Motors No. F400M-278)	2
	Q2465	Stud - clamp, 3/8" x 1" (Continental Motors No. X-19096)	2
		50A1023 - Nut, hex., (Griseo), 3/8"-16 (Continental Motors No. X-18337)	2
	35P200	Washer - plain, 12/32" I.D. (Continental Motors No. X-14323)	2
9	33A5275	Cable - distributor to spark plug	4
10	10A385	Spark Plug - No. 2 Comm., Champion D-16 or AC-TC36	4
11	10A16817	Coil - ignition, with clamp	1
		50A3848 - Bolt, hex., 1/4"-20 x 1"	4
		50A1899 - Nut, hex., 1/4"-20	4
		GM2384033 - Bush, coil, GS and LPS equipped	2
12	35A6501	Bracket - coil	1
		50A4066 - Nut, hex., 7/16"-20	2
		50A4201 - Washer, plain, 3/32" I.D., 5/8" O.D.	2
13	33A5280	Cable - coil to distributor, 5" long	1




Fig. 2-11 - VOLTAGE REGULATOR, GENERATOR, STARTING MOTOR AND DISTRIBUTOR

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs
		BATTERY, BATTERY BOX, CABLES AND WIRING HARNESS	
		Group I	
		Used on MA 30 Lift Trucks to No. 25000125, Inc.	
		Used on MA 43 Lift Trucks to No. 26100543, Inc.	
		Used on MA 60 Lift Trucks to No. 28200183, Inc.	
	10P2347	Battery - dry, 12 volt, 53 amp. hr., heavy duty, type 25M	1
	10P2367	Electrolyte - 3 - 2 qt. package	7
	10P2368	Electrolyte - 5 gallon container	7
	10P2369	Fuse - electrolyte dispenser, for 5 gallon container	7
		GM3297608 - Box, battery, pass. terminal (GS and LPS equipped)	1
1	35A6281	Case - battery	1
2	35A6283	Hold-Down - battery, front	1
3	10A5938	Stud - front, hold down	1
		50A4210 - Washer, plain, 13/32" I.D., 13/16" O.D.	1
		50A3761 - Nut, wing, 3/8"-16	1
4	35A6282	Hold-Down - battery, rear	1
		50A3682 - Bolt, hex., 3/8"-16 x 1/2"	1
		50A3664 - Bolt, hex., 3/8"-16 x 3/4"	1
5	35A6171	Cable - ground, frame to battery	1
6	35A6170	Cable - start Lig motor to battery	1
	35A9124	Cable - starting motor to disconnect switch, 21-1/2" long (GS and LPS)	1
	35A2634	Harness - wiring, upper	1
	35A6458	Harness - wiring, lower	1
	35A3109	Harness - generator to regulator	1
7	10A6424	Clip - harness	3
8	10A12478	Clip - harness	2
9	13P659	Clip - harness	2
		GM120392 - Washer, plain, 7/32" I.D., 5/8" O.D.	6
	35A1966	Wire - light switch, temperature gauge and fuel gauge, 14 Ga., 6" long	2
	35A1967	Wire - ammeter and starter switch, 14 Ga., 13" long	2
	35A7720	Wire - horn relay to horn, 16 Ga., 18" long (F188)	1
	35A1103	Wire - harness to coil, 14 Ga., 8" long	1
	35A4239	Wire - meter to ground, 14 Ga., 12" long	1
	35A6146	Wire - harness to hour meter, 14 Ga., 4" long	1
10	35A7990	Hose - wiring harness cover, 7/8" O.D. x 15" long	1
		POSITIVE CRANKCASE VENTILATION	
	35A6463	Cover - valve tappet	1
	35A6463	Gasket - valve cover	1
	35A6461	Tube - breather to elbow	1
		GM9402825 - Elbow, 45°	2
		GM144068 - Pipe, coupling, 1/4"	1
	10A18718	Valve - ventilation	1
		GM128051 - Nipple, pipe, 1/4" x 1"	1
	35A6444	Gasket - cylinder stud	2
	10A18921	Breather - filter	1




Fig. 2-12 - BATTERY BOX AND CABLES

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No Pcs
		BATTERY, BATTERY BOX, CABLES AND WIRING HARNESS	
		Group II	
		Used on MA 30 Lift Trucks No. 26000126 and after.	
		Used on MA 40 Lift Trucks No. 26100544 and after.	
		Used on MA 30 Lift Trucks No. 26200186 and after.	
	10P2347	Battery - dry, 12 volt, 68 amp. hr., heavy duty, type 2 SM	-
	10P2367	Electrolyte - 2 - 2qt. package	-
	10P2368	Electrolyte - 5 gallon container	-
	10P2369	Hose - electrolyte dispenser, for 5 gallon container	-
		GM3297803 - Bolt, battery, post, terminal (UL approved)	1
1	35A6281	Case - battery	1
2	35A6282	Hold-Down - battery, front	1
3	10A9838	Stud - front, hold-down	1
		50A4210 - Washer, plain, 19/32" I.D., 19/16" O.D.	1
		50A3761 - Nut, wing, 3/8"-16	1
4	35A3232	Hold-Down - battery, rear	1
		50A8662 - Bolt, hex., 3/8"-16 x 1/2"	1
		50A3664 - Bolt, hex., 3/8"-16 x 8/4"	1
5	35A6171	Cable - ground, frame to battery	2
6	35A6170	Cable - starting motor to battery	1
	35A8192	Harness - wiring, upper	1
	35A8192	Harness - wiring, lower	1
	35A8190	Harness - generator to regulator	1
	35A8207	Harness - horn to horn button	1
		50A4668 - Clip, upper harness to cowl, 9/16"	1
		50A4662 - Clip, harness, on diff. case and trans. valve, 1/4"	2
		50A4666 - Clip, harness, on valve and bell housing, 1/2"	2
	35A1086	Wire - temperature gauge to fuel and oil gauges, 14 Ga. x 6" long	2
	35A1067	Wire - ammeter and starter switch, 14 Ga. x 13" long	1
		HEAD LAMP AND REAR TAIL LAMP	
11	10A18240	Lamp - spot light (35A5012)	1
		Includes the following 2 parts:	
12	10P1701	Unit - sealed, lamp element	1
13	10P1702	Reflector - rubber, sealed unit	1
13	30A8596	Handle - spot light control (38A5011)	1
		50A2824 - Pin, roll, 3/16" x 1-1/2"	1
		50A1921 - Nut, hex., 1/2"-13	1
16	35A4119	Knob - light control (used with 30A5011 lever)	-
17	35A6354	Label - knob, Mobilift (used on 35A4119 knob)	1
	35A8236	Knob - light control (used on 30A8596 lever)	1
		50A4637 - Ring, knob (used with 35A8236 knob)	1
18	35A7575	Bearing - with flange	1
		50A2646 - Bolt, hex., 1/4"-20 x 5/8"	2
		GM120352 - Washer, plain, 9/32" I.D., 5/8" O.D.	6
		50A4264 - washer, plain, 5/16" I.D., 3/4" O.D.	2
19	35A8591	Bracket - upright, light mount (35A7572)	1
20	35A2161	Clip - wire, spot light	4
	15A15557	Clip - wire	1
	35A1068	Wire - ignition switch to light switch, 12 ga., 5" long	1
	35A3004	Wire - with fuse, spot light and taillight, 36" long	2
	35A3009	Wire - connector to light, 14 ga., 7" long	1
	35A6723	Wire - light to ground	1
21	35A9787	Switch - light (35A408)	1
22	35A2467	Clip - wire, on lower radiator bolt	1
	35A6471	Wire - junction to switch, 14 Ga., 30" long	1
	35A6470	Wire - switch to light, 14 Ga., 50" long	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
HEAD LAMP AND REAR TAIL LAMP (Cont'd)			
23	35A3031	Lamp - tail and stop Includes the following 4 parts:	1
24	35P363	Lens - tail lamp	1
25	35P366	Retainer - lens	1
28	35P364	Gasket - retainer	1
27	35P603	Connector - with nuts and washers	2
28	35A5285	Bracket - tail light GM126957 - Bolt, rd. hd., 5/8"-11 x 4-1/2" GM102639 - Nut, hex., 5/8"-11 GM446247 - Washer, plain, 13/16" I.D., 1-1/2" O.D.	1




Fig. 2-12A - BATTERY BOX, CABLES AND LIGHTS

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		INSTRUMENT PANEL AND INSTRUMENTS	
1	35A8588	*Panel - instrument, 8-3/4" x 26-3/8" long *GM180077 - Bolt, hex., 5/16"-18 x 3/4" *50A1764 - Nut, speed, type 1, 5/16"	1 3 8
2	35A7386 35A512	**Panel - instrument, 5-5/8" wide x 26-3/8" long Gauge - ammeter	1 1
3	35A512	Gauge - engine temperature	1
4	35A519	Unit - temperature sending	1
5	35A517	Gauge - oil pressure	1
6	35A520	Unit - oil pressure sending	1
7	35A514	Gauge - fuel, gasoline engine	1
8	35A408	Switch - light (special)	1
9	35A9040	Switch - ignition and starting meter Includes the following part:	1
	35P1509	Key - switch	1
	35A8055	Washer - switch	2
10	35A4277	*Hour Meter (35A 8059)	1
10	35A8590	**Hour Meter	1
11	10A3486	*Dampener - vibration, hour meter *GM106737 - Screw, rd. hd., No. 8-32 x 3/8"	1 3
12	10A2296	*Switch - pressure, hour meter, gasoline engine	1
12	35A8116	**Switch - pressure, hour meter, gasoline engine	1
13	35A7076	*Bracket - pressure switch and sending unit	1
14	30A2312	*Hose - bracket to crankcase, 11" long, gasoline engine *GM119922 - Bushing, reducer, 1/4" x 1/5"	1 1
15	85A210	*Light - warning	1
16	35A309	*Unit - transmission warning light	1
17	35A7702	Horn (10A10699) GM120613 - Nut, gripco, 1/4"-28 (for 10A10699) Nut - horn to bracket, 7/8"-20 (for 35A7762 horn)	1 2 1
16	35A7763	Bracket - horn (10A10700) GM180076 - Bolt, hex., 5/16"-18 x 5/8"	1 2
19	35A516	*Relay - horn	1
19	35A8188	**Relay - horn *Used on MA 20 Trucks to No. 28000125, Inc. *Used on MA 40 Trucks to No. 26100543, Inc. *Used on MA 60 Trucks to No. 28200185, Inc. **Used on MA 30 Trucks No. 28000126 and after. **Used on MA 40 Trucks No. 26100544 and after. **Used on MA 60 Trucks No. 28200186 and after. 50A3648 - Bolt, hex., 1/4"-20 x 1/2" 50A1688 - Nut, hex., 1/4"-20	1 2 2
20	35A3901	Rod - choke, with knob, 16" long 50A4938 - Nut, hex., 3/8"-24	1 1
21	35A56 35A8184	Plate - warning, parking brake #Switch - electrical cut-off #GM2963921 - Boot, disconnect switch	1 1 2
	35A8342	#Decal - switch	1
	35A8227	#Cover - instrument #50A4617 - Grommet, instrument panel #GM5297603 - Boot, oil pressure switch #GM2864033 - Boot, water temperature and oil pressure sending unit #NOTE: Used on trucks GS or LPS equipped.	1 1 1 2




Fig. 2-13 - INSTRUMENT PANEL AND INSTRUMENTS

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	Qty Per
LP GAS EQUIPMENT			
1	D1186	Tank - fuel, with fittings	1
		GM120377 - Nut, hex., 3/8"-16	4
		GM120394 - Washer, plain, 13/32" I.D., 13/16" O.D.	4
	30A7139	Plate - tank mounting, with studs (KA80)	1
	36A7070	Plate - tank mounting, with studs (KA40-50)	1
		GM121386 - Bolt, rd. hd., 5/8"-11 x 5"	2
		GM122659 - Nut, hex., 5/8"-11	2
		GM448247 - Washer, plain, 11/16" I.D., 1-1/2" O.D.	4
2	35P516	Strap - mounting, fuel tank, R.H.	1
2	35P508	Strap - mounting, fuel tank, L.H.	1
	35A7156	Grommet - hose	3
3	35P1088	Vaporizer - assembly, includes thermostat housing	1
	35P1085	Repair Kit - vaporizer (includes diaphragm, seat, seals and washers)	1
4	35P1064	Solenoid - 12 volt	1
5	35P1095	Regulator - Zenith Model C	1
		Includes the following 3 parts:	
6		GM115056 - Nipple, pipe, 1/4" N.P.T.	2
7		30A972 - Elbow, street, 1/4"	1
		GM144515 - Adapter, tube, 1/4" N.P.T. x 3/8"	1
	35P1672	Valve - block and spring assembly	1
	35P1378	Screw - adjusting, fuel pressure	1
	35P1385	Orifice - fuel inlet	1
	35P1096	Repair Kit - regulator (includes diaphragm, gaskets and seals)	1
		GM213107 - Nut, hex., 3/4"-16	1
8	35P1086	Carburetor - LP gas (see breakdown on page 2-36)	1
	35P1087	Gasket - carburetor	1
9	35P509	Elbow - carburetor, 3/8" N.P.T. x 3/8" tube	1
10	35P514	Bullhead - filter	1
		Includes the following 2 parts:	
11		GM144355 - Elbow, adapter, 1/4" N.P.T. x 3/8" tube, 90°	2
	35P1608	Element - filter	1
	35P1608	Spring - filter	2
		GM125700 - Washer, internal lock, 7/8"	1
12	35P515	Relief Valve	1
	10A5097	Plate - fuel pump cover	1
	10A6843	Gasket - plate	1
	35P530	Dash - plug, instrument gauge	1
		GM178433 - Pipe, cap, gasoline tank	1
13	35P509	Elbow - adapter, 3/8" N.P.T. x 3/8" tube, x 90°	1
	35P1086	Bracket - hose, and clamp	1
14	35P1089	Hose - water bypass	1
15	35P1509	Hose - carburetor to regulator, 25" long (35P1090)	1
16	35P1091	Hose - filter to solenoid	1
17	35P1092	Hose - filter to tank	1
18	35P519	Coupling - hose to tank, female	1
19	D1178	Coupling - hose to tank, male	1
		Includes the following 2 parts:	
	30A1701	"O"-Ring - coupling	1
	35P1769	Gasket - coupling	1
20	35P625	Switch - vacuum	1
		GM181883 - Bolt, hex., 7/16"-20 x 3/4"	4
		GM271505 - Nut, hex., 7/16"-20	4
21	35P1093	Wire - solenoid to pressure switch, 24" long	1
22	35P1094	Wire - pressure switch to starter, 26" long	1
	35P1610	Gasket - thermostat housing	1




Fig. 2-14 - LP GAS EQUIPMENT

MORLIFT • MA SERIES LIFT TRUCKS

Ref No	Part No	DESCRIPTION	No. Pcs
		L.P. GAS CARBURETOR	
	35P108E	Carburetor - LP gas	1
		Includes the following 23 parts:	
1	Body - carburetor, order 35P138E assembly	1
2	35P1779	Shaft - assembly, throttle and idle stop	1
3	35P1413	Plate - throttle shaft	1
4		GM135506 - Screw, blinding head, No. 4-40 x 1/4"	2
5	35P1413	Seal - throttle shaft	2
6	35P1780	Retainer - seal	2
7	35P1779	Screw - idle adjusting	1
8	CE7117	Spring - idle adjusting screw	1
9		GM222544 - Screw, adjusting, idle stop	1
10	10P750	Spring - screw, throttle stop	1
11	35P1779	Venturi	1
12	3546R	Screw - venturi retaining	1
13	35P1761	Shaft - choke	1
14	3455K	Flare - choke shaft	1
15		GM135506 - Screw, blinding head, No. 4-40 x 1/4"	2
16	35P1762	Plug - choke shaft	1
17	35P1787	Gasket - plug	1
18	35P1783	Bracket - choke cable	1
19	3411K	Bushing - choke shaft	1
20	3042R	Clamp - choke cable	1
21	35P1738	Screw - main load adjusting, 5/16" - 24 x 1-1/4"	1
22		30A3002 - Nut, hex., 5/16" - 24	1
23	35P1784	Lever - assembly, choke shaft	1
24		GM113625 - Screw, fillister head, No. 8-32 x 5/16"	1
25	35P1785	Spring - choke return	1
26	35P761	Lever - throttle	1
	35P885	Lever - governor	1
27	35P765	Spring - governor lever	1
28	35P772	Clevis - assembly, inner and outer	2
		Includes the following part:	
29		GM110480 - Screw, fillister head, No. 10-24 x 7/8"	2
30		GM120861 - Nut, clevis, screw, No. 10-24	2
31	35P767	Washer - clevis	2
32	35P1087	Gasket - carburetor	1
33	JE180	Stud - carburetor to manifold, 5/16" - 18 x 1-1/4"	2




Fig. 2-14A - LP Gas Carburetor

MORLIIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs
TRANSMISSION CASE, CONVERTER AND PUMP			
1	35A5167	+Case - transmission	1
1	35A7529	++Case - transmission	1
		+NOTE: Used on MA 30 Lift Trucks to No. 26090145, Inc.	
		+NOTE: Used on MA 40 Lift Trucks to No. 26100626, Inc.	
		+NOTE: Used on MA 50 Lift Trucks to No. 26200205, Inc.	
		++NOTE: Used on MA 80 II Lift Trucks No. 23000146 and after.	
		++NOTE: Used on MA 40 II Lift Trucks No. 26100629 and after.	
		++NOTE: Used on MA 60 II Lift Trucks No. 26200208 and after.	
		50A3887 - Bolt, hex., 3/8"-16 x 1-1/4"	20
		50A3869 - Bolt, hex., 3/8"-16 x 1-3/4"	1
		50A3870 - Bolt, hex., 3/8"-16 x 2"	2
		50A1325 - Bolt, hex., 3/8"-16 x 2-1/2"	7
		50A1441 - Screw, cap, 3/8"-16 x 1-1/4"	1
2	35A3260	Plug - magnetic, in case	1
3	10A1540	Pin - dowel, case to housing, 3/8" x 3/4"	2
4	35A5104	Manifold - with steel balls	1
5	35A5438	*Skirt - manifold	1
		GM145641 - Ball, steel, 3/16" dia.	3
		50A3856 - Bolt, hex., 5/16"-13 x 1"	5
6	35A5909	Dip Stick	1
7	35A5806	Tube - filler, also dip stick support, 29/32" I.D., x 11-5/16" long	1
8		*50A1762 - "O" ring, fillet tube	1
	35A8059	Sump Filter - assembly	1
		Includes the following 6 parts:	
		50A3858 - Bolt, hex., 5/16"-18 x 1"	3
9	35P1494	Flange - filter mounting (35A8267)	1
		Includes the following parts:	
10	35P1502	Pin - flange	1
11	35P1501	Bolt - hex., 1/4"-20 x 4-1/2"	1
12	35P1496	Tube - section (35A819)	1
13	35P1497	Element - filter (35A813)	1
14	35P1498	Gasket - filter element	1
15	35A817	*Gasket - filter flange	1
16	35A5103	Bell Housing - with steel balls	1
		GM145657 - Ball, steel, 1/2"	3
		50A855 - Plug, pipe, socket head, 1/2"-14	1
17	35A5132	*Gasket - housing to transmission case	1
18	35A5111	Cap - bearing	1
		50A3858 - Bolt, hex., 5/16"-18 x 1-1/2"	1
19		*50A961 - "O" ring, cap	1
20	35A311	Pump - converter	1
		Includes the following 3 parts:	
		50A5032 - Bolt, hex., 5/16"-18 x 1-1/3"	7
21	10A29	"O" Ring - converter pump, 1/2" I.D., 11/16" O.D.	1
22	M53C	"O" Ring - converter pump, 5-1/2" I.D., 5-3/4" O.D.	1
23	35P613	*Seal - oil, converter pump	1
24	10A3297	*Washer - copper, pump bolts	7
25	35A5731	*Gasket - pump to housing	1
		NOTE: Parts with single asterisk () are part of 35R33.	
	35R33	Gasket Set - transmission overhaul	1
26	35A5730	Converter (Lung Model F40-261)	1
27	35A822	Kit - drive plate, converter to flywheel, with bolts and washers	1
		Includes the following parts:	
28		50A1977 - Bolt, hex., plate bolt, plate to flywheel, 5/16"-18 x 5/8"	6
29	35P1506	Washer - drive plate bolt, 5/16" I.D., 13/16" O.D.	6
30		GM9409125 - Bolt, hex., plate bolt, plate to converter, 3/8"-24 x 1/2"	6




Fig. 2-15 - TRANSMISSION CASE, CONVERTER AND PUMP

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs.
		TRANSMISSION	
	35R42	Housing - assembly, input shaft Consists of the following 11 parts:	1
1	35A2133	Housing	1
2	35A300	Piston	2
3	35A333	Plate - friction	8
4	35A334	Plate - backing	4
5	10A18453	Ring - back-up	2
6	10A15339	Ring - piston	2
7	35A336	Ring - retainer, back-up ring	2
8	35A355	Ring - oil seal	2
9	35A331	Spring - tension	2
10	35A332	Retainer - spring	2
11	35A343	Ring - snap, spring retainer	2
12	35A323	Shaft - input, 13-5/8" long GM145641 - Bull, steel, 5/16"	1 2
13	35A341	*Ring - oil seal, 1-1/4" O.D.	2
14		* 50A700 - Ring, quad., input shaft	3
15	35A5081	Gear - forward, with bushing	1
16	35A5083	Gear - reverse, with bushing	1
17	35A339	Bushing - gear	2
18	35A337	Washer - thrust, gear to spring retainer	2
19	35A369	Washer - thrust, gear to bearing	2
20	35A342	Bearing - ball, input shaft	2
21	35A991	Ring - collector, ball bearing	1
22		* 50A767 - "O" Ring, collector ring	1
23	35A993	* Ring - piston	1
24	35A990	Retainer - piston ring	1
25		* 50A768 - Ring, retainer	1
26	35B6460	* Shaft - output, with ring gear, matched +GM104115 - Rivet, button head, 5/8" x 1-1/4"	1 8
26	35B7903	++ Shaft - output, with ring gear, matched, less bull pinion	1
	35A7618	++ Shaft - bull pinion, see page 69 for illustration	1
	35A8490	++ Bolt - 12 pt., 7/16" - 14 x 3/4"	12
		+NOTE: Used on MA 30 Lift Trucks to No. 28000145, Inc. +NOTE: Used on MA 40 Lift Trucks to No. 28100628, Inc. +NOTE: Used on MA 50 Lift Trucks to No. 28200205, Inc. ++NOTE: Used on MA 30 II Lift Trucks No. 28000146 and after. ++NOTE: Used on MA 40 II Lift Trucks No. 28100629 and after. ++NOTE: Used on MA 50 II Lift Trucks No. 28200206 and after.	
27	35A5082	Gear - forward, output shaft, 21 teeth	1
28	35A5084	Gear - reverse, output shaft, 49 teeth	1
29		50A578 - Ring, snap, gear retainer	3
30	35A5116	Cone - bearing, converter end	1
31	35A5114	Cup - bearing, converter end	1
32	35A5113	Cone - bearing, trans. end case	1
33	35A5112	Cup - bearing, trans. case end	1
34	35A5314	Nut - lock, bearing to shaft	2
35		* 50A1746 - Washer, locknut *NOTE: Parts with single asterisk are part of 35R39.	1
36	35A5085	Gear - reverse idler, with bearings, 51 teeth	1
37	35A853	Bearing - needle, reverse gear	2
38	35A5304	Shaft - with roll pin, idler gear 50A2245 - Pin, roll, 5/16" x 3/4"	1 1
39	35A5312	Washer - thrust, idler gear	2





Fig. 2-16 - TRANSMISSION

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		TRANSMISSION CONTROL VALVE AND REGULATOR	
		Group I. Used on Lift Trucks with Hydraulic Inching.	
	35R55	Valve - control, complete	1
		Consists of the following 48 parts:	
		50A3663 - Bolt, hex., cad., 3/8"-16 x 1-5/8"	2
		50A8672 - Bolt, hex., cad., 3/8"-16 x 2-3/4"	2
		*50A1828 - Star-o-seal, bolts, 3/8"	4
1	35A7333	Body - valve	1
2	35A5848	Spool - directional, 2-7/32" long	1
3		50A4285 - Ball, steel, 5/16"	1
		50A4445 - Plug, pipe, hex, socket, 1/8"-27	9
4	35A608H	Spring - spool ball, 23/32" long	1
5	10A10829	Seal - oil, lever spool	2
6	85A689	Spool - inching	1
7	35A689	Spring - centering inching spool, 3/4" long	2
8	85A7766	Spring - inching spool	1
9	35A8368	Piston - inching	1
10		50A3575 - Ring, quad	2
11	35A895	Seal - piston	1
12	85A088	Washer - piston seal	1
13	35A696	Spring - inching piston, 2-1/2" long	1
14	35A5184	Plug - inching spring	1
15		50A196 - Snap ring	1
16	10A136	"O" ring - inching plug, 13/16" I.D.	1
17	35A5185	Plug - vent, inching plug	1
18	35A5210	Disc - filter, inching plug	1
19	35A275	Spool - pressure reducer, 3/4" O.D.	1
20	35A274	Spring - pressure spool, 1-3/4" long	1
21	35A1259	Valve - relief	1
22	35A1249	Piston - relief valve	1
23	35A1248	Spring - relief valve	1
24	10A6829	"O" Ring - relief valve	2
25	35A392	Spool - priority valve, 15/16" long	1
26	35A391	Guide - priority valve	1
27	35A390	Spring - priority valve	1
28	35A377	Valve - lube relief	1
29		50A4266 - Ball, steel, 3/8"	1
30	10A13108	Spring - lube relief ball, 1" long	1
31	35A5177	Block - valve, 15/16" long	3
32	35A5187	Block - valve, 5/8" long	3
33	10A6329	"O" Ring - valve blocks, 9/16" I.D.	6
34	10A6330	Ring - snap, valve blocks	6
35	35A6283	Switch - neutral starting	1
36	35A7204	Gasket - body to transmission case	1
37	35A7282	Body - pressure regulator valve	1
		50A1937 - Bolt, hex., cad., 3/8"-16 x 3-1/2"	2
		50A2249 - Bolt, hex., cad., 3/8"-16 x 4-3/8"	1
		*50A1828 - Star-o-seal, bolts, 3/8"	3
		*NOTE: Parts with single asterisk are part of 35U83.	
38	35A890	Spool - pressure regulator	1
39	35A5187	Block - spool, 5/8" long	1
40	10A6329	"O" Ring - block	1
41	10A6330	Snap Ring - spool	1
42	35A7323	Piston - regulator valve	1
43	35A7364	Spring - piston, regulator valve, center	1
44	35A7365	Spring - piston to spool, inner	1
45	35A5177	Block - piston, 15/16" long	1
46	10A6329	"O" Ring - piston, block	1
47	10A6330	Snap Ring - piston block	1
48	35A7366	Orifice - regulator valve	1
49	35A5187	Block - orifice, 5/8" long	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs.
TRANSMISSION CONTROL VALVE AND REGULATOR (Cont'd)			
50	10A832B	"O" Ring - orifice and block	2
51	10A8830	Snap Ring - block	1
52	35A736T	Screen - orifice	1
53		50A2870 - Snap ring, orifice.....	1
54		GM145841 - Ball, steel, 5/16".....	3
55		GM141112 - Pin, dowel	1
56		GM444855 - Plug, pipe, crsk, 1/8"-27	2
57		50A2878 - "O" Ring, regulator valve	5



MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
		1 TRANSMISSION CONTROL VALVE AND REGULATOR	
		Group II. Used on Lift Trucks with Mechanical Inching with Regulator.	
	39B2645	Valve - control, complete	1
		Includes the following 42 parts:	
1	35A5012	Body - valve	1
		50A2688 - Bolt, hex., 3/8"-16 x 1-1/2"	2
		50A2672 - Bolt, hex., 3/8"-16 x 2-3/4"	2
		* 50A1829 - Stat-o-seal, bolts, 3/8"	4
2	35A5848	Spool - directional, 8-7/32" long	1
8		50A4265 - Ball, steel, 5/16"	1
		50A4445 - Plug, pipe, hex. socket, 1/8"-27	3
4	35A 6063	Spring - spool ball, 25/32" long	1
5	10A18229	Seal - oil, lever spool, 3/4" I.D., 1/4" wide	2
6	35A 690	Spool - inching, 1-5/8" long	1
7	35A 639	Spring - centering, inching spool, 3/4" long	1
8	35A8027	Spring - inching spool	1
9	35B8000	Inching spool - assembly, complete, mechanical inching	1
15		50A198 - Snap Ring, sleeve retainer	1
16	35A3006	Seal - inching spool in valve housing	1
19	35A375	Spool - pressure reducer, 3/4" O.D.	1
20	35A374	Spring - pressure spool, 1-3/4" long	2
21	35A1356	Valve - relief	1
22	35A1249	Piston - relief valve	2
23	35A1248	Spring - relief valve	1
24	10A6329	"O" Ring - relief valve	2
25	35A392	Spool - priority valve, 15/16" long	1
26	35A381	Guide - priority valve	2
27	35A390	Spring - priority valve	2
28	35A377	Valve - tube relief	1
29		50A4266 - Ball, steel, 8/32"	2
30	10A18105	Spring - tube relief ball, 1" long	4
31	35A5177	Block - valve, 10/16" long	3
32	35A5187	Block - valve, 5/8" long	8
33	10A6329	"O" Ring - valve blocks, 9/16" I.D.	6
34	10A 6330	Ring - snap, valve blocks	6
35	35A 5253	Switch - neutral starting, with screw type terminals	1
36	35A7667	Switch - neutral starting, with slip type terminals	1
38	35A7364	Gasket - body to transmission case	1
37	35A7292	Body - pressure regulator valve	1
		50A1926 - Bolt, hex., 3/8"-16 x 3-1/4"	1
		50A1927 - Bolt, hex., cad., 3/8"-16 x 3-1/2"	1
		50A2849 - Bolt, hex., cad., 3/8"-16 x 4-8/8"	1
		* 50A1829 - Stat-o-seal, bolts, 3/8"	3
		* NOTE: Parts with single asterisk are part of 35B80.	
38	35A 690	Spool - pressure regulator	1
39	35A5197	Block - spool, 5/8" Long	1
40	10A 6328	"O" Ring - block	1
41	10A 6380	Snap Ring - spool	1
42	35A7523	Piston - regulator valve	1
43	35A7969	Spring - piston, regulator valve, outer	1
44	35A7365	Spring - piston to spool, inner	1
45	35A5177	Block - piston, 15/16" long	1
46	10A 6327	"O" Ring - piston, block	1
47	10A 6330	Snap Ring - piston block	1
48	35A7366	Orifice - regulator valve	1
49	35A5187	Block - orifice, 5/8" long	1
50	10A6329	"O" Ring - orifice and block	2
51	10A6330	Snap Ring - block	2
52	35A7367	Screen - orifice	2
53		50A2879 - Snap Ring, orifice	2
54		GM245641 - Ball, steel, 5/16"	3

MORRIS - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
TRANSMISSION CONTROL VALVE AND REGULATOR (Cont'd)			
55		53A5081 - Pir. dowel, 1/8" x 11/16"	1
56		GM444955 - Plug, pipe, c/sk., 1/8" -27	2
57		56A2976 - "O" Ring, regulator valve	5




FIG. 2-17A - TRANSMISSION CONTROL VALVE AND REGULATOR

MOHLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		TRANSMISSION CONTROL VALVE	
		Group III. Used on Lift Trucks with Mechanical Inching less Regulator.	
	39C1545	Valve - control, complete	1
1	35A9738	Includes the following 26 parts: Body - valve	1
		50A9568 - Bolt, hex., 3/8" - 16 x 1-1/2"	2
		50A9072 - Bolt, hex., 3/8" - 16 x 2-3/4"	6
		* 50A1329 - Stat-o-seal, bolts, 3/8"	7
		* NOTE: Parts with single asterisk are part of 35883.	
2	35A6848	Spool - directional, 6-7/32" long	1
3		50A4265 - Ball, steel, 5/16"	1
		50A4445 - Plug, pipe, hex. socket, 1/8" #27	2
4	35A6096	Spring - spool ball, 23/32" long	1
5	10A16928	Seal - oil, lever spool, 3/4" I.D., 1/4" wide	2
6	35A690	Spool - locking, 1-5/8" long	1
7	35A688	Spring - centering, locking spool, 3/4" long	1
8	35A8027	Spring - inching spool	1
9	35R800C	Locking Spool - assembly, complete, mechanical inching	1
15		50A19E - Snap Ring, sleeve retainer	1
16	35A8088	Seal - inching spool in valve housing	1
19	35A375	Spool - pressure reducer, 3/4" O.D.	1
20	35A374	Spring - pressure spool, 1-3/4" long	1
21	35A1250	Valve - relief	1
22	35A1249	Piston - relief valve	1
23	35A1249	Spring - relief valve	1
24	10A8328	O Ring - relief valve	2
25	35A392	Spool - priority valve, 15/16" long	1
26	35A391	Guide - priority valve	1
27	35A390	Spring - priority valve	1
28	35A377	Valve - lube relief	1
29		50A4266 - Ball, steel, 3/8"	1
30	10A18105	Spring - lube relief ball, 1" long	1
31	35A5177	Block - valve, 1-1/16" long	3
32	35A5197	Block - valve, 3/4" long	3
33	10A8330	O Ring - valve blocks, 9/16" I.D.	6
34	10A8330	Ring - snap, valve blocks	6
35	35A7627	Switch - neutral starting	1
36	35A5196	Gasket - body to transmission case	1




FIG. 2-17B - TRANSMISSION CONTROL VALVE

MORILLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
TRANSMISSION CONTROLS, FILTER AND OIL LINES			
Group 1 - Used on Lift Trucks with Hydraulic Inching.			
1	35A6174	Lever - hand control	1
2	35A6976	Knob - hand lever	1
3	35A6133	Support - lever, mounts to steering column	2
		GM158077 - Bolt, hex., 5/16"-16 x 3/4"	4
4	35A6120	Arm - control lever	1
		50A2832 - Pin, roll, 3/16" x 1"	2
5	35A6131	Spacer - arm, 1" O.D. x 3/4" long	1
6	35A6147	Cable - push and pull, hand lever to bell crank	1
		GM120613 - Nut, hex. jam, 1/4"-28	2
7		GM192249 - Clevis, cable to lever, 1/4"-28	1
		GM158077 - Pin, clevis, 1/4"	1
		GM127141 - Pin, cotter, 1/16" x 5/8"	1
9	35A6060	"U"-Bolt - cable to bracket, 1/4"-28	1
		GM120387 - Nut, hex., 1/4"-28	2
9	35A6046	Bellcrank	1
10		GM192249 - Clevis, bellcrank, 1/4"-28	1
		GM158077 - Pin, clevis, 1/4"	1
		GM127141 - Pin, cotter, 1/16" x 5/8"	1
11	35A7529	Support - bellcrank	1
		50A4212 - Washer, plain, 17/32" I.D., 1-1/16" O.D.	1
		50A3831 - Pin, cotter, 3/32" x 1"	1
		GM192588 - Set Screw, socket head, 3/8"-16 x 1"	1
		GM124828 - Nut, hex., jam, 3/8"-16	1
12	35A6062	Link - bellcrank to valve, 3/4" x 2-3/4"	2
13		50A3862 - Pin, link, 3/8"	2
		50A3823 - Pin, cotter, 3/32" x 3/4"	2
14	35A5893	Filter - spin-on	1
15	35A6159	Base - spin-on filter	1
16		50A2284 - Elbow, 90°, 3/8" N.P.T. to 3/4"-16 J.I.C.	2
		GM180122 - Bolt, hex., 3/8"-16 x 1"	2
17	35A6223	Tube - filter to transmission case	1
18		50A4424 - Elbow, 3/4"-10 U.N.F., 90°	1
19	10A12012	"O" Ring - elbow to case	1
20	35A1456	Hose - filter to cooler inlet	1
21	35A6145	Tube - hose to cooler	1
22	35A6297	Tube - control valve to cooler outlet	1
23	35A882	Hose - tube to cooler outlet	1
		50A4996 - Elbow, 90°, 3/8" N.P.T. to 3/4"-16	1
		50A4411 - Elbow, 45°, 3/8" N.P.T. to 3/4"-16 J.I.C.	1
24	35A6373	Elbow - tube to control valve, 3/16"-18 to 3/4"-16	1
25	10A16405	"O" Ring - elbow to control valve	1




Fig. 2-18 - TRANSMISSION CONTROLS, FILTER AND OIL LINES

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs.
		TRANSMISSION CONTROLS, FILTER AND OIL LINES	
		Group II - Used on Lift Trucks with Mechanical Inching.	
		Used on MA 20 Lift Trucks to No. 28000125, Inc.	
		Used on MA 40 Lift Trucks to No. 28000543, Inc.	
		Used on MA 50 Lift Trucks to No. 28200135, Inc.	
1	35A6174	Lever - hand control	1
2	35A6476	Knob - hand lever	1
3	35A6138	Support - lever, mounts to steering column	2
		GM180077 - Bolt, hex., cad., 5/16"-18 x 3/4"	4
4	35A6129	Arm - control lever	1
		30A2822 - Pin, roll, 3/16" x 1"	2
5	35A6181	Spacer - arm, 1" O.D. x 8/4" long	1
8	35A6147	Cable - push and pull, hand lever to bell crank	1
		GM120612 - Nut, hex. jam, 1/4"-28	2
7		GM192243 - Clevis, cable to lever, 1/4"-28	1
		GM180077 - Pin, clevis, 1/4"	1
		GM127141 - Pin, cotter, 1/16" x 5/8"	1
9	35A6060	"U" Bolt - cable to bracket, 1/4"-28	1
		GM120267 - Nut, hex., 1/4"-28	2
9	35A6002	Bellcrank - directional control	1
		Includes the following part:	
10	35A2252	Bushing - bellcrank, 1/2" wide	2
		GM121224 - Pin, cotter, 3/32" x 1"	2
11		GM193249 - Clevis, bellcrank, 1/4"-28	1
12		GM180077 - Pin, clevis, 1/4"	1
		GM127141 - Pin, cotter, 1/16" x 5/8"	1
13	35A7990	Support - bellcrank	1
14		GM102595 - Set Screw, socket head, 3/8"-16 x 1"	1
15		GM124829 - Nut, hex., jam, 3/8"-16	1
		30A4212 - Washer, plain, 17/32" I.D., 1-1/16" O.D.	1
		30A3881 - Pin, cotter, 3/32" x 1"	1
16	35A2007	Link - bellcrank to valve, U-shaped, 4-3/16" long	1
17	35A7994	Bellcrank - mechanical inching	1
		Includes the following part:	
		30A3881 - Pin, cotter, 3/32" x 1"	1
		30A4212 - Washer, plain, 17/32" I.D., 1-1/16" O.D.	1
18	35A7603	Bearing - needle, mechanical inching bellcrank	2
19	15P609	Link - connecting bellcrank to inching spool	1
20	35A3010	Spring - inching spool return	1
21	35A3013	Turnbuckle - bellcrank to pedal	1
22	35A3014	Clevis - turnbuckle to brake pedal, 3/8" x 2-1/2"	1
23		30A3852 - Pin, roll, 3/8" x 1-1/32" long	3
		30A3829 - Pin, cotter, 3/32" x 3/4"	3
24	35A7992	Clevis - turnbuckle to bellcrank, 3/8" x 5-1/4"	1
25	35A3015	Pin - clevis, 3/8" x 1-1/32" long	1
26	35A5533	Filter - spin-on	1
27	35A6159	Base - spin-on filter	1
28		30A2284 - Elbow, 90°, 3/8" N.P.T. to 3/4"-16 J.I.C.	2
		30A3566 - Bolt, hex., 3/8"-16 x 1"	2
29	35A6329	Tube - filter to transmission case	1
30		GM4910977 - Elbow, 90°	1
31	10A12012	"O" Ring - elbow to case	1
32	35A6145	Tube - assembly, filter to cooler	1
34	35A8607	Tube - control valve to cooler under (35A8287 and 35A8602)	1
		30A4995 - Elbow, 90°, 3/8" N.P.T. to 3/4"-16	1
		30A4411 - Elbow, 45°, 3/8" N.P.T. to 3/4"-16 J.I.C.	1
36	35A6373	Elbow - tube to control valve, 3/16"-15 to 3/4"-16	1
37	10A16401	"O" Ring - elbow to control valve	1




FIG. 2-18A - TRANSMISSION CONTROLS, FILTER AND OIL LINES

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs
TRANSMISSION CONTROLS, FILTER AND OIL LINES			
Group III			
Used on MA30-II Lift Trucks No. 2800012E and after.			
Used on MA40-II Lift Trucks No. 2810082B and after.			
Used on MA50-II Lift Trucks No. 28200196 and after.			
1	35A8220	Lever - hand control, in instrument panel	1
		50A2824 - Pin, roll, 1/4" x 1"	2
		50A2826 - Pin, roll, 1/4" x 1-1/4"	1
2	35A8476	Knob - hand lever	1
3	35A8228	Hub - lever	1
		50A3655 - Bolt, hex., 5/16"-18 x 3/4"	2
		50A2824 - Pin, roll, 1/4" x 1"	2
4	35A8219	Lever - directional	1
		50A2823 - Pin, roll, 1/4" x 1"	1
5	35A8248	*Ball joint - shift lever	1
		*NOTE: Used on MA30 Lift Trucks to No. 28000145, Inc.	
		Used on MA40 Lift Trucks to No. 2810082S, Inc.	
		Used on MA50 Lift Trucks to No. 28200206, Inc.	
6	35A8805	**Ball joint - shift lever	1
		**NOTE: Used on MA30-II Lift Trucks No. 28000146 and after.	
		Used on MA40-II Lift Trucks No. 2810082S and after.	
		Used on MA50-II Lift Trucks No. 28200206 and after.	
		50A3730 - Nut, hex., 5/16"-18	2
7	35A8225	Connector - link, 3/8"-16 x 1-5/8"	1
		50A1930 - Nut, hex., 3/8"-16	2
		50A3829 - Pin, cutter, 3/32" x 3/4"	2
8	35A8231	Link - bellcrank to valve, l-wraped, 3/8" x 1-15/16"	2
9	35A8221	Bellcrank - directional spool	1
		Includes the following part:	
10	35A2252	Bushing - bellcrank, 1/2" wide	2
11	35A8029	Support - bellcrank	1
		50A4212 - Washer, plain, 17/32" I.D., 1-1/16" O.D.	1
		50A3331 - Pin, cutter, 3/32" x 1"	1
12	35A7994	Bellcrank - inching control	1
		Includes the following part:	
		50A4212 - Washer, plain, 17/32" I.D., 1-1/16" O.D.	1
		50A3331 - Pin, cutter, 3/32" x 1"	1
13	35A7609	Bearing - needle, bellcrank	2
14	15P609	Link - connecting, bellcrank to inching spool	1
15	35A8010	Spring - inching spool return	1
16	35A8013	Turnbuckle - bellcrank to pedal	1
17	35A8014	Clevis - turnbuckle to brake pedal, 3/8" x 2-1/2"	1
		50A3852 - Pin, link, 3/8" x 1-1/2" long	3
		50A3829 - Pin, cutter, 3/32" x 3/4"	3
18	35A7998	Clevis - turnbuckle to bellcrank, 3/8" x 2-1/4"	1
20		GM192420 - Nut, hex. jam, L.H., 3/8"-16	1
21	35A8015	Pin - clevis, 3/8" x 1-1/32" long	1
22	35A8033	Filter - spin-on	1
23	35A8158	Base - spin-on filter	1
24		50A2284 - Elbow, 90°, 3/4" N.P.T. to 3/4"-16 J.I.C.	2
		50A3666 - Bolt, hex., 3/8"-16 x 1"	2
25	35A6829	Tube - filter to transmission case	1
26		GM4913977 - Elbow, 90°	1
27	10A12012	"O" Ring - elbow to case	1
28	35A6143	Tube - assembly, filter to cooler	1
29	35A8607	Tube - control valve to cooler outlet (35A6887 and 35A962)	1
		50A4995 - Elbow, 90°, cooler inlet, 3/8" N.P.T. to 3/4"-16	1
		50A4441 - Elbow, 45°, cooler outlet, 3/8" N.P.T. to 3/4"-16	1
30	35A6373	Elbow - tube to control valve, 3/16"-16 to 3/4"-16	1
31	10A16405	"O" Ring - elbow to control valve	1




FIG. 2-18B • TRANSMISSION CONTROLS, FILTER AND OIL LINES

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
HYDRA-LIZER, STEERING WHEELS AND LINKAGE			
1	36A6394	Fork - steering, right hand (36A5166)	1
2	36A6395	Fork - steering, left hand (36A5527)	1
3		50A1719 - Nut, hex., lock, 1" - 14 N.F.	2
		50A2167 - Washer, flat, 1/8" x 1-1/32" I.D., 1-5/8" O.D.	2
		50A4997 - Nut, hex., slotted, 1" - 14 N.F.	2
		50A2534 - Washer, flat, 3/16" x 1-1/64" I.D., 1-3/4" O.D.	2
		50A3601 - Pin, cotter, 3/16" x 2-1/4"	2
4	36A7337	Stop - assembly, fork, used only with 36A5166 and 36A5527 forks	2
		GM130176 - Bolt, hex., 1/2" - 13 x 1-1/4", for 36A7336 stop	4
		50A2647 - Set Screw, hex. socket, 3/8" - 16 x 1"	4
		50A3742 - Nut, hex., jam, 3/8" - 16	4
5	36A5102	Wheel - less cushion tire	2
6	35A6356	Tire - cushion, 5" x 10" x 10-1/2"	2
7	35A6174	Seal - oil, 2-11/16" I.D., 3-7/8" O.D.	2
8	35A3146	Cap - hub, 4-1/8" O.D.	2
9	36A4101	Cone - bearing, inner	2
10	10A7292	Cup - bearing, inner	2
11	10A7061	Cone - bearing, outer	2
12	10A7062	Cup - bearing, outer	2
13	36A6136	Cylinder - right hand	1
14	36A5157	Cylinder - left hand	1
		50A5035 - Bolt, hex., 3/4" - 16 x 1-3/8"	2
		50A933 - Plug, pipe, 1/2" N.P.T.	2
15	35A8403	Bushing - inside cylinder, 4-1/2" I.D., 5" O.D.	2
16	35A6431	Retainer - bushing	2
17	35A9577	Ring - lock, retainer	2
18	35A6404	Seal - oil, in cylinder	2
19	36A6038	Piston - with bushing (36A5163)	2
20	35A6402	Bushing - piston, outer, 4-8/4" I.D., 5" O.D.	2
21		50A1731 - Ring, quad., piston	4
22	10A7330	Cone - bearing, piston, upper	2
23	10A7331	Cup - bearing, piston, upper	2
24	35A4161	Cone - bearing, piston, lower	2
25	10A7292	Cup - bearing, piston, lower	2
26	35A6174	Seal - oil, piston bearing, 2-13/16" I.D., 3-7/8" O.D.	2
27	35A5184	Head - piston, with threaded holes, 8/8"-16	2
27	35A3605	Head - piston, with drilled holes, 1/32"	2
		50A1376 - Bolt, lock, 5/16" - 18 x 3/4", for 35A3605 head	2
28		50A1760 - "O" Ring, piston head	2
29	35A5161	Tube - with nuts, connecting cylinders	1
		50A2251 - Connector, 3/8" P.T. to 1/2" tube	2
30	35A5196	Socket - tie rod, 9" long, R.H. thread	2
31	35A554	Socket - tie rod, 3-3/4" long, L.H. thread	2
		GM102647 - Nut, hex., slotted, 1/2" - 20	4
		GM108896 - Cotter, 1/8" x 1"	4
		GM271291 - Fitting, grease, 1/4" - 28	4
32	10P1331	Cover - dust, tie rod socket, rubber	4
33	36A696	Sleeve - adjusting, tie rod, 7/8" O.D. x 5-5/8" long	2
34	35A537	Clamp - adjusting sleeve	4
		50A3608 - Bolt, hex., 3/8" - 16 x 1-3/8"	4
		50A1900 - Nut, hex., 3/8" - 16	4
35	35A6194	Housing - steering	1
36		50A3000 - Nut, hex., slotted, 3/8" - 16	1
		50A9768 - Pin, cotter, 1/8" x 1"	1
		50A4203 - Washer, plain, 21/32" I.D., 1-5/16" O.D.	1
37	10A7332	Cone - bearing, steering housing, lower	1
38	10A7333	Cup - bearing, steering housing, lower	1
39	35A5383	Cone - bearing, with seal, steering housing, upper	1
40	10A14362	Cup - bearing, steering housing, upper	1
41	20H3364	Cap - bearing, steering housing, lower	1

MOHIFT - MA SERIES LIFT TRUCKS

Part No.	DESCRIPTION	Part No.	Ref. No.
1	GM10868 - Pin, pipe, 1/2"	35P1051	1
1	Housing - with bushing	85P984	2
1	Jack - steering column	35P1052	3
1	GM1B7540 - Grommet, rubber		
1	Shaft - steering, with worm	35P1059	4
1	Bearing - steering shaft, upper	85P952	5
1	Spring - upper, bearing	85P956	6
1	Seat - upper bearing spring	85P955	7
1	Code - bearing, steering worm	10P2280	8
2	Cup - bearing, steering worm	10P2281	9
2	Bearing - bearing	10P2282	10
1	Ball - steel, steering worm	35P951	11
4	Guide - ball return	85P1061	12
1	Clamp - ball guide	35P1380	13
1	Block - ball, steering worm	35P1062	14
1	Adjuster - worm, lateral bearing	10P2279	15
1	Nut - lock, bearing adjuster	10P2291	16
1	Shaft - cross, with gear	10P2280	17
1	Hacking - steering arm	10P2282	18
1	Nut - steering arm	10P2283	19
1	Cover - side, with bushing	10P2280	20
1	Bracket - side cover	10P2280	21
1	Adjuster Kit - lead adjuster, side cover	13P546	22
1	Screw - lead adjusting, side cover	85P559	23
1	Nut - lead adjusting screw	13P587	24
1	Arm - steering	35A6581	25
1	Steering Wheel	35A6138	26
1	GM11498 - Nut, steering wheel, part, 1/2"-20		27
1	Wilton - horn	35A6142	28
1	Cover - horn button	35A6141	29
1	Plate - base	35A6444	30
1	Cup - contact	35A6443	31
3	GM14022 - screw, rd. hd., No. 10-12 x 5/8"		32
1	Spring - contact cup	35A6441	33
1	Cap - contact	35A6445	34
2	Bush - contact to sleeve	35A6442	35
1	Sleeve - contact bush	35A6438	36
1	Spring - bush, in sleeve	35A6440	37
Group 1 MA 80 Low Power Steering STEERING LINKAGE ASSEMBLY			
No. Pcs.		Part No.	Ref. No.

MODLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pos.
STEERING GEAR Group II Used on MA 30 with Power Steering and MA 40 and MA 60.			
1	35A8797	Gear - steering, assembly, less jacket and shaft (35A8895)..... Includes the following 21 parts: 35A3676 - Bolt, hex., 7/16"-14 x 2-1/4" 35A1933 - Bolt, hex., 7/16"-14 x 2" 35A1294 - Bolt, hex., 7/16"-14 x 2-1/2"	1 2 1
2	35P932	Housing - with bearing and connector	1
3	35P944	Bearing - pinion shaft	1
4	35P934	Gear - assembly	1
5	35P938	Rack - piston nut assembly, with worm	1
6	35P949	Ring - piston	1
7	35P948	Guide - ball return	1
7A	35P1787	Kit - recirculating balls	1
8	35P947	Clamp - return guide	1
9	35P940	Plug - piston rack	1
10	35P955	Valve - assembly	1
11	35P930	Spring - valve spool	1
12	35P957	Bearing - thrust, valve assembly, lower	1
13	35P953	Bearing - thrust, valve assembly, upper	1
14	35P927	Plug - adjuster, assembly	1
15	35P952	Bearing - needle, adjuster plug	1
16	35P943	Nut - lock, adjuster plug	1
	35P939	Kit - seal, adjuster plug	1
17	35P929	Cover - side, with bushing	1
18	35P945	Nut - lock adjuster screw	1
19	35P959	Plug - housing end	1
20	35P941	Kit - service, consists of seals, rings and washers	1
20A	35A8798	Steering Shaft and Column Assembly	1
		Includes the following 8 parts:	
21	35P1880	Shaft - steering, with flange assembly (35P926)	1
22	35P1881	Jacket - with bearings, bushing and seal (35P950)	1
		Includes the following 4 parts:	
23	35P1882	Bushing - jacket, lower (for 35A8798 steering shaft).....	1
24	35P952	Bearing - assembly, upper	1
25		GM187049 - Grommet, rubber, 1/4" I.D.	1
26	35P954	Seal - oil, lower bearing	1
27	35P958	Retainer - lower bearing seal	1
28	35P955	Sear - spring, upper bearing	1
29	35P956	Spring - upper bearing	1
30	35P931	Flange - assembly, lower (for 35A8295 steering gear)	1
33	35A8712	Bushing - steering shaft, lower (for 35A8295 steering gear) (35P951)	1
	35A8799	Bolt - 12 F., flange mounting, 3/8"-24 x 1-1/4"	1
31	35A8300	Arm - steering	1
32	35P963	Nut - shaft to steering arm	1
33	35A6136	Wheel - steering	1
34		GM114496 - Nut, steering wheel, 1/2"-20	1
		35A4212 - Washer, wheel nut, 17/32" I.D., 1-1/16" O.D.	1
35	35A6142	Button - horn	1
36	35A6141	Cover - horn button	1
37	35A6444	Plate - base	1
38		35A5034 - Screw, rd. hd., No. 10 x 1/2"	3
39	35A6443	Cup - contact	1
40	35A6441	Spring - contact cup	1
41	35A6445	Cap - contact	1
42	35A6442	Brush - contact in sleeve	2
43	35A6137	Sleeve - contact brush	1
44	35A6443	Spring - brush, in sleeve	1




Fig. 2-21 - STEERING GEAR, MA30 w/POWER STEERING AND MA40 AND 50

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pos.
		DIFFERENTIAL AND AXLE	
		Group 1	
		Used on MA 80 Lift Trucks to No. 28000145, Inc.	
		Used on MA 40 Lift Trucks to No. 26100225, Inc.	
		Used on MA 50 Lift Trucks to No. 26300205, Inc.	
1	85A5180	Case - differential	1
		50A3867 - Bolt, hex., 3/8"-16 x 1-1/4"	11
2	10A11543	Pin - dowel, 3/8" x 3/4"	2
	35A5453	Stud - diff. case to trans. case, 3/8"-16 x 1-3/8"	9
		GM120377 - Nut, hex., 8/9"-16	9
8	35A8843	*Shim - diff. case to trans. case, .002 thick (35A8833)	A.R.
3	35A8844	*Shim - diff. case to trans. case, .003 thick (35A8836)	A.R.
3	35A8845	*Shim - diff. case to trans. case, .005 thick (35A8837)	A.R.
		NOTE: Parts with single asterisk () are part of 35R23.	
5	3886460	Ring Gear - with bull pinion and output shaft, 14 teeth	1
6	10A7059	Cone - bearing, pinion shaft, left hand	1
7	10A7060	Cup - bearing, pinion shaft, left hand	1
8	10A7051	Cone - bearing, pinion shaft, right hand	1
9	10A7052	Cup - bearing, pinion shaft, right hand	1
10	85A5150	Cup - bearing, pinion shaft, right hand	1
11		50A1743 - "O" Ring	1
12	85A5442	Shim - right hand bearing cap, .002	A.R.
13	85A5441	Shim - right hand bearing cap, .003	A.R.
14	85A5440	Shim - right hand bearing cap, .005	A.R.
15	85A5287	Cup - bearing, pinion shaft, left hand	1
16		50A1744 - "O" Ring	1
17	35A5445	Shim - left hand bearing cap, .002	A.R.
18	35A5444	Shim - left hand bearing cap, .003	A.R.
19	85A5443	Shim - left hand bearing cap, .005	A.R.
	88A2240	Cage - differential assembly, 4 pinion, with bull gear, 29 T., (80A5087) .. includes the following: 1 - 36A8862 cage, 2 - 35A5130 gear, A.R. - 35A7262, 35A7268, 85A7234, 85A5553 washer, 1 - 35A7609 shaft, 4 - 35A5131 pinion, 4 - 35A7613 washer, 1 - 35A5351 cover, 8 - 35A8491 bolt.	1
20	36A8852	++Cage - differential, with bull gear and bushing, 29 teeth	1
21	10A8225	Cone - bearing, differential cage, left hand	1
22	10A8227	Cup - bearing, differential cage, left hand	1
23	35A5291	++Cage - differential, right hand	1
		+50A2834 - Pin, roll, 3/16" x 1-1/2"	1
23	35A8861	++Cage - cover, differential, right hand	1
	85A8491	++Bolt - cage cover, 12 pt., 3/9"-16 x 8/4"	8
24	8027H	Cone - bearing, right hand cage	1
25	10A6335	Cup - bearing, right hand cage	1
26	35A5132	++Pinion - differential cage	2-4
27	35A5129	++Shaft - differential pinion, 3/4" x 5"	1
	35A7309	++Shaft - differential pinion	1
28	35A5127	++Washer - thrust, pinion to cage, beveled, 49/64" I.D., 1-21/32" O.D. ...	2
	35A7313	++Washer - thrust, pinion to cage, beveled with lock, 49/64" I.D., 1-21/32" O.D.	4
		*NOTE: Used on lift trucks with 2 pinion differential.	
		++NOTE: Used on lift trucks with 4 pinion differential as listed for serial numbers in heading.	
29	35A5303	Shaft - axle, with flange, 17-3/16" long	2
30	35A5180	Gear - bevel, on axle	2
31	35A7282	Washer - thrust, bevel gear, 1-3/4" I.D., 2-13/16" O.D. x .030	A.R.
31	35A7268	Washer - thrust, 1-8/4" I.D., 2-13/16" O.D. x .032	A.R.
31	35A7264	Washer - thrust, 1-3/4" I.D., 2-13/16" O.D. x .035	A.R.
31	35A8353	Washer - thrust, 1-3/4" I.D., 2-13/16" O.D. x .036	A.R.
32	35A5305	Housing - axle, left hand	1
		GM180175 - Bolt, hex., 1/2"-13 x 1-1/4"	12
33	10A7848	"O" Ring - housing to case, 4-1/8" dia.	1




FIG. 2-22 - DIFFERENTIAL AND AXLE

MOBILIFT - MA SERIES LIFT TRUCKS

Part No	DESCRIPTION	No Pcs
34	Shaft - housing to case, 1.000	A.R.
35	Shaft - housing to case, 1.000	A.R.
36	Shaft - housing to case, 1.000	A.R.
37	Housing - bearing, with oil seal and steel half GM145887 - Ball, steel, 3/16" dia.	2
38	Seal - oil, bearing housing	10A19178
39	Oil ring - axle flange to housing, 4-7/8" O.D.	10A10135
40	Cone - bearing, axle to housing (10A8440)	50A1702
41	Cup - bearing, axle to housing	10A6441
42	50A1740 - Ring, bearing retainer	
43	Shaft - bearing, 0.020	55A7275
44	Shaft - bearing, 0.020	55A7276
45	Shaft - bearing, 0.020	55A7277
46	Shaft - bearing, 0.020	55A7278
47	Shaft - bearing, 0.030	55A7279
48	Shaft - bearing, 0.030	55A7280
49	Shaft - bearing, 0.035	55A7281
50	Shaft - bearing housing, 0.002	55A5436
51	Shaft - bearing housing, 0.002	55A5437
52	Shaft - bearing housing, 0.020	55A5438
53	Wheel - drive, less cushion tire, MA 30	55A5591
54	Tire - cushion, 8" x 12-1/8" x 15", MA 50	55A5592
55	Wheel - drive, less cushion tire, MA 40	55A5593
56	Tire - cushion, 7" x 12-1/8" x 15", MA 40	55A5594
57	Wheel - drive, less cushion tire, MA 50	55A5595
58	Tire - cushion, 8" x 12-1/8" x 15", MA 50	55A5596
59	Shaft - drive wheel to housing, 3/16" dia	55A5597
60	Bearing - differential case, 1/4" N.P.T.	55A5598

Group 1 (Cont'd)
 Used on MA 30 Lift Trucks to No. 29800145, Inc.
 Used on MA 40 Lift Trucks to No. 26100228, Inc.
 Used on MA 50 Lift Trucks to No. 26200205, Inc.

DIFFERENTIAL AND AXLE (Cont'd)




FIG. 9-22 - DIFFERENTIAL AND AXLE

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs.
		DIFFERENTIAL AND AXLE Group II	
		Used on MA 30 II Lift Trucks No. 28000146 and after. Used on MA 40 II Lift Trucks No. 28100628 and after. Used on MA 50 II Lift Trucks No. 28200206 and after.	
1	35A7815	Case - differential	1
2	35A8753	Washer - studs and bolts, 3/4" O.D.	10
		50A1441 - Bolt, 12 pt., 3/8"-16 x 1-1/4"	3
		50A5098 - Stud, case, 3/8"-16 x 1-3/4"	7
		50A1900 - Nut, hex., 3/8"-16	7
3	10A11543	Pin - dowel, 3/8" x 3/4"	2
4	35A8843	*Shim - differential case to transmission case, .002 thick	A.R.
4	35A8844	*Shim - differential case to transmission case, .003 thick	A.R.
4	35A8845	*Shim - differential case to transmission case, .005 thick	A.R.
5	35A7818	Shaft - bull pinion, 12 teeth	1
8	35B7803	Ring Gear and Pinion - matched set	1
7	35A8400	Bolt - ring gear, drilled, 12 pt., 7/16"-14 x 3/4"	12
8	10A7058	Cone - bearing, pinion shaft, left hand	1
9	10A7060	Cup - bearing, pinion shaft, left hand	1
10	10A7051	Cone - bearing, pinion shaft, right hand	1
11	10A7052	Cup - bearing, pinion shaft, right hand	1
12	35A8244	Cap - bearing, pinion shaft, right hand	1
13		50A1748 - "O" Ring, cap, 8-8/16" O.D.	1
		50A2704 - Screw, cap, 3/8"-16 x 1"	5
14	35A5442	Shim - right hand bearing cap, .002	A.R.
14	35A5441	Shim - right hand bearing cap, .003	A.R.
14	35A5440	Shim - right hand bearing cap, .005	A.R.
15	35A7817	Cap - bearing, pinion shaft, left hand	1
16		50A1744 - "O" Ring, bearing cap, 8-7/16" O.D.	1
		50A2704 - Screw, cap, 3/8"-16 x 1"	2
		50A2705 - Screw, cap, 3/8"-16 x 1-1/4"	2
17	35A8241	Shim - left hand bearing cap, .002	A.R.
17	35A8242	Shim - left hand bearing cap, .003	A.R.
17	35A8243	Shim - left hand bearing cap, .005	A.R.
18	35A7806	Cage - differential, with bushing and bull gear, 31 teeth	1
		Includes the following part:	
19	35A8482	Bushing - cage (ream to fit)	1
20	35A8237	Cone - bearing, differential cage, left hand	1
21	35A8238	Cup - bearing, differential cage, left hand	1
22	35A7807	Cover - differential cage, with bushing, right hand	1
		Includes the following part:	
23	35A8482	Bushing - cover, (ream to fit)	1
24	35A8481	Bolt - cover, 12 pt., 3/8"-16 x 3/4"	8
25	35A8235	Cone - bearing, right hand cage cover	1
26	35A8236	Cup - bearing, right hand cage cover	1
27	35A8234	Pinion - differential cage	4
28	35A7809	Shaft - differential pinions	1
29	35A7812	Washer - thrust, pinion to cage	4
		*NOTE: Parts with single asterisk are part of 35R33.	




FIG. 2-22A - DIFFERENTIAL AND AXLE

MOBILECT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		DIFFERENTIAL AND AXLE (Cont'd) Group II (Cont'd)	
		Used on MA 30 II Lift Trucks No. 28000146 and after. Used on MA 40 II Lift Trucks No. 26100629 and after. Used on MA 50 II Lift Trucks No. 26200206 and after.	
30	35A8246	Shaft - axle, with flange, 17-3/16" long.....	2
31	35A7808	Gear - bevel, on axle, 18 teeth	2
32	35A7814	Race - bearing, bevel gear, 1/16" x 2" I.D. x 2-23/32" O.D.	2
33	35A7815	Bearing - drum, bevel gear	2
34	35A7812	Shim - thrust bearing, .002 x 2" I.D., 2-25/32" O.D.	A.R.
34	35A7810	Shim - thrust bearing, .003 x 2" I.D., 2-23/32" O.D.	A.R.
34	35A7811	Shim - thrust bearing, .005 x 2" I.D., 2-23/32" O.D.	A.R.
35	35A8364	Housing - axle, left hand	1
		50A3660 - Bolt, hex., 1/2"-13 x 1-1/4".....	11
36	M333	"O" Ring - housing to case, 4-1/4" O.D.	1
37	35A5446	Shim - housing to case, .002	A.R.
37	35A5447	Shim - housing to case, .003	A.R.
37	35A5448	Shim - housing to case, .005	A.R.
37	35A5711	Shim - housing to case, .050	A.R.
38	35A6028	Seal - axle housing and differential case, outer ends	2
39	35A5493	Collar - housing, seal retainer	2
40	35A8360	Housing - bearing	2
		50A2746 - Screw, flat head, 3/8"-16 x 1"	4
41	35A8229	Seal - oil, bearing housing	2
42	35A7752	Cone - bearing, axle to housing	4
43	10A8441	Cup - bearing, axle to housing	4
44		50A1740 - Ring, bearing retainer	2
45	35A7276	Shim - bearings, .020	A.R.
45	35A7270	Shim - bearings, .022	A.R.
45	35A7277	Shim - bearings, .026	A.R.
45	35A7273	Shim - bearings, .023	A.R.
45	35A7279	Shim - bearings, .020	A.R.
45	35A7280	Shim - bearings, .022	A.R.
45	35A7281	Shim - bearings, .036	A.R.
46	35A5436	Shim - bearing housing, .002	A.R.
46	35A5435	Shim - bearing housing, .003	A.R.
46	35A5494	Shim - bearing housing, .020	A.R.
47	35A6501	Wheel - drive, less cushion tire, MA 30	2
48	35A6580	Tire - cushion, 6" x 12-1/8" x 18", MA 30	2
47	35A6282	Wheel - drive, less cushion tire, MA 40	2
48	35A6347	Tire - cushion, 7" x 13-1/8" x 18", MA 40	2
47	35A6387	Wheel - drive, less cushion tire, MA 50	2
48	35A6338	Tire - cushion, 8" x 12-1/8" x 18", MA 50	2
49		50A3084 - Stud, drive wheel to housing, 5/16"-12 x 2-7/16".....	16
		50A1036 - Nut, hex., 9/16"-12	16
50	35A3381	Breather - differential case, 1/4" N.P.T.	1
51	35A8241	Plug - inspection, hex head, 2-1/2"-1E	1
52	35A8250	Washer - plug, (copper), 2-7/8" O.D.	1




FIG. 2-22A - DIFFERENTIAL AND AXLE

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		BRAKES	
1	35A5774	Brake - complete, right hand	1
1	35A5775	Brake - complete, left hand	1
		50A1279 - Screw, cap, 5/8" - 18 x 1"	12
2	35P1562	Plate - backing, right and left hand brake (35P964)	2
8	35P966	Shoe - brake, with lining, bonded	4
5	35P970	Link - lever, assembly, right hand brake	1
6	35P974	Link - lever, assembly, left hand brake	1
7	35P969	Pin - hold-down, brake shoe	4
8	35P104	Spring - hold-down pin	4
9	35P108	Retainer - hold-down pin	8
10	35P966	Spring - brake shoe return	2
11	35P98	Spring - brake shoe retainer	2
13	35P972	Push Rod - cylinder	4
14	35P967	Cylinder - wheel	2
		50A1405 - Bolt, hex., 1/2 pr. socket, 5/16" x 1 1/2"	4
15	35P64E	* Spring - wheel cylinder	2
16	M1572	* Cup - spring	4
17	35P977	Piston - cylinder	4
18	35P978	* Box - cylinder	4
	35R49	* Kit - wheel cylinder	1
		* NOTE: Kit includes parts identified with a single asterisk.	
19	35P975	Screw - bleeder, wheel cylinder	2




Fig. 2-23 - BRAKES

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	Qty
DRAKE LINKAGE AND MASTER CYLINDER			
1	35A5571	Pedal - brake and inching	1
2	36A7591	Support - with bearing, brake pedal,	1
		50A366 - Bolt, hex., 1/2"-28 x 1-1/2"	3
3	35A7592	Bearing - support, 3/4" I.D., 1" O.D.	4
4	36A7688	Shaft - brake pedal, 3/5" x 4-1/4"	1
5	35A5574	Bellcrank - pedal to master cylinder	2
6	35A7590	Shaft - bellcrank to support, 3/4" x 5-1/4"	1
7	36A5576	Hub - with clevis, cylinder to bell crank, used with 56A3877 cylinder	1
		50A2826 - Pin, roll, 1/4" x 1-1/4"	3
8	35A2250	Clevis - bell crank and cylinder rod	1-2
9		50A4284 - Clevis, brake pedal, 7/16"	1
10		50A3856 - Pin, clevis, 7/16"	3
		50A3829 - Pin, cotter, 3/32" x 5/4"	3
11	35A800	Pad - brake pedal	2
		50A4988 - Nut, hex., 3/8"-24	2
12	35A5378	*Spring - pedal return	1
12	35A8010	**Spring - pedal return	1
13	35A5858	Lever - hand brake	1
		50A3070 - Bolt, hex., 3/8"-16 x 8"	2
		50A1345 - Nut, hex., 3/8"-16	2
14	35A5860	Cable - lever to right hand brake, 22" long	1
15	35A5860	Cable - lever to left hand brake, 58-5/4" long	1
		50A802 - Clip, brake cable	1
		GM199016 - Bolt, hex., 1/4"-20 x 1/2"	1
		GM120075 - Nut, hex., 1/4"-20	1
16	35A169	Pin - cable to lever, 5/16" x 13/16"	2
		50A2829 - Pin, cotter, 3/32" x 5/4"	2
17	35A190	Clamp - cable	4
		50A8055 - Bolt, hex., 5/16"-18 x 3/4"	2
		50A3659 - Bolt, hex., 5/16"-18 x 1-3/4"	1
		50A9730 - Nut, hex., 5/16"-18	1
18	35A191	Spacer - between clamps, 1/2" x 1/2"	1
18	35A5861	Pin - clevis, 1/4" x 5/8"	2
		50A5516 - Pin, cotter, 1/26" x 5/8"	2
20	55A5377	Cylinder - master, 1", see page 2-70 for breakdown	1
	35A3956	Cylinder - master, 7/8", see page 2-76 for breakdown	1
		50A4910 - Bolt, hex., 3/8"-16 x 1-2/8"	2
		50A954 - Plug, sq. hd., 1/8"	1
21	35A5864	*Cross - in master cylinder, 4 way, 3/8"-24 to 1/8"-27 N.P.T.	1
		**50A4754 - Tee, cylinder, 3 way, 3/8"-24 to 1/8"-27 N.P.T.	1
		**50A954 - Plug, sq. hd., 1/8"-27 N.P.T.	1
22	35A6332	Tube - cross to right hand brake	1
23	35A6330	Tube - cross to left hand brake	1
24		50A1781 - Connector, tube to brake	2
25		50A940 - Bolt, connector	2
26		50A941 - Gasket, bolt to connector	2
27		50A337 - Gasket, connector to brake	2
28	35A6328	*Tube - cross to inching valve	1
		*GM137420 - Elbow, valve, 3/8"-24 to 1/8"-27 N.P.T.	1
		*Notes: Used on trucks with hydraulic inching.	
		**Notes: Used on trucks with mechanical inching.	
29	10A6424	Clip - brake tubes	2
30	35A587	Switch - stop light	1




Fig. 2-24 - BRAKE LINKAGE AND MASTER CYLINDER

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
		MASTER CYLINDER - 1"	
		Group I	
1	35A5377	Cylinder - master, 1" (Order 35A8063) Includes the following 6 parts:	1
2	35P961	*Valve - check	1
3	35P923	Spring - check valve	1
4	10P208	*Cup - check valve spring	1
5	35P962	*Piston	1
6	35P963	*Lockring	1
7	35P251	*Boot - rubber	1
8	35P925	Cap - filler	1
9	35P924	Gasket - filler cap	1
	35P922	*Repair Kit - for 1" cylinder	1
		NOTE: Repair Kit consists of parts identified with an asterisk ().	
10	30A5376	Rod - with clevis, cylinder to bell crank	1
		MASTER CYLINDER - 7/8"	
		Group II	
11	35A8058	Cylinder - master, 7/8" Includes the following 10 parts:	1
12	35P330	Rod - cylinder, less clevis	1
13	35P1040	**Valve - check, assembly	1
14	35P1041	Spring - check valve	1
15	35P1042	**Cup - check valve spring	1
16	35P1043	**Piston - cylinder (includes "O" ring)	1
17	35P1044	**"O" Ring - piston	1
18	35P1045	**Lockring - piston	1
19	35P334	**Boot - cylinder (rubber)	1
8	35P925	Cap - filler	1
9	35P924	Gasket - filler cap	1
	35P1597	**Repair Kit - for 7/8" cylinder	1
		NOTE: Repair Kit consists of parts identified with a double asterisk ().	
22	35A2253	Clevis - cylinder rod, 7/16"-20	1
23		30A4740 - Nut, hex, jam, 7/16"-20	1




FIG. 2-24A - MASTER CYLINDERS

MOBILE - MA SERIES LIFT TRUCKS

Part No.	Part No.	DESCRIPTION	Qty. Req.
1	35A 6265	Hood - assembly	1
2	35A 6265	Shaft - hood to support, 1/2" x 18-8/4"	2
3	35A 6067	Grounder - rubber bumper, 3/16" dia., gasoline engine	4
4	35A 6400	Support - hood, front, with grille	1
4	35A 8866	Bolt, hex, 3/8"-16 x 1"	4
4	35A 1900	Nut, hex, 3/8"-16	4
1	35A 6490	Shield - gas cap, regular	1
1	35A 6090	Shield - filler, gas tank (for GS or LPS equipped)	1
1	35A 7598	Seal - shield, (for GS or LPS equipped)	1
6	35A 5174	Closure - hydraulic, oil tank	6
7	35A 6346	Hood - excitation, rear, gasoline engine	7
9	35A 8750	Washer, plate, 3/8" L.D., 7/8" O.D.	9
9	35A 8750	Nut, hex, 3/16"-18	9
6	35A 8855	Bolt, hex, 3/16"-18 x 3/4"	6
6	35A 8750	Nut, hex, 3/16"-18	6
11	35A 5402	Link - with pin, hood, 3/4" x 5-1/4"	11
15	10A 15973	Pin - link to hood, 3/8" x 1-1/3"	15
18	35A 6072	Spring - hood latch	18
14	35A 6070	Anchor - hood spring	14
10	35A 6071	Pin - hood anchor, 5/16" x 1-1/4"	10
2	35A 8829	Pin, corner, 3/32" x 3/4"	2
2	35A 8702	Washer, plate, 1/32" L.D., 1 1/16" O.D.	2
1	35A 5412	Panel - stop, right hand	1
1	35A 5413	Panel - stop, left hand	1
4	35A 8668	Bolt, hex, 3/8"-16 x 1-1/2"	4
4	35A 8028	Washer, plate, 13/32" L.D., 1" O.D.	4
2	35A 4960	Emblem - hood, 1-1/16" X 2-3/8"	2
6	35A 8765	Nut, hex, No. 8-32	6
1	35A 6148	Panel - assembly	1
1	35A 8210	Panel - assembly	1
3	35A 8075	Bolt, hex, 1/2"-18 x 1-1/4"	3
2	35A 8881	Bolt, hex, 1/2"-18 x 1-1/2"	2
1	35A 8075	Bolt, hex, 1/2"-18 x 1-9/8"	1
6	35A 8662	Bolt, hex, 1/2"-18 x 1-3/4"	6
1	35A 8075	Bolt, hex, 1/2"-18 x 1-7/8"	1
1	35A 8020	Bolt, hex, 3/4"-16 x 3/4"	1
2	35A 8020	Bolt, hex, 3/8"-18 x 1-1/2"	2
4	35A 8810	Bolt, hex, 3/8"-16 x 1-1/4"	4
6	35A 8075	Nut, hex, 3/8"-16	6
8	35A 8075	Nut, hex, 3/8"-16	8
1	35A 8398	Panel - instrument	1
8	35A 1764	Nut, spec, type I, 5/16"	8
8	35A 1764	Washer, plate, 11/32" L.D., 1 1/16" O.D.	8
1	35A 6125	Support - steering column, upper	1
4	35A 8022	Bolt, hex, 3/8"-18 x 1"	4
4	35A 2087	Nut, hex, 3/8"-16	4
1	35A 6508	Clamp - steering column	1
4	35A 19014	Bolt, hex, 3/8"-16 x 1-1/4"	4
5	35A 19014	Washer, plate, 13/32" L.D., 1 1/16" O.D.	5

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs
HOOD, PANELS, AND SEAT (Cont'd)			
23	35A6130	Bracket - steering column to cowl, lower section	2
	35A7593	** Panel - instrument	1
	35A3102	** D-Bolt - steering column	2
		** 50A5733 - Nut, hex., 5/16"-18	7
		** 50A4421 - Washer, plain, 11/32" I.D., 11/16" O.D.	3
		* NOTE: Used on MA 30 Trucks to No. 26000125, Inc.	
		* NOTE: Used on MA 40 Trucks to No. 26100543, Inc.	
		* NOTE: Used on MA 50 Trucks to No. 26200185, Inc.	
		** NOTE: Used on MA 30 Trucks No. 26000126 and after.	
		** NOTE: Used on MA 40 Trucks No. 26100544 and after.	
		** NOTE: Used on MA 50 Trucks No. 26200186 and after.	
24	35A6385	Seat - assembly, bucket type	1
		50A5002 - Nut, hex., 5/16"-24 U.N.F.	4
		50A4202 - Washer, plain, 11/32" I.D., 11/16" O.D.	4
		Includes the following 6 parts:	
	35P1316	Seat - shell, with foam rubber, 3" (35P1313)	1
	35P1314	Cover - seat, for 2" foam rubber	1
	35P1317	Cover - seat, for 3" foam rubber	1
	35P496	Slide - seat, left hand	1
	35P1315	Spring - adjusting arm	1




Fig. 2-25 - HOOD, PANELS AND SEAT

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
		FRAME, OVERHEAD GUARD AND COUNTERWEIGHT	
1	-----	Frame - main, assembly	1
		Includes the following part:	
		50A4446 - Plug, hex., socket, 3/8" N.P.T.	2
		50A4489 - Plug, pipe, 1/4" N.P.T.	1
		50A4441 - Plug, pipe, 1/2"	1
	35A5222	Pin - pivot, steering housing	1
2	-----	Guard - overhead, order from Mobilift Sales Department	1
		GM180122 - Bolt, hex., 3/8"-16 x 1"	6
		50A188E - Nut, hex., lock, 3/8"-16	4
		GM426767 - Nut, hex., 7/8"-14	2
		GM446266 - Washer, plain, 16/16"	2
3	35A6736	Counterweight - MA 30	1
		50A8711 - Bolt, hex., 3/4"-10 x 3-1/2", MA 30	1
3	35A5325	Counterweight - MA 40	1
		50A1069 - Bolt, hex., 3/4"-10 x 6", MA 40	1
3	35A6132	Counterweight - MA 60	1
		50A1073 - Bolt, hex., 3/4"-10 x 8-1/2", MA 50	1
		50A4214 - Washer, plain, 5/32" thick	1
		50A3751 - Nut, hex., 3/4" 10	1
4	35A5826	Pin - hitch, 1" x 6-3/8"	1
		50A2822 - Pin, roll, 5/16" x 2-1/4"	1
5	35A5429	Bracket - engine mount	1
		50A3891 - Bolt, hex., 5/8"-11 x 1-1/4"	2
6	35A5430	Mounting - center bodded	2
		50A3667 - Bolt, hex., 1/2"-13 x 8"	2
		50A4087 - Washer, plain, cad., 7/64" x 9/16" I.D., 7/8" O.D.	4
		50A2580 - Washer, plain, 1/4" x 17/32" I.D., 2" O.D.	2
		50A1799 - Nut, elastic stop, cad., 1/2"-13	2
7	36A612R	Breather - filler cap, with dip stick, used with duplex mat	1
7	36A718S	Breather - filler cap, with dip stick, used with high free and low free mats	1
8	36A5389	*Support - steering gear and owl	1
	36A5390	**Support - steering gear	1
		GM271547 - Bolt, hex., 5/8"-11 x 1-1/2"	3
		GM180179 - Bolt, hex., 1/2"-13 x 1-3/4"	10
		GM120978 - Nut, hex., 1/2"-13	10
9	35A534E	Support - axle housing, right hand	1
10	35A534F	Support - axle housing, left hand	1
		50A3708 - Bolt, hex., 3/4"-10 x 2-1/2"	4
		*50A3709 - Bolt, hex., cad., 3/4"-10 x 2-3/4"	3
11	35A522V	*Bracket - tilt cylinder mount, U-shaped	2
	35A6929	**Bracket - tilt cylinder mount, U-shaped	1
		*GM271771 - Bolt, hex., cad., 3/4"-10 x 2"	4
		*50A1135 - Nut, grip lock, 3/4"-10	4
		*GM181017 - Washer, flat, 1/8" x 13/16" I.D., 1-1/2" O.D.	4
12	36A7145	*Plate - floor	1
	36A8290	**Plate - floor	1
		50A3684 - Bolt, hex., 3/8"-16 x 3/4"	2
	35A7769	Bumper - floor plate (sponge rubber)	2
13	36A7143	*Clip - support, floor plate, front	2
	35A8217	**Clip - floor plate, front	1
14	35A620A	*Support - engine mounting, left hand	1
15	35A620I	*Support - engine mounting, right hand	1
16	35A620E	*Support - hood, front, left hand	1
	35A8229	**Support - hood, front, left hand	1
17	35A620G	*Support - hood, front, right hand	1
	35A8230	**Support - hood, front, right hand	1
		50A3667 - Bolt, hex., 3/8"-16 x 1-1/4"	8
		50A4205 - Washer, plain, 13/32" I.D., 13/16" O.D.	8
18	35A6204	*Support - flywheel housing, left hand	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs
		FRAME, OVERHEAD GUARD AND COUNTERWEIGHT (Cont'd)	
19	35A8206	*Support - flywheel housing, right hand	1
		*50A3686 - Bolt, hex., 3/8" - 16 x 1"	8
		*GM180207 - Bolt, hex., 9/16" - 12 x 1-1/2"	6
		*GM124583 - Nut, hex., 9/16" - 12	6
		*GM181458 - Washer, plain, 19/32" I.D., 1-3/16" O.D.	6
		*50A4210 - Washer, plain, 19/32" I.D., 13/16" O.D.	8
	35A9250	**Safety Walk - floor plate, 7" x 21-1/2"	1
	35A8255	**Safety Walk - frame, L.H. side, 5-1/4" x 7"	1
		*NOTE: Used on MA 30 Lift Trucks to No. 28000125, Inc.	
		*NOTE: Used on MA 40 Lift Trucks to No. 28100543, Inc.	
		*NOTE: Used on MA 50 Lift Trucks to No. 28200185, Inc.	
		**NOTE: Used on MA 30 Lift Trucks No. 28000126 and after.	
		**NOTE: Used on MA 40 Lift Trucks No. 28100544 and after.	
		**NOTE: Used on MA 50 Lift Trucks No. 28200186 and after.	




FIG. 2-26-FRAME, OVERHEAD GUARD AND COUNTERWEIGHT

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	Qty. Req.
HYDRAULIC PUMP			
1	35A7410	Pump - 16.5 G.P.M., MA 20 less P.S., Wooster No. F3-13BH5-1-R-01	1
1	35A7580	Pump - 16.5 G.P.M., MA 20 with P.S., Wooster No. FVP3-13EH5-1-R-02	1
1	35A5846	Pump - 21 G.P.M., MA 40 and MA 50, Wooster No. PVFS-19EH-5-1-R-02	1
		50A1750 - Bolt, hex., 3/8"-16 x 8-1/4"	1
		50A1791 - Bolt, hex., 3/8"-16 x 5-1/4"	1
		50A1829 - Star-o-seal, pump bolts	2
		50A1345 - Nut, hex., (Eccs) 3/8"-16	1
		50A1782 - Nut, elastic stop, pump shaft, 5/8"-16	1
2	35P1111	Body - pump, for 35A7410 and 35A7580 pumps	1
2	35P999	Body - pump, for 35A5846 pump	1
3	35P981	Cover - body, rear, for 35A7580 and 35A5846 pumps	1
3A	35P1112	Cover - body, rear, for 35A7410 pump	1
4		GM433114 - Bolt, hex., 3/8"-16 x 4-1/4" for 35A7410 and 35A7580 pumps	4 or 6
5		GM450517 - Bolt, hex., 3/8"-16 x 4-3/4" for 35A7580 pump	2
4		GM188235 - Bolt, hex., 3/8"-16 x 4-1/2" for 35A5846 pump	4
5		GM188259 - Bolt, hex., 3/8"-16 x 3" for 35A5846 pump	2
6	35P1110	Washer - cover bolts, for 35A7410 and 35A7580 pumps	6
6	35P988	Washer - cover bolts	6
7	35P960	Cover - body, front	1
8	35P997	Seal - oil, front cover to shaft	1
9	35P986	Seal - front cover to body on 35A5846 and 35A7580 front and rear on 35A7410 pumps	2
10	35P996	Gasket - seal, front cover to body	1
11	35P966	Spacer - front cover to body	1
12	35P1000	Gasket - seal, rear cover to body, for 35A7580 and 35A5846 pumps	1
13	35P1113	Gear - drive, for 35A7410 and 35A7580 pump	1
13	35P982	Gear - drive, for 35A5846 pump	1
14	35P1114	Gear - driven, for 35A7410 and 35A7580 pumps	1
14	35P983	Gear - driven	1
15	35P994	Bearing - drive and driven gears	4
15A	35P1117	Plug - rear plate, 1-5/16"-12, for 35A7410 pump	1
16B	10A12027	"O" Ring - plug, 1-3/16" I.D., 1-7/16" O.D., for 35A7410 pump	1
16	35P1600	Valve - flow divider, for 35A5846 pump and 35A7580 pump (35P1601) Includes the following 9 parts:	1
17	-----	Cartridge - assembly, includes seat (Order 35P1600)	1
18	-----	Piston - cartridge for 35A5846 and 35A7580 pumps (Order 35P1600)	1
19	35P1104	Spring - piston, outer	1
20	35P1106	Spring - piston, inner	1
22	10A8330	Susp Ring - cartridge	1
23	35P1101	Ball Guide - assembly	1
24	35P1102	Screw - adjusting	1
25	35P1105	Spring - pressure, inner, ball guide	1
26	35P1106	Spring - pressure, outer, ball guide	1
27	35P1103	Plug - cartridge	1
28	35P1107	Gasket - plug	1
29	10P1734	"O" Ring - flow divider, lower	1
30	10A75	"O" Ring - flow divider, intermediate	2
31	10A80	"O" Ring - flow divider, upper	1
32	35P511	Gear - hydraulic pump, Continental No. F400H-33b	1
33		GM106751 - Key, Woodruff, No. 3, for 35A7410 and 35A5846 pumps	1
		GM106738 - Key, Woodruff, No. 5/32" x 5/8", for 35A7580 pump	1
34	35A705	Gasket - hydraulic pump	1

MOBILELT - MA SERIES LIFT TRUCKS

Part No.	Part No.	DESCRIPTION	No. Pcs.
35A 7011	35A 6478	Valve - control, complete, MA 30 fact includes the following 25 parts	1
		35A1825 - Bolt, hex., 3/8" - 16 x 2-1/2"	3
		35A1930 - Nut, hex., 3/8" - 16	3
15P 600		Seal - spool	4
15P 606		Spring - spool centering	2
10P 1658		Washer - stop, centering spring	2
16P 654		Coilac - stop, centering spring	2
15P 652		Bolt - stop collar	2
16P 1630		Washer - stop collar	2
15P 655		Disc - stop collar	2
15P 657		Ring - stop, stop disc	2
15P 663		Corner - rubber, spool opening	2
15P 670		Ring - ball check	1
10A 9329		"O" Ring - ball check plug	1
35P 216		Plunger - check and relief valve	1
35P 277		Spring - plunger, check valve (DS and after)	1
35P 216		Seat - relief valve	1
10A 12012		"O" Ring - relief valve seal	1
35P 221		Spring - relief	1
35P 222		Guide - relief valve	1
35P 213		Ball - relief guide	1
10A 15498		Washer - spacer, relief spring	1
10A 15490		Shim - relief spring	1
10A 15487		Cap - relief spring	1
35P 221		Plug - port	1
35P 225		"O" Ring - port plug	1
35P 1034		Plug - conversion, special	1
15P 747		Gasket - conversion plug	1
35A 6500		Plate - support, valve and handle	1
35A 6539		35A 6535 - Bolt, hex., 3/8" - 16 x 1"	2
35A 6539		Handle - control, valve and lower (35A 6538)	1
35A 6500		Handle - control, tilt (35A 6537)	1
35A 7757		35A 7750 - Washer, plain, 13/32" I.D., 13/16" O.D.	3
35A 7757		Washer - handles (35A 7756)	2
35A 6594		Pin - handle to support, 3/8" x 4-3/8"	1
35A 6539		50A 6539 - Pin, roll, 1/8" x 1"	2
35A 6539		Link - handle to valve spool, 3/8" x 2-1/4"	4
35A 4119		Knob - control handle (threaded)	2
35A 6536		Label - lift control	1
35A 6535		Label - riding lever	1
35A 6535		Knob - tilt cylinder (not threaded)	1
35A 6535		Knob - tilt cylinder (not threaded)	1
35A 6594		Knob - tilt cylinder (not threaded)	1
		NOTE: Used on trucks with relief knobs	
		NOTE: Used on trucks with relief knobs	




Fig. 2-28 - MAST CONTROL VALVE

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per
HYDRAULIC OIL LINES AND FITTINGS			
1	35A 635	Strainer - on oil tank	1
2	36A 6205	+Flange - strainer	1
2	36A 8331	+Flange - strainer	1
		50A 8605 - Bolt, hex., 2/8" - 16 x 7/8"	6
3	35A 3295	Gasket - flange to tank	1
4	35A 6336	+Tube - pump to strainer	1
4	35A 6337	++Tube - pump to strainer	1
5		+30A 2415 - Elbow, 1" x 3/4"	1
5	10A 14720	+Elbow - flange (rubber)	1
6		50A 4605 - Elbow, 1-5/16" x 1/2, 90°	1
7	10A 12027	"O" Ring - elbow to pump	1
8	10A 67	-Hose - connecting, tube to elbow	1
		50A 4225 - Clamp, hose, 1-3/8"	2
9		+30A 2450 - Nipple, pipe, 3/4"	1
		+NOTE: Used on MA 30 Trucks to No. 25000123, Inc.	
		+NOTE: Used on MA 40 Trucks to No. 26100543, Inc.	
		-NOTE: Used on MA 50 Trucks to No. 26200185, Inc.	
		++NOTE: Used on MA 30 Trucks No. 2500020 and after.	
		++NOTE: Used on MA 40 Trucks No. 26100544 and after.	
		++NOTE: Used on MA 50 Trucks No. 26200190 and after.	
10	35A 6256	*Tube and Hose - assembly, pump to steering gear, 46-3/4"	1
10A	35A 6506	*Hose - tube, 3/8" I.D., x 2" long	1
11	35A 6173	*Adapter - pump to tube, 9/16" - 18 I.D.	1
12	10A 12012	*"O" Ring - connector to pump	1
13	35A 6303	*Tube - steering gear to hyd. tank (35A 6303)	1
14		50A 4413 - Elbow, 1/4" P.T. 9/16", 90°	1
14A		50A 4084 - Clip - steering gear tube, (10A 12478)	1
		GM190116 - Bolt, hex., 3/8" - 16 x 5/8"	1
		*NOTE: Used on LH Trucks with power steering.	
15	35A 6881	Tube - pump to control valve	1
16		50A 4383 - Elbow, 90°	1
17	10A 14630	"O" Ring - elbow to pump	1
18	35A 1326	Hose - tube to control valve	1
19		50A 4425 - Elbow, 90°, 7/8" - 14 U.N.F.	2
	10A 16235	"O" Ring - valve inlet	2
20	35A 6382	Tube - valve to tank sump	1
21	35A 6502	Hose - tube to tank sump, 15/16" I.D., x 3-1/2" long (35A 3037)	1
		50A 4285 - Clamp, hose, 1-3/8"	2
22	35A 6732	Tube - valve to tilt cylinder tee, forward tilt	1
23	35A 6733	Tube - valve to tilt cylinder tee, back tilt	1
24	35A 1297	Tee - tubes	2
25		50A 4445 - Plug, pipe, hex. socket, 1/8" - 27	2
26		50A 4424 - Elbow, tube to valve, 3/4" - 16, 90°	2
	10A 12012	"O" Ring - elbow to valve	2
27	10A 16296	"O" Ring - elbow to valve	2
28	35A 6139	Hose - tee to tilt cylinder, short, 3/8" x 15"	2
29	35A 6140	Hose - tee to tilt cylinder, long, 3/8" x 19"	2
30		50A 4423 - Elbow, 90°, 3/16" - 18 N.F.	4
31	10A 16406	"O" Ring - elbow to cylinder	4
32	35A 7800	Tube - control valve to lift cylinder (35A 6134)	1
34	35A 1587	Hose - lift cylinder to tube, 1/2" I.D., x 19-1/2" (35A 1269)	1
35		50A 4426 - Connector, hose, 7/8" - 14 N.F.	1
	10A 16256	"O" Ring - connector	1
		50A 603 - Clip, lift cylinder, hose	1
36	35A 1341	Hose - lift cylinder to tank sump, 5/8" O.D. x 24"	1
		50A 4305 - Clamp, hose, 5/8"	2
37		50A 2304 - Nipple, pipe, 1/8" x 1-1/2"	1
38	35A 7215	**Cover - filter	1
39	35A 6206	**Gasket - filter cover	1
		**NOTE: Used on Triplex Mast 190" and up.	

MOBILIFT - MA SERIES LIFT TRUCKS

Ref No	Part No	DESCRIPTION	No. Pcs.
TILT CYLINDER			
1	35A6080	+Cylinder - assembly	2
2	35A8338	++Cylinder - assembly	2
Each includes the following 18 parts:			
3	35P1033	+Shell - assembly	2
4	35P1923	++Shell - assembly	2
5	35P30E	Piston - half	2
6	35P241	Piston - half	2
7	35P310	*"O" Ring - piston to rod	2
8	35P307	*Wiper - nylon, piston	4
9	35P308	Packing - assembly	2
10	35P948	+Rod - piston, 11-1/2" long, for 35A6080 cylinder	2
10	35P1924	++Rod - piston, 11" long, for 35A8338 cylinder	1
11		50A1140 - Nut, piston rod, 1-1/8"-12	2
12	35P208	Retainer - piston rod seal	2
13	35P814	Bushing - piston rod retainer	2
14	M1065	*"O" Ring - retainer to bushing	2
15	35P204	*Packing - assembly	2
16	35P309	*"O" Ring - retainer to outer shell	2
17	10A7845	*Ring - back-up, retainer "O" ring	2
18	35P210	Washer - threaded with nylon pellet	2
19	35P135	Pellet - nylon, threaded washer	2
20	35P209	*Ring - wiper, piston rod	2
	35R82	*Repair Kit - cylinders	1
NOTE: Repair Kit consists of the above parts identified by an asterisk().			
21	35B022E	End - piston rod	2
Includes the following parts:			
22	15A13163	++Bushing - piston rod end and head end	4-2
		GM151643 - Bolt, hex., 3/8"-24 x 1-1/2"	2
		GM120369 - Nut, hex., 3/8"-24	2
23	35A7233	++Bearing - head end, on 35A8338 cylinder	2
24	35A5301	++Pin - cylinder, upright end, 1-1/4" x 3-1/4"	4-2
		50A1771 - Pin, roll, upright end, 1/4" x 3"	2
25	35A858E	++Pin - cylinder, head end, rear, 1" O.D. x 2-5/16" long	2
		50A4187 - Set Screw, dog point, frame end, 3/8"-16 x 3/8"	2
+NOTE: Used on MA 30 Trucks to No. 25000125, Inc.			
+NOTE: Used on MA 40 Trucks to No. 26100543, Inc.			
+NOTE: Used on MA 50 Trucks to No. 26200185, Inc.			
++NOTE: Used on MA 30 Trucks No. 28000120 and after.			
++NOTE: Used on MA 40 Trucks No. 26100544 and after.			
++NOTE: Used on MA 50 Trucks No. 26200186 and after.			




FIG. 2-30 - TILT CYLINDER

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		DUPLEX MAST	
1	-----	Rail - outer assembly, see chart on page 118 Includes the following 2 parts:	1
2	35A5054	Cap - bearing, outer rail pivot	2
	35A5366	Screw - bearing cap, 5/8" x 11 x 2-3/4"	4
		GM191758 - Fitting, grease, 1/8" straight	4
3	35A5727	Bushing - bearing cap	2
4	-----	Rail - inner assembly, see chart on page 118	1
5	35A5558	Shoe - mast 35A1676 - Screw, hex. socket, 3/8" - 16 x 5/8"	2
6	35A5556	Shim - mast shoe	A, R,
7	35A706	Roller - mast	13
8	D317	Bearing - mast roller	13
9		35A577 - Ring, snap, mast bearing, 2-5/32" I.D.	10
10		35A578 - Ring, snap, mast bearing, 1-3/8" I.D.	10
11	-----	Carriage - assembly, order from Mobilift Sales Department	1
12	35A5017	Bearing - thrust, carriage	4
13	35A5766	Pin - thrust bearing GM102594 - Set Screw, cup point, 9/32" - 16 x 5/8"	2
14	-----	Rack - load safety, order from Mobilift Sales Department GM271722 - Bolt, hex., 5/8" - 11 x 2"	4
	35A5871	Tracker - mounting, load rack to carriage	2
15	-----	Chain - 2 x 4 landing, see chart on page 19 for length of chain	2
17	35A5043	Link - connecting, 3 links with 2 pins	-
18	35A5362	Anchor - chain, 2-1/2" long	2
19	35A5760	Pin - chain anchor, 3/4" x 2-1/8" long 35A1752 - Ring, retainer, anchor pin	2
20	35A5653	Anchor - chain, 4-1/2" long	2
21	35A5827	Pin - chain anchor, 5/16" x 1-1/8" GM108572 - Pin, cotter, 3/32" x 1/2"	4
22	-----	Rod - chain anchor, see chart on page 118 GM212758 - Nut, hex., jam, 3/4" - 16 35A197 - Nut, spherical, 3/4" - 16	2
23	-----	Cylinder - lift, see chart on page 18 GM180190 - Bolt, hex., 3/8" - 16 x 2" GM124629 - Nut, hex. jam, 3/8" - 16	1
24	35A5286	Head - piston, with return line to front of cylinder	1
	35A7912	Head - piston, with return line to rear of cylinder GM102592 - Set Screw, cup point, 3/8" - 10 x 1/2"	1
25	35A980	Guide - piston head GM183179 - Bolt, hex., 1/2" - 16 x 1-5/4" GM126378 - Nut, hex., jam, 1/2" - 16	4
26	35A5520	Block - stop, outer rail, 1/2" thick x 2" x 2-7/8" GM271715 - Bolt, hex., 5/8" - 11 x 1"	4
26	35A8307	Block - stop, outer rail, 1/2" thick x 1-1/2" x 2-1/4" 35A1825 - Bolt, hex., 3/8" - 16 x 2-1/2"	4
	35A5333	Block - stop, outer rail, 3/8" thick x 1-1/2" x 2-3/8"	2
	35A5338	Shim - stop block, .0280 x 1-1/2" x 1-5/4"	2
27	35A5749	Sheave - chain, 3-1/4" dia.	1
28	35A5750	Sheave - chain, 5-1/4" dia.	2
29	35A5316	Bearing - sheave	6
30	35A5760	Pin - sheave bearing, head and lower holes in rail, 1" x 2-3/4"	4
30	35A5362	Pin - sheave bearing, upper holes in rail, 1" x 2-1/8" 35A2846 - Pin, roll, 3/32" x 3/4"	2
31	-----	Fork - lifting, order from Mobilift Sales Department	2
32	35A668	Pin - fork stop, 2-1/16" long	2
32	35A669	Lock - stop pin	2
34	35A667	Spring - stop pin 35A2832 - Pin, roll, 3/16" x 1"	2

MORLIST - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
DUPLEX MAST (Cont'd)			
	35A4097	Washer - fork lock, 1/16" x 21/32" I.D., 7/8" O.D.	2
35	36A3737	Latch - includes bushing	1
36	13A13328	Bushing - latch, 5/8" I.D., 5/8" long	1
37	35A4084	Pin - latch, 5/8" x 1-7/8"	1
	36A3843	Pin, roll, 3/16" x 1-1/4"	1
38	35A3636	Cap - latch dog	1
39	35A2037	Plunger - latch dog	1
40	35A3636	Spring - latch dog	1
41	35A7385	Tube - vent, 1/4" and 3/8" O.D., J-shaped (35A7310)	1
42	15P1776	Hose - vent tube, 1 foot, see chart on page 119 for length needed	1
	15P309	Strap - hose	2
	36A3073	Clamp, hose, 7/16"	2
43	35A7337	Elbow - vent hose, 90°, 1/4" x 1/8 N.P.T.	1
44	35A7070	Strap - vent hose	2
	GM132073	Screw, rd. hd., 1/4" x 20 x 2-1/2"	2
45	35A1464	Spacer - vent hose	2




FIG. 2-31 - DUPLEX MAST

MORLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		DUPLEX LIFT CYLINDER (Cascade) Group I 4" Diameter, for MA 30	
1	35A7907	Cylinder - lift, complete, 35-1/2" long (35A6745)	1
1	35A7905	Cylinder - lift, complete, 40-1/2" long (35A6753)	1
1	35A7970	Cylinder - lift, complete, 44" long (35A6755)	1
		Each includes the following 34 parts:	
2	35P119E	Shell - for 35-1/2" cylinder, with 1/2" lock nut, Ref. No. 30	1
2	35P1455	Shell - for 35-1/2" cylinder, with 3/4" lock nut, Ref. No. 30	1
2	35P1197	Shell - for 40-1/2" cylinder, with 1/2" lock nut, Ref. No. 30	1
2	35P1456	Shell - for 40-1/2" cylinder, with 3/4" lock nut, Ref. No. 30	1
2	35P1198	Shell - for 44" cylinder, with 1/2" lock nut, Ref. No. 30	1
2	35P1457	Shell - for 44" cylinder, with 3/4" lock nut, Ref. No. 30	1
3	35P833	Screw - button head, cylinder shell	1
4	35P832	*Seal - button head screw	1
5	35P1199	Tube - intermediate, for 35-1/2" cylinder	1
5	35P1203	Tube - intermediate, for 40-1/2" cylinder	1
5	35P1201	Tube - intermediate, for 44" cylinder	1
6	35P1202	Plunger - for 35-1/2" cylinder	1
6	35P1209	Plunger - for 40-1/2" cylinder	1
6	35P1204	Plunger - for 44" cylinder	1
7	35P183	*Ring - wiper, intermediate tube (35P1235 inter.)	1
9	35P182	*Spring - garter, wiper ring	1
9	35P1207	Retainer - wiper ring	1
10	10A784E	*"O" Ring - retainer, size 3-3/4" I.D., 4" O.D. (35P617 inter.)	1
11	35P1208	Bushing - intermediate tube	1
12	35P1209	*"O" Ring - intermediate tube bushing, size 3-3/8" I.D., 3-3/8" O.D.	1
13	35P1210	*Ring - back-up, "O" ring	1
14	35P1211	*Packing - tube bushing	1
15	35P1212	*Ring - wiper, plunger	1
16	35P1206	*Spring - garter, wiper ring	1
17	35P1213	Retainer - plunger wiper ring	1
18	35P174	*"O" Ring - wiper retainer, size 2-1/2" I.D., 2-3/4" O.D.	1
19	35P1214	Piston	1
20	35P1215	*Packing - piston	1
21	10A785H	*"O" Ring - piston, inner, size 1-1/2" I.D., 1-3/4" O.D.	1
22	35P1216	*Ring - back-up, "O" ring	1
23	35P1217	Ring - snap, piston retainer	1
24	35P1215	Bearing - intermediate tube	1
25	35P1219	Ring - bearing retainer	1
26	35P1220	Ring - snap, bearing	1
27	35P1221	Head - cylinder, used on cylinders with 1/2" lock nut, Ref. No. 30	1
27	35P1498	Head - cylinder, used on cylinders with 3/4" lock nut, Ref. No. 30	1
28	35P1222	*"O" Ring - cylinder head, size 3-7/8" I.D., 4-1/8" O.D.	1
29	35P1459	*Ring - back-up, head "O" ring	1
29A	35P1460	*Ring - nylon, cylinder head, upper, used with 3/4" lock nut, Ref. No. 30	1
30	35P1224	Nut - lock, cylinder head, 1/2"	1
30	35P1481	Nut - lock, cylinder head, 3/4"	1
31	35A4209	Spacer - intermediate tube, 1/4" x 3-3/8" O.D., for 35-1/2" and 40-1/2" cylinders	1
31	35A3453	Spacer - intermediate tube, 1" x 3-3/8" O.D., for 35-1/2" cylinder	1
32	35A4100	Spacer - plunger, 1/4" x 2-3/8" O.D., for 40-1/2" and 44" cylinders	2
32	35A4099	Spacer - plunger, 1" x 2-3/8" O.D., for 35-1/2" cylinder	2
33	35A7790	Spring - oil restrictor, 5-3/4 coils, 1-7/32" long (35A4992)	1
34	35A7795	Washer - perforated, oil restrictor (35P1225)	1
35	35A7792	Spacer - oil restrictor (35A4991)	1
36	35A7793	Hat - sleeve, oil restrictor	1
	35R70	*Repair Kit - lift cylinder (35R59)	-
		NOTE: Repair Kit consists of the above items identified by an asterisk ().	
37	35P1226	Rod - end, cylinder top, 3-1/8" long	1
	35P1227	Lock Washer - rod	1




FIG. 2-82 - DUPLEX LIFT CYLINDER, 4" DIAMETER

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		DUPLEX LIFT CYLINDERS (Cascade) Group II 4-3/4" Diameter, for MA 40 and 50	
1	35A7927	Cylinder - lift, complete, 35-1/2" long (35A5237).....	1
1	35A7935	Cylinder - lift, complete, 40-1/2" long (35A5245).....	1
1	35A7940	Cylinder - lift, complete, 44" long (35A5250).....	1
		Each includes the following 34 parts:	
2	35P120	Shell - for 35-1/2" cylinder, with 1/2" lock nut, Ref. No. 30.....	1
2	35P1402	Shell - for 35-1/2" cylinder, with 3/4" lock nut, Ref. No. 30.....	1
2	35P1121	Shell - for 40-1/2" cylinder, with 1/2" lock nut, Ref. No. 30.....	1
2	35P1403	Shell - for 40-1/2" cylinder, with 3/4" lock nut, Ref. No. 30.....	1
2	35P842	Shell - for 44" cylinder, with 1/2" lock nut, Ref. No. 30.....	1
2	35P1404	Shell - for 44" cylinder, with 3/4" lock nut, Ref. No. 30.....	1
3	35P833	Screw - button head, cylinder shell.....	1
4	35P682	* Seal - button head screw.....	1
5	35P1122	Tube - intermediate, for 35-1/2" cylinder.....	1
5	35P1123	Tube - intermediate, for 40-1/2" cylinder.....	1
5	35P644	Tube - intermediate, for 44" cylinder.....	1
6	35P1124	Plunger - for 35-1/2" cylinder.....	1
6	35P1124	Plunger - for 40-1/2" cylinder.....	1
6	35P840	Plunger - for 44" cylinder.....	1
7	35P322	* Ring - wiper, intermediate tube.....	1
8	35P309	* Spring - garter, wiper ring.....	1
9	35P334	Retainer - wiper ring.....	1
10	10P1241	* "O" Ring - retainer, 4-1/2" I.D., 4-3/4" O.D.....	1
11	35P336	Bushing - intermediate tube.....	1
12	10A10793	* "O" Ring - intermediate tube bushing, 4-1/8" O.D., 4-3/8" O.D.....	1
13	35P33E	* Ring - back-up, "O" ring.....	1
14	35P937	* Packing - tube bushing.....	1
15	35P641	* Ring - wiper, plunger.....	1
16	35P329	* Spring - garter, wiper ring.....	1
17	35P334	Retainer - plunger wiper ring.....	1
16	10A11847	* "O" Ring - wiper retainer, 3-1/4" I.D., 3-1/8" O.D.....	1
19	35P630	Piston.....	1
20	35P624	* Packing - piston.....	1
21	10A4729	* "O" ring - piston, inner, 2-1/4" I.D., 2-1/2" O.D.....	1
22	35P621	* Ring - back-up, "O" ring.....	1
23	35P323	Ring - snap, piston retainer.....	1
24	35P626	Bearing - intermediate tube.....	1
25	35P325	Ring - bearing retainer.....	1
26	35P627	Ring - snap, bearing.....	1
27	35P323	Head - cylinder, used on cylinders with 1/2" lock nut, Ref. No. 30.....	1
27	35P1465	Head - cylinder, used on cylinders with 3/4" lock nut, Ref. No. 30.....	1
28	10A13105	* "O" Ring - cylinder head, lower, 4-5/8" I.D., 4-7/8" O.D.....	1
28	35P1466	* Ring - back-up, head "O" ring.....	1
29A	35P1487	* Ring - nylon, cylinder head, upper, used with 3/4" lock nut, Ref. No. 30.....	1
30	35P331	NUT - lock, cylinder head, 1/2".....	1
30	35P1468	NUT - lock, cylinder head, 3/4".....	1
31	35A5330	Spacer - intermediate tube, 1/4" x 4-5/32" O.D., for 35-1/2" and 40-1/2" cylinders.....	1
31	35A5332	Spacer - intermediate tube, 1" x 4-5/32", for 35-1/2" cylinder.....	1
32	35A5332	Spacer - plunger, 1/4" x 3-5/32", for 35-1/2" and 40-1/2" cylinders.....	1
32	35A5334	Spacer - plunger, 1" x 3-5/32", for 35-1/2" cylinders.....	1
33	35A7796	Spring - oil restrictor (35P1025 later).....	1
34	35P148	Washer - perforated, oil restrictor.....	1
35	35P143	Spacer - oil restrictor.....	1
	35R71	* Repair Kit - lift cylinder (35RS7).....	1

NOTE: Repair Kit consists of the above items identified by an asterisk ().




FIG. 2-88 - DUPLEX LEFT CYLINDER, 4-9/4" DIAMETER




FIG. 2-34 - UPRIGHT FOR TRIPLEX T3J-FREE LIFT

MOBILE - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		TRIPLEX TRI-FREE LIFT CYLINDER (Cascade Viewmast) Group II 4-3/4" Diameter, for MA 33 and 40	
1	-----	*Cylinder - assembly, complete	1
		*NOTE: Order above part by M.F.H., and O.A.H.L. Each includes the following 43 parts:	
2	35P1484	Shell - cylinder, outer, for 70" O.A.H.L. mast	1
2	35P1793	Shell - cylinder, outer, for 76" O.A.H.L. mast	1
2	35P1790	Shell - cylinder, outer, for 82" O.A.H.L. mast	1
2	35P1674	Shell - cylinder, outer, for 88" O.A.H.L. mast	1
2	35P1791	Shell - cylinder, outer, for 94" O.A.H.L. mast	1
3	35P833	Screw - button head, cylinder shell	1
4	35P832	**Seal - button head screw	1
5	35P844	Tube - cylinder, intermediate, for 70" O.A.H.L. mast	1
5	35P1792	Tube - cylinder, intermediate, for 76" O.A.H.L. mast	1
5	35P1799	Tube - cylinder, intermediate, for 82" O.A.H.L. mast	1
5	35P1875	Tube - cylinder, intermediate, for 88" O.A.H.L. mast	1
5	35P1794	Tube - cylinder, intermediate, for 94" O.A.H.L. mast	1
6	35P1795	Plunger - cylinder, inner, for 70" O.A.H.L. mast	1
6	35P1796	Plunger - cylinder, inner, for 76" O.A.H.L. mast	1
6	35P1797	Plunger - cylinder, inner, for 82" O.A.H.L. mast	1
6	35P1876	Plunger - cylinder, inner, for 88" O.A.H.L. mast	1
6	35P1798	Plunger - cylinder, inner, for 94" O.A.H.L. mast	1
7	35P822	**Ring - wiper, intermediate tube	1
8	35P831	**Spring - garter, wiper ring	1
9	35P834	Retainer - wiper ring	1
10	10P1241	**"O" Ring - retainer, 4-1/2" I.D., 4-3/4" O.D.	1
11	35P826	Bushing - intermediate tube	1
12	10A13793	**"O" Ring - intermediate tube bushing, 4-1/8" I.D., 4-5/8" O.D.	1
13	35P835	**Ring - back-up, "O" ring	1
14	35P837	**Packing - tube bushing	1
15	35P840	**Ring - wiper, plunger	1
16	35P859	**Spring - garter, wiper ring	1
17	35P858	Retainer - plunger wiper ring	1
18	10A11847	**"O" Ring - wiper retainer, 2-1/2" I.D., 2-3/4" O.D.	1
19	35P820	Piston	1
20	35P824	**Packing - piston	1
21	10A4723	**"O" Ring - piston, inner, 1-1/2" I.D., 1-3/4" O.D.	1
22	35P821	**Ring - back-up, "O" ring	1
23	35P828	Ring - snap, piston retainer	1
24	35P825	Bearing - intermediate tube	1
25	35P825	Ring - bearing retainer	1
26	35F827	Ring - snap, bearing	1
27	35P176E	Head - cylinder	1
28	10A15135	**"O" Ring - cylinder head, lower, 4-5/8" I.D., 4-7/8" O.D.	1
29	35P1466	**Ring - back-up, head "O" ring	1
30	35P1467	**Ring - cylinder head, upper	1
	35R71	Repair Kit - for cylinder	1
		NOTE: Repair Kit consists of the above items identified by a double asterisk ().	
31	35P1468	Nut - lock, cylinder head	1
32	35P1857	Spacer - plunger, for 133" M.F.H., 2-3/4" I.D., 3-5/32" O.D. x 6" long.	1
32	35P1858	Spacer - plunger, for 137", 173", and 209" M.F.H., 2-3/4" I.D., 3-5/32" O.D., 4" long	1
32	35P1859	Spacer - plunger, for 141", 177", 189" and 212" M.F.H., 2-3/4" I.D., 3-5/32" O.D. x 2" long	1
32	35P1842	Spacer - plunger, for 185" M.F.H., 2-3/4" I.D., 3-5/32" O.D. x 5" long.	1
33	35P1830	Body - restrictor	1
34	10A18295	"O" Ring - body	1
35	35A4922	Spring - oil restrictor	1
36	35P1337	Washer - perforated, oil restrictor	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		TRIPLEX TRI-FREE LIFT CYLINDER (Cascade View/Inst) (Cont'd)	
37	35P143	Speed - oil restrictor.....	1




FIG. 8-35 - TRIPLEX TRI-FREE LIFT CYLINDER, 4 1/4" DIAMETER

MOHLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per
		TRIPLEX TUB-FREE LIFT CYLINDER (Cascade Viewmast) Group III 5" Diameter, for MA 50	
1	-----	*Cylinder - assembly, complete	1
		*NOTE: Order above part by M.F.H. and O.A.H.L. Each includes the following 43 parts:	
2	35P1804	Shell - cylinder, outer, for 76" O.A.H.L. mast	1
2	35P1805	Shell - cylinder, outer, for 76" O.A.H.L. mast	1
2	35P1806	Shell - cylinder, outer, for 82" O.A.H.L. mast	1
2	35P1807	Shell - cylinder, outer, for 88" O.A.H.L. mast	1
2	35P1807	Shell - cylinder, outer, for 94" O.A.H.L. mast	1
3	35P890	Screw - button head, cylinder shell	1
4	35P892	**Screw - button head screw	1
5	35P1818	Tube - cylinder, intermediate, for 76" O.A.H.L. mast	1
6	35P1818	Tube - cylinder, intermediate, for 76" O.A.H.L. mast	1
5	35P1820	Tube - cylinder, intermediate, for 82" O.A.H.L. mast	1
6	35P1820	Tube - cylinder, intermediate, for 82" O.A.H.L. mast	1
5	35P1821	Tube - cylinder, intermediate, for 88" O.A.H.L. mast	1
6	35P1821	Tube - cylinder, intermediate, for 88" O.A.H.L. mast	1
6	35P1822	Tube - cylinder, intermediate, for 94" O.A.H.L. mast	1
6	35P1823	Plunger - cylinder, inner, for 76" O.A.H.L. mast	1
6	35P1824	Plunger - cylinder, inner, for 76" O.A.H.L. mast	1
6	35P1825	Plunger - cylinder, inner, for 82" O.A.H.L. mast	1
6	35P1825	Plunger - cylinder, inner, for 82" O.A.H.L. mast	1
6	35P1826	Plunger - cylinder, inner, for 88" O.A.H.L. mast	1
6	35P1826	Plunger - cylinder, inner, for 88" O.A.H.L. mast	1
7	35P1814	**Ring - wiper, intermediate tube	1
8	35P1813	**Spring - garter, wiper ring	1
9	35P1812	Retainer - wiper ring	1
10	35P1808	**"O" Ring - retainer, 4-3/4" I.D., 5" O.D.	1
11	35P1810	Bushing - intermediate tube	1
12	35P1808	**"O" Ring - intermediate tube bushing, 4-3/8" I.D., 4-5/8" O.D.	1
13	35P1809	**Ring - back-up, "O" ring	1
14	35P1822	**Packing - tube bushing	1
15	35P1806	**Ring - wiper, plunger	1
16	35P182	**Spring - garter, wiper ring	1
17	35P1827	Retainer - plunger wiper ring	1
18	35P181	**"O" Ring - wiper retainer, 3-1/2" I.D., 3-3/4" O.D.	1
19	35P186	Piston	1
20	35P1811	**Packing - piston	1
21	35P174	**"O" Ring - piston, inner, 2-1/2" I.D., 2-3/4" O.D.	1
22	35P175	**Ring - back-up, "O" Ring	1
23	35P175	Ring - snap, piston retainer	1
24	35P1810	Bearing - intermediate tube	1
25	35P1816	Ring - bearing, retainer	1
26	35P1817	Ring - snap, bearing	1
27	35P1708	Head - cylinder	1
28	35P1800	**"O" Ring - cylinder head, lower, 4-7/8" I.D., 5-1/8" O.D.	1
29	35P1801	**Ring - back-up, head "O" ring	1
30	35P1802	**Ring - nylon, cylinder head, upper	1
	35P1823	**Repair Kit - for cylinder	1
		NOTE: Repair Kit consists of the above items identified by a double asterisk ().	
31	35P1800	Nut - lock, cylinder head	1
32	35P1800	Spacer - cylinder, for 133" M.F.H., 3" I.D., 3-3/8" O.D. x 6" long	1
33	35P1803	Spacer - cylinder, for 163" and 165" M.F.H., 3" I.D., 3-3/8" O.D. x 5" long	1
32	35P1801	Spacer - cylinder, for 137", 173" and 203" M.F.H., 3" I.D., 3-8/8" O.D. x 4" long	1
32	35P1802	Spacer - cylinder, for 141", 177", 189" and 218" M.F.H., 3" I.D., 3-3/8" O.D. x 2" long	1
33	35P1826	Body - restrictor	1
34	16A16285	"O" Ring - body	1
35	35A4892	Spring - oil restrictor	1

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs.
		TRIFLEX TRI-FREE LIFT CYLINDER (Cascade Viewmast) (Cont'd)	
36	35P1337	Washer - perforated, oil restrictor	1
37	35P146	Spacer - oil restrictor	1




FIG. 2-3E - TRIFLEX TRI-FREE LIFT CYLINDER, 6" DIAMETER

MOELLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
CROSS HEAD FOR UPRIGHT (Cascade Viewmax) Group IV			
1	35P1629	Cross Head - upright	1
2	-----	Bolt - socket head, 1/8"-20 x 1-1/4"	2
3	35P1630	Pad - head	1
4	-----	Bolt - flat head, hex socket, 1/4"-28 x 1/2"	2
5	35P1631	Sheave - cross head	2
6	35P1632	Shaft - sheave	2
7	-----	Socket Jam Screw - 5/16"-24	2
8	-----	Set Screw - cup point, hex, socket, 5/16"-24 x 5/8"	2
9	-----	Fitting - grease, straight, 1/4"-23	2
10	35P1633	Shoe - head	2
11	-----	Bolt - hex., socket	2
12	-----	Bolt - hex., socket, 5/8"-11 x 1"	2
13	35P1634	Slip - shoe	A, R.
14	35P1635	Support - shoe	2
15	-----	Bolt - hex., 3/8"-24 x 1"	2




FIG. 2-94 - CROSS HEAD FOR UPRIGHT

ADAPTING PARTS FOR TRIPLEX TRI-FREE LIFT (Cascade Viewmax)			
35A3727	Bushing - axle	2	
50A4629	Fitting, grease	2	
35A8709	Hose - vent, 1/4" I.D. x 103" long	1	
35A6587	Hose - lift cylinder, 1/8"-14 x 1/2" I.D. x 19-1/2"	1	
35A8203	Hose - protector, 1-1/8" I.D. x 14" long	1	
10A22767	Fitting - vent hose, 1/4" I.D. x 1/8"-27 x 1-1/4" long	1	
35A7507	Elbow - vent hose, 90°, 1/4"-18 N.P.T.	1	
50A3573	Clamp, hose, 1/16"	2	

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
CARRIAGE FOR TRIPLEX TRI-FREE LIFT (Cascade Viewmast) Group V			
1	-----	Carriage - assembly, order from Mobilift Sales Department	1
Includes the following parts:			
2	35P1820	Wear Pad - carriage	2
3	-----	Bolt - hex. socket, flat head, 1/4"-28 x 3/8"	4
4	35P1863	Shim - wear pad	A.R.
5	35P1845	Roller - assembly, carriage guides	4
6	-----	Bolt - hex. socket, 1/2"-18 x 2"	4
7	35P1866	Nut - bolt, roller support, 1/2"-18	4
8	35P1870	Screw - adjusting, roller assembly	4
9	35P1868	Roller - carriage	4
10	35P1867	Sleeve - roller	4
11	35P1854	Washer - roller, inner	4
12	-----	Fitting - grease, straight, 1/4"-28	5
13	35P1869	Plug - roller, outer	4
14	35P1864	Screw - hex. socket, 5/16"-16 x 1"	2




FIG. 2-36 - CARRIAGE FOR TRIPLEX TRI-FREE LIFT

Part No.	Part No.	DESCRIPTION	No. Per.
1	---	Rail - outer, assembly	1
2	---	Rail - inner, assembly	1
3	---	Rail - center, assembly	1
4	3SP602	Pad - wear	32
5	25P1146	Cylinder - assembly, see page 128 for breakdown	1
6	25P686	Roller - chain	4
7	3SP091	Race - bearing	4
8	25P689	Bearing - roller	4
9	3SP657	Washer - bearing, inner	4
10	3SP656	Washer - bearing, outer	4
11	25P1127	Pin - dowel	4
12	3SP733	Screw - roller	4
13	---	Chain - lifting, 1" pitch, No. AL-444	3
14	---	Chain - lifting, 3/4" pitch, No. AL-434	2
15	3SP661	Anchor - chain, 3/4" pitch chain	4
16	3SP734	Nut - anchor	4
17	3SP1126	Pin - chain anchor	4
18	3SP1129	Flare - end, carriage spindle	2
19	3SP1130	Screw - plate	2
20	3SP690	Spacer - cylinder to inner channel	1
21	3SP632	Screw - spacer	1
22	3SP1765	Hose - assembly, with guard and fittings	1
23	3SP1131	Hose - cylinder	1
24	3SP696	Adapter - hose to elbow	1
25	3SP695	Adapter - hose to tube	1
26	3SP1150	Hose - cylinder	1
27	3SP1776	Guard - hose (spiral)	1
28	3SP692	Adapter - hose to elbow	1
29	3SP694	Connector - tube to cylinder	1
30	3SP1133	Anchor - chain, upper, for 1" pitch chain	2
31	3SP1128	Pin - anchor	2
32	3SP658	Turnbuckle - anchor rod	2
33	3SP1137	Pin - anchor	2
34	3SP1136	Pin - anchor	2
35	3SP1138	Roller - roller	4
36	3SP1139	Roller - bearing retaining, inner	4
37	3SP1140	Roller - bearing retaining, inner	4
38	3SP1141	Roller - bearing, retaining, inner	4
39	3SP1142	Cover - bearing	4
40	25P1139	Ring - cover retaining, outer	4
41	25P1134	Ring - roller	4
42	25P1140	Shaft - roller	4
43	25P1143	Support - shaft	4
44	25P1134	Screw - shaft support	4
45	---	GM15024 - Bolt, hex, 3/8" - 24 X 1 - 3/4"	4

TRIPLEX MAST - HIGH RISE LIFT (KULSKRÖCKER)
 Group 1
 Used on 4000# lift to Mast Serial No. 3FL-089, Inc.
 Used on 5000# lift to Mast Serial No. 3FL-089, Inc.

M400
 MA-10
 MA-50

MOBILE - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Per	
		TRIPLEX MAST - HIGH FREE LIFT (Knickerbocker) (Cont'd)	MA30	MA50
45	3521147	Roller - shaft	4	4
		GM444688 - 21lg. pipe, hydraulic tank, 1/2"-27	1	1




FIG. 2-39 - TRIPLEX MAST, HIGH FREE LIFT

MOHELIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs	
		TRIPLEX MAST - HIGH FREE LIFT (Kaiserhohler) Group II Used on 4000 # lift with Mast Serial No. 3FL-400 and after. Used on 5000 # lift with Mast Serial No. 3FL-5-400 and after.	MA30	MA30
1	-----	*Rail - outer, assembly	1	1
2	-----	*Rail - inner, assembly	1	1
3	-----	*Rail - center, assembly	1	1
4	35P690	Pad - wear	32	32
5	-----	*Cylinder - assembly, see breakdown on pages 110 or 112	1	1
6	35P690	Roller - chain	4	4
7	35P691	Race - bearing	4	4
8	35P699	Bearing - roller	4	4
9	35P687	Washer - bearing, inner	4	4
10	35P688	Washer - bearing, outer	4	4
11	35P1127	Pin - dowel	4	4
12	35P721	Screw - roller	4	4
13	35P698	Washer - lock	2	2
14	-----	GM10A354 - Fitting, grease, 1/8"-30°	2	2
15	-----	*Chain - lifting, 1" pitch, No. AL-844	2	2
16	-----	*Chain - lifting, 3/4" pitch, No. AL-844	2	2
17	35P661	Anchor - chain, 3/4" pitch chain	4	4
18	35P754	Nut - anchor	4	4
19	35P1160	Pin - chain anchor	4	4
20	35P1129	Plate - end, carriage spindle	2	2
21	35P633	Screw - plate	2	2
22	35P690	Spacer - cylinder to inner channel	1	1
23	35P682	Screw - spacer	1	1
	35P1763	*Hose - assembly, with guard and fittings Consists of the following 4 parts:	1	-
24	35P1131	*Hose - cylinder	1	-
	35P1762	*Gusto - hose (spiral)	1	-
25	35P896	Adapter - hose to elbow	1	-
26	35P895	Adapter - hose to tube	1	-
	35P1761	*Hose - assembly, with guard and fittings Consists of the following 4 parts:	-	1
24	35P1150	*Hose - cylinder	-	1
	35P1778	*Gusto - hose (spiral)	-	1
		*NOTE: Order by serial number of lift plus MFH and OABL.		
25	35P890	Adapter - hose to elbow	-	1
26	35P895	Adapter - hose to tube	-	1
27	35P1875	Clamp - elbow	1	1
28	35P1148	Elbow - hose, 90°	1	1
29	35P899	Elbow - tube to adapter, 90°	1	1
30	35P1872	Tube - cylinder	1	1
31		30A442c - Connector, tube to cylinder, with O-ring	1	1
	10A1E8E5	"O" Ring - connector	1	1
32	35P1135	Anchor - chain, upper, for 1" pitch lift chain	2	2
33	35P1160	Pin - anchor	2	2
34	35P606	Turtbuckle - anchor rod	2	2
35	35P1872	Yolk - turtbuckle, 3/16" x 14 x 4"	2	2
36		GM218753 - Nut, hex., jam, 3/4"-16	4	4
37	35P1136	Anchor - chain, lower, for 1" pitch lift chain	2	2
38	35P1137	Pin - anchor	2	2
39	35P1138	Peg - roller	4	4
40	35P1139	Ring - bearing retainer, outer	4	4
41	35P1140	Bearing - roller	4	4
42	35P1768	Fitting - grease, 1/4" drive x 30° (Alomite 1608)	4	4
44	35P1141	Ring - bearing, retainer to peg	4	4
45	35P1142	Cover - bearing	4	4
46	35P1144	Tire - roller	4	4
47	35P1873	Shaft - roller	4	4
48	35P1874	Support - shaft	8	8

MOBILIFT • MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Per	
			MA30	MA40 MA50
TRIPLEX MAST - HIGH FREE LIFT (Knechtrocker) (Cont'd)				
49	35P1134	Screw - support, for grease fitting	4	4
50	-----	Fitting - grease (Alecrite 1758-13)	4	4
51		GM215324 - Screw, hex. head, 3/8" -24 x 1-3/4'	-	-
		GM173123 - Washer, slakeproof, 3/8"	8	8
52		50A4206 - Washer, plain, 3/8"	9	9
53	35P1147	Roller - shaft	4	4
54	35P1089	# Washer - restrictor valve
55	35P1670	# Spring - restrictor valve	1	1
56	35P107	# Spacer - restrictor valve
57		#EBA4423 - Connector, tube
58	10AJ0235	# "O" Ring - connector
#NOTE: Used on lifts with restrictor valves installed.				




FIG. 2-40 - TRIPLEX MAST, HIGH FREE LIFT

MOBILE - MA 8925 LIFT TRUCKS

Part No.	Part No.	DESCRIPTION	No. Per
35P120	35P120	Cylinder - lift, assembly	1
35P119	35P119	Cylinder - lift, assembly	1
35P122	35P122	Tube - cylinder, outer	2
35P740	35P740	Tube - cylinder, outer	2
35P123	35P123	Tube - cylinder, inner	2
35P741	35P741	Tube - cylinder, inner	2
35P742	35P742	Tube - cylinder, inner	2
35P710	35P710	Packing set - lower section	1
35P711	35P711	Kit - packing, lower section	1
35P712	35P712	Seal - wear, outer cylinder	2
35P713	35P713	Ring - wear, outer cylinder	2
35P714	35P714	Ring - stop ring	1
35P715	35P715	Ring - stop ring	1
35P716	35P716	Packing set - outer cylinder, top section	1
35P717	35P717	Kit - packing, top section, outer cylinder	1
35P718	35P718	Ring - wear, upper packing nut	1
35P719	35P719	Ring - wear, upper packing nut	1
35P720	35P720	Ring - stop ring	1
35P721	35P721	Ring - stop ring	1
35P722	35P722	Ring - stop ring	1
35P723	35P723	Ring - stop ring	1
35P724	35P724	Ring - stop ring	1
35P725	35P725	Ring - stop ring	1
35P726	35P726	Ring - stop ring	1
35P727	35P727	Ring - stop ring	1
35P728	35P728	Ring - stop ring	1
35P729	35P729	Ring - stop ring	1
35P730	35P730	Ring - stop ring	1
35P731	35P731	Ring - stop ring	1
35P732	35P732	Ring - stop ring	1
35P733	35P733	Ring - stop ring	1
35P734	35P734	Ring - stop ring	1
35P735	35P735	Ring - stop ring	1
35P736	35P736	Ring - stop ring	1
35P737	35P737	Ring - stop ring	1
35P738	35P738	Ring - stop ring	1
35P739	35P739	Ring - stop ring	1
35P740	35P740	Ring - stop ring	1
35P741	35P741	Ring - stop ring	1
35P742	35P742	Ring - stop ring	1
35P743	35P743	Ring - stop ring	1
35P744	35P744	Ring - stop ring	1
35P745	35P745	Ring - stop ring	1
35P746	35P746	Ring - stop ring	1
35P747	35P747	Ring - stop ring	1
35P748	35P748	Ring - stop ring	1
35P749	35P749	Ring - stop ring	1
35P750	35P750	Ring - stop ring	1
35P751	35P751	Ring - stop ring	1
35P752	35P752	Ring - stop ring	1
35P753	35P753	Ring - stop ring	1
35P754	35P754	Ring - stop ring	1
35P755	35P755	Ring - stop ring	1
35P756	35P756	Ring - stop ring	1
35P757	35P757	Ring - stop ring	1
35P758	35P758	Ring - stop ring	1
35P759	35P759	Ring - stop ring	1
35P760	35P760	Ring - stop ring	1
35P761	35P761	Ring - stop ring	1
35P762	35P762	Ring - stop ring	1
35P763	35P763	Ring - stop ring	1
35P764	35P764	Ring - stop ring	1
35P765	35P765	Ring - stop ring	1
35P766	35P766	Ring - stop ring	1
35P767	35P767	Ring - stop ring	1
35P768	35P768	Ring - stop ring	1
35P769	35P769	Ring - stop ring	1
35P770	35P770	Ring - stop ring	1
35P771	35P771	Ring - stop ring	1
35P772	35P772	Ring - stop ring	1
35P773	35P773	Ring - stop ring	1
35P774	35P774	Ring - stop ring	1
35P775	35P775	Ring - stop ring	1
35P776	35P776	Ring - stop ring	1
35P777	35P777	Ring - stop ring	1
35P778	35P778	Ring - stop ring	1
35P779	35P779	Ring - stop ring	1
35P780	35P780	Ring - stop ring	1
35P781	35P781	Ring - stop ring	1
35P782	35P782	Ring - stop ring	1
35P783	35P783	Ring - stop ring	1
35P784	35P784	Ring - stop ring	1
35P785	35P785	Ring - stop ring	1
35P786	35P786	Ring - stop ring	1
35P787	35P787	Ring - stop ring	1
35P788	35P788	Ring - stop ring	1
35P789	35P789	Ring - stop ring	1
35P790	35P790	Ring - stop ring	1
35P791	35P791	Ring - stop ring	1
35P792	35P792	Ring - stop ring	1
35P793	35P793	Ring - stop ring	1
35P794	35P794	Ring - stop ring	1
35P795	35P795	Ring - stop ring	1
35P796	35P796	Ring - stop ring	1
35P797	35P797	Ring - stop ring	1
35P798	35P798	Ring - stop ring	1
35P799	35P799	Ring - stop ring	1
35P800	35P800	Ring - stop ring	1

LIFT CYLINDER - T20PLEX HIGH SPEED LIFT (Kitcherbocker) Group III

Used on 3000# lift to Mast Serial No. 3P1-398, Inc.
 Used on 5000# lift to Mast Serial No. 3P1-5-398, Inc.

*Cylinder - lift, assembly
 *Cylinder - lift, assembly

*Tube - cylinder, outer
 *Tube - cylinder, outer
 *Tube - cylinder, inner
 *Tube - cylinder, inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner

*Tube - inner
 *Tube - inner
 *Tube - inner




FIG. 2-4) - LIFT CYLINDER - TRIFLEX HIGH FREE LIFT

MOBILIFT • MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.	
LIFT CYLINDER - TRIPLEX HIGH PRESS LIFT (Kniekerbocker)				
Group Dc				
Used on 4900# Lift Cylinders, Mast Serial No. 3FL-400 thru 3FL-498, 11C. Used on 5900# Lift Cylinders, Mast Serial No. 2FL-5-400 thru 3FL-6-492.				
			4900#	5900#
1	-----	*Cylinder - lift, assembly	1	-
1	-----	*Cylinder - lift, assembly	-	1
Each includes the following 38 parts:				
2	35P1630	*Tube - cylinder, outer	1	-
3	35P1797	*Tube - cylinder, outer	-	1
3	35P1631	*Tube - interstage	1	-
3	35P1709	*Tube - interstage	-	1
4	35P1230	*Tube - plunger, inner	1	-
4	35P1710	*Tube - plunger, inner	-	1
5	35P1873	Packing Set - outer cylinder, lower section	1	1
6	35P1255	+Nut - packing, lower section	1	1
6A	35P729	-Scr Screw - packing nut	1	1
9	35P1891	--NLL - packing, lower section (replaces Ref. Nos. 6, 6A, 6 and 10).....	:	:
9	35P1879	Ring - wiper, packing nut	1	1
9	35P1891	+Ring - wear, outer cylinder, lower	:	:
10	35P1259	-Ring - wear, outer cylinder, upper	:	:
11	35P1682	+Stuffing Box - outer tube, lower end	1	2
11	35P1682	--Stuffing Box - outer tube, lower end	:	1
*NOTE: Order by serial number of lift plus MPH and OAHIL.				
+NOTE: Used on lifts serial number 3FL-400 thru 3FL-499 and 3FL-5-402.				
++NOTE: Used on lifts serial number 3FL-460 thru 3FL-468.				
12	35P1684	Ring - retaining, stuffing box, outer	-	1
13	35P1686	Ring - retaining, stuffing box, inner	2	1
14	35P1683	Sequence Valve - interstage tube	:	:
15	35P1687	Pinch - cylinder, on interstage tube	2	1
16	35P701	Packing Set - top section, outer cylinder	1	1
17	35P703	Nut - packing, top section, outer cylinder	1	1
18	35P714	Ring - wiper, upper packing nut	:	1
19	35P132	"O" Ring - upper packing nut, 5-1/4" O.D.	1	1
20	35P717	Packing Set - plunger to interstage	1	1
21	35P706	Gland - plunger packing	:	1
22	35P713	"O" Ring - plunger gland, 4-1/2" O.D.	1	1
23	35P714	Ring - wiper, plunger gland	1	1
24	35P708	Cap - interstage, upper	1	1
25	13P1364	"O" Ring - interstage cap, 4-1/8" O.D.	1	1
26	35P703	Washer - back up, interstage cap	1	1
27	35P711	Spacer - vent, interstage cap	1	1
28	35P710	Washer - seal, vent screw	1	1
29	35P1247	Spacer - plunger tube, order by MPH and OAHIL	-	1
NOTE: Serial number of lift is stamped on top of outer tube on front side of Ref. No. 2.				




FIG. 2-42 - LIFT CYLINDER - TRIPLEX HIGH FREE LIFT

MOBILIFT - 3M SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Per	
LIFT CYLINDER - TRIPLEX HIGH FREE LIFT (Kleckerbocker)				
Group V				
Used on 4000 # lift cylinders, Mast Serial No. 3FL-439 and after. Use on 5000 # lift cylinders, Mast Serial No. 3FL-5-464 and after.				
			4000#	5000#
1	35P1634	*Cylinder - lift, assembly	1	-
1	35P1700	*Cylinder - lift, assembly	-	1
Each includes the following 28 parts:				
2	35P1688	*Tube - cylinder, outer	1	-
2	35P1707	*Tube - cylinder, outer	-	1
3	35P1696	*Tube - interstage	1	-
3	35P1703	*Tube - interstage	-	1
4	35P1230	*Tube - plunger, inner	1	-
4	35P1710	*Tube - plunger, inner	-	1
*NOTE: Order by serial number of lift plus MFI and OATFL.				
5	35P1696	Packing Set - outer cylinder, lower section	1	1
6	35P1696	Adapter - packing, outer cylinder, lower section	1	1
7	35P1637	Nut - packing, lower section	1	1
8	35P1670	Ring - wiper, packing nut	1	1
9	35P1688	Sequence Valve - interstage tube	1	1
10	35P1687	Piston - cylinder, on interstage tube	1	1
11	35P1633	Stuffing Box - outer tube, lower tube	1	1
12	35P1684	Ring - retainer, stuffing box, outer	1	1
13	35P1690	Ring - retaining, stuffing box, inner	1	1
14	35P701	Packing Set - top section, outer cylinder	1	1
15	35P703	Nut - packing, top section, outer cylinder	1	1
16	35P704	Ring - wiper, upper packing nut	1	1
17	35P152	"O" Ring - upper packing nut, 5-1/4" O.D.	1	1
17	35P717	Packing Set - plunger to interstage	1	1
19	35P705	Gland - plunger packing	1	1
20	35P718	"O" Ring - plunger gland, 4-1/4" O.D.	1	1
21	35P714	Ring - wiper, plunger gland	1	1
22	35P702	Cap - interstage, upper	1	1
23	10P1364	"O" Ring - interstage cap, 4-1/8" O.D.	1	1
24	35P706	Washer - back up, interstage cap	1	1
25	35P711	Screw - vent, interstage cap	1	1
26	35P716	Washer - seal, vent screw	1	1
27	35P1247	Spacer - plunger	-	1
NOTE: Serial numbers of lift is stamped on top, outside of tube, Ref. No. 2.				




FIG. 2-43 - LIFT CYLINDER - TRIPLEX HIGH FREE LIFT

MORLIFT - MA SERIES LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per	
		TRIPLEX MAST - LOW FREE LIFT (Knickerbocker)		
		Group I	MAS0	MA50
			MA40	
1	-----	* Rail - outer assembly	1	1
2	-----	* Rail - center assembly	1	1
3	-----	* Rail - inner assembly	1	1
4	35P662	Pad - wear	32	32
5	35P1151	* Cylinder - assembly, see page 116 for breakdown	1	-
6	35P1170	* Cylinder - assembly, see page 116 for breakdown	-	1
6	35P1152	Head - upright	1	1
7	35P1153	Washing - head	4	4
8	35P685	Ring - head retaining	1	1
9	35P681	Lock - roller shaft	2	2
10	35P665	Shaft - 3" chain roller	2	2
11	35P669	Bearing - 3" chain roller	2	2
12	35P654	Roller - chain	2	2
13	35P1154	Rocker - chain lever	2	2
14	35P1155	Lever - rocker	2	2
15	35P1156	Shaft - chain roller	2	2
16	35P1157	Roller - chain lock	2	2
17	35P651	Lock - roller shaft	2	2
18	35P691	Bearing - roller, lower	2	2
19	35P688	Race - bearing, inner	2	2
20	35P686	Roller - chain	2	2
21	35P687	Washer - thrust, bearing	4	4
22	35P1159	Wing - bearing retainer	2	2
23	35P661	Anchor - chain, upper	2	2
24	35P1160	Pin - anchor	4	4
25	35P734	Lock Nut - anchor	2	2
26	35P661	Anchor - chain, lower	2	2
27	35P734	Lock Nut - anchor	2	2
28	-----	* Chain - lift, 3/4" pitch, No. AL-864	4	4
29	35P1161	Elbow - tube to cylinder, 90°	1	1
30	35P661	Anchor - chain	2	2
31	35P1160	Pin - anchor	2	2
32	35P636	Tambuckle - anchor chain	2	2
33	35P1163	* Rod - lift	2	2
34	35P1164	Tube - cylinder	1	1
35	35P1165	* Hose - cylinder	1	1
36	35P690	Elbow - fuel line to tube	1	1
37	35P1166	Elbow - tube to hose	1	1
38	35P1167	Adapter - elbow to hose and tube to elbow	2	2
39	35P1138	Peg - roller	4	4
40	35P1139	Ring - bearing retainer, outer	4	4
41	35P1140	Bearing - roller	4	4
42	35P1141	Ring - bearing retainer, inner	4	4
43	35P1144	Tire - roller	4	1
44	35P1142	Cover - bearing	4	4
45	35P1139	Ring - cover retaining	4	4
46	35P1146	Shaft - roller	4	4
47	35P1145	Support - shaft	4	4
48	35P1134	Screw - shaft support	4	4
		GM215524 - Nut, hex., 3/8" x 1-5/8"	4	4
49	35P1147	Roller - shaft	4	4
50	35P1168	Stop - channel	2	2
		GM446363 - Plug, pipe, hydraulic tank, 1/8" x 27	1	1
		*NOTE: Order parts for lifts as to MPH and OASL.		




FIG. 2-44 - TRIPLEX MAST - LOW FREE LIFT

MORLIFT - MA SERIES LIFT TRUCKS

VARIABLE PARTS CHART - For MA 30 - 40 - 50 with Duplex Masts

Duplex Outer Rail	Duplex Inner Rail	MA 30 Cylinder Assy.	MA 40-50 Cylinder Assy.	Chain Assy. LINKS	Chain Inches	Chain Anchor Rod	Wear Hose	CAH	MPH
36A5696 - 60-1/2"	36A5697 - 60-1/2"	36A5740 - 33"	36A5232 - 33"	36A5798 - 165	135-1/4"	36A5780 - 14"	36A7327 - 10"	63-1/2"	91"
36A5697 - 62"	36A5698 - 62"	36A5741 - 33"	36A5233 - 33"	36A5799 - 171	123-1/4"	36A5780 - 14"	36A7327 - 16"	63"	94"
36A5698 - 63-1/2"	36A5699 - 63-1/2"	36A5742 - 33"	36A5234 - 33"	36A5800 - 175	131-1/4"	36A5780 - 14"	36A7327 - 16"	63-1/2"	97"
36A5699 - 65"	36A5700 - 65"	36A5743 - 33"	36A5235 - 33"	36A5801 - 179	124-1/4"	36A5780 - 14"	36A7327 - 16"	63"	100"
36A5700 - 68-1/2"	36A5670 - 68-1/2"	36A5744 - 35-1/2"	36A5236 - 35-1/2"	36A5802 - 175	134-1/4"	36A5781 - 16-1/2"	36A7328 - 19"	62-1/2"	103"
36A5701 - 68"	36A5671 - 68"	36A5745 - 35-1/2"	36A5237 - 35-1/2"	36A5802 - 183	137-1/4"	36A5781 - 16-1/2"	36A7328 - 19"	71"	106"
36A5702 - 69-1/2"	36A5672 - 69-1/2"	36A5746 - 35-1/2"	36A5238 - 35-1/2"	36A5803 - 187	140-1/4"	36A5781 - 16-1/2"	36A7328 - 19"	72-1/2"	108"
36A5703 - 71"	36A5673 - 71"	36A5747 - 33"	36A5239 - 33"	36A5804 - 196	141-3/4"	36A5782 - 18"	36A7329 - 21-1/2"	74"	112"
36A5704 - 72-1/2"	36A5674 - 72-1/2"	36A5748 - 34"	36A5240 - 34"	36A5806 - 199	144-3/4"	36A5782 - 18"	36A7329 - 21-1/2"	75-1/2"	115"
36A5705 - 74"	36A5675 - 74"	36A5749 - 35"	36A5241 - 35"	36A5807 - 197	147-3/4"	36A5782 - 18"	36A7329 - 21-1/2"	77"	118"
36A5706 - 75-1/2"	36A5676 - 75-1/2"	36A5750 - 36"	36A5242 - 36"	36A5808 - 201	150-3/4"	36A5782 - 18"	36A7329 - 21-1/2"	78-1/2"	121"
36A5707 - 77"	36A5677 - 77"	36A5751 - 41-1/2"	36A5243 - 41-1/2"	36A5808 - 201	150-3/4"	36A5783 - 21"	36A7330 - 24"	80"	124"
36A5708 - 78-1/2"	36A5678 - 78-1/2"	36A5752 - 40-1/2"	36A5244 - 40-1/2"	36A5809 - 205	153-3/4"	36A5783 - 21"	36A7330 - 24"	81-1/2"	127"
36A5709 - 80"	36A5679 - 80"	36A5753 - 40-1/2"	36A5245 - 40-1/2"	36A5810 - 209	156-3/4"	36A5783 - 21"	36A7330 - 24"	83"	131"
36A5710 - 81-1/2"	36A5680 - 81-1/2"	36A5754 - 41"	36A5246 - 41"	36A5810 - 209	156-3/4"	36A5784 - 24"	36A7331 - 26-1/2"	84-1/2"	133"
36A5711 - 83"	36A5681 - 83"	36A5755 - 44"	36A5247 - 44"	36A5811 - 213	159-3/4"	36A5784 - 24"	36A7331 - 26-1/2"	86"	136"
36A5712 - 84-1/2"	36A5682 - 84-1/2"	36A5756 - 44"	36A5248 - 44"	36A5812 - 217	162-3/4"	36A5784 - 24"	36A7331 - 26-1/2"	87-1/2"	139"
36A5713 - 86"	36A5683 - 86"	36A5757 - 44"	36A5249 - 44"	36A5813 - 221	165-3/4"	36A5784 - 24"	36A7331 - 26-1/2"	89"	142"
36A5714 - 87-1/2"	36A5684 - 87-1/2"	36A5758 - 44"	36A5250 - 44"	36A5814 - 225	168-3/4"	36A5784 - 24"	36A7331 - 26-1/2"	90-1/2"	145"
36A5715 - 89-1/2"	36A5685 - 89-1/2"	36A5759 - 47"	36A5251 - 47"	36A5814 - 225	168-3/4"	36A5785 - 25"	36A7332 - 30"	92-1/2"	148"
36A5716 - 91"	36A5686 - 91"	36A5760 - 47"	36A5252 - 47"	36A5815 - 229	171-3/4"	36A5785 - 25"	36A7332 - 30"	94"	151"
36A5717 - 92-1/2"	36A5687 - 92-1/2"	36A5761 - 47"	36A5253 - 47"	36A5816 - 233	174-3/4"	36A5785 - 25"	36A7332 - 30"	95-1/2"	154"
36A5718 - 94"	36A5688 - 94"	36A5762 - 47"	36A5254 - 47"	36A5817 - 237	177-3/4"	36A5785 - 25"	36A7332 - 30"	97"	157"
36A5719 - 96-1/2"	36A5689 - 96-1/2"	36A5763 - 50"	36A5255 - 50"	36A5817 - 237	177-3/4"	36A5786 - 31-1/2"	36A7333 - 33"	98-1/2"	160"
36A5720 - 97-1/2"	36A5690 - 97-1/2"	36A5764 - 51"	36A5256 - 50"	36A5818 - 243	182-1/4"	36A5786 - 31-1/2"	36A7333 - 33"	100-1/2"	163"
36A5721 - 99"	36A5691 - 99"	36A5765 - 50"	36A5257 - 50"	36A5819 - 247	185-1/4"	36A5786 - 31-1/2"	36A7333 - 33"	102"	166"
36A5722 - 100-1/2"	36A5692 - 100-1/2"	36A5766 - 50"	36A5258 - 50"	36A5820 - 251	188-1/4"	36A5786 - 31-1/2"	36A7333 - 33"	103-1/2"	169"
36A5723 - 102"	36A5693 - 102"	36A5767 - 53"	36A5259 - 53"	36A5820 - 251	188-1/4"	36A5787 - 39-1/2"	36A7334 - 36"	105"	172"
36A5724 - 103-1/2"	36A5694 - 103-1/2"	36A5768 - 53"	36A5260 - 53"	36A5821 - 255	191-1/4"	36A5787 - 39-1/2"	36A7334 - 36"	105-1/2"	175"
36A5725 - 105-1/2"	36A5695 - 105-1/2"	36A5769 - 53"	36A5261 - 53"	36A5822 - 261	195-3/4"	36A5787 - 39-1/2"	36A7334 - 36"	108-1/2"	178"

NOTE: For breakdown of Duplex Lift Cylinders see pages 82 and 84.

MORLIFT - MA SERIES LIFT TRUCKS

Rev. No.	Part No.	DESCRIPTION	No. Pcs.	
VARIABLE PARTS CHART TRIPLEX MAST				
Upright Assy. High Free Lift MA 30 - 40	Upright Assy. High Free Lift MA 30	Upright Assy. Low Free Lift MA 30 - 40	Upright Assy. Low Free Lift MA 30	Mast Height
-----	-----	36A 6876	36A 6871	150"
36A 6887	36A 6881	36A 6877	36A 6872	135"
36A 6888	36A 6882	36A 6878	36A 6873	144"
36A 6889	36A 6883	36A 6879	36A 6874	153"
36A 6890	36A 6884	36A 6880	36A 6875	162"
36A 6891	36A 6885	36A 6881	36A 6876	171"
36A 6892	36A 6886	36A 6882	36A 6877	180"
36A 6893	36A 6887	36A 6883	36A 6878	189"
36A 6894	36A 6888	36A 6884	36A 6879	198"
36A 6895	36A 6889	36A 6885	36A 6880	207"
36A 6896	36A 6890	36A 6886	36A 6881	216"

NOTE: Carriage, Forks, Fork Extensions and Load Safety Racks are to be ordered from Mobilift Sales Department.

DECALS, PAINT AND HYDRAULIC FLUID

35A8816	Decal - Mobilift, on upright (50A4883)	2
35A8818	Decal - Mobilift, on hood sides (35A4889)	2
35A8822	Decal - Mobilmatic, on cow-l sides	2
35A8821	Decal - High Free Lift, on mast	2
35A6081	Decal - side strip, 1-3/4" x 40-1/2"	3
35A6454	Decal - strip, R.H., 2-1/2" x 10-1/2"	1
35A6453	Decal - strip, L.H., 2-1/2" x 10-1/2"	1
15P1013	Paint - yellow, quart can	-
15P1013	Paint - yellow, gallon can	-
15P1014	Paint - yellow, 10 oz. pressurized can	-
10P706	Fluid - hydraulic (1 quart)	-
10P1027	Fluid - hydraulic (1 gallon)	-
10P708	Fluid - hydraulic (5 gallon)	-
13P707A	Fluid - hydraulic (54 gallon)	-

MOBLIFT - MA SERIES LIFT TRUCKS

Qty. No.	Part No.	DESCRIPTION	No. Pcs.	
			Narrow Reel	Wide Reel
		HOSE REELS		
1	35A1489	Reel - hose, left hand, 91" thru 145"	1	-
1	35A8536	Reel - hose, left hand, 146 thru 216"	-	1
1	35A3244	Reel - hose, right hand, 91" thru 145"	1	-
1	35A0934	Reel - hose, right hand, 146" thru 216"	-	1
		Each include the following 21 parts:		
		GM180475 - Bolt, hex., 1/2"-18 x 1-1/4"	2	2
		GM120378 - Nut, hex., 1/2"-18	2	2
		30A46494 - Washer, plain, 3/16" I.D., 1-7/8" O.D.	2	2
3	35P1175	Shaft - assembly, reel	1	-
2	35P1176	Shaft - assembly, reel	-	1
3	35P1179	Nipple - shaft, 2"	1	1
4	35P1192	Elbow - nipple, female	1	1
5	35P1174	Elbow - shaft, male end	1	1
6	35P1182	Hub - reel	1	-
6	35P1181	Hub - reel	-	1
7	10A7956	"O" Ring - shaft	3	3
8	35P1021	Ring - back-up, "o" ring	4	4
9	35P1184	Snap Ring - hub	1	1
10	35P1097	Elbow - hub, 45°	2	2
11	35P1153	Elbow - hub, 90°	2	2
12	35P1162	Bar - reel	1	-
12	35P1171	Bar - reel	-	1
13	35P1177	Flange - reel, inner	1	2
14	35P1178	Divider - reel, center ring	1	3
15	35P1131	Flange - reel, outer	1	1
		GM120375 - Nut, hex., 1/4"-20	4	4
		GM180735 - Bolt, hex., 5/16"-18 x 3-1/4"	6	-
		GM187963 - Bolt, hex., 5/16"-18 x 4-1/2"	-	6
		GM120376 - Nut, hex., 3/16"-18	6	0
16	35P1179	Spacer - flanges, 1-5/16" long	1	-
16	35P1180	Spacer - flanges, 1-15/16" long	-	11
17	35P1185	Spring - assembly, with cover, R.H.	1	1
17	35P1186	Spring - assembly, with cover, L.H.	1	1
18	35A1482	Block - junction, hydraulic hoses	1	1
		Includes the following 12 parts:		
		GM186126 - Bolt, hex., 3/8"-16 x 1-1/2"	1	1
		30A3420 - Washer, plain, 1-3/8"	1	1
19	35P1189	Body - block	1	1
20	35P1191	Plunger - body	1	1
21	35P1182	Plug - body	2	2
		GM145645 - Ball, steel, 3/16"	2	2
22	35P1193	Spring - ball	2	2
23	35P1194	Spacer - spring and ball	2	2
24	35P1069	Shaft - block	1	1
25	35P1189	"O" Ring - shaft	3	3
26	35P1193	Ring - back-up, "o" ring	2	2
27	35P1187	Snap Ring - shaft	2	2
28	35P1185	Connector - hose to shaft	2	2
29	10A8379	"O" Ring - connector, 3/8" I.D.	2	2
30	10A8025	"O" Ring - plug, body, 13/32" I.D.	2	2
	35A6835	Tube - reel to valve, L.H., 3/8" x 20-9/16" long	1	1
	35A6836	Tube - reel to valve, L.H., 3/8" x 20-3/4" long	1	1
	35A6837	Tube - reel to valve, R.H.	1	1
	35A6839	Tube - reel to valve, R.H., 3/8" x 9-7/8" long	1	1
		GM2410976 - Connector, tubes to valve	2	2
	35P1640	*Hose - reels, 1 foot of hose 3/8" I.D. (Order length as needed for lift)	2	2
		30A2620 - Fitting, hose ends	1	1
		*NOTE: Duplex Masts require 10" more hose and Triplex Masts require 11" more hose than what the MFD is.		

MOBLIM7 - MA SERIES LIFT TRUCKS

Qty	Part No	DESCRIPTION	No. Pos	
HOSE REELS (Cont'd)				
	10A15435	"O" Ring - fitting to valve	3	2
	55A7021	Fox - over head gun, 1/4" x 1-3/4" x t-1/2"	2	2




FIG. 2-48 - HOSE REELS

MOBLIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs	
			Single	Double
AUXILIARY VALVES				
1	35A6487	Valve - control, complete	1	-
1	35A6486	Valve - control, complete	-	1
		GM435115 - Bolt, hex., 3/8"-16 x 4-1/4"	3	3
		GM120377 - Nut, hex., 3/8"-16	3	3
		GM120388 - Washer, plain, 7/16" I.D., 1" O.D.	3	3
2	15F650	Seal - spool	2	4
3	15F658	Spring - spool centering	1	2
4	10P1652	Washer - stop, centering spring	1	2
5	15F654	Collar - stop, centering spring	1	2
6	15F052	Nut - stop collar	1	2
7	10P1650	Washer - lock, stop collar nut	1	2
8	15F055	Disc - stop collar	1	2
9	15F657	Ring - snap, stop disc	1	2
10	15F663	Donut - rubber, spool opening	1	2
11	35P215	Flg - ball check	1	1
12	10A6829	"O" Ring - ball check plug	1	1
13	35P218	Flinger - check and relief valve	2	2
	20P4777	Sprite - plunger, check valve (D5 and other)	1	1
14	35P216	Seat - relief valve	-	1
15	10A12912	"O" Ring - relief valve seat	-	1
16	35P257	Spring - relief	-	1
17	35P222	Guide - relief spring	-	1
18	35P213	Ball - relief guide	-	1
19	10A16489	Washer - spacer, relief spring	1	1
20	10A16490	Shim - relief spring	1	1
21	10A16487	Gasket - relief spring cap	1	1
22	35P220	Cap - relief spring	1	1
23	35P1098	Plug - pipe	2	1
24	36A4292	Handle - control, auxiliary valve, straight (36A6578)	-	1
25	36A8591	Handle - control, auxiliary valve, offset (36A6577)	-	1
26	36A6578	Pin - handle to support, 1/4" x 1-3/8"	1	2
		50A1916 - "E" Ring, pin, 3/8"	2	4
27	35A7077	Link - handle to valve spool	1	2
28	36A4119	*Knob - control handle (dreaded)	1	2
29	35A8354	*Label - knob, Mobilift, 1-1/2" dia. for 36A4119 knob	1	2
	36A5296	**Knob - control lever (not dreaded)	1	2
		** 50A4887 - Ring, knob to handle	1	2
		*NOTE: Used on trucks with 2 piece knobs.		
		**NOTE: Used on trucks with solid knobs.		
30	35A0557	Spacer - valve and coil	3	3
31	35A9120	Plug - adaptor, 7/16"-14 x 1-3/8"	1	1
32		30A1068 - Quad ring, to control valve	1	1
33	35A6737	Tube - pressure, to valve	1	1
34	85A6172	Elbow - valve, 90°, 3/4" UNF-37° x 7/8"-14 UNF	2	2
35	10A10285	"O" Ring - elbow	2	2
36		50A1992 - Elbow, valve, 90° Parallel, 5/8" size	1	1
37	35A8736	Tube - valve return	1	1
38		GM8403710 - Connector, tank, 37° connector 5/8"	1	1




FIG. U-47 - AUXILIARY VALVES

MOBILIFT - MA SERIES LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs	
			Single	Double
SHEAVE TAKE-UP FOR HOSES				
1	36A8033	Junction Block - hoses	1	2
2	36A8030	Support - assembly, R.H.	-	1
3	36A8031	Support - assembly, L.H.	1	-
4	36A8032	Bracket - support, R.H.	-	1
5	36A8032	Bracket - support, L.H.	1	-
6	10A11140	Snap Ring - pin	1	2
7	35A8122	Block - guide rod	1	2
8	35A8122	Block - upright, welds to outer channel, 1" x 1-9/16"	2	4
9	35A8121	Spacer - upright, 3/4" x 1-7/16" x 7/64" thick	1	2
10	35A8121	Spacer - upright, 1-7/8" x 2" x 1/8" thick	1	2
11	36A8030	Block - sheave take-up	1	2
		Includes the following parts:		
12	36A8030	Pin - sheave, 1" x 3-1/8"	1	2
13	10A11140	Snap Ring - pin	1	2
14	-----	*Hose - junction block to elbow and elbow to aux. valve	4	6
15	-----	*Hose - elbow to aux. valve, R.H. side, long, 3/8" I.D.	-	1
15	-----	*Hose - elbow to aux. valve, R.H. side, short, 3/8" I.D.	-	1
		*Note: See chart on page 126 for length of hoses needed.		
	35P1640	Hose - 1" of 3/8" I.D. single braid hose	-	-
16		35A1620 - Fitting, hose ends	8	16
17		35A4330 - Elbow, hoses, upper ends, 90°	2	4
18		35A4423 - Elbow, hoses to valve, 90°	2	4
19	10A1E400	"O" Ring - elbow	2	4
20	35A8022	Clamp - hose, mounts to support, U-shaped	-	2
		35A3648 - Bolt, hex., 1/4"-20 x 3/4"	1	2
		35A3649 - Nut, hex., 1/4"-20 x 1-1/4"	2	4
		35A1E98 - Nut, hex., 1/4"-20	3	6
21	35A8304	Band - hoses, 3/4" I.D. x 1" long	30	60
22	-----	Rod - guide, see chart on page 126 for length of rod needed	2	4
23	35B8034	Sheave - block and support, 4-13/16" dia.	2	4
		Includes the following parts:		
24	35A8031	Bushing - sheave, 1" I.D., 2" long	2	4




FIG. 2-43 - SIBAVE TAKE-TIP FOR HOSES

MOBILIFT - MA SERIES LIFT TRUCKS

GUIDE RODS AND HOSES FOR SHEAVE TAKE-UP

MFH	OAJL	Guide Rod	Length	Hose Block to Elbow and Elbow to Aux. Valve	Hose Elbow to Aux. Valve R.H. Side	Hose Elbow to Aux. Valve R.L. Side
94"	61"	50A4688	36-1/2"	73"	71"	68"
97"	63-1/2"	50A4693	37-3/4"	74-1/2"	72-1/2"	67-1/2"
109"	69"	50A4694	38-1/2"	76"	74"	69"
109"	69-1/2"	50A4695	39-1/4"	77-1/2"	75-1/2"	70-1/2"
106"	71"	50A4696	40"	78"	77"	72"
109"	72-1/2"	50A4698	40-3/4"	80-1/2"	78-1/2"	73-1/2"
112"	74"	50A4698	40-3/4"	82"	80"	75"
119"	76-1/2"	50A4699	42-1/4"	83-1/2"	81-1/2"	78-1/2"
118"	77"	50A4697	42-3/4"	85"	83"	78"
121"	78-1/2"	50A4697	43-3/4"	86-1/2"	84-1/2"	79-1/2"
124"	80"	50A4698	44-1/2"	88"	86"	81"
127"	81-1/2"	50A4698	45-1/4"	89-1/2"	87-1/2"	82-1/2"
130"	83"	50A4699	46"	91"	89"	84"
133"	84-1/2"	50A4690	46-3/4"	92-1/2"	90-1/2"	85-1/2"
136"	86"	50A4641	47-1/2"	94"	92"	87"
139"	87-1/2"	50A4692	48-1/2"	95-1/2"	93-1/2"	88-1/2"
142"	89"	50A4643	49"	97"	95"	90"
145"	90-1/2"	50A4644	49-2/4"	98-1/2"	96-1/2"	91-1/2"
148"	92-1/2"	50A4645	51"	100-1/2"	98-1/2"	93-1/2"
151"	94"	50A4647	51-3/4"	102"	100"	95"
154"	95-1/2"	50A4646	52-1/2"	103-1/2"	101-1/2"	96-1/2"
157"	97"	50A4650	53-1/4"	105"	103"	98"
160"	98-1/2"	50A4631	54"	106-1/2"	104-1/2"	99-1/2"
163"	100-1/2"	50A4653	55-1/4"	108-1/2"	106-1/2"	101-1/2"
166"	102"	50A4654	56"	110"	108"	103"
169"	103-1/2"	50A4655	56-3/4"	111-1/2"	108-1/2"	104-1/2"
172"	105"	50A4656	57-1/2"	113"	111"	106"
175"	106-1/2"	50A4657	58-1/4"	114-1/2"	112-1/2"	107-1/2"
178"	108-1/2"	50A4658	60-1/4"	116-1/2"	114-1/2"	109-1/2"

Note: Hose lengths listed are less fittings.

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
90276	64	92315	24	10A 6329	46	10A18718	32
90315	8	92325	24	10A 6330	46	10A18921	32
90385	10	92335	24	10A 6335	64	10A21399	30
90395	10	92345	24	10A 6424	32	10A22767	102
90815	10	92405	26	10A 6849	38		
90845	4	92415	26	10A 7051	58		
90855	4	92465	30	10A 7052	58	10P 30	18
90875	4	92755	26	10A 7059	64	10P 75	22
909153	8	92765	26	10A 7060	64	10P 240	22
909252	8	92935	4	10A 7213	22	10P 241	22
90955	8	92955	17	10A 7292	58	10P 308	76
90975	4	93135	14	10A 7330	58	10P 347	20
91025	5	9411K	40	10A 7331	58	10P 706	119
91065	20	9455K	40	10A 7332	58	10P 707A	119
91075	20	9542R	40	10A 7333	58	10P 708	119
91085	20	9546R	40	10A 7846	64	10P 747	22
91115	4			10A 7848	88	10P 750	22
91135	4			10A 7956	92	10P 751	22
91165	4	CE 7117	40	10A 8025	120	10P 755	22
911952	10			10A 8226	64	10P 756	22
91215	10			10A 8227	64	10P 772	22
91265	10	C 317	90	10A 8441	66	10P 774	22
91275	10	C 684	78	10A 8616	16	10P 912	22
91285	10	C 1173	38	10A 9072	16	10P 919	22
91305	10	C 1186	38	10A 9818	20	10P 920	22
91345	10			10A 9838	32	10P 921	22
91435	4			10A10401	4	10P 923	22
91475	4	EE 9504	22	10A11140	124	10P 927	22
91495	4	EE 9520	22	10A11543	42	10P 928	22
91585	4	EE 9538	22	10A11847	94	10P 929	22
91615	8			10A12012	52	10P 947	22
91625	8			10A12027	82	10P 948	22
91635	8	JE 130	22	10A12478	32	10P 1087	119
91695	8			10A13028	91	10P 1241	94
91715	8			10A13135	66	10P 1331	58
91725	8	M 333	70	10A13793	94	10P 1364	108
91735	8	M 536	42	10A14362	58	10P 1650	84
91745	8	M 873	72	10A14720	86	10P 1652	84
91755	8	M 1065	88	10A14830	86	10P 1701	34
91775	4			10A15240	34	10P 1702	34
91785	4			10A15639	44	10P 1734	82
91795	4	10A 27	42	10A15973	78	10P 1872	18
91805	4	10A 30	82	10A16285	86	10P 1873	18
91815	4	10A 67	86	10A16329	46	10P 1874	18
91905	11	10A 75	82	10A16405	52	10P 1882	20
91945	11	10A 136	46	10A16487	84	10P 1886	20
92175	24	10A 307	28	10A16489	84	10P 1889	20
92185	24	10A 2296	36	10A16490	84	10P 2142	60
92195	24	10A 3397	42	10A16817	30	10P 2279	60
92205	24	10A 3436	36	10A16904	18	10P 2280	60
92225	24	10A 4729	94	10A18105	46	10P 2281	60
92235	24	10A 5097	38	10A18176	66	10P 2282	60
92295	24	10A 6319	120	10A18453	44	10P 2283	60

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
10P 2289	60	15P 465	8	35A 336	44	35A 1464	91
10P 2290	60	15P 467	4	35A 337	44	35A 1469	120
10P 2291	60	15P 469	14	35A 339	44	35A 1482	120
10P 2292	60	15P 472	14	35A 341	44	35A 2109	32
10P 2347	32	15P 473	14	35A 342	44	35A 2133	44
10P 2367	32	15P 502	26	35A 353	44	35A 2151	34
10P 2368	32	15P 510A	4	35A 355	44	35A 2252	54
10P 2369	32	15P 562	4	35A 369	44	35A 2253	74
10P 2530	18	15P 609	54	35A 374	46	35A 2467	34
10P 2704	18	15P 652	84	35A 375	46	35A 2694	32
		15P 654	84	35A 377	46	35A 3004	34
		15P 655	84	35A 387	74	35A 3009	34
10R 385	30	15P 656	84	35A 390	46	35A 3031	35
		15P 657	84	35A 391	46	35A 3120	122
		15P 660	84	35A 392	46	35A 3244	120
15A13163	88	15P 663	84	35A 408	36	35A 3260	42
15A15557	34	15P 683	14	35A 511	36	35A 3453	92
		15P 684	14	35A 512	36	35A 3696	91
		15P 747	84	35A 513	36	35A 3697	91
15P 23	20	15P 859	32	35A 514	36	35A 3698	91
15P 24	20	15P 909	91	35A 516	36	35A 4084	91
15P 45	8	15P 1013	119	35A 519	36	35A 4097	91
15P 47	8	15P 1014	119	35A 520	36	35A 4099	92
15P 48	8	15P 1015	119	35A 564	58	35A 4100	92
15P 53	14			35A 667	90	35A 4119	34
15P 58	10			35A 668	90	35A 4161	58
15P 77	24	20H 3664	58	35A 669	90	35A 4209	92
15P 97	24			35A 688	46	35A 4283	32
15P 100	24			35A 689	46	35A 4341	86
15P 101	24	20P 4777	84	35A 690	46	35A 4932	98
15P 103	24			35A 695	46	35A 4969	78
15P 167	26			35A 696	46	35A 5042	90
15P 171	26	30A 1701	38	35A 698	86	35A 5059	36
15P 172	26	30A 2312	36	35A 705	82	35A 5082	44
15P 173	26			35A 708	90	35A 5084	44
15P 174	26			35A 837	90	35A 5111	42
15P 175	26	35A 56	36	35A 849	44	35A 5112	44
15P 176	26	35A 178	20	35A 862	52	35A 5113	44
15P 178	26	35A 179	20	35A 886	58	35A 5114	44
15P 276	10	35A 189	74	35A 887	58	35A 5115	44
15P 277	10	35A 190	74	35A 920	90	35A 5127	64
15P 279	10	35A 191	74	35A 980	44	35A 5129	64
15P 282	4	35A 200	74	35A 981	44	35A 5130	64
15P 285	8	35A 210	36	35A 993	44	35A 5131	64
15P 286	8	35A 309	36	35A 1067	32	35A 5134	30
15P 304	26	35A 311	42	35A 1068	32	35A 5135	22
15P 451	10	35A 317	42	35A 1102	32	35A 5136	30
15P 456	8	35A 322	42	35A 1248	46	35A 5137	30
15P 458	6	35A 330	44	35A 1249	46	35A 5148	58
15P 461	8	35A 331	44	35A 1250	46	35A 5150	64
15P 462	8	35A 332	44	35A 1297	86	35A 5161	58
15P 463	8	35A 333	44	35A 1326	86	35A 5162	58
15P 464	8	35A 334	44	35A 1459	52	35A 5164	58

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35A 5167	42	35A 5291	64	35A 5448	66	35A 5859	74
35A 5171	30	35A 5292	66	35A 5453	64	35A 5860	74
35A 5174	58	35A 5294	24	35A 5520	90	35A 5861	74
35A 5177	46	35A 5296	16	35A 5530	94	35A 5871	90
35A 5180	64	35A 5300	62	35A 5532	94	35A 5887	26
35A 5184	46	35A 5301	88	35A 5533	8	35A 5888	26
35A 5185	46	35A 5303	64	35A 5536	90	35A 5891	66
35A 5186	50	35A 5305	64	35A 5538	90	35A 5894	74
35A 5187	46	35A 5306	16	35A 5727	90	35A 5895	28
35A 5192	42	35A 5313	44	35A 5730	42	35A 5896	28
35A 5194	58	35A 5314	44	35A 5731	42	35A 5899	28
35A 5195	58	35A 5316	90	35A 5749	90	35A 5901	36
35A 5206	86	35A 5317	90	35A 5750	90	35A 5906	42
35A 5210	46	35A 5321	20	35A 5755	90	35A 5908	42
35A 5222	80	35A 5323	58	35A 5760	90	35A 6052	52
35A 5229	80	35A 5325	80	35A 5766	90	35A 6060	52
35A 5232	118	35A 5326	80	35A 5774	72	35A 6067	78
35A 5233	118	35A 5327	17	35A 5775	72	35A 6068	78
35A 5234	118	35A 5329	17	35A 5780	118	35A 6069	78
35A 5235	118	35A 5330	59	35A 5781	118	35A 6070	78
35A 5236	118	35A 5331	59	35A 5782	118	35A 6072	78
35A 5237	118	35A 5332	94	35A 5783	118	35A 6080	88
35A 5238	118	35A 5334	94	35A 5784	118	35A 6087	30
35A 5239	118	35A 5338	59	35A 5785	118	35A 6088	46
35A 5240	118	35A 5339	26	35A 5786	118	35A 6129	52
35A 5241	118	35A 5341	30	35A 5787	118	35A 6130	79
35A 5242	118	35A 5342	80	35A 5798	118	35A 6131	52
35A 5243	118	35A 5343	80	35A 5799	118	35A 6132	80
35A 5244	118	35A 5344	26	35A 5800	118	35A 6133	52
35A 5245	118	35A 5345	26	35A 5801	118	35A 6135	78
35A 5246	118	35A 5371	74	35A 5802	118	35A 6138	60
35A 5247	118	35A 5374	74	35A 5803	118	35A 6139	86
35A 5248	118	35A 5377	74	35A 5804	118	35A 6140	86
35A 5249	118	35A 5379	74	35A 5806	118	35A 6141	60
35A 5250	118	35A 5387	20	35A 5807	118	35A 6142	60
35A 5251	118	35A 5388	26	35A 5808	118	35A 6145	52
35A 5252	118	35A 5394	84	35A 5809	118	35A 6146	32
35A 5253	118	35A 5408	78	35A 5810	118	35A 6147	52
35A 5254	118	35A 5424	78	35A 5811	118	35A 6148	26
35A 5255	118	35A 5429	80	35A 5812	118	35A 6158	9
35A 5256	118	35A 5430	80	35A 5813	118	35A 6159	52
35A 5257	118	35A 5434	66	35A 5814	118	35A 6170	32
35A 5258	118	35A 5435	66	35A 5815	118	35A 6171	32
35A 5259	118	35A 5436	66	35A 5816	118	35A 6172	122
35A 5260	118	35A 5439	42	35A 5817	118	35A 6173	86
35A 5261	118	35A 5440	64	35A 5818	118	35A 6174	52
35A 5269	16	35A 5441	64	35A 5819	118	35A 6200	80
35A 5270	17	35A 5442	64	35A 5820	118	35A 6201	80
35A 5275	30	35A 5443	64	35A 5821	118	35A 6202	80
35A 5283	46	35A 5444	64	35A 5822	118	35A 6203	80
35A 5287	64	35A 5445	64	35A 5846	82	35A 6204	80
35A 5288	35	35A 5446	66	35A 5848	46	35A 6205	81
35A 5290	30	35A 5447	66	35A 5858	74	35A 6263	78

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35A 0101	10	35A 0294	04	35B 5054	90	35P 314	08
35A 0105	16	35A 0295	34	35B 5226	08	35P 363	35
35A 0108	18	35A 0302	29	35B 7803	44	35P 364	35
35A 0109	18	35A 0304	124	35B 8000	48	35P 365	35
35A 0115	18	35A 0305	90	35B 8089	124	35P 366	35
35A 0116	36	35A 0307	90	35B 8090	124	35P 384	76
35A 0121	124	35A 0308	90			35P 386	76
35A 0122	124	35A 0329	00			35P 467	20
35A 0124	32	35A 0337	06	35P 55	20	35P 468	20
35A 0188	36	35A 0338	08	35P 56	20	35P 469	20
35A 0192	34	35A 0342	36	35P 57	20	35P 495	79
35A 0193	34	35A 0360	70	35P 58	20	35P 496	79
35A 0194	36	35A 0364	70	35P 59	20	35P 502	30
35A 0196	34	35A 0490	44	35P 60	20	35P 509	30
35A 0197	18	35A 0491	64	35P 99	72	35P 514	30
35A 0203	102	35A 0492	68	35P 102	72	35P 515	30
35A 0206	18	35A 0493	70	35P 104	72	35P 516	30
35A 0207	34	35A 0553	64	35P 135	08	35P 519	30
35A 0214	9	35A 0507	06	35P 148	94	35P 525	30
35A 0216	70	35A 0508	08	35P 149	94	35P 530	30
35A 0217	00	35A 0509	29	35P 152	100	35P 546	60
35A 0219	56	35A 0550	36	35P 153	100	35P 551	60
35A 0220	56	35A 0591	34	35P 168	100	35P 553	60
35A 0226	56	35A 0605	58	35P 173	100	35P 567	60
35A 0227	36	35A 0607	54	35P 174	92	35P 568	62
35A 0228	56	35A 0608	06	35P 175	100	35P 584	60
35A 0229	00	35A 0622	124	35P 181	100	35P 613	42
35A 0230	00	35A 0623	124	35P 182	92	35P 648	72
35A 0231	56	35A 0628	70	35P 183	92	35P 651	114
35A 0234	68	35A 0629	70	35P 204	08	35P 653	106
35A 0235	68	35A 0707	50	35P 208	08	35P 654	114
35A 0236	68	35A 0709	102	35P 209	08	35P 656	104
35A 0237	68	35A 0711	70	35P 210	08	35P 661	104
35A 0238	68	35A 0712	62	35P 213	04	35P 662	104
35A 0241	68	35A 0730	50	35P 215	04	35P 666	114
35A 0242	68	35A 0753	68	35P 216	04	35P 669	114
35A 0243	68	35A 0786	29	35P 217	04	35P 680	116
35A 0244	68	35A 0787	34	35P 218	04	35P 683	116
35A 0245	70	35A 0797	62	35P 220	04	35P 685	114
35A 0246	56	35A 0798	62	35P 222	04	35P 686	104
35A 0248	29	35A 0799	62	35P 225	04	35P 687	104
35A 0249	29	35A 0808	56	35P 227	04	35P 688	104
35A 0250	70	35A 0813	119	35P 238	59	35P 689	104
35A 0251	70	35A 0816	119	35P 239	59	35P 690	104
35A 0252	29	35A 0821	119	35P 241	59	35P 691	104
35A 0253	29	35A 0822	119	35P 242	55	35P 692	104
35A 0254	29	35A 0839	124	35P 251	76	35P 694	104
35A 0255	01	35A 0843	64	35P 306	08	35P 695	104
35A 0256	01	35A 0844	64	35P 307	08	35P 696	104
35A 0257	30	35A 0845	64	35P 308	08	35P 698	106
35A 0288	36	35A 0851	64	35P 309	08	35P 699	104
35A 0299	36			35P 310	08	35P 701	108
35A 0293	04			35P 311	08	35P 703	108

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35A 6264	9	35A 6473	84	35A 6769	118	35A 7687	48
35A 6281	32	35A 6476	52	35A 6788	80	35A 7720	32
35A 6282	32	35A 6487	122	35A 6833	120	35A 7733	30
35A 6283	32	35A 6488	122	35A 6834	120	35A 7736	36
35A 6286	86	35A 6490	78	35A 6835	120	35A 7737	36
35A 6287	52	35A 6501	30	35A 6836	120	35A 7738	36
35A 6294	17	35A 6502	86	35A 6837	120	35A 7739	36
35A 6295	17	35A 6556	86	35A 6838	120	35A 7752	66
35A 6296	17	35A 6557	122	35A 7070	91	35A 7761	36
35A 6321	9	35A 6579	122	35A 7075	28	35A 7762	36
35A 6328	74	35A 6580	66	35A 7077	122	35A 7763	36
35A 6329	52	35A 6581	60	35A 7091	121	35A 7766	46
35A 6330	74	35A 6582	90	35A 7142	28	35A 7767	84
35A 6331	86	35A 6583	90	35A 7156	38	35A 7769	90
35A 6332	74	35A 6585	60	35A 7236	88	35A 7792	92
35A 6336	86	35A 6591	66	35A 7275	66	35A 7793	92
35A 6346	78	35A 6592	66	35A 7276	66	35A 7795	92
35A 6354	34	35A 6643	32	35A 7277	66	35A 7796	92
35A 6355	84	35A 6644	32	35A 7278	66	35A 7799	42
35A 6356	84	35A 6725	34	35A 7279	66	35A 7808	70
35A 6357	66	35A 6732	86	35A 7280	66	35A 7809	64
35A 6358	58	35A 6733	86	35A 7281	66	35A 7810	70
35A 6362	90	35A 6736	122	35A 7282	64	35A 7811	70
35A 6366	90	35A 6737	122	35A 7283	64	35A 7812	70
35A 6368	46	35A 6740	118	35A 7284	64	35A 7813	64
35A 6373	52	35A 6741	118	35A 7292	46	35A 7814	70
35A 6381	119	35A 6742	118	35A 7304	46	35A 7815	70
35A 6382	86	35A 6743	118	35A 7307	91	35A 7816	68
35A 6383	79	35A 6744	118	35A 7323	46	35A 7817	68
35A 6388	36	35A 6745	118	35A 7327	118	35A 7818	44
35A 6389	28	35A 6746	118	35A 7328	118	35A 7866	86
35A 6397	66	35A 6747	118	35A 7329	118	35A 7927	94
35A 6398	66	35A 6748	118	35A 7330	118	35A 7935	94
35A 6401	58	35A 6749	118	35A 7331	118	35A 7940	54
35A 6402	58	35A 6750	118	35A 7332	118	35A 7957	92
35A 6403	58	35A 6751	118	35A 7333	118	35A 7965	92
35A 6404	58	35A 6752	118	35A 7334	118	35A 7970	92
35A 6436	28	35A 6753	118	35A 7338	46	35A 7985	91
35A 6438	84	35A 6754	118	35A 7364	46	35A 7998	54
35A 6439	60	35A 6755	118	35A 7365	46	35A 8007	54
35A 6440	60	35A 6756	118	35A 7366	46	35A 8008	48
35A 6441	60	35A 6757	118	35A 7367	47	35A 8010	54
35A 6442	60	35A 6758	118	35A 7396	32	35A 8012	48
35A 6443	60	35A 6759	118	35A 7410	82	35A 8013	54
35A 6444	60	35A 6760	118	35A 7411	84	35A 8014	54
35A 6445	60	35A 6761	118	35A 7573	34	35A 8015	54
35A 6453	32	35A 6762	118	35A 7580	82	35A 8027	48
35A 6454	119	35A 6763	118	35A 7589	74	35A 8040	36
35A 6455	119	35A 6764	118	35A 7590	74	35A 8055	36
35A 6461	32	35A 6765	118	35A 7592	74	35A 8058	74
35A 6463	32	35A 6766	118	35A 7596	36	35A 8059	42
35A 6470	34	35A 6767	118	35A 7598	20	35A 8085	124
35A 6471	34	35A 6768	118	35A 7608	54	35A 8091	124

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35P 704	108	35P 794	5	35P 856	10	35P 914	11
35P 705	108	35P 795	10	35P 857	24	35P 915	10
35P 706	108	35P 796	10	35P 858	26	35P 916	4
35P 708	108	35P 797	10	35P 859	24	35P 917	8
35P 709	108	35P 798	10	35P 860	24	35P 918	4
35P 710	108	35P 799	10	35P 862	30	35P 919	5
35P 711	108	35P 800	10	35P 863	30	35P 920	5
35P 712	108	35P 801	10	35P 866	17	35P 921	5
35P 713	108	35P 802	10	35P 867	17	35P 922	76
35P 714	108	35P 803	10	35P 868	17	35P 923	76
35P 715	108	35P 804	10	35P 869	17	35P 924	76
35P 716	108	35P 805	10	35P 870	20	35P 925	76
35P 717	108	35P 806	10	35P 871	20	35P 927	62
35P 718	108	35P 807	10	35P 872	20	35P 928	62
35P 719	108	35P 808	10	35P 873	20	35P 929	62
35P 720	108	35P 809	10	35P 874	20	35P 930	62
35P 733	104	35P 811	82	35P 875	20	35P 931	62
35P 734	104	35P 812	8	35P 876	20	35P 932	62
35P 739	108	35P 813	8	35P 877	20	35P 933	62
35P 740	108	35P 814	10	35P 878	20	35P 934	62
35P 741	108	35P 815	8	35P 879	20	35P 935	62
35P 742	108	35P 817	8	35P 880	26	35P 936	62
35P 760	22	35P 818	8	35P 881	24	35P 937	62
35P 761	22	35P 820	94	35P 882	24	35P 938	62
35P 762	22	35P 821	94	35P 883	24	35P 939	62
35P 763	22	35P 822	94	35P 884	24	35P 940	62
35P 764	22	35P 823	94	35P 885	24	35P 941	62
35P 765	22	35P 824	94	35P 886	24	35P 942	62
35P 766	22	35P 825	94	35P 887	24	35P 943	62
35P 767	22	35P 826	94	35P 888	24	35P 944	62
35P 768	22	35P 827	94	35P 889	24	35P 947	62
35P 769	22	35P 828	94	35P 890	24	35P 948	62
35P 770	22	35P 829	94	35P 891	24	35P 949	62
35P 771	22	35P 831	94	35P 892	24	35P 952	60
35P 772	22	35P 832	92	35P 893	10	35P 953	62
35P 773	22	35P 833	92	35P 894	10	35P 954	62
35P 774	22	35P 834	94	35P 895	10	35P 955	60
35P 775	22	35P 835	94	35P 896	10	35P 956	60
35P 776	22	35P 836	94	35P 897	10	35P 957	24
35P 777	26	35P 837	94	35P 898	10	35P 961	76
35P 778	4	35P 838	94	35P 899	10	35P 962	76
35P 779	4	35P 839	94	35P 900	10	35P 963	76
35P 780	4	35P 840	94	35P 901	10	35P 966	72
35P 781	4	35P 842	94	35P 902	10	35P 967	72
35P 783	4	35P 844	94	35P 903	10	35P 968	72
35P 784	4	35P 846	94	35P 904	10	35P 969	72
35P 785	4	35P 848	88	35P 905	10	35P 970	72
35P 786	4	35P 849	8	35P 906	10	35P 972	72
35P 787	4	35P 850	11	35P 909	5	35P 974	72
35P 788	4	35P 851	11	35P 910	5	35P 975	72
35P 789	4	35P 852	5	35P 911	5	35P 976	72
35P 790	5	35P 853	8	35P 912	4	35P 977	72
35P 793	5	35P 855	26	35P 913	5	35P 978	8

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35P 979	8	35P 1091	38	35P 1152	114	35P 1206	92
35P 980	5	35P 1092	38	35P 1153	114	35P 1207	92
35P 981	5	35P 1093	38	35P 1154	114	35P 1208	92
35P 982	4	35P 1094	38	35P 1155	114	35P 1209	92
35P 983	4	35P 1095	38	35P 1156	114	35P 1210	92
35P 984	26	35P 1096	38	35P 1157	114	35P 1211	92
35P 985	22	35P 1097	120	35P 1158	120	35P 1212	92
35P 986	22	35P 1098	122	35P 1159	114	35P 1213	92
35P 987	22	35P 1101	82	35P 1160	106	35P 1214	92
35P 988	22	35P 1102	82	35P 1161	114	35P 1215	92
35P 989	82	35P 1103	82	35P 1162	120	35P 1216	92
35P 990	82	35P 1104	82	35P 1163	114	35P 1217	92
35P 991	82	35P 1105	82	35P 1164	114	35P 1218	92
35P 992	82	35P 1106	82	35P 1165	114	35P 1219	92
35P 993	82	35P 1107	82	35P 1166	114	35P 1220	92
35P 994	82	35P 1108	82	35P 1167	114	35P 1221	92
35P 995	82	35P 1111	82	35P 1168	114	35P 1222	92
35P 996	82	35P 1112	82	35P 1170	114	35P 1224	92
35P 997	82	35P 1113	82	35P 1171	120	35P 1226	92
35P 998	82	35P 1114	82	35P 1172	120	35P 1227	92
35P 999	82	35P 1116	82	35P 1173	120	35P 1228	108
35P 1000	82	35P 1117	82	35P 1174	120	35P 1229	108
35P 1018	24	35P 1120	94	35P 1175	120	35P 1230	108
35P 1024	26	35P 1121	94	35P 1176	120	35P 1231	116
35P 1030	20	35P 1122	94	35P 1177	120	35P 1232	116
35P 1031	120	35P 1123	94	35P 1178	120	35P 1233	116
35P 1032	4	35P 1124	94	35P 1179	120	35P 1234	116
35P 1033	88	35P 1125	94	35P 1180	120	35P 1235	116
35P 1034	84	35P 1126	104	35P 1181	120	35P 1236	116
35P 1040	76	35P 1127	104	35P 1182	120	35P 1237	116
35P 1041	76	35P 1128	104	35P 1183	120	35P 1238	116
35P 1042	76	35P 1129	104	35P 1184	120	35P 1239	116
35P 1043	76	35P 1130	104	35P 1185	120	35P 1240	116
35P 1044	76	35P 1131	104	35P 1186	120	35P 1241	116
35P 1045	76	35P 1132	104	35P 1187	120	35P 1242	116
35P 1057	60	35P 1133	104	35P 1188	120	35P 1243	116
35P 1058	60	35P 1134	104	35P 1189	120	35P 1244	116
35P 1059	60	35P 1135	104	35P 1190	120	35P 1247	108
35P 1060	60	35P 1136	104	35P 1191	120	35P 1314	79
35P 1061	60	35P 1137	104	35P 1192	120	35P 1315	79
35P 1062	60	35P 1138	104	35P 1193	120	35P 1316	79
35P 1064	10	35P 1139	104	35P 1194	120	35P 1317	79
35P 1065	10	35P 1140	104	35P 1195	120	35P 1413	40
35P 1066	10	35P 1141	104	35P 1196	92	35P 1415	40
35P 1067	26	35P 1142	104	35P 1197	92	35P 1449	30
35P 1069	120	35P 1144	104	35P 1198	92	35P 1450	30
35P 1083	38	35P 1145	104	35P 1199	92	35P 1455	92
35P 1084	38	35P 1146	104	35P 1200	92	35P 1456	92
35P 1085	38	35P 1147	105	35P 1201	92	35P 1457	92
35P 1086	38	35P 1148	104	35P 1202	92	35P 1459	92
35P 1087	38	35P 1149	104	35P 1203	92	35P 1460	92
35P 1088	38	35P 1150	104	35P 1204	92	35P 1461	92
35P 1089	38	35P 1151	114	35P 1205	100	35P 1462	94

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35P 1463	94	35P 1706	112	35P 1797	98	35P 1850	96
35P 1464	94	35P 1707	110	35P 1798	98	35P 1851	96
35P 1465	94	35P 1708	110	35P 1799	100	35P 1852	96
35P 1466	94	35P 1709	112	35P 1800	100	35P 1853	100
35P 1467	94	35P 1710	110	35P 1801	100	35P 1854	103
35P 1468	94	35P 1739	116	35P 1802	100	35P 1855	96
35P 1453	92	35P 1740	12	35P 1803	100	35P 1856	96
35P 1494	42	35P 1741	12	35P 1804	100	35P 1857	98
35P 1496	42	35P 1742	12	35P 1805	100	35P 1858	98
35P 1497	42	35P 1743	12	35P 1806	100	35P 1859	98
35P 1498	42	35P 1746	12	35P 1807	100	35P 1860	100
35P 1501	42	35P 1747	12	35P 1808	100	35P 1861	100
35P 1502	42	35P 1748	12	35P 1809	100	35P 1862	100
35P 1559	36	35P 1749	12	35P 1810	100	35P 1863	103
35P 1562	72	35P 1750	12	35P 1811	100	35P 1864	103
35P 1596	42	35P 1751	12	35P 1812	100	35P 1865	103
35P 1597	76	35P 1752	12	35P 1813	100	35P 1866	103
35P 1600	82	35P 1753	12	35P 1814	100	35P 1867	103
35P 1601	18	35P 1754	12	35P 1815	100	35P 1868	103
35P 1603	18	35P 1757	12	35P 1816	100	35P 1869	103
35P 1604	18	35P 1758	12	35P 1817	100	35P 1870	103
35P 1605	38	35P 1759	4	35P 1818	100	35P 1872	38
35P 1608	38	35P 1762	104	35P 1819	100	35P 1873	38
35P 1609	38	35P 1763	104	35P 1820	100	35P 1874	98
35P 1610	38	35P 1764	104	35P 1821	100	35P 1875	98
35P 1640	120	35P 1765	26	35P 1822	100	35P 1876	98
35P 1669	107	35P 1766	4	35P 1823	100	35P 1877	100
35P 1670	107	35P 1767	62	35P 1824	100	35P 1878	100
35P 1671	107	35P 1768	106	35P 1825	100	35P 1879	100
35P 1672	106	35P 1769	38	35P 1826	100	35P 1880	62
35P 1673	106	35P 1772	30	35P 1827	100	35P 1881	62
35P 1674	106	35P 1773	104	35P 1828	100	35P 1882	62
35P 1675	106	35P 1776	91	35P 1829	102	35P 1885	38
35P 1676	106	35P 1777	40	35P 1830	102	35P 1923	88
35P 1678	110	35P 1778	40	35P 1831	96	35P 1924	88
35P 1679	110	35P 1779	40	35P 1832	96	35P 1925	14
35P 1680	110	35P 1780	40	35P 1833	102	35P 1926	14
35P 1681	110	35P 1781	40	35P 1834	102	35P 1927	14
35P 1682	110	35P 1782	40	35P 1835	102	35P 1928	7
35P 1683	110	35P 1783	40	35P 1836	98	35P 1929	14
35P 1684	110	35P 1784	40	35P 1837	98	35P 1930	14
35P 1685	110	35P 1785	40	35P 1838	96	35P 1931	6
35P 1686	110	35P 1786	40	35P 1839	96	35P 1932	6
35P 1687	110	35P 1787	40	35P 1840	96	35P 1933	6
35P 1688	110	35P 1788	98	35P 1841	96	35P 1934	7
35P 1689	110	35P 1789	98	35P 1842	96	35P 1935	7
35P 1690	110	35P 1790	98	35P 1843	96	35P 1936	14
35P 1691	110	35P 1791	98	35P 1844	96	35P 1937	14
35P 1694	112	35P 1792	98	35P 1845	96	35P 1938	14
35P 1695	112	35P 1793	98	35P 1846	96	35P 1939	14
35P 1696	112	35P 1794	98	35P 1847	96	35P 1940	14
35P 1697	112	35P 1795	98	35P 1848	96	35P 1941	14
35P 1698	112	35P 1796	98	35P 1849	96	35P 1942	14

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
35P 1943	14	36A 5157	58	36A 5706	118	36A 6968	119
35P 1944	14	36A 5173	30	36A 5707	118	36A 6969	119
35P 1945	14	36A 5205	86	36A 5708	118	36A 6970	119
35P 1946	14	36A 5228	66	36A 5709	118	36A 6971	119
35P 1947	14	36A 5286	50	36A 5710	118	36A 6972	119
35P 1948	14	36A 5304	44	36A 5711	118	36A 6973	119
35P 1949	14	36A 5376	74	36A 5712	118	36A 6974	119
35P 1950	14	36A 5389	80	36A 5713	118	36A 6975	119
35P 1951	14	36A 5390	80	36A 5714	118	36A 6976	119
35P 1952	14	36A 5402	78	36A 5715	118	36A 6977	119
35P 1953	6	36A 5406	78	36A 5716	118	36A 6978	119
35P 1954	6	36A 5412	78	36A 5717	118	36A 6979	119
35P 1955	8	36A 5413	78	36A 5718	118	36A 6980	119
35P 1956	8	36A 5666	118	36A 5719	118	36A 6981	119
35P 1957	8	36A 5667	118	36A 5720	118	36A 7076	38
35P 1958	8	36A 5668	118	36A 5721	118	36A 7079	38
35P 1959	8	36A 5669	118	36A 5722	118	36A 7139	38
35P 1960	26	36A 5670	118	36A 5723	118	36A 7143	80
35P 1961	26	36A 5671	118	36A 5724	118	36A 7145	80
35P 1962	26	36A 5672	118	36A 5725	118	36A 7185	80
35P 1963	26	36A 5673	118	36A 6048	52	36A 7218	86
35P 1964	30	36A 5674	118	36A 6128	80	36A 7337	58
35P 1965	30	36A 5675	118	36A 6143	78	36A 7591	74
35P 1966	14	36A 5676	118	36A 6365	78	36A 7599	52
35P 1967	14	36A 5677	118	36A 6500	84	36A 7806	68
35P 1968	14	36A 5678	118	36A 6876	119	36A 7807	68
35P 1969	14	36A 5679	118	36A 6877	119	36A 7912	90
35P 1970	13	36A 5680	118	36A 6878	119	36A 7990	54
35P 1971	14	36A 5681	118	36A 6879	119	36A 7994	54
35P 1972	6	36A 5682	118	36A 6880	119	36A 8002	54
35P 1975	14	36A 5683	118	36A 6881	119	36A 8029	56
35P 1976	14	36A 5684	118	36A 6882	119	36A 8080	124
		36A 5685	118	36A 6883	119	36A 8081	124
		36A 5686	118	36A 6884	119	36A 8082	124
35R 32	88	36A 5687	118	36A 6885	119	36A 8083	124
35R 40	5	36A 5688	118	36A 6886	119	36A 8093	124
35R 41	5	36A 5689	118	36A 6887	119	36A 8099	20
35R 43	44	36A 5690	118	36A 6888	119	36A 8208	30
35R 49	72	36A 5691	118	36A 6889	119	36A 8221	56
35R 55	46	36A 5692	118	36A 6890	119	36A 8272	29
35R 70	92	36A 5693	118	36A 6891	119	36A 8290	80
35R 71	94	36A 5694	118	36A 6892	119	36A 8291	122
35R 83	42	36A 5695	118	36A 6893	119	36A 8292	122
		36A 5696	118	36A 6894	119	36A 8334	86
		36A 5697	118	36A 6895	119	36A 8594	58
36A 328	44	36A 5698	118	36A 6896	119	36A 8555	58
36A 3707	91	36A 5699	118	36A 6961	119	36A 8556	16
36A 5081	44	36A 5700	118	36A 6962	119	36A 8598	34
36A 5083	44	36A 5701	118	36A 6963	119	36A 8599	84
36A 5085	44	36A 5702	118	36A 6964	119	36A 8600	84
36A 5103	42	36A 5703	118	36A 6965	119	36A 8606	58
36A 5104	42	36A 5704	118	36A 6966	119	36A 8852	64
36A 5156	58	36A 5705	118	36A 6967	119		

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
36B 6460	44	50A 1763	42	50A 3575	46	50A 4212	52
		50A 1764	36	50A 3646	34	50A 4214	80
		50A 1771	88	50A 3648	29	50A 4221	78
39A 2240	64	50A 1780	82	50A 3649	124	50A 4222	16
		50A 1781	82	50A 3654	78	50A 4226	26
		50A 1782	82	50A 3655	30	50A 4265	46
39B 1545	48	50A 1797	22	50A 3656	26	50A 4266	46
		50A 1799	80	50A 3657	18	50A 4276	28
		50A 1813	28	50A 3658	42	50A 4284	74
39C 1545	50	50A 1827	78	50A 3659	30	50A 4285	86
		50A 1829	46	50A 3662	32	50A 4286	18
		50A 1893	62	50A 3664	28	50A 4288	26
50A 193	20	50A 1894	62	50A 3665	86	50A 4289	18
50A 196	46	50A 1898	29	50A 3666	16	50A 4290	18
50A 197	90	50A 1900	18	50A 3667	42	50A 4305	88
50A 577	90	50A 1911	34	50A 3668	46	50A 4398	20
50A 578	44	50A 1916	122	50A 3669	42	50A 4399	9
50A 602	74	50A 1925	42	50A 3670	42	50A 4411	52
50A 603	86	50A 1926	29	50A 3671	30	50A 4413	86
50A 766	44	50A 1927	46	50A 3672	46	50A 4421	79
50A 767	44	50A 1977	42	50A 3673	74	50A 4423	86
50A 768	44	50A 1978	58	50A 3676	62	50A 4424	52
50A 937	74	50A 1986	80	50A 3680	70	50A 4425	86
50A 940	74	50A 1992	122	50A 3681	74	50A 4428	86
50A 941	74	50A 2029	78	50A 3682	78	50A 4430	26
50A 954	5	50A 2167	58	50A 3687	80	50A 4439	80
50A 955	42	50A 2249	46	50A 3691	80	50A 4441	56
50A 961	42	50A 2281	58	50A 3708	80	50A 4445	46
50A 973	38	50A 2284	52	50A 3709	80	50A 4448	80
50A 1000	16	50A 2354	86	50A 3711	80	50A 4605	86
50A 1033	30	50A 2415	86	50A 3730	18	50A 4629	59
50A 1045	24	50A 2480	86	50A 3742	58	50A 4662	34
50A 1069	80	50A 2584	58	50A 3753	80	50A 4664	86
50A 1073	80	50A 2590	80	50A 3753	29	50A 4666	34
50A 1096	66	50A 2620	120	50A 3755	30	50A 4668	34
50A 1135	80	50A 2647	58	50A 3761	32	50A 4740	76
50A 1140	88	50A 2704	68	50A 3782	78	50A 4754	74
50A 126B	96	50A 2705	68	50A 3783	58	50A 4817	36
50A 1279	72	50A 2746	70	50A 3801	58	50A 4837	126
50A 1405	72	50A 2822	80	50A 3818	28	50A 4838	126
50A 144L	42	50A 2824	56	50A 3829	24	50A 4839	126
50A 1666	122	50A 2826	56	50A 3831	52	50A 4840	126
50A 1676	90	50A 2832	52	50A 3852	52	50A 4841	126
50A 1719	58	50A 2834	34	50A 3855	28	50A 4842	126
50A 1731	58	50A 2839	84	50A 3856	74	50A 4843	126
50A 1740	66	50A 2843	91	50A 4187	88	50A 4844	126
50A 1743	64	50A 2845	44	50A 4190	16	50A 4845	126
50A 1744	64	50A 2848	90	50A 4201	24	50A 4847	126
50A 1745	44	50A 2874	26	50A 4202	22	50A 4848	126
50A 1746	16	50A 2878	47	50A 4203	58	50A 4850	126
50A 1753	90	50A 2879	47	50A 4204	34	50A 4851	126
50A 1760	58	50A 3420	120	50A 4205	80	50A 4853	126
50A 1761	74	50A 3573	91	50A 4210	24	50A 4854	126

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
50A 4855	126						
50A 4856	126						
50A 4857	126						
50A 4858	126						
50A 4859	124						
50A 4883	119						
50A 4887	34						
50A 4893	126						
50A 4894	126						
50A 4895	126						
50A 4896	126						
50A 4898	126						
50A 4899	126						
50A 4910	74						
50A 4938	36						
50A 4963	126						
50A 4972	28						
50A 4986	30						
50A 4987	80						
50A 4988	86						
50A 4995	52						
50A 4997	58						
50A 4998	78						
50A 4999	59						
50A 5000	58						
50A 5001	28						
50A 5002	40						
50A 5031	49						
50A 5032	42						
50A 5033	20						
50A 5034	62						
50A 5035	58						
50A 5038	68						
50A 5084	70						