

1-2002

OPERATION AND MAINTENANCE MANUAL



OPERATION AND MAINTENANCE MANUAL

Copyright © 2002 Luffert Forklift
All rights reserved. No part of this manual may be reproduced without the written permission of Luffert Forklift.

TABLE OF CONTENTS

CHAPTER 1. INTRODUCTION	1-1
Section I. General Description	1-1
II. Detailed Description	1-1
Specifications	1-5
CHAPTER 2. OPERATING INSTRUCTIONS	1-7
Section I. Initial Preparation for Use	1-7
II. Operating Instructions	1-8
III. Principles of Operation	1-10
CHAPTER 3. FIELD MAINTENANCE	1-12
Section I. Lubrication	1-12
II. Preventive Maintenance Service	1-12
CHAPTER 4. OVERHAUL (SHOP MAINTENANCE).....	1-26
Section I. General.....	1-26
II. Removal, Disassembly, Repair and Reassembly	1-26
4-7. Battery, Clamp and Cables	1-26
4-12. Gasoline Tank, Lines and Fittings	1-28
4-16. Seat	1-26
4-21. Horn Button	1-26
4-26. Steering Gear and Drag Link	1-27
4-31. Head and Rear Lamps	1-27
4-36. Instrument Panel, Switches and Gage	1-28
4-41. Radiator, Hoses, and Thermostat	1-30
4-46. Muffler.....	1-30
4-50. Throttle Controls	1-30
4-55. Water Pump and Fan Assembly	1-30
4-60. Generator.....	1-31
4-65. Starting Motor	1-32
4-70. Distributor.....	1-33
4-75. Voltage Regulator	1-33
4-80. Wheels.....	1-34
4-85. Steering Axle (MY 40).....	1-34
4-90. Steering Axle (MY 60).....	1-35
4-95. Brakes, Inching Mechanism, and Master Cylinders	1-36
4-99. Drive Axle and Differential	1-37
4-104. Control Levers, Control Valve and Oil Filter	1-37
4-109. Transmission Case, Converter and Pump	1-38
4-114. Transmission and Reverse Idler Shaft	1-39
4-119. Fuel Pump and Fuel Filter	1-40
4-124. Carburetor (Gasoline)	1-40
4-129. LP-Gas Equipment	1-41
4-134. Oil Pump.....	1-41
4-139. Engines	1-42
4-143. Hydraulic Pump (MY 40)	1-46
4-148. Hydraulic Pump (MY 60)	1-46
4-153. Hydraulic Control Valve	1-47
4-158. Hydraulic Steering Booster	1-48
4-163. Tilt Cylinders	1-49
4-168. Lift Cylinder (Duplex)	1-49
4-173. Lift Cylinder (Simplex).....	1-50
4-178. Mast and Related Parts	1-51
CHAPTER 5. REPAIR PARTS SECTION	Chapter 5, page 1




Fig. 1-1.

CHAPTER 1

INTRODUCTION

Section I. General Description

1-1. SCOPE

1-2. This manual provides instructions on the operation, maintenance and overhaul of the MY Series Lift Trucks. Most of the instructions apply to both the MY 40 and the MY 60. Where there are differences, it will be noted either in the text or the paragraph heading.

1-3. It is strongly recommended that all personnel concerned with the various phases of this manual have a thorough knowledge and understanding of the equipment and the instructions pertaining thereto, before performing any procedure with the equipment.

1-4. GENERAL DESCRIPTION

1-5. Due to its design and intended purpose, the equipment will be referred to as "lift truck" throughout this manual. Reference to either the right or left sides of the

lift truck are made in respect to the normal direction of travel, which is forward.

1-6. The trucks can be equipped with either a gasoline or LP gas engine. The MY 40 has a capacity of 4000 pounds, the MY 60 a capacity of 6000 pounds, both at a 24 inch load center.

1-7. The lift truck is a completely self-contained vehicle. Its power train consisting of a four-cylinder gasoline engine, a hydraulic torque converter, and a multiple disc clutch and power shaft type transmission. All these assemblies are integrally mounted together, forming one compact unit, which in turn drives the front axle differential and the front drive wheels. A gear-type pump, driven from the engine camshaft, supplies pressure to the hydraulic system. Electrical components of the lift truck utilize the current supplied from one 12-volt battery.

Section II. Detailed Description

1-8. DETAILED DESCRIPTION

1-9. **ENGINE.** The engine (figure 1-2) is a four-cylinder, four-cycle gasoline or LP-Gas operated, valve-in-head type. Its normal speed with no load is 1750 rpm. One complete stroke is required for intake, compression, power, and exhaust, thereby providing one power stroke per cylinder for each two revolutions of the crankshaft.

1-10. **TORQUE CONVERTER.** The torque converter (figure 1-2) is a compact, complete, sealed unit consisting of an impeller, turbine, and single-stage stator. The charging pump is coupled to the engine flywheel through the impeller hub. The oil from the pump charges the converter, and the torque is multiplied by the stator. The turbine is splined to the input shaft in the transmission.

1-11. **TRANSMISSION.** The transmission (figure 1-2) is a power shaft gear box equipped with two pairs of hydraulically actuated multiple disc clutches. One set of clutches is mounted on the input shaft and controls the forward and reverse movement of the lift truck. The other set is mounted on the output shaft, and determines either high or low range. The control valve receives pressure from an engine-driven hydraulic pump mounted on the transmission cover. The valve is controlled by the hand levers mounted on the steering column. An "inching" valve, incorporated into the control valve supplies only partial pressure to the clutches, when it is activated by the inching pedal. This feature provides very slow ground speeds at full engine speed.

1-12. **INCHING SYSTEM.** The inching system is controlled by the combination inching - braking pedal (figure 1-7). The pedal actuates a valve which supplies a restricted pressure to the clutch. The clutch is thus allowed to slip, thereby delivering only partial power to the drive wheels, with a resultant slow ground speed.

1-13. **DIFFERENTIAL AND DRIVE AXLE.** See figure 1-2. Coupled to, and driven by the transmission pinion shaft (output), is the conventional type automotive differential. The assembly is provided with an internal gear reduction at the axle end, which forms an offset in the axle and allows a lower center of gravity for the lift truck. A common lubricant is used for the transmission, differential, and axles.

1-14. **STEER AXLE.** The rear axle of the lift truck is supported by a heavy-duty axle casting which embodies the conventional wheel spindles, steering arms, tie rods, and drag link which in turn is connected to the hydraulic steering booster.

1-15. **HYDRAULIC SYSTEM.** The hydraulic tank is an integral part of the main frame, on the right hand side. A gear type pump draws fluid from the tank, to a control valve, and to the hydraulic steering booster. Fluid under pressure is available on demand at each of these components when the engine is running. Return lines complete the circuit when the cylinders or booster are not in use. Extra valves are available for operating attachments. The system is controlled by hand levers located conveniently to the right of the operator.




Fig. 1-2. Power Train

- | | |
|---------------------|-----------------|
| 1. Engine | 3. Transmission |
| 2. Torque converter | 4. Differential |

1-16. HYDRAULIC STEERING SYSTEM. Steering of the lift truck is accomplished by an 18-inch diameter steering wheel, which is mounted on an automotive-type steering column. A hydraulic steering booster is incorporated into the drag link. As the steering wheel is turned, a valve in the booster opens, and hydraulic pressure from the hydraulic system assists in turning the rear wheels.

1-17. ELECTRICAL SYSTEM. The electrical system consists of a 12-volt battery, generator, voltage regulator, starter, coil, and distributor. The battery is the basic source of electrical current; the generator maintains the battery in a charged condition; and the voltage regulator governs the amount of voltage output into the electrical system. Head and tail lights are available as optional equipment.

1-18. LIFT AND TILT ASSEMBLY. The lift and tilt assembly consists of an upright fork, a lift cylinder, and two tilt cylinders. The lift and tilt mechanism is controlled by hand levers located at the right of the operator's seat. The truck is capable of lifting its rated load from ground level up to a specified height, depending on the mast assembly on the truck. The mast can be tilted from 6° forward of vertical to 12° aft of vertical (other degrees of tilt optional). A restrictor valve in the system provides that the load will not drop at a rate of more than 30 feet per minute in case of hydraulic failure or damage to the lines.

1-19. SERVICE AND PARKING BRAKES.

a. The heavy duty type service brake uses two identical brake shoes which are anchored against individual anchor pins mounted in a spider fastened to the axle. Individual shoe return springs, each hooked between an anchor pin and the underside of its shoe table, hold the shoes anchored. A brake backing plate, mounted behind the spider, supports the brake wheel cylinder and provides three shoe support pads for each shoe against which the shoes rest. Shoes are loosely held on the backing plate by hold-down pins and spring clips, two being used on the secondary shoe, one on the primary shoe. Opposite the anchor, brake shoes are linked by a floating star wheel adjuster and a single retracting spring hooked between the shoe ribs so that it engages and locks the star wheel. The star wheel is reached through a slot in the backing plate and is used to expand the shoes as required to adjust lining clearance. The star wheel link causes the shoes to function as a single compound unit. In operation, one shoe, depending upon drum rotation, leaves its anchor. (The "primary" shoe is dragged from its anchor by forward drum rotation while the "secondary" shoe remains anchored. In reverse drum rotation, the "secondary" shoe is the one leaving the anchor.)

b. The same brake shoes are utilized in a cable operated parking brake. A toggle lever, pinned to the rib of the secondary shoe, engages a connecting link, pinned to the primary shoe rib. The parking brake cable is connected




Fig. 1-3. Hydraulic Flow Diagram

at the opposite end of the toggle lever. When the cable is pulled taut, movement of the toggle lever on its fulcrum pin causes the connecting link to expand the shoes into the brake drum.

1-20. FUEL SYSTEM (GASOLINE). A 10-gallon gasoline fuel tank is an integral part of the frame on the left hand side. It contains a "protected" safety filler cap. The fuel suction line originates at the inside bottom of the tank and arranges at the upper right hand corner of the tank, thereby preventing loss of fuel should a fuel line be broken. A plug is provided at the tank bottom for fuel drainage and cleaning. A fuel shut-off valve is installed in the flexible hose leading from the tank to the fuel pump.

1-21. FUEL SYSTEM (LP-GAS). The LP-Gas system consists of a replaceable tank (33-1/2 pound capacity), a filter, a converter, and the carburetor. The fuel is confined to the tank as a liquid under pressure. When the valve is opened, the liquid passes to the converter where it is changed into a gas, and then is metered to the carburetor.

1-22. COOLING SYSTEM. Cooling of the engine is accomplished by an 18-inch, six-bladed pusher type fan (3, figure 1-19) and a water circulating pressure system radiator. The bottom portion of the radiator is designed with coils to cool the torque converter fluid.

1-23. EXHAUST SYSTEM. Engine exhaust vapors are vented out of the exhaust manifold on the upper left side of the engine, down through a muffler and out of a tail pipe at the rear of the lift truck.

1-24. SERVICING ACCESSIBILITY. See figure 1-4. Raising the appropriate hood section and propping it open with the support rod provides easy access for servicing the battery, air cleaner, generator, starter, distributor, spark plugs, fan belt, engine and transmission oil supplies, filters, and dipsticks. The radiator and fuel tank are serviced externally. The hydraulic tank fill tube is located under the right hand hood section.

1-25. WHEELS AND TIRES. The brake drums for the drive wheels are included in the wheel centers. Tire pressures are given in paragraph 2-9.



Fig. 1-4. Servicing Accessibility

1-26. SEAT. See figure 1-5. The seat is adjustable forward and backward. The release handle is located on the right side of the seat frame.




Fig. 1-5. Seat

1. Release handle

ENGINE SPECIFICATIONS:

Make	MOLINE
Bore and stroke	3-3/4 x 5 in.
Number of cylinders	4
Displacement	220 cu. in.
Ft./lb. torque @ 1800 rpm	170
Ft./lb. torque peak @ 1200 rpm	199
CRANKSHAFT	
Material	drop forged steel, heat treated
Bearings	3 precision
Front and intermediate	2-3/4 in. dia. x 1-5/8 in.
Rear	3 in. dia. x 2-3/16 in.
CYLINDERS AND HEADS	
Cast	in pairs
Material	special alloy cast iron
CONNECTING RODS	
Style	Drop-forged steel, heat-treated section
Bearings	2-5/8 in. x 1-1/4 in.
PISTONS	
Material	Aluminum Alloy
Rings	4
Compression	two 3/32 in. wide
Oil	two 5/32 in. wide
RINGS	
Bearing (in rod)	1 in. x 1-3/8 in.
CAMSHAFT	
Number of bearings	3
Drive	Helical gears
VALVES AND VALVE MECHANISM	
Location	in head
Tappets	barrel ported
Intake valves	alloy steel, 1-1/4 in. dia.
Exhaust valves	alloy steel, 1-11/64 in. dia. port.
Exhaust valve seat inserts	stellite
LUBRICATION	
Gas and LP gas	1 12-volt battery
Spark Plugs	18 mm
Generator capacity	20 amps
Regulator capacity	20 amps
LUBRICATION	Pressure points to rod, main and camshaft bearings, timing gears, valve mechanism
Pump	gear
Location	submerged in sump
Capacity	6 gpm at 30 psi
Filter	full flow with replaceable spin-on element
Crankcase capacity	7 qt.
Oil level gauge	bayonet
Pressure gauge	on instrument panel
COOLING SYSTEM	
Pump	centrifugal V-belt drive
Capacity	40 gpm at 1800 rpm
Fan	18 in. dia. 6 blade
Radiator capacity	6-1/2 gals.
Core	flat tube and fin type

DIMENSIONS AND SPECIFICATIONS

	MY 40	MY 60
Capacity @ 24 in. load center	4000 lbs.	6000 lbs.
Inch pound rating	176,000	264,000
Free lift	12-1/2 in. Simplex 64 in. Duplex	18-3/4 in. Simplex 60 in. Duplex
Weight--service	8340 lbs.	9850 lbs.
Tilt 6° forward	optional 8° forward optional 0° forward	optional 8° forward optional 0° forward
Tilt 12° back	optional 10° back	optional 10° back
Length less forks	96 in.	112 in.
Width--single drive tires	45 in.	53 in.
dual drive tires	60-1/2 in.	69 in.
Wheelbase	56 in.	72 in.
Underclearance--mast	5 in.	5 in.
center	8-1/2 in.	7-3/8 in.
Turning Radius outside	85 in.	92 in.
Turning Radius inside	11 in.	19 in.
Turns in intersecting aisles	72 in.	89 in.
Engine hp (Sea level calculated) @ 1800 rpm	58	58
Speeds (MPH)	High Range Low Range	High Range Low Range
Forward	0 - 11.5 0 - 6.8	0 - 12 0 - 7.5
Reverse	0 - 11.5 0 - 6.8	0 - 12 0 - 7.5
Speed of lift--loaded	60 fpm	58 fpm
Fuel capacity	16 gals.	18 gals.
Protektoseal gas cap	standard	standard
LP gas (optional)	33-1/2 lbs.	33-1/2 lbs.
Tires--Steer	6:00 x 9 x 10 ply	7:50 x 10 x 10 ply
Single drive (Standard)	7:50 x 15 x 12 ply	8:25 x 15 x 12 ply
Dual drive (Optional)	7:50 x 15 x 10 ply	7:50 x 15 x 10 ply
NOTAT (Optional)	laminated rubber	laminated rubber
Tread--steer	96 in.	42-3/16 in.
single drive	36-1/2 in.	43-1/2 in.
Standard fork length	42 in.	42 in.
Center of drive axle to face of forks	19-1/2 in.	20-1/2 in.
Carriage--standard (ITA)	44 in.	48 in.
Carriage--extra wide (optional)	60 in.	72 in.

CHAPTER 2

OPERATING INSTRUCTIONS

Section 1. Initial Preparation For Use

2-1. SERVICE UPON DELIVERY.

a. **UNLOADING.** Since the lift truck may be shipped from the factory in a number of ways, no attempt will be made to cover all methods of unloading procedures. The trucks were shipped from the factory in accordance with standard shipping procedures, and should be unloaded from their carriers in a safe, logical manner.

b. **REMOVAL OF PROTECTIVE MATERIALS AND DISASSEMBLED COMPONENTS.** Remove any protective tape or padding from the lighting components of the lift truck. Remove any components that have been packaged separately and attached to or shipped with the lift truck; refer to the Table of Contents and note the page number on which that component is listed. Install the component accordingly.

c. **VISUAL INSPECTION FOR SHIPPING DAMAGE.** Although every attempt has been made at the factory to protect the equipment against damage during shipment, it is possible for some damage to be incurred. It is necessary, therefore, that a careful, visual inspection be made of the lift truck upon delivery and before placing it in operation. It is further recommended that a written record be maintained which outlines the nature of the damage, and the urgency required in its correction.

d. **SERVICE PRIOR TO USE.** The following procedures are to be accomplished before operation of the lift truck:

2-5. BATTERY.

a. The battery is shipped without electrolyte. Raise the left hand section of the hood, remove the battery from the lift truck, and discard any vent plug seals. Fill all cells to the proper level with electrolyte. Allow the battery to stand for about 20 minutes after filling.

WARNING

Electrolyte can burn or damage the eyes, skin, or clothing. Wear safety glasses to prevent damage to the eyes due to splashed electrolyte. If electrolyte is spilled on the skin or clothing, flush off immediately with a solution of baking soda and water, or some other neutralizing agent, then flush off with clean water.

b. Code date the battery according to the month and year. Stamp the code on the insullon conductor nearest the negative terminal of the battery. The first number of the code indicates the month (1-January, 2-February, etc.), and the second number indicates the year (1-1961, 2-1962, etc.).

c. Give the battery a booster charge after it has been filled and dated. Fast charge for at least 10 minutes at the rate of 30 to 40 amps; or slow charge for at least 30 minutes at 10 amps. See paragraphs 2-7, 3-6, and 3-9 for battery service procedures and data.

d. If any electrolyte spilled on the battery, flush it off with clean water. Dry the battery before installing.




Fig. 1-6. Battery

e. The battery has a negative ground. Install it with the negative terminal toward the front of the truck. Install the clamp and cables.

f. **ELECTRICAL SYSTEM.** Inspect wiring and connections. Actuate light switch and inspect the lights for proper response. Place ignition switch "ON" and test for electrical current to that component. With switch on, test horn.

g. **FUEL SYSTEM (GASOLINE).** Open the fill cover of the fuel tank located on the left side of the lift truck; fill as necessary with a good grade of regular gasoline. Close the tank cover, and padlock if desired. Wipe the tank free of dirt or fuel hose leakage, and inspect fuel line and engine-mounted accessories for signs of fuel leakage at their connections. Open shut-off valve located on fuel tank-to-fuel pump line.

h. **FUEL SYSTEM (LP-GAS).** Open the valve on the fuel supply tank. Check all connections in the fuel line for evidence of leaks. A leak will result in a formation of frost at the point of the leak.

i. **WHEELS AND TIRES.** Inflate front tires to 85 pounds and rear tires to 30 pounds pressure. Inspect tires very closely for nails, glass, or any other foreign particles that may impair the life.

2-10. HYDRAULIC SYSTEM. Remove the breather cap from the hydraulic tank located on the right side of the lift truck. Fill as necessary in accordance with the lubrication instructions given in figure 1-10. The capacity of the system with a duplex cylinder is 12 gallons, with a simplex cylinder, 11 gallons. With the mast fully raised and oil in the lines and cylinders, the oil should be up to the "Full" mark on the dipstick.

2-11. LUBRICATION. The lift trucks are completely serviced prior to delivery with lubricants specified for the ambient factory temperatures, and should require no further lubrication at point of delivery unless temperatures differ greatly from those at the factory. If such is the case, service the lift truck according to the lubrication chart, figure 1-10.

Section II. Operating Instructions

2-14. STARTING THE LIFT TRUCK.

a. If the lift truck is equipped with an LP-Gas engine, open the valve on the tank slowly. If the valve is opened too fast, an excess flow valve will snap shut and stop the flow of fuel. If this happens, close the valve and wait for a "click". This will indicate that the pressure has equalized on both sides of the excess flow valve. Then open the tank valve slowly.

b. Position the forward-reverse shift lever (1, figure 1-8) in neutral. A neutral starting switch prevents the engine from starting unless this lever is in neutral.

c. Turn the ignition switch (11, figure 1-8) to "ON".

d. Depress the starter button (10, figure 1-8) and release it as soon as the engine starts. Do not depress button longer than eight seconds. If the engine fails to start on first try, allow the engine and starting motor drive to come to a complete stop before making a second attempt. This will prevent damage to the starting motor housing, the drive, and the flywheel ring gear. On a gasoline engine, it may be necessary to use the choke (5, figure 1-7). When the engine starts, allow it to gradually warm up to its normal operating temperature (approximately 190° F.). Do not race the engine during this warm-up period.

e. Normal procedure would be to shift into either high or low gear from neutral with the lower lever, and then shift into either forward or reverse direction with the upper lever. However, no damage will result if the direction is selected first and then the gear range desired. Both levers must be shifted into an operating position before the lift truck will move.

f. Apply foot pressure on the accelerator pedal and steer the lift truck in the direction selected.

g. Refer to Table I to correct any malfunction of the lift truck or its components under operating conditions.

2-12. LIFT TRUCK BODY. Inspect all sheet metal and fabricated parts for distortion or damage. Tighten all screws and nuts, particularly those of the steering wheel column, instrument panel components, and brake and accelerator pedals.

2-13. COOLING SYSTEM. Remove the engine radiator cap and inspect the coolant level. If weather is above freezing temperatures, add clean water until it covers the radiator core as seen through the fill cap opening. For operation in sub-freezing temperatures, provide the 18.5 quart capacity cooling system with a good grade permanent anti-freeze solution. Inspect for coolant leakage at all connections.

CAUTION

If, after starting the engine, there is very little or no pressure indicated on the engine oil pressure gage, or if there is a sudden drop in pressure while operating the lift truck, stop the engine immediately and determine the cause. Correction usually consists of replenishing the crankcase oil supply. Located on the instrument panel is a red warning light (3, figure 1-8). This light will glow only when the transmission lubricant temperature is excessive, and indicates that the transmission oil supply is dangerously low and must be immediately replenished before further lift truck operation.




Fig. 1-7. Controls

1. Clutch pedal
2. Brake pedal
3. Accelerator pedal
4. Parking brake
5. Choke button (gasoline only)
6. Thrift lever
7. Lift lever




Fig. 1-8. Instrument Panel

1. Forward - reverse lever
2. Height - low range lever
3. Transmission warning light
4. Light switch location
5. Temperature gage
6. Oil pressure gage
7. Hourmeter
8. Fuel gage
9. Ammeter
10. Starter button
11. Ignition switch

2-15. LOADING PROCEDURE.

a. Drive the lift truck into position as near the load's center of weight as possible. Place one of the transmission shift levers in neutral; position the forks slightly below the level of the load, drive the truck forward until the forks are directly beneath the load. If the depth of the load permits, drive forward until the load is against the back rest.

b. Apply the service brakes while lifting the load.

c. Move the lift control handle (closest to operator) to the rear to raise the load. If the nature of the load permits, move the lift control handle to the rear, to tilt the load rearward against the back rest for maximum stability.

d. For maximum safety and stability, carry the load just high enough to clear obstacles or uneven terrain.

2-16. UNLOADING PROCEDURE.

a. Drive loaded lift truck to unloading area and position for unloading. Apply the service brakes, and move one of the transmission control levers to neutral.

b. Move lift control lever until load is lowered to the ground or is at the desired height for stacking. If load was tilted rearward against back rest while transporting, move tilt control lever forward until mast is vertical.

c. Release brakes, place transmission control lever in operative position, and move lift truck slowly forward until load is in desired position. Apply brakes and shift transmission into neutral.

d. Lower forks until they are relieved of load's weight. Back up lift truck until forks are clear of load. Lower forks to safe transport position.

2-17. INCHING CONTROL. The inching valve is controlled by the left hand pedal on the combination braking-inching pedal assembly (figure 1-7). Depress the pedal slightly with the left foot - use just the portion of pedal travel before the brakes can be felt to take hold. Depress the accelerator pedal with the right foot. Extremely slow ground speeds can be attained for operating in confined or dangerous areas, while the speed of the lift remains normal.

2-18. STOPPING THE LIFT TRUCK.

a. Drive the lift truck to an area suitable for parking and place the transmission control levers in neutral. Apply the parking brake.

b. Tilt the mast slightly forward and lower the forks to the bottom of the mast.

WARNING

Unless conditions prevent, always unload forks and lower them to bottom of mast before leaving lift truck, to avoid danger to personnel.

c. If the headlight was used, push in the light switch to turn off the light.

d. Turn the ignition switch to the "OFF" position.




Fig. 1-9. LP-Gas Tank

1. Gage
2. Fuel valve
3. Quick coupler
4. Relief valve

2-19. **CHANGING LP-GAS TANKS.** To change LP tanks, close the fuel valve. Disconnect the quick coupler, and release the clamps. Lift the tank out of the bracket. Install the new tank, secure it with the clamps, and connect the quick coupler.

IMPORTANT: THE LP TANK MUST BE FILLED IN ACCORDANCE WITH ICC AND LOCAL REGULATIONS.

2-20. SAFETY PRECAUTIONS.

2-21. The following safety precautions must always be observed:

a. Driver should be thoroughly familiar with the lift truck, its capabilities and its limitations, before attempting its operation. Never attempt operation of a lift truck known to be faulty.

b. Provide adequate ventilation in operational areas; avoid prolonged operation in enclosed areas.

c. Constantly check for personnel and obstacles in path of both lift truck and load; keep lifting forks in driver's view whenever possible.

d. Transport load at lowest practical level, for maximum stability and visibility. Avoid sudden stops, sharp turns in either direction, and excessive speed.

e. Never leave the lift truck unattended with engine running or load elevated. Lower forks to bottom of mast and apply parking brakes before leaving lift truck.

f. Strap or otherwise secure load to carriage when descending grades steeper than 10 degrees from horizontal in a forward direction. Do not attempt operation of loaded lift truck on ascents or descents greater than 20 degrees.

g. Do not attempt to lift or transport loads that exceed the rated capacity of the truck.

h. Always secure forks in position with lock levers.

i. Close the tank valve on an LP-Gas unit when leaving the truck unattended.

Section III.

PRINCIPLES OF OPERATION

2-22. **Instruments and Controls** (See figures 1-7 and 1-8).

2-23. **OIL PRESSURE GAGE.** The oil pressure gage (6, figure 1-8) does not indicate the amount of oil in the crankcase; it indicates the pressure of the oil in the engine lubricating system. The gage electrically senses the oil pressure and reflects it on the gage dial. With the engine at normal operating temperature and speed, the oil pressure should be between 25 and 35 pounds.

2-24. **ENGINE TEMPERATURE GAGE.** This gage (5, figure 1-8) indicates the temperature of the cooling fluid. Engine operation under normal conditions should register approximately 150 degrees on the gage. Temperatures excessively higher or lower than 160 degrees indicate a dirty or restricted radiator, or loss of coolant. Do not operate the lift truck until these conditions are corrected.

2-25. **IGNITION SWITCH.** The ignition switch (11, figure 1-8) is a means of opening and closing the ignition circuit; the engine is inoperative unless the switch is turned "ON".

2-26. **STARTER SWITCH.** Depressing the starter switch (10, figure 1-8) with ignition switch "ON", energizes the starting motor which in turn drives the engine flywheel ring gear until combustion takes place in the engine.

2-27. **AMMETER.** The ammeter (9, figure 1-8) indicates the activity of the electrical system. If the needle in-

dicates a continuous discharge when the engine is operating above an idle speed, the trouble would probably be a loose or broken fan belt, a short in some wire or component of the electrical system, or a faulty generator or regulator. The gage needle should move slightly to the positive side of the "0" mark on the ammeter when the engine is running at full governed speed and the battery is fully charged.

2-28. **HOURMETER.** The hourmeter (7, figure 1-8) reflects the actual hours of engine operation. Its main purpose is to be the determining factor as to when the lift truck components require overhaul procedures.

2-29. **WARNING LIGHT.** The red warning light (3, figure 1-8) senses the transmission oil temperature and glows only when the temperature is in excess of proper operating limits. This condition is usually remedied by bringing the transmission oil level to full.

2-30. **FUEL GAGE**

a. **Gasoline.** The fuel gage (8, figure 1-8) electrically senses and indicates the amount of fuel in the lift truck fuel tank.

b. **LP-Gas.** The gage (1, figure 1-9) indicates the amount of LP-Gas in the tank.

2-31. **CHOKE CONTROL.** (Gasoline only). The choke control button (2, figure 1-7) is cable connected to the choke disc in the carburetor assembly. Pulling forward on the choke button closes the choke disc, thereby enriching the air and gasoline mixture and providing quicker

starting of a cold engine. Push the choke button in as the engine warms up to operating temperature; if all carburetor settings are correct, the resulting fuel mixture will be correct for proper engine operation.

2-22. LIGHTING SYSTEM (OPTIONAL). Pulling outwardly on the light button (4, figure 1-8) closes the circuit to the lights, thereby energizing them from the current supplied by the battery. Returning button inwardly toward the panel opens the circuit, and renders the lights inoperative.

2-23. POWER TRAIN (ENGINE AND TRANSMISSION). With the ignition switch in the "ON" position, actuation of the various components is achieved in the following sequence: Depressing the starter button energizes the starting motor which is pinion meshed with the engine flywheel ring gear teeth. As the ring gear is rotated by the starting motor, the crankshaft is forced to rotate. It is at this point that fuel vapors enter the piston chambers and are ignited by the electrical impulse delivered by the spark plugs. The synchronized firing order of the

spark plugs produces a continuous source of driving energy for the crankshaft. The transmission is inter-connected to the engine by a torque converter and plate arrangement, and a series of multiple disc clutches in the transmission allows the operator a selection of two speeds in either forward or reverse direction, and also a neutral position when no travel is desired. The transmission is in turn geared to the differential of the drive axle by means of a bevel pinion and ring gear. Shifting of the levers results in rotating the axle shafts in a clockwise or counterclockwise movement, depending upon which gears are engaged within the transmission housing.

2-24. HYDRAULIC SYSTEM. The hydraulic pump provides a constant flow of hydraulic fluid under pressure when the engine is running. The control levers direct the flow to the lift or tilt cylinders or to the hydraulically actuated attachments. Fluid is also supplied directly from the pump to the hydraulic steering booster. Return passages in the system provide a complete circuit for the fluid when the cylinders are not being utilized.

CHAPTER 3

FIELD MAINTENANCE

Section I. Lubrication

3-1. LUBRICATION INFORMATION.

- a. The lubrication chart (figure 1-10) illustrates lubrication points of the lift truck and prescribes approved lubricants, recommended intervals, and application procedures.
- b. In order that the lubricants can accomplish the protection for which they were intended, they must be kept free from dust, dirt, water, or other forms of contaminants.
- c. Wipe each lubrication fitting clean with a cloth before applying lubricants.
- d. Apply only the grade of lubricant specified for operation under the temperature ranges indicated.
- e. It is recommended automotive practice to operate the lift truck immediately after a complete lubrication change in order to distribute the lubricant most effectively.
- f. Special or detailed instructions for servicing the lift truck components are outlined in the lubrication chart under "NOTES".

Section II. Preventive Maintenance Services

3-2. PERIODIC IN-SERVICE MAINTENANCE.

3-3. GENERAL. The instructions contained in this section are intended to aid the operator in maintaining the lift truck in an efficient, trouble-free condition. It is the purpose of this section to acquaint the operator with the possibilities of equipment malfunction, the indications of malfunction, and the corrective measures to be taken. Thorough understanding of the instructions by the operator is required to prevent minor malfunctions from going unnoticed until a part or a system is damaged beyond repair, resulting in removing the lift truck from service for extended periods.

3-4. SPECIAL MAINTENANCE TOOLS. No special tools are required by operating personnel to maintain the lift truck in serviceable condition. Standard tools, commonly used by automotive mechanics, should be made available to the operator.

3-5. MAINTENANCE CHARTS. In addition to, and summarizing the procedures of this section, Table I is presented in chart form to provide the operator with a ready reference as to typical troubles, the probable cause, and remedy procedures required.

3-6. ELECTRICAL SYSTEM.

NOTE

Disconnect battery ground cable before working on electrical components.

3-7. BATTERY. Battery "life" depends entirely upon proper care and thorough periodic inspections. The most important service in maintaining the battery, is to inspect the electrolyte (liquid) level daily. Add distilled water until the tops of the plates are covered approximately 1/8 inch. If distilled water is not avail-

able, use clean rain water or regular drinking water that is low in mineral content. Since the water and the electrolyte in the battery will not mix until charged by the generator current, make a practice of operating the engine for a minimum of one hour after filling if the danger of freezing exists.

WARNING

If the battery electrolyte is accidentally spilled or comes in contact with skin or clothing, immediately apply baking soda or a similar neutralizing agent.


3-8. Use an accurate hydrometer to check the electrolyte specific gravity. When fully charged, the reading should be 1.240 to 1.260 at a liquid temperature of 80° F. Wide variations from this reading between the cells indicates a faulty battery, and requires replacement with a new battery.

WARNING

Since the batteries release highly flammable hydrogen gas when being charged, keep all forms of sparks or flame away from lift truck.

3-9. Wash batteries clean with solution 1/2 pound baking soda mixed with 1 quart of water, apply with a brush, and flush with clear water. Prevent solution from entering vent holes; make sure holes are open after cleaning. Apply a light film of petroleum jelly to the battery terminals and cable clamps to retard corrosion.

3-10. GENERATOR. In addition to maintaining the generator (1, figure 1-17) in a clean condition at all times, a more detailed inspection of the brushes and commutator is required every 500 hours of operation. With the generator mounted on the engine, remove the commuta-



CODE	TYPE	CODE	TYPE
CG	Chassis Grease	BF	Brake Fluid
EO	Engine Oil	WB	Wheel Bearing Grease
GL	Gear Lube	FO	Transmission Oil (ATF)

APPLICATION SCHEDULE

LUBE POINT	CODE	HOURS	LUBE POINT	CODE	HOURS
Chain Sheave (2)	CG	40	Tilt Cyl. Anchor Pins (4)	CG	40
Lift Chain (2)	EO	40	*Differential	TO	500
*Steering Gear	GL	40	*Transmission	TO	500
Lucing Master Cylinder	BF	40	Brake Pedal	CG	40
*Starter	EO	300	*Brake Master Cyl.	BF	40
*Air Cleaner	EO	40	*Fuel Pump	None	500
Drag Link & Cylinder (2)	CG	40	*Engine Oil	EO	8
*Trans. Oil Filter	TO	500	Hydraulic Tank	TO	2000
*Radiator	None	8	*Engine Oil Filter	EO	400
Steer Axle (2)	CG	40	Battery	None	8
Steer Axle Bearings (2)	WB	1000	*Generator	EO	60
Mast Mounting Pins (2)	CG	40	*Distributor	EO	300

* - See "LUBRICATION NOTES"

Fig. 1-10. Lubrication Chart (Sheet 1 of 2)

LUBRICATION NOTES

Hours listed in "APPLICATION SCHEDULE" refer to actual hours of machine operation. Bracketed () numbers indicate similar lubrication points requiring lubrication. An asterisk * indicates detailed lubrication instructions as follows:

***AIR CLEANER.** Service air cleaner every 40 operating hours or oftener as required. Remove and empty oil cup. Scrape out sediment and wash cup thoroughly. Refill cup to level mark with same grade oil as used in engine.

***STEERING GEAR.** Check oil level every 40 operating hours. Keep reservoir filled with SAE 90 gear lube. Use a high grade straight mineral oil.

***BRAKE AND INCHING MASTER CYLINDERS.** Check fluid level every 40 hours. Keep filled to within 1/4" from top. Keep vent hole in filler cap open at all times.

***GENERATOR.** Every 60 operating hours, add 8 to 10 drops SAE 10W engine oil to the respective oil cups.

***STARTER.** Place 8 to 10 drops SAE 10W oil in oil cup every 300 operating hours.

***ENGINE OIL.** The crankcase capacity is 6 U.S. quarts; the filter holds an additional quart. Check twice daily, drain and refill every 200 operating hours and change filter every 400 operating hours under normal service.

***DISTRIBUTOR.** Each 300 operating hours place 3 or 4 drops SAE 10W oil on wick under rotor. Remove plug at side of housing and fill with SAE 20 oil each 300 operating hours. Apply a trace of high quality ball bearing lubricant to the breaker cam every 900 operating hours.

***HYDRAULIC OIL TANK.** Check daily and maintain level at "Full" mark on dipstick, with mast fully raised. Use ATF Type A Suffix A AOATF 696A (Texaco oil). Drain, clean, and refill every 2000 hours.

***RADIATOR.** Check daily. Refill as required. Add permanent type anti-freeze when air temperature is 32° F. or lower.

***FUEL PUMP.** Clean bowl and screen.

***TRANSMISSION.** ATF Type A Suffix A AOATF 696A (Texaco) oil. Change oil and filter every 500 operating hours. Drain transmission, change filter, and clean suction strainer in transmission case after first 40 hours. Check oil level daily.

***DIFFERENTIAL.** The lubricant used in the differential is common to the transmission; therefore, checking and changing are the same.

TORQUE CONVERTER. The lubricant used in the converter is common to the transmission and differential. Drain at the time of the transmission oil change. Rotate converter until drain plug is visible in hole in bottom of housing. Converter will recharge itself with engine running. Recheck transmission oil level after charging converter.

BREATHERS. Check and clean the breathers for the crankcase, hydraulic system, and the differential each 40 operating hours. Clean the breather cups in solvent, dip in clean engine oil, then shake out the excess oil.

Fig. 1-10. Lubrication Chart (Sheet 2 of 2)

tor cover and inspect the brushes for wear. Do not grasp the brush leads and pull the brushes out of the holders against the spring tension. Do not snap the brush arm down against the brushes. Clean a dirty commutator using a strip of number 00 sandpaper or a brush seating stone, held against the commutator with a piece of flat hardwood while the engine is idling. Blow out all dust and grit with compressed air. Do not use emery cloth to clean the commutator. Replace worn brushes with new brushes, being sure to tighten brush leads and screws, field leads, and all connections. Brush holder springs have sufficient tension if they hold the brushes tight against the commutator; replace springs if they do not. Prevent brushes from sticking by keeping the holders clean.

3-11. **GENERATOR AND FAN BELT.** Frequently inspect the fan and generator drive belt for proper tension; a loose or slipping belt will cause engine over-

heating and reduce generator charging rate and the rpm of the driven pulley. Check belt tension (figure 1-11) by pressing on the belt mid-way between the fan and crankshaft pulleys with a force of approximately 10 pounds. Proper belt deflection should be 3/4 to 1 inch. Adjust belt tension by loosening generator mounting bolts and the adjusting bar cap screw, pull outwardly on the generator until correct tension is applied, and then tighten nuts and cap screw. Replace a worn or grease-soaked belt as it will not be capable of driving the fan or generator at their proper speeds.

3-12. **STARTING MOTOR.** Service the starting motor, brushes and commutator in accordance with the instructions outlined for the generator assembly (paragraph 3-10 above). If the starting motor pinion fails to engage the engine fly-wheel ring gear, it indicates a sticking drive pinion and requires removal from the engine. Remove the negative lead wire from the battery, disconnect all




Fig. 1-11. Belt Tensor.

wires from the motor, remove the large lock bolt that secures the starting motor to the engine, and withdraw the motor from the engine flywheel housing. Wash the pinion and shaft of the motor with clean kerosene, dry completely, and re-install on engine being sure that the lock bolt engages the upper hole in the starting motor housing. Clean the lead wire terminals and make proper connections of the motor leads and the negative lead of the battery. If starting motor still fails to operate, install a new assembly in its place (tag the faulty motor for overhaul).

3-13. SPARK PLUGS. Whenever engine performance is unsatisfactory, fuel consumption is excessively high, or idling is rough, it is an indication that the most logical component to check first is the spark plugs. Using a 7/8 inch deep socket wrench, loosen the plugs two full turns, blow all dirt away from the ports, and then remove the plugs. Clean the plugs with a sand blast cleaner if available, clean plug threads with a wire bristle brush, and restore damaged threads in the head ports with a suitable size tap. Clean the sparking surfaces to a bright smoothness with a fine point file. Reset the plug gap to 0.023 to 0.028 inch for gasoline engines, 0.014 to 0.026 inch for L.P.-Gas engines. Set gap by bending the ground or outside electrode, and test with a wire feeler gage. Using new copper gaskets, install the new or cleaned plugs, and tighten them to 34 foot-pounds torque. If no torque wrench is available, install finger tight, and then tighten an additional 3/4 turn with the deep socket wrench.

3-14. DISTRIBUTOR. Remove the distributor (2, figure 1-17) cap wipe it clean with a cloth, and inspect it closely for cracks (usually very thin). Inspect the cap and

rotor for chips, cracks, or carbonized paths which allow high-tension leaks to ground. Inspect and discard a cap seal if it is glazed or treated with oil. Check the centrifugal advance mechanism for unbinding movement by turning the distributor shaft in its direction of rotation, and then release it. The advance springs should return the shaft to its original position without sticking. Clean the distributor points with a fine cut contact file; do not attempt to remove all roughness, but merely remove scale and dirt from the contacting surfaces. Do not use emery cloth or sandpaper as their abrasive particles will imbed in the surfaces and cause the points to burn. Adjust the point gap to 0.016 inch by turning the engine over until the cam follower block for the breaker lever is on the high point of the cam lobe. Loosen the lock screw, turn the eccentric screw to obtain the above stated gap, and then tighten the lock screw. Apply a light film of half beating lubricant to the breaker cam; place two drops of light engine oil on the felt in the distributor shaft. Discard all parts that are worn, burned, pitted, or set in an otherwise unserviceable condition. No further distributor servicing is required for field maintenance, however, if timing lights are available ignition timing can be checked at this time by following the procedure outlined in paragraph 3-32. Secure distributor cap in its original location on the distributor, and install cap spark plug wires.

3-15. OIL PUMP. With the engine running at full governed speed and normal operating temperature, the dash panel-mounted oil pressure gage should register between 25 to 35 pounds. Erratic action, flickering, or a sudden lowering in the pressure is not always an indication of oil pump malfunction; check the crankcase oil level, test for a faulty gage by disconnecting the oil gage tube at the engine connection and turn the engine over with the starting motor. If a steady stream of oil comes out of the fitting in the crankcase, the gage is faulty and not the pump. If no oil comes out of the fitting, or the stream is broken and weak, it indicates a plugged oil intake passage or a plugged float screen. Clean the oil passage. Remove the cover from the lower right side of the engine after draining the crankcase oil, remove the cutter pin (1, figure 1-12) that secures the float to the connector tube, and withdraw the float and screen assembly. Thoroughly clean the screen using clean kerosene, dry completely, inspect for damage, and re-install it in its original position. Unscrew the oil filter located at the rear right side of the engine and discard it. Install new filter. An oil pressure regulator (figure 1-13) is installed on the left side of the oil pump housing. To adjust the oil pressure on the pressure gage, loosen the lock nut of the regulator and rotate the setscrew clockwise to increase pressure, and counterclockwise to decrease oil pressure. When the gage indicates low oil pressure and no further adjustment of the regulator setscrew is possible, it indicates that the oil pump gears have too much end clearance or are worn beyond serviceable limits, or that the regulator spring has collapsed or is broken. Drain the crankcase oil, remove the attaching parts that secure the pump to the crankcase, and with-

draw the pump assembly. Inspect the gears and spring; remove and replace as necessary. Do not remove the oil pump drive shaft as that would also require removal of the entire distributor assembly which in turn involves re-timing of the engine. This should only be done in the shop. Install and check for drive gear and clearance as outlined in the oil pump overhaul procedures of Chapter 4.




Fig. 1-12. Oil Float and Screen

1. Center pin
2. Float




Fig. 1-13. Oil Pressure Regulator

1. Adjusting screw
2. Lock nut

8-16. GOVERNOR. Inspect the governor and carburetor linkages (figure 1-14) for signs of rough edges, paint, or binding. Adjust linkage for proper governed speeds of 1750 rpm as follows: Start engine and allow it to reach normal operating temperature. Stop engine and disconnect the spring and plunger assembly from the fork shaft, disconnect the carburetor control rod, then push the rod back until the lever for the throttle disc shaft is all the way back against its stop on the carburetor. Push the lever for the governor fork shaft all the way back also,

and then adjust the shaft pin on the carburetor control rod until the pin is 1/16-inch past the upper hole in the governor arm. Insert the pin in the fork shaft and secure it with washers and a center pin. Lock pin in position with the lock nut. Move the hand throttle control to the idle position and connect the adjusting rod spring to the lower hole in the governor fork shaft, making certain that the adjusting rod plunger is in proper alignment with the lever for the fork shaft. If the plunger is not in alignment, reposition the adjusting rod guide so that the plunger is centered on the lever. Thread the plunger in or out until it contacts the edge of the fork shaft, insuring a positive latching position, and then secure with the lock nut. To check the governed speed, move the throttle linkage to the wide open position, and adjust the jam nuts in the direction necessary to obtain the desired governed speed. Tighten the nuts against each other after obtaining setting.




Fig. 1-14. Governor Linkage

1. Jam nuts
2. Plunger
3. Pivot pin
4. Governor arm

8-17. GASOLINE CARBURETOR. (See figure 1-15). Inspect the linkages for signs of rough edges, paint, or binding. Check all connections for evidence of leaking. If the engine fails to start or does not operate properly, make the following carburetor adjustments.

- a. Screw in the idle adjusting needle (A, figure 1-15) until it just seats, then open the needle 2 full turns.
- b. Make certain the idle speed stop screw (B, figure 1-15) is holding the throttle disc slightly open.
- c. Start the engine and allow it to warm up at an idle speed of approximately 500 rpm.
- d. After the engine has warmed up to normal operating temperature (approximately 190 degrees), release the accelerator pedal and allow the engine to idle.
- e. Adjust the idle speed stop screw to obtain an engine idle speed of 450 to 500 rpm.

f. Turn out the (idle adjusting needle until the engine speed drops from an over-lean gas mixture. Then, turn the needle in until the engine runs smoothly and steadily.




Fig. 1-15. Carburetor

1. Block drains
2. Idle speed stop screw
3. Idle adjusting needle

3-19. LP-GAS SYSTEM.

a. Power adjustment. Set the pointer (not the slot) on the power adjustment screw between 2 and 3. Warm the engine up to normal operating temperature. Turn adjusting screw clockwise to enrich mixture, counterclockwise for leaner mixture.

b. Idle adjustment. Set the idle speed stop screw to obtain an idle speed of 450 to 500 rpm. Set the idle screw for the smoothest idle (approximately three full turns out).




Fig. 1-16. LP-Gas Carburetor

1. Power adjustment
2. Idle speed stop screw
3. Idle adjusting screw

c. FILTER. The filter element needs very little service. Generally speaking, it should be cleaned or changed only if a loss of power is noted which can be traced to no other cause. The element is located in the relief valve assembly. See figure 1-9.

d. LP tank. It is recommended that the tank be removed when the truck is out of service, such as over-night. Store the tank in a safety rack.

3-19. COOLING SYSTEM.

3-20. The cooling system plays an important role in the life and efficiency of an internal combustion engine. Overheating not only causes the engine to knock and lose power, but also results in damage to bearings and other moving parts of the engine.

3-21. Overcooling, although less sudden in effect than overheating, may be equally dangerous to the engine. Low engine temperatures cause the formation of sludge which interferes with proper lubrication. It also creates harmful acids which attack engine parts.

WARNING

Be careful when removing radiator cap when engine is hot. Turn cap slowly until it reaches vent position then allow steam pressure to escape before removing.

3-22. A pressure-type cooling system raises the boiling point of the coolant and permits the engine to operate at higher temperatures without coolant loss. A pressure-type system will not function properly unless it is absolutely airtight, consequently, the system must be kept in good condition. Air in the system will also force coolant out of the overflow pipe, reduce the rate of heat transfer, and accelerate rusting within the system.

3-23. The cooling system has 3 drains - the radiator drain, located at the lower side of the bottom tank; and a drain for each engine block (1, figure 1-15). When ever the system is drained, it should be done at the end of a day's run when any foreign material is in suspension and will be removed with the coolant. To insure complete draining, open all drains and remove the radiator cap.

3-24. The type of coolant used in the radiator (1, figure 3-14) depends on climatic conditions. If there is no danger of freezing, use a solution of clean, soft water and rust inhibitor; however, if the truck will be exposed to freezing temperatures, use a permanent type anti-freeze.

3-25. Avoid the use of water having a high mineral content or containing other impurities. Water containing minerals or other foreign material will form deposits throughout the cooling system. These deposits, in addition to restricting the proper flow of coolant, act as an insulator to prevent the effective




Fig. 1-17, Right Side View

1. Generator
2. Distributor
3. Auxiliary control valve

transfer of heat. Clean rain water and a rust inhibitor is a good coolant solution.

3-26. If the danger of freezing exists, fill the cooling system with a permanent type anti-freeze solution. Follow the recommendation of the anti-freeze manufacturer to obtain a solution that will give the desired protection for the lowest anticipated temperatures. After filling the radiator, run the engine until it reaches normal operating temperature and the thermostat opens. This will establish circulation through the radiator and engine blocks to insure proper mixing of the anti-freeze and water. If the solution is not thoroughly mixed, slush ice may form. Slush ice will stop circulation, causing overheating and subsequent loss of coolant. Another reason for running the engine is to release any air trapped in the engine water jacket by the closed thermostat. When the thermostat opens, the trapped air is released and the water passages fill with coolant. Eliminating trapped air lowers the coolant level of the radiator, and more water must be added to fill it to the proper level.

3-25. As mentioned previously, rust inhibitors should always be used in a radiator to protect it against corrosion. Most high-quality anti-freeze solutions are compounded with a rust inhibitor or corrosion deterrent. Do not add a rust inhibitor to these solutions as the chemical reaction may damage the system. Maintain full strength corrosion protection in the coolant system at all times. Corrosion inhibitors tend to lose their effectiveness with use, and we recommend draining the system and renewing the inhibitor every 6 months. In a system that was clean originally, the appearance of rust in the radiator, or in the solution, is an indication that the inhibitor is weakened or exhausted completely. Whenever the cooling system shows signs of rust, the coolant should be drained, the system flushed, and the radiator refilled with fresh coolant containing an inhibitor.




Fig. 1-18, Left Side View

1. Fuel tank filler cap
2. Air cleaner
3. Fan
4. Torque converter filter

3-25. After the anti-freeze solution is drained in the spring, it is recommended that the cooling system be flushed thoroughly, cleaned if necessary, and a suitable rust inhibitor added to a summer filling of fresh water. In areas where anti-freeze is not required, add rust inhibitor to a fresh filling of water both spring and fall.

NOTE

Flush the system thoroughly before and after the use of anti-freeze solutions.

3-26. Efficient operation of the cooling system requires an occasional cleaning, particularly at seasonal changes when anti-freeze solution is added or drained. The proper method of cleaning depends on the condition of the system. The exterior of the radiator should also




Fig. 1-19, Checking Thermostat

1. Thermostat
2. Thermometer

be cleaned regularly. Dirt, insects, or other foreign material will clog the radiator fins and reduce cooling efficiency. Clean the fins with forced air or water. Straighten any bent fins noticed during the cleaning operation, but be careful not to injure the tubes or break the bond between fins and tubes.

3-30. To check the thermostat, first clean it, and then suspend it in a container of clean water along with a thermometer. Heat the water and check the opening and closing temperatures. If the valve fails to open at 19° or more above the rated opening temperature (180°), or fails to close at 10° to 16° below this temperature, the thermostat should be replaced.

3-31. TIRES. Tires are an integral and expensive part of the lift truck. It is important that they be kept in the best possible condition as follows:

- a. Tires should always be kept inflated to the recommended pressure.
- b. The lift truck should never be driven at high speed over rocky or rough ground.
- c. When the lift truck is not in use, it should be kept out of the sun as much as possible. Sunlight causes surface checking of the tires.
- d. The lift truck should not be parked on oily or greasy floors. Oil and grease deteriorate rubber and shorten tire life.
- e. Tire damage should be repaired immediately. Small breaks or cuts allow dirt and moisture to enter and cause fabric rot.
- f. If the lift truck is to be out of service for any length of time, it should be blocked up to take the weight off the tires. If this is not possible, check the tires regularly and keep them inflated to the recommended pressure.



Fig. 1-20. Engine Timing

1. Timing mark
2. Timing pointer

3-32. ENGINE TIMING. (See figure 1-20). To check the timing, connect a 12-volt timing light to the spark plug for the number 1 cylinder (the one closest to the radiator end of the engine). Set the accelerator to obtain an engine speed of 1750 rpm. Allow the engine to warm up to normal operating temperature. Direct the timing light at the timing pointer (2, figure 1-20) and the crankshaft sheave. As the light flashes, the timing mark (1, figure 1-20) on the sheave should line up with the pointer. If the mark does not line up with the pointer, loosen the distributor lock nuts, and rotate the distributor body to correct the timing. Tighten the lock nuts.

3-33. STORING THE LIFT TRUCK.

3-34. If the lift truck is to be stored for an extended period of time, the following steps should be taken to prevent unnecessary deterioration and to insure top performance when the lift truck is returned to service.

- a. Drain the crankcase, filter, and transmission. Flush the units with kerosene or diesel fuel, install new filters, and refill the units with the specified grade of fresh oil.
- b. Thoroughly lubricate the lift truck, and service the air cleaner and breathers according to the instructions given in this manual. Drive the lift truck for a short distance to distribute the fresh lubricants.
- c. Drain and flush the cooling system. Leave the radiator and block drains open to prevent the collection of condensation.
- d. Drain the gasoline tank, filter, and carburetor. Make certain the system is completely drained as any fuel remaining in the system will oxidize and form gummy deposits. Leave the shut-off valve and the carburetor drain open. Clean the fuel filter. If the truck has an LP-Gas system, close the fuel valve, remove the tank, and store it in a safety rack.
- e. Remove the valve covers and flush the valves, rocker arms, and push rods with heavy oil (SAE 30) to prevent rust.
- f. Remove the spark plugs and pour a liberal amount of engine oil into each cylinder. Turn the engine over several times to distribute a protective oil film on the pistons and cylinder walls.
- g. Remove the battery and store it in a cool, dry place where it will not freeze. Keep the battery fully charged, and maintain the proper electrolyte level. A run-down battery will deteriorate rapidly when stored. If the terminals and the top of the battery appear corroded, clean them with a stiff brush and a solution of baking soda and water. Make certain the vent holes in the filler caps are open.
- h. Drain and flush the hydraulic system. Remove the strainer (4, figure 2-30) from the hydraulic tank and clean. Replace the screen and fill the tank to the specified level in accordance with the lubrication chart.

(figure 1-10). Operate the hydraulic controls for several minutes to distribute the new fluid throughout the system. Contract the cylinders during storage.

i. Thoroughly clean the lift truck. Check for worn or damaged parts, and make any necessary repairs, replacements or adjustments. Touch up any areas where the paint has worn or rubbed off.

j. Block up the lift truck to take the weight off the tires. If the weight is left on the tires, they may take a "set" and become permanently damaged.

k. Store the lift truck in a dry building, however, if it cannot be stored inside, cover it with a tarpaulin.

3-35. TROUBLE SHOOTING.

3-36. Trouble shooting involves taking the proper steps to locate the source of a trouble, and then correcting the trouble. Do not confuse trouble shooting with an engine tune up. In an engine tune up, all parts of the system where the trouble is occurring are checked. For example, in an ignition tune up, the battery, which is the source of electrical energy, is tested first; then the battery cable connections are inspected, etc. This checking and testing is continued in successive steps until each portion of the system that can have an influence on other portions is thoroughly tested and any abnormalities corrected.

3-37. In trouble shooting, the serviceman wishes to locate the part responsible for the trouble by quickly eliminating all other parts. For example, suppose the engine misses (misfires) under a heavy load. In about 85 per cent of the engines with this trouble, it will be found that the

ignition system is at fault. Of course, faulty valve action or an inadequate fuel supply can also cause an engine to miss. However, if the engine had a faulty valve action, the missing would usually be evident at all times instead of occurring only when the engine is under heavy load. An inadequate fuel supply can also be dismissed if the engine does not show a lack of power under a steady pull with an average load.

3-38. The first step in trouble shooting the ignition system is to check the spark output from the ends of the spark plug wires. Check each wire by holding it 1/16-inch away from the engine block while cranking the engine with the ignition switch turned on. If each wire shows a good spark, it indicates that the ignition system from the ends of the spark plug wires back to the battery is satisfactory. Thus, nothing would be gained by checking the distributor, battery, battery cables, ignition switch, etc. By this one test, it has been established that the ignition system is delivering a satisfactory spark to each spark plug. Since the rest of the ignition system has been eliminated, it is logical to assume that faulty spark plugs are responsible for the trouble.

3-39. Trouble shooting can be applied to any part of the lift truck that is not functioning properly and follows the same pattern:

- a. First confirm the suspected condition before proceeding with any tests.
- b. Next determine and recognize the possible causes.
- c. Finally isolate the cause (or causes) by performing a series of quick tests to eliminate the others.

TROUBLES, CAUSE, AND REMEDY

TRouble	POSSIBLE CAUSE	SUGGESTED REMEDY
ENGINE IS HARD TO START OR FAILS TO START	No fuel in carburetor.	Make sure fuel shut-off valve is open. Check fuel lines and filter.
	Water in fuel.	Open carburetor drain to check for water. Drain system and refill with fresh fuel if there is evidence of water.
	Water in cylinders.	Check head gasket.
	Weak spark.	Check ignition system.
	No spark.	Check wiring and connections.
	Incorrect ignition timing.	Check ignition timing.
	Incorrect valve adjustment.	Check valve clearances.
	Restricted air intake.	Clean and service air cleaner.
	Restricted exhaust.	Clear soot and foreign material from exhaust passages.
Poor compression.	Check valves, rings, etc.	

TABLE 1 (CONT.)

TROUBLES, CAUSE, AND REMEDY

TROUBLE	POSSIBLE CAUSE	SUGGESTED REMEDY
ENGINE STARTS, BUT FAILS TO KEEP RUNNING	Insufficient fuel supply.	Check fuel supply at carburetor. Make sure fuel shut-off valve is open. Check fuel lines and filter.
	Faulty wiring or connections.	Check wiring and tighten connections.
	Clogged air channels in fuel cap.	Check by removing cap. If this corrects situation, clean old cap or install new one.
ENGINE RUNS UNEVENLY AND BACKFIRES	Lean fuel mixture.	Adjust carburetor.
	Shorted ignition wires or distributor.	Check wiring and distributor.
	Sticking distributor advance mechanism.	Check distributor advance and clean if sticking.
	Incorrect ignition timing.	Check ignition timing.
	Incorrect valve adjustment.	Check valve clearances.
	Blown cylinder head gasket.	Replace gasket.
ENGINE BACKFIRES, BUT WILL NOT START	Poor compression.	Check valves, rings, etc.
	Moisture on ignition parts.	Wipe all dirt and moisture from coil, spark plugs, spark plug leads, and from interior of distributor cap.
	High-tension wires shorted.	Check wiring.
	Spark plug leads connected to wrong plug positions or distributor cap terminals.	Check spark plug lead connections.
	Sticking distributor advance mechanism.	Check distributor advance and clean if sticking.
ENGINE MISFIRES AT HIGH SPEED	Incorrect ignition timing.	Check ignition timing.
	Spark plug gap too wide.	Check plug gap.
	Weak spring on distributor breaker point.	Alter spring tension or install new points.
	Poor ground connection on condenser.	Tighten condenser ground screw.
	Coil breaks down when hot.	Check coil at operating temperature.
	Sticking valves.	Check valves.
ENGINE MISFIRES UNDER LOAD	Incorrect valve spring tension.	Check spring tension.
	Faulty ignition.	Check ignition system.
	Faulty spark plugs.	Check plugs, clean and gap.
	Faulty carburetor.	Clean carburetor and check float level.

TABLE 1 (CONT)

TROUBLES, CAUSE, AND REMEDY

TROUBLE	POSSIBLE CAUSE	SUGGESTED REMEDY
ENGINE MISFIRES UNDER LOAD (CONT)	Engine overheating or pre-ignition.	Check cooling system, ignition timing, and spark plugs. Remove carbon deposits in combustion chambers.
	Incorrect valve adjustment or faulty valves.	Check valves.
	Poor compression.	Check valves, rings, etc.
	Faulty valve action.	Check valves.
	Faulty spark plugs.	Clean and gap, or replace plugs.
	Low coil output.	Test for satisfactory spark at end of each spark plug lead.
	Incorrect ignition timing.	Check ignition timing.
	Sticking distributor advance mechanism.	Check distributor advance and clean if sticking.
HIGH FUEL CONSUMPTION	Leak in fuel system.	Check fuel lines and connections.
	Incorrect carburetor adjustments.	Clean and adjust carburetor. Check for proper float level.
	Restricted air intake.	Check for high oil level in air cleaner cup. Clean and service air cleaner.
	Improper oil viscosity.	Drain crankcase and fill with oil of recommended viscosity.
	Dragging brakes.	Adjust free pedal travel.
	Faulty spark plugs.	Clean and gap, or replace plugs.
	Sticking distributor advance mechanism.	Check distributor advance and clean if sticking.
	Incorrect ignition timing.	Check ignition timing.
	Engine not operating at correct temperature.	Check cooling system.
	Incorrect valve adjustment or sticking valves.	Check valve action.
	Worn valves, guides, rings, cylinders, etc.	Overhaul engine.
	Engine lugging.	Shift to low range.
	Excessive engine speed.	Adjust governor.
ENGINE LACKS POWER	Carburetor throttle disc does not open fully.	Check throttle linkage and throttle shaft.

TABLE 1 (CONT)

TROUBLES, CAUSE, AND REMEDY

TROUBLE	POSSIBLE CAUSE	SUGGESTED REMEDY
ENGINE LACKS POWER (CONT)	Restricted exhaust.	Clean soot and foreign material from exhaust passages.
	Dragging brakes.	Adjust brakes.
	Improper oil viscosity.	Drain crankcase and fill with oil of recommended viscosity.
	Faulty governor action.	Check linkage. Adjust governor to obtain recommended rpm.
	Incorrect carburetor adjustments.	Clean and adjust carburetor. Check for proper float level.
	Poor-quality fuel.	Drain fuel system and refill with fresh fuel.
	Restricted air intake.	Check for high oil level in air cleaner cup. Clean and service air cleaner.
ENGINE OVERHEATS	Low coolant level.	Add coolant and check for leaks.
	Clogged cooling system.	Clean and flush system.
	Clogged radiator fins.	Clean with forced air or water.
	Faulty thermostat.	Replace thermostat.
	Faulty water pump.	Repair or replace pump.
	Slipping fan belt.	Tighten or replace belt.
	Fuel mixture too lean.	Clean and adjust carburetor. Tighten all connections.
	Sticking distributor advance mechanism.	Check distributor advance and clean if sticking.
	Incorrect ignition timing.	Check ignition timing.
	Pre-ignition.	Check ignition timing and spark plugs. Remove carbon deposits in combustion chambers.
HIGH OIL CONSUMPTION	Improper oil viscosity.	Drain crankcase and fill with oil of recommended viscosity.
	Oil pressure too high.	Adjust oil pressure regulator screw to obtain recommended pressure.
	Oil leaks.	Check seals, gaskets, connections, etc.
	Clogged crankcase breather.	Clean breather element.
	Engine overheating.	Check timing and cooling system.
	Worn or scored pistons, pins, rings, bearings, valve guides, etc.	Overhaul engine.

TABLE 1 (CONT)

TROUBLE, CAUSE, AND REMEDY

TROUBLE	POSSIBLE CAUSE	SUGGESTED REMEDY
HIGH OR LOW OIL PRESSURE	Plugged or leaking oil lines.	Clean, tighten, or replace lines.
	Dirty intake screen on oil pump.	Clean screen.
	Worn oil pump.	Repair or replace pump.
	Worn bearings.	Replace bearings.
	Improper oil viscosity or crankcase dilution.	Drain crankcase and fill with oil of recommended viscosity.
	Incorrect setting of oil pressure regulator screw.	Adjust regulator screw to obtain recommended pressure.
	Faulty oil pressure gage.	Check accuracy of gage by disconnecting oil line just above filter housing and connecting test gage.
SLIPPAGE IN DRIVE SYSTEM	Faulty clutch.	Repair or replace clutch.
	Faulty pump.	Replace faulty component.
	Low oil level.	Fill to correct level.
	Defective torque converter.	Replace converter.
LIFT TRUCK OPERATES IN ONE DIRECTION BUT NOT IN THE OTHER	Defective clutch.	Repair or replace clutch.
DRIVE SYSTEM NOISY	Low oil level.	Fill to proper level.
	Worn or broken gear or shaft.	Replace faulty component.
SYSTEM WILL NOT LIFT, LIFTS TOO SLOWLY, OR STICKS WHEN LOWERING	Leak in system.	Tighten loose connections. Replace damaged component.
	Defective control valve.	Replace valve.
	Defective hydraulic pump.	Repair or replace pump.
	Defective lift cylinder.	Repair or replace cylinder.
	Dirty plunger assembly.	Clear exposed surface of plunger.
	Low hydraulic pressure.	See "LOW HYDRAULIC PRESSURE" below.
LOW HYDRAULIC PRESSURE	Defective pump.	Repair or replace pump.
	Leak in system.	Tighten loose connections. Replace faulty components.
	Defective valve.	Replace valve.

TABLE I (CONT.)

TROUBLES, CAUSE, AND REMEDY

TROUBLE	POSSIBLE CAUSE	SUGGESTED REMEDY
EXCESSIVE HYDRAULIC PRESSURE	Defective valve.	Replace valve.
SYSTEM LIFTS, BUT WILL NOT LOWER LOAD	Defective valve.	Replace valve.
EXCESSIVE NOISE OR HAMMERING.	Defective pump.	Repair or replace pump.
	Air in system.	Purge system.
SERVICE BRAKES NOT EFFECTIVE	Worn brake lining.	Adjust brakes or replace linings.
	Inefficient brake fluid.	Add fluid as specified in lubrication chart.
	Broken or loose line.	Tighten connection or replace defective line.
	Faulty brake cylinder.	Repair or replace cylinder.
SPONGY BRAKE ACTION	Air in system.	Bleed system.
BRAKES DO NOT RELEASE	Incorrect brake adjustment.	Adjust brakes.
BRAKES GRAB	Dirt in brake drum.	Clean and adjust brakes.
	Defective lining.	Replace linings.
	Scored brake drum.	Turn down or replace drum.
	Brake fluid on lining.	Replace linings.

CHAPTER 4

OVERHAUL (SHOP MAINTENANCE)

Section I. General

4-1. GENERAL.

4-2. This chapter consists of instructions relating to the removal, disassembly, repair, and reassembly of the components involved in the lift truck.

4-3. No special tools are required to overhaul the equipment. Tools and testing devices required are those commonly employed at a shop having overhaul facilities. Assuming that only skilled automotive mechanics will perform the procedures described in this manual, obvious and elementary instructions have been purposely omitted.

4-4. An attempt has been made, wherever possible, to treat the assemblies in their logical order of accessibility sequence. For complete disassembly, refer to the Table of Contents, locate the assembly desired and note its page number. Repeat for each assembly.

4-5. Unless otherwise indicated, all bolts should be torqued to the following values:

1/4 inch8 to 10 foot pounds
5/16 inch15 to 18 foot pounds
3/8 inch30 to 35 foot pounds
7/16 inch50 to 55 foot pounds
1/2 inch75 to 85 foot pounds
9/16 inch115 to 125 foot pounds
5/8 inch155 to 170 foot pounds
3/4 inch270 to 300 foot pounds

Section II. Removal, Disassembly, Repair, and Reassembly

4-6. EQUIPMENT OVERHAUL.

4-7. BATTERY, CLAMP, AND CABLES.

4-8. REMOVAL. (See figure 2-16.) Removal and disassembly is accomplished at the same time as follows:

- a. Prop left side of hood open with support rod.
- b. Lift battery and box and wiring assembly out. Remove cables and hold down assembly. Remove battery from box.
- c. Remove pivot pin (24, figure 2-16) and remove box.

4-9. DISASSEMBLY. Disassembly is completed with removal of parts.

4-10. REPAIR.

a. Clean battery and other parts with stiff brush and baking soda and water solution. When foaming stops, flush battery with clean water. Use care not to get solution into vent holes.

b. Inspect battery and test. Inspect battery cables, and other parts. Replace battery if damaged or test indicates poor condition. Replace all parts severely damaged or corroded beyond repair. Replace badly deteriorated cables.

4-11. REASSEMBLY. (See figure 2-16.) Reassembly is accomplished in the reverse order of disassembly.

4-12. GASOLINE FUEL TANK, LINES, AND FITTINGS. (See figure 2-21.) The tank is an integral part of the lift truck frame and cannot be retrieved.

4-13. DISASSEMBLY. (See figure 2-11.) Disassembly is completed by removing the shut-off valve (1), filler assembly (4), fuel gage sending unit (14), and drain plug.

4-14. REPAIR.

- a. Clean parts and flush tank with solvent.
- b. Inspect parts and tank.
- c. Discard defective or damaged parts and replace with new parts.

4-15. REASSEMBLY. Reassemble in reverse order of disassembly.

4-16. SEAT.

4-17. REMOVAL. (See figure 2-29.) Remove seat from frame. Remove frame from hood.

4-18. DISASSEMBLY. Unscrew sheet metal screws holding back rest to frame.

4-19. REPAIR.

- a. Discard bent frame, worn cushion and back rest.

4-20. REASSEMBLY. (See figure 2-29.) Reassemble in the reverse order of disassembly.

4-21. WORN BUTTON.

4-22. REMOVAL. (See figure 2-26.) Removal and disassembly are accomplished at the same time as follows:

- a. Disconnect battery ground wire. Disconnect horn button wire at horn relay.
- b. Press and turn horn cover (36) to release button (37), contact cup (38), horn button spring (39), and contact cap (40).
- c. Remove screws holding base plate (44) and pull wire, plate, and parts out of steering column.

4-23. DISASSEMBLY. Disassembly has been accomplished with completion of removal steps.

4-24. REPAIR.

- a. Clean and inspect parts. Check wire and insulating ferrule. Replace if damaged or defective. Check horn button spring compression. Spring must prevent button from making contact unless pressed.

4-25. REASSEMBLY. (see figure 2-26.) Reassemble in reverse order of disassembly.

4-26. STEERING GEAR AND DRAG LINK.

4-27. REMOVAL (see figure 2-26 or 2-26A.)

- a. Disconnect the accelerator pedal and linkage and remove the front section of the floor plate.
- b. Drive out the roll pin through the hand lever arm (28, figure 2-20) at the lower end of the control lever shaft. Loosen the hand lever clamp (37, figure 2-20) at the lower end of the shaft tube.
- c. Remove the horn button assembly (paragraph 4-22) and remove the steering wheel.
- d. Loosen the clamps (38, figure 2-20). Remove the hand lever control shaft and tube.
- e. Remove the steering arm (24, figure 2-26) from the shaft (27).
- f. Remove the steering gear (1) attaching bolts and the steering post clamp. Remove the entire steering gear assembly.
- g. Remove the rear end of the drag link (26) from the hydraulic steering booster.

4-28. DISASSEMBLY. (see figure 2-26 or 2-26A.)

- a. Remove side cover (20). Press cross shaft (17) out of housing. Remove bushings (3) and oil seal (2).
- b. Loosen clamp (14) and remove bolts holding upper cover (10) to housing. Remove cam and tube assembly (5). Use care not to lose any steel balls (7), when retaining ring (8) is removed.
- c. Remove all parts enclosed in jacket tube (10).

- d. Unscrew roller plug (31) enough to remove front end of drag link from steering arm. To further disassemble drag link, unscrew plug completely. Pull remaining parts from socket on drag link.

4-29. REPAIR.

- a. Discard oil seals which show signs of leakage.
- b. Discard bearings which show excessive wear.
- c. Discard bent steering tube or steering linkage, or other damaged components.

4-30. REASSEMBLY. (See figure 2-26 or 2-26A.) Reassemble in reverse order of disassembly.

- a. Replace all gaskets and oil seals.
- b. Clean all parts in solvent.
- c. Use just enough shim (16) to obtain a slight drag when steering shaft is turned, before cross shaft is installed.
- d. Install cross shaft at center of its travel, and install steering arm centered between stops. See figure 1-21.
- e. To adjust cross shaft end play, turn adjusting screw (21) in tight, then back off 1/4 turn.
- f. Adjust stop bolts (1, figure 1-21) to stop steering arm in each direction, before stops on steering axle make contact.




Fig. 1-21. Steering Arm and Stops

1. Stop bolts
2. Steering arm

4-31. HEAD AND REAR LAMPS. (OPTIONAL.)

4-32. REMOVAL (see figure 2-16.)

- a. Disconnect battery ground wire.

b. Disconnect lead wires to lamps and remove lamps.

4-33. DISASSEMBLY. (see figure 2-16.)

a. Remove front head lamp molding screw and molding (13). Pull sealed beam unit out of lamp head.

b. Remove lens retainer (20) and remove lens (18).

4-34. REPAIR. Inspect and replace all defective parts.

4-35. REASSEMBLY. (see figure 2-16.) Reassemble in reverse order of disassembly.

4-36. INSTRUMENT PANEL, SWITCHES, AND GAGES.

4-37. REMOVAL. (see figure 2-17.)

a. Remove the clamp holding the steering post to the instrument panel.

b. Disconnect battery ground wire.

c. Remove bolts holding instrument panel (1) to front shroud. Lift out panel.

d. Disconnect wires from instruments.

4-38. DISASSEMBLY. (see figure 2-17.) Disassembly is complete upon removing switches and gages from the instrument panel.

4-39. REPAIR. Repair is limited to checking condition and performance of switches, gages, and components. Inspect wiring for broken connections, corrosion, and damaged insulation. Discard all defective parts and replace with new parts.

4-40. REASSEMBLY. (see figure 2-17.)

a. Install gages and switches on instrument panel.





Fig. 1-29. Sheet 1 of 2

- 7. To stop light wire - orange
- 8. To tail light wire - black
- 9. To "B" terminal on regulator - orange and black
- 10. To water temperature indicator - yellow
- 11. To negative terminal on stop light switch - orange
- 12. To positive terminal on stop light switch - orange
- 13. To warning light indicator - natural white
- 14. To horn relay - red
- 15. To neutral starting switch
- 16. To coil - purple
- 17. To battery terminal on starter - red
- 18. To oil pressure indicator - black

- 19. To fuel gage indicator - dark green
- 20. To starter solenoid - brown
- 21. To head light wire - black
- 22. Capacitor
- 23. Ignition switch
- 24. Starter switch
- 25. Ammeter
- 26. Fuel gage
- 27. Hour meter
- 28. Oil pressure gage
- 29. Temperature gage
- 30. Warning light
- 31. Light switch
- 32. Fuse



4-41. RADIATOR, HOSES AND THERMOSTAT.

4-42. REMOVAL. (see figure 2-14.)

- a. Remove radiator cap and open radiator drain valve and block drains (2, figure 1-16).
- b. Remove cooling fan (15, figure 2-12.)
- c. Disconnect clamps and remove upper and lower hoses. Thermostat (1E) is located in upper hose.
- d. Remove 4 radiator mounting bolts.

4-43. DISASSEMBLY. (see figure 2-14.)

- a. Remove radiator drain valve.

4-44. REPAIR.

- a. Inspect radiator, thermostat, and hoses. Test thermostat as outlined in Chapter 9. Discard defective radiator and hoses. Repair minor ruptures in radiator if accessible. Discard radiator if damage is excessive.

4-45. REASSEMBLY. (see figure 2-14.)

- a. Install drain valve and attach radiator to mounting.
- b. Attach hoses and thermostat, using proper clamps as in figure 2-14. Tighten clamps securely.
- c. Close radiator drain valve. Refill radiator as described in Chapter 3. Check connections for leaks.

4-46. MUFFLER.

4-47. REMOVAL. (see figure 2-5). Removal and disassembly is complete upon disconnecting all clamps.

4-48. REPAIR.

- a. Inspect and discard all parts that show excessive rust and deterioration. Replace with new parts.

4-49. REASSEMBLY. (see figure 2-5). Reassemble in reverse order of disassembly.

- a. Lubricate threads on bolts, clamps, and connecting surface of muffler and pipe.
- b. Align muffler and pipe so they cannot contact other parts of lift truck. Tighten nuts and bolts securely.

4-50. THROTTLE CONTROLS.

4-51. REMOVAL. (see figure 2-9.) Disassembly of throttle control linkage is accomplished as follows:

- a. Disconnect spring (6).
- b. Remove cotter pins and linkage.

- c. Remove front section of floor plate (5, figure 2-28).

- d. Remove cross shaft (2) and pedal (1).

4-52. DISASSEMBLY. Disassembly is accomplished when throttle controls are removed.

4-53. REPAIR.

- a. Clean parts in solvent and inspect.
- b. Replace parts with excessive wear.

4-54. REASSEMBLY. (see figure 2-9.) Reassemble in reverse order of disassembly.

- a. Lubricate control rod ends and cross shaft where it moves in support and foot pedal hinge. Install front section of floor plate.

- b. Use new cotter pins.

4-55. WATER PUMP AND FAN ASSEMBLY.

4-56. REMOVAL. (see figure 2-12.)

- a. Drain cooling system. Loosen fan belt and remove fan and water pump assembly. Remove tube from engine block.

4-57. DISASSEMBLY. (see figure 2-12.)

- a. Remove fan (15) from hub (8).
- b. Press fan hub off shaft, remove pulley (7).
- c. Remove lock spring (4) and press at fan hub end to remove shaft and bearing assembly from the housing.
- d. Remove impeller (6), seal (5), and slinger ring (3) from shaft.

4-58. REPAIR.

- a. Clean parts and inspect. Discard excessively worn parts and replace with corresponding new part. Replace "O" ring seals on tube.

4-59. REASSEMBLY. (see figure 2-12.)

- a. Press seal into housing, using suitable tool, or piece of pipe, that contacts only the seal flange, NOT the carbon ring.
- b. Slip oil slinger on shaft and insert shaft in housing from fan hub end. Align grooves in bearing and housing and install the lock wire.
- c. Press impeller on shaft with .006 inch clearance between impeller and housing.
- d. Press pulley and fan hub on shaft until end of shaft extends out of hub 21/32 inch.

c. Insert tube with new "O" rings into engine block and install water pump assembly.

1. Refill cooling system as described in Chapter 3.

4-20. GENERATOR. (See figure 3-16.)

4-21. REMOVAL.

- Disconnect battery ground wire and generator to voltage regulator wires.
- Remove drive belt tension adjustment nut screw at top of generator and remove belt.
- Remove generator from mounting bracket.

4-22. DISASSEMBLY.

- Remove generator brush cover head nut and screws. Remove cover head.
- Remove the two top bolts and lockwashers.
- Tap off commutator end frame assembly. Tap off the drive end frame assembly and slide armature out of field frame. Remove nut, washer and pull off drive pulley. Remove drive end frame and components. Remove the three screws and lockwashers holding the ball bearing and retainer parts.
- Remove the screws securing the brush leads and remove screws holding the ground and insulated brush parts.
- Remove the arm terminal stud nut, washers and stud. Remove the terminal to brush stud nut, washer, and stud.
- Remove the two screws holding the pole shoes, insulation and field coils.

4-23. REPAIR.

- Clean the field coils with a cloth dampened with an approved cleaning solvent. Do not soak in solvent. Dry the assembly with clean, dry, compressed air, taking care not to damage insulation or leads.
- Blow all loose dirt from the armature assembly with clean, dry, compressed air. Wipe off with a cloth dampened with an approved cleaning solvent; dry thoroughly. Sand the commutator with a No. 60 flat paper. Clean out dirt from the commutator bars, but do not damage or scratch the bars or the mica.
- Clean the brush arm with a cloth dampened with an approved cleaning solvent; dry thoroughly.
- Clean the cover head, the commutator end cover, the rim bolts, the drive end cover, and the bearing retainer plate, and all nuts, bolts, screws, and lockwashers with an approved cleaning solvent.

c. Clean and inspect the ball bearings.

1. Inspect the field coils for worn or frayed insulation, broken leads, loose or corroded terminals, or other damage. Replace if damaged.

g. Using a test probe set consisting of a lamp in series with two test points and connected to a 210-volt lighting circuit, check the field coils and pole pieces in the field frame. Secure with two pole screws.

h. Position the field coils, insulation and pole pieces in the field frame, secure with the two pole screws.

i. Check for grounds by touching one test probe to the field lead and the other probe to the frame. If the lamp lights, the field coils are grounded. Replace a grounded field assembly.

j. Touch the probes to the two leads of each coil. If the lamp fails to light, the coil is open. Replace the field assembly if any coil is open.

k. Inspect the armature assembly to make sure all windings are properly pressed into the coil slots and are properly soldered to the commutator bars. Replace the armature if windings are loose or unsoldered at the commutator.

1. Inspect the armature size for wear. Replace the armature assembly if worn or scored.

m. Inspect the commutator for wear, roughness, and out-of-round; place the armature in V-blocks and check the concentricity of the commutator with a dial indicator. If the commutator is rough, or worn, or if concentricity is greater than 0.001 inch, turn down.

n. Inspect the bearing seats on the armature shaft, or place the armature assembly if seat wear is evident.

o. Check the armature for grounds, open circuits, and shorts as follows: Check for grounds by touching one end of the probes of the test set to the shaft or core and the other probe to each of the commutator bars in turn. Do not touch probes to brush or bearing surfaces. If the lamp lights, the armature is grounded and must be replaced.

p. Check for an open armature circuit by touching the probes to the stem on a pair of adjacent commutator bars. If the lamp does not light the circuit is open. Repeat this test on each pair of adjacent commutator bars. Replace an open armature.

q. Test for a shorted armature by placing the armature on a growler and holding a thin strip of steel above the core. Turn the armature slowly. If the armature is shorted, the armature will set up a magnetic field, causing the steel strip to vibrate. If the armature is shorted, inspect the commutator bars and risers for copper chips or solder that may be shorting between bars. If the short cannot be located and corrected, re-

Place the armature.

z. Inspect the commutator end head and drive end head for cracks, distortion, or other damage; replace if damaged.

5. Inspect the brushes for wear, oil saturation, chips or other damage; replace if damaged or worn to less than 3/8 inch.

6. Inspect the cover band for fit on the generator frame, cracks, and other damage; replace the band if it cannot be straightened out to provide a snug fit, or if it is otherwise damaged.

u. Inspect all parts for wear, cracks, breaks, distortion or other damage; replace damaged parts.

4-64. REASSEMBLY.

a. Install the arm terminal stud, washers and nut in proper sequence with field coil lead attached.

b. Insert the terminal to brush stud, washers and nut in proper sequence with field coil lead attached.

c. Install ground and insulator brush packages.

d. Place the assembled commutator frame end on the assembled armature. Reassemble the felt washer, washer retainer, ball bearing, space washer, gasket and bearing retainer plate to drive end frame and secure with screws and lockwashers.

e. Assemble the commutator end frame, armature, field frame and drive end frame. Secure with thru bolts and washers.

f. Insert brushes and attach brush leads. Check brush seating.

g. Install cover band and secure with nut and screw.

h. Slip space collar over shaft and insert Woodruff key. Install drive pulley and secure with lockwasher and nut.

i. Install generator on engine and attach drive belt.

j. Connect battery ground wires.

k. Polarize generator by momentarily connecting jumper wire from "B" terminal of regulator to "A" terminal of generator.

4-65. STARTING MOTOR.

4-66. REMOVAL. (See figure 2-16.) Removal is accomplished by disconnecting battery ground wire and wires to magnetic switch. Remove lock nut and set screws from flywheel housing. Starter motor pulls out.

4-67. DISASSEMBLY. (See figure 2-16.) Disassembly

is similar to paragraph 4-62, "GENERATOR".

a. Remove magnetic switch, brush cover band and thru bolts with washers.

b. Remove brush lead screws and brushes. Tap commutator end cover and remove. Tap drive housing and remove. Slide armature out of field housing from drive end.

c. Remove screws and lockwashers on brush ground leads. Remove brush attaching screws, holders, springs and brushes. Remove brush jumper lead screw, lockwasher and lead. Remove terminal stud nut, washers and terminal stud.

d. Remove pole shoe screws, field coils and pole shoes.

e. Remove motor drive dowel pin and motor drive.

4-68. REPAIR.

a. Cleaning and inspection of starting motor parts is the same as cleaning and inspection of "GENERATOR". Refer to paragraph 4-63a through paragraph 4-65a.

b. Inspect the brushes for wear, oil soaked condition, or other damage. If the brushes are damaged or worn to less than 3/16 inch, discard them and replace with new ones.

c. Test the insulated brush holder-hinge pins on commutator end frame assembly for grounds by touching one probe of a test set to each of the hinge pins. Touch the other test probe to ground on the commutator end frame assembly. Replace the commutator end frame assembly if any of the pins are grounded.

d. Reassemble brush holders and springs to commutator and springs to commutator end frame. Place the armature in a padded vise and install the commutator end space washer and the commutator end frame assembly on the armature shaft. Install a grounded brush or a scrape brush in the brush holder. Replace the commutator end frame assembly if the brush does not slide freely in the holder, or if the brush edge are not in perfect alignment with the commutator segments.

e. Check the brush spring tension. If the brush spring tension is not within the proper limits, replace the brush spring.

f. Feel for side play of the commutator end frame assembly on the armature shaft. Replace the commutator end frame assembly if side play can be felt.

g. Inspect the motor drive for broken springs, cracked screws, broken lockwashers, broken pinion teeth, or other damage. Discard motor drive and replace if needed.

h. Check center bearing plate bushing fit on armature shaft. Replace bushing with new one if too loose.

3. Check motor drive fit on articulation shaft. Replace motor drive if too loose.

4-69. REASSEMBLY. (see figure 2-16.)

a. Apply a light coat of oil to the armature shaft bearing surfaces. Remove all excess oil, making sure oil does not reach commutator, brushes, field and frame assembly, or armature.

b. Install the spacer washer on the end of the shaft, slide the commutator end frame and pin assembly on the shaft, replace the contact bearing plate.

c. Insert the assembled motor drive and spacer washer into the drive housing.

d. Position the assembled drive housing over the assembled armature and frame assembly, secure to the commutator end frame and pin assembly with the two thru bolts and lockwashers.

e. Check the end play in the end of the drive housing by mounting a dial indicator on the cranking motor with the plunger against the end of the armature shaft. Move the armature to its two extreme positions and read the dial indicator reading. End play must be between 0.003 inch and 0.062 inch. If end play is excessive, install additional spacer washers.

f. Seat the brushes to the commutator by wrapping a strip of No. 00 sandpaper around the commutator and turning the armature slowly in the direction of rotation (clockwise as viewed from the drive end). Allow one brush at a time to contact the sandpaper until the surface assumes the curvature of the commutator. A few rotations will be sufficient to seat each brush. Blow all dust and sand from the cranking motor with clean, dry, compressed air.

g. Install the cover band and clamp securely with the cover band screw and nut. Attach magnetic switch.

h. Align upper hole in starting motor drive housing with lock bolt hole. Install lock nut and bolt engaging top hole in starting motor drive housing. Draw bolt up snug and tighten lock nut.

i. Connect wires to magnetic switch.

4-70. DISTRIBUTOR.

4-71. REMOVAL. (see figure 2-15.)

a. Disconnect battery ground wire. Disconnect high tension lead wire and low tension lead. Disconnect spark plug wires.

b. Remove distributor cap. Note position of rotor and mark distributor housing with spot of bluing so cap can be re-installed with rotor in same position on reassembly. Remove distributor hold down clamp screws, washers and clamps. Withdraw distributor from crankcase.

4-72. DISASSEMBLY. (see figure 2-15.)

a. Lift rotor from shaft and remove housing cover. Remove screws holding condenser and breaker points, remove nuts, washers, bushing and terminal stud. Remove screws, lockwashers, securing spring clips and breaker plate.

b. Drive out coupling to shaft pin and pull coupling from shaft. Remove spacer and shim washers. Pull distributor shaft assembly and weight plate from housing.

c. Remove nuts and lockwashers securing weight hold down plate. Remove weight springs and hold down plate. Remove cam and weights.

4-73. REPAIR.

a. Clean parts in solvent and dry carefully.

b. Inspect all parts for excessive wear, corrosion or deterioration. Replace defective parts with new ones, particularly the points, condenser, rotor or distributor cap.

4-74. REASSEMBLY. (see figure 2-15.) Reassemble distributor in the reverse order of disassembly.

a. Assemble cam and weights to distributor shaft and weight plate.

b. Slide spacer washer under weight plate and insert shaft in distributor housing. Align breaker plate with distributor housing. Install breaker plate, spring clips, spring support, and locator in breaker housing. Secure with screws and lockwashers.

c. Install terminal stud, inside bushing, outside washer and nut. Attach condenser and breaker points. Attach breaker spring to terminal stud and secure with nut.

d. Slide coupling spacer washer and shim on to bottom end of distributor shaft. Align coupling with hole in shaft and press coupling on to shaft. Insert pin. Check end play in shaft. There should be .003 clearance between coupling and end of housing. Use other shims if needed.

e. Install housing cover and rotor.

f. Assemble distributor to crankcase, aligning coupling with mating gear so rotor returns to approximate spot marked on housing. Attach clamps, distributor cap and all wires in proper order.

g. Adjust point gap to .018 inch, with breaker lever on high point of cam lobe. Retune ignition according to paragraph 3-32, in Chapter 3.

4-75. VOLTAGE REGULATOR. (See figure 2-15.)

4-76. REMOVAL. Disconnect wires and remove regulator from mounting bracket.

4-77. DISASSEMBLY,

- a. Remove cover and gasket.

5. It is advisable to make the tests and adjustments listed in paragraph 4-76, before completely disassembling the regulator, and then remove only the faulty components.

4-78. REPAIR,

- a. Mechanical checks and adjustments (air gaps, point opening) must be made with battery disconnected and regulate preferably off the lift truck.

CAUTION

The current relay contact points must never be closed by hand with the battery connected to the regulator. This would cause a high current to flow through the units and would seriously damage them.

- b. Electrical settings must be checked and adjusted with the regulator mounted in the operating position and at operating temperature. Run the engine for at least 15 minutes, with no electrical load other than ignition, to reach operating temperature.

- c. The engine must be operated at governed speed, and generator voltage must be kept high enough to insure sufficient current output, for testing and adjusting.

- d. After any tests or adjustments, the generator must be polarized after the leads are connected, but before the engine is started, as follows: Momentarily connect a jumper between the "GEN" and "BAT" terminals of the regulator. This allows a momentary surge of current through the generator, thus correctly polarizing it. Failure to do this may result in severe damage due to vibration, arcing, and burning of the relay contact points.

- e. Use a spoon or ratchet file to clean the contact points. Never use emery cloth or sandpaper to clean the points. File very lightly to avoid excessive loss of metal. Replace badly worn or damaged components.

- f. Adjust air gap of voltage regulator and current regulator to .075 inch. Press down on armature and adjust air gap by means of the knurled nuts.

- g. Adjust air gap of output relay to .020 inch. Press down on armature until points just close, then raise or lower armature as required by loosening two screws in back of relay. Tighten screws after adjustment. Adjust relay point opening to .020 inch by bending upper armature stop.

- h. Voltage regulator setting - connect 1/4 ohm fixed resistor (not less than 25 watts) at "BAT" terminal of regulator in series with battery. Connect voltmeter from "BAT" terminal to ground. Operate engine at governed speed and operating temperature. Adjust voltage regulator closing voltage to 13.8 to 14.8 volts,

by means of adjusting screw.

- i. Current regulator setting - connect ammeter from "BAT" terminal in series with battery. Place load across battery about equal to current regulator setting (load may be a carbon pile or bank of lights). Operate engine at governed speed and normal operating temperature. Adjust current regulator setting between 18.5 and 21.5 amperes, with adjusting screw.

- j. Output relay setting - connect voltmeter between "GEN" terminal and ground. Operate engine at governed speed and normal operating temperature. Adjust closing voltage to 11.8 to 13.3 volts, with adjusting screw.

4-79. REASSEMBLY.

Reassemble in reverse order of disassembly.

4-80. WHEELS,

4-81. REMOVAL. (see figure 2-26.)

- a. Jack up lift truck. Remove wheel center bolts (9) and remove drive wheel and tire assembly.

- b. Remove wheel and tire assembly from steer axle nut (1).

4-82. DISASSEMBLY. (see figure 2-26.)

WARNING

DEFLATE TIRES BEFORE DISASSEMBLY OF FRONT OR REAR WHEELS.

- a. Separate inner half (9) and outer half (6) of rear wheels.

- b. Remove retaining ring (13A). This ring is used with single drive wheels only. Remove nuts from studs (12). Remove clamps (11).

- c. Remove spacer. The spacer is used only on trucks with dual drive wheels.

4-83. REPAIR,

- a. Discard damaged components.

4-84. REASSEMBLY. (see figure 2-26.)

Reassemble in reverse order of disassembly.

- a. Inflate rear tires to 90 pounds. Inflate front tires to 85 pounds.

4-85. STEERING AXLE (MY 50),

4-86. REMOVAL. (see figure 2-21.)

- a. Jack up rear of lift truck. Disconnect rear station of drag link from steering housing (11).

b. Remove bolts from front and rear pivot bearings (8). Roll axle assembly out from under lift truck.

4-87. DISASSEMBLY. (See figure 2-21.)

- a. Remove wheels and tires as explained in paragraph 4-81.
- b. Remove bearings (3) and bushings (9) from shaft (13). Remove lock screw and remove shaft from axle (-).
- c. Remove tie rod assembly (16, 17, 18, and 15).
- d. Remove expansion plugs. Remove lock screw from spindles (3 and 4), and remove plug (5). Remove thrust bearings (8) and needle bearings (2).
- e. Remove the slotted nut and lock pin (13) from pin (12). Remove bearing cups (15) and cones (14).

4-88. REPAIR. (See figure 2-21.) Replace any worn or damaged parts, especially bushings, bearings, and seals.

4-88. REASSEMBLY. (See figure 2-21.) Reassemble in reverse order of disassembly.

- a. Apply Loctite sealant, type "A", or equal to pin (12) before installing bearings.
- b. Adjust pre-load on bearings (14) to 25 to 40 inch pounds, by means of slotted nut. Secure nut with center key through the nearest slot.
- c. If the entire steering axle has been disassembled, the steering system must be reset. Place the rear wheels and steering housing in neutral (straight-ahead steering condition).
- d. Close the hydraulic steering booster completely and then extend the rod 8 inches.
- e. Adjust the rear section of drag link and the tie rods to fit without moving the steering housing from the straight-ahead position.
- f. Adjust stop bolts (1, figure 1-21) to allow 71 degree angle of inside wheel with frame (inside wheel in relation to direction of turn). Adjust stops against arm for both directions. Secure stop bolts with the jam nuts.
- g. Adjust stop bolts (1A, figure 2-21) on axle to 1/16 inch clearance from arm on spindle when steering arm (2, figure 1-21) is against stop bolt. Adjust stops for both directions. Secure stop bolts with jam nuts. The axle stops must not contact the spindle arm before the steering arm contacts its stops. The axle stops are designed to prevent damage to the system if the wheels deflect when they hit an obstruction.
- h. Make any minor adjustments on tie rods or rear section of drag link as necessary.

4-89. STIFFING AXLE (MY 80)

4-89. REMOVAL. (See figure 2-21A.)

- a. Jack up rear of lift truck.
- b. Remove rear end of drag link from center steering arm (15).
- c. Remove bolts from axle support shafts (41). Roll entire axle assembly away from lift truck.

4-92. DISASSEMBLY. (See figure 2-21A.)

- a. Remove wheels and tires as explained in paragraph 4-81.
- b. Remove hub cap (19). Remove center key and spindle bearing nut (20). Pull hub assembly (21) from steering knuckle (7, 8).
- c. Remove seal (20), cones (24 and 25), and cups (12 and 23) from hub.
- d. Remove nuts (26) and remove tie rod assembly. Loosen tie rod clamp (25) and remove tie rod ends (22 and 21) from sleeve (27).
- e. Remove draw bar (12), drive out pin (14) and plug (17). Remove bearings (3 and 9).
- f. Remove grease cap (16) and nut (10). Pull steering arm assembly (15) off shaft (2). Remove cones (13), cups (20), seal (21), and cups (23).

4-90. REPAIR. (See figure 2-21A.)

- a. Replace any worn or damaged parts, especially bushings and bearings.
- b. Replace seals (21 and 26).
- c. Replace tie rod end covers (24) if they are damaged or deteriorated.

4-94. REASSEMBLY. (See figure 2-21A.) Reassemble in reverse order of disassembly.

- a. Draw up wheel bearings (34 and 35) with slotted nut (37) to approximately 50 foot-pounds torque. Back off the nut 1/4 turn, then secure with cotter key.
- b. Adjust bearings (13) with nut (16) in the same manner as in 4-94a above.
- c. Tighten bolts (5) as follows: Dry threads - 95 foot-pounds, oiled threads - 75 foot-pounds.
- d. If the entire steering axle has been disassembled, the steering system must be reset. Place the rear wheels and steering arm (15) in neutral (straight-ahead steering condition).

e. Close the hydraulic steering booster completely and then extend the rod five inches.

f. Adjust the rear section of the drag link and the tie rods to fit in position without moving the steering arm or wheels from the straight-ahead position.

g. Adjust stop bolts (1, figure 1-21) to allow a 56 degree angle of inside wheel to frame (inside wheel in relation to direction of turn). Adjust stop bolts against arm for both directions. Secure stop bolts with jam nuts.

h. Adjust stop bolts (15) on axle to within 1/16 inch from pad on steering knuckle (7) when steering arm (2, figure 4-1) is against stop bolt. Adjust axle stop bolts for both directions, and secure with jam nuts. The axle stops must not contact the steering knuckle pad before the front steering arm contacts its stops. The axle stop bolts are placed to prevent damage to the steering system if the wheels deflect sharply when they hit an obstruction.

4-95. BRAKES, INCHING MECHANISM, AND MASTER CYLINDERS. (See figures 2-23 and 2-24.)

4-96. REMOVAL AND DISASSEMBLY. (See figure 2-25.)

a. Release parking brake, easing cable tension.

b. Remove wheel and drum (paragraph 4-91).

c. Unhook shoe return springs (9) from anchor pins (5). Spring pliers aid removal.

d. Loosen the shoes by depressing each spring clip (8) in turn, and rotating its guide pin (7) one-quarter turn.

e. Spread shoes (6) from cylinder push rods (26) and anchor pins (5), and lift out the shoes. Slip the parking brake cable end from the slot in the end of the lever and pin assembly (19).

f. Unhook star wheel retracting spring (10) to separate shoe and parts. Remove the lever and pin assembly (19) and the link and pin assembly (17) from the shoes by removing the clips (18) holding them to the shoes. Pull the anchor pins (5) from the brake spider (2).

g. Separate the brake line from the wheel cylinder (20) and remove the cylinder from the backing plate (1). Remove the rubber end boots (24) and push out internal parts.

h. See figure 2-24. Disconnect tubes (44 and 46) from master cylinders. Pull pins (18). Remove stop light wire from switch (56). Remove master cylinders and linkage.

i. Remove rod and boot assembly. Remove link wire, stop plate, and piston assembly. Remove swivel connector (51) and push remaining parts out piston end of cylinder.

j. Remove the pedals, linkage, and other components as required.

4-97. REPAIR.

a. Discard tubing showing signs of leakage.

b. Discard worn brake linings, broken cables, and broken or weak springs.

c. Discard worn or bluish wheel cylinder or master cylinder parts.

d. Discard worn bushings or bearings or other faulty components of the linkage.

4-98. REASSEMBLY. (See figure 2-25.) Reassemble in reverse order of disassembly.

a. Using lubricate or other brake lubricant, thinly coat the shoe pads on the backing plate, the anchor pins, and the star wheel threads. Also grease the parking brake cable and conduit, and lever and link fulcrum points.

b. Install anchor pins in the brake spider with the slots in the pins faced to engage the brake shoes.

c. Collapse the star wheel link, threading the screw into the nut. Back off 1/2 turn and make sure it turns freely.

d. Replace the shoes, first attaching the lever and pin (19), and link and pin (17) assemblies to the shoes. Install the guide clips, pins, and return springs in the most convenient manner to align shoes to anchors, push rod slots, star wheel slots, and to hook the parking brake cable into the slot of the lever (19).

e. Reassemble wheel cylinders in reverse order of disassembly. Dip internal parts in clean brake fluid to facilitate assembly. Install brake drums and wheels. Assemble master cylinders in reverse order of disassembly, with vent holes in front at bottom. Fill master cylinders with approved brake fluid.

f. Bleed brakes and inching system as required. Brake bleed screws are located on the back of the backing plates. To bleed the inching system, depress the pedal and loosen plug (42, figure 2-24). Replenish the fluid in the master cylinders as necessary.

g. Jack up side of lift truck. Remove dust cover from star wheel access slot. Insert brake tool to engage star wheel teeth. To tighten brakes, use the slot edge as a fulcrum, and moving the tool handle toward the center of the brake, rotate the star wheel. Tighten until the brakes are locked solidly against the drum.

h. Back off the star wheel until the drum turns freely (8 to 10 notches). Replace dust cover.

i. Adjust clevis (24, figure 2-24) to obtain 3/4 inch free travel on the brake pedal.

j. See figure 2-24. Adjust clevis (17) until sleeve (28) is 1/32 inch from washer (30A), which is held against shoulder on rod (29) by spring (30). This 1/32 inch free

play is very important. It allows for expansion of the hydraulic fluid in the lines, thus permitting the plunger in the inching cylinder to return to a fully unloaded position when the inching pedal is released.




Fig. 1-23. Brake Adjustment Location

1. Bleeder
2. Access slot

4-99. DRIVE AXLE AND DIFFERENTIAL.

4-100. REMOVAL.

- a. Block up front end of lift truck. Support transmission case.
- b. Remove drive wheels and brake assemblies.
- c. Remove mounting bolts which hold differential to transmission.
- d. Remove bolts from support clamp (7, figure 2-28.)

4-101. DISASSEMBLY. (see figure 2-22.)

- a. Remove the bolts holding the wheel shaft housing (8).
- b. Remove lock nut (12), and washer (13), from wheel shaft (10).
- c. Remove gear (11), and wheel shaft (10).
- d. Remove cones (14 and 16), cups (15 and 17), oil seal (18), and sleeve (19).
- e. Remove bearing retainer (7). Using puller, pull axle (4) out of assembly.
- f. Remove drive axle housing (1).
- g. Cages (22 and 22A) and the ring gear (27) are assembled and line retained. For this reason it is

necessary that they be marked before disassembly, so they can be reassembled in their original positions. Remove the nuts from cage bolts (23). Disassemble ring gear (27) and cages (22 and 22A), bevel gears (28), and pinion (30) and shaft (32) assemblies. Remove from differential case.

- h. Remove pinions and bushings (31) from shaft.

4-102. REPAIR. (see figure 2-22.)

- a. Discard gears that show excessive wear or have broken teeth. The ring gear and pinion (27) must be replaced as a matched set only.
- b. Discard oil seals and gaskets showing signs of leakage. Discard worn or damaged bearings and bushings.

4-103. REASSEMBLY. (see figure 2-22.) Reassemble in reverse order of disassembly.

- a. Clean all parts in an approved solvent.
- b. Replace all gaskets and "O" rings.
- c. Torque bolts (23) to 75-85 foot pounds.
- d. Add sufficient shims (2) to obtain 15 to 25 inch pounds preload on bearings (24).
- e. When differential is attached to transmission, move shims (2) from one side to the other, as necessary, to obtain .006 to .012 inch backlash between ring gear and transmission pinion shaft (27).
- f. Add shims (7A) to obtain 10 to 15 inch pounds preload on bearings (5A).
- g. Adjust lock nut (12) to obtain 30 to 40 inch pounds preload on bearings (14 and 16).

4-104. CONTROL LEVERS, CONTROL VALVE, AND OIL FILTER.

4-105. REMOVAL. (see figure 2-20).

- a. Remove control levers and shafts as explained in paragraph 4-87.
- b. Remove links (48).
- c. Disconnect valve body (3) and porting block (1) from transmission case.
- e. Remove priority valve (items 12 thru 16, figure 2-18) and relief valve (items 3 thru 6, figure 2-19), and components.
- f. Remove oil filter assembly (49).

4-106. DISASSEMBLY. (See figure 2-20).

- a. Remove cover bolt (57) from oil filter cover (54)

and remove cartridge (53) and parts from oil filter body (50).

b. Remove valve body (3) from porting block (1). Spools (6) and (8) can now be removed.

c. Remove locking cylinder (23) from valve body (3).

d. Remove snap ring (32). Remove internal parts from locking cylinder.

e. Remove snap ring (12) and remove locking spool (18) and components.

f. Remove snap ring (12) and remove pressure regulator spool (13) and components.

g. Remove snap ring (12) and remove both control lever spools (5) and components.

h. Remove snap ring (12), blow through elbow (87) to remove plug (11). Remove relief valve (15) and components.

i. Remove remaining components.

4-107. REPAIR.

a. Discard "O" rings, oil seals, and gaskets which show signs of leakage.

b. Discard damaged hoses and tubing.

c. Discard broken or weak springs.

d. Discard marred or blamished valve spools. If the polished surfaces inside the valve body are marred, discard the entire assembly.

e. Clean all parts thoroughly in solvent.

4-108. REASSEMBLY. (See figure 2-20). Reassemble in the reverse order of disassembly.

a. Screw elbow (87) with "O" ring (68) into valve body before attaching body to porting block.

b. Install control spools (5) in body. Then slip oil seals (9) over spools; do not push spools through seals. Place lip end of inner seal in; lip end of outer seal out.

c. Torque mounting bolts (1, through 10, figure 1-24) to 30 foot pounds in the order shown. Then torque the bolts to 60 foot pounds in same order.

d. Torque socket head bolt (11, figure 1-24) to 15 foot pounds.

e. Replace oil filter cartridge (52).

f. Adjust rods (2, figure 1-25) for desired lever position.

g. Place control levers in high range and reverse positions respectively. Adjust stop bolts (1, figure 1-25) to prevent spools being forced past detent position.




Fig. 1-24. Torque Sequence



Fig. 1-25. Converter Linkage

- 1. Stop bolts
- 2. Rods

4-109. TRANSMISSION CASE, CONVERTER, AND PUMP.

4-110. REMOVAL. (See figure 2-13).

- a. Remove differential assembly as described in 4-85 above.
- b. Remove control valve, priority valve, and relief valve from side of transmission case (paragraph 4-100).
- c. Remove bolts holding converter drive plate to engine flywheel. Turn engine over to remove each bolt in turn, through opening and notch. See figure 1-26.




Fig. 1-26. Converter Mounting Bolt.

1. Bolt lined up with notch.

4-111. DISASSEMBLY. (See figure 2-18).

- a. Remove dipstick (10) and dipstick sleeve (11).
- b. Remove drive plate (25), converter (36), and ball housing (32).
- c. Remove pump (35) from cover (17).
- d. Remove filter mounting flange (26), gasket (27), and filter (28 and 29).
- e. Unscrew attaching parts and remove manifold (22) from cover (17).
- f. Remove reverse idler gears cover (30) from side of case.
- g. Remove nuts (37, figure 2-19), and washer (38, figure 2-19) from pinion shaft (2, figure 2-19) and remove cover (17). Support the shaft to prevent damage while the cover is being removed.

4-112. REPAIR. (See figure 2-18).

- a. Discard all gaskets and "O" rings.
- b. Discard gears with broken teeth and those that show excessive wear.
- c. Discard defective converter and pump.
- d. Clean filter screen (29).

4-113. REASSEMBLY. (See figure 2-18). Reassemble in the reverse order of disassembly.

- a. Install all new gaskets and seals.
- b. Align gears and spline shafts per paragraph 4-113.
- c. Install between engine and differential. Adjust backlash per paragraph 4-103 e.

4-114. TRANSMISSION AND REVERSE IDLER SHAFT.

4-115. REMOVAL. (See figure 2-19). Removal is accomplished with the disassembly procedures of the transmission case, converter, and pump (paragraph 4-110).

4-116. DISASSEMBLY. (See figure 2-19).

- a. Remove collector ring ball bearing (24) and "O" ring. Remove retaining ring (25D) and piston retainer from input shaft (1). Remove piston rings, input shaft ball bearings, carrier to bearing thrust washers, input shaft carrier assemblies, plate housing thrust washers, and quad washers. Remove spring retainer snap rings, spring retainers, piston springs, and oil seal rings. Remove backup rings, retaining rings, friction plates, backing plates, input shaft housing pistons and balls, and piston rings.

- b. Remove components from output pinion shaft (2) in same order as on input shaft, remove reverse gear (39) and idler shaft (44) with bearings and components.

4-117. REPAIR.

- a. Clean all parts in solvent and inspect for damage and excessive wear. Interchange all defective parts with new replacement parts.

4-118. REASSEMBLY. (See figure 2-19). Reassembly is accomplished in reverse order of disassembly. The housings (4) are stamped with an "I" for input (upper), and an "O", for output (lower). Be sure to reinstall the pistons and other components in the housings from which they were removed. Wipe each part with a clean, oil-soaked cloth.

- a. Reassemble pistons and components on shafts and into housings in proper sequence. Install pistons (6 and 7) in each housing with oil relief holes 180° apart for proper balance. A spot of grease will hold balls (8) in place during reassembly of pistons to housings.
- b. Reassemble carrier assemblies and components to shafts. IT IS VERY IMPORTANT THAT THE OIL HOLES IN THE INNER RIB OF THE HOUSING ARE ALIGNED WITH THE SERIES OF FOUR SMALL IN-LINE OIL HOLES IN THE SHAFTS. MARK THESE PARTS AS NECESSARY TO ASSURE PROPER ASSEMBLY AND SUBSEQUENTLY PROPER OPERATION. Coat quad ring (34) with Lubriplate to protect them during assembly. Stake retainer (25C) to groove in shaft. Seat all lock and retaining

rings properly. Use new oil seals and "O" rings. Fit parts properly; avoid scratching or burring finishes.

c. Do not use Permatex on any gaskets.

d. Adjust taper roller bearings on pinion shaft to 10-15 inch pounds net rolling torque pre-load.

e. Torque bolts as follows: 5/16 inch, 20 foot pounds; 3/8 inch, 40 foot pounds. 1/2 inch, 60 foot pounds, and all 3/8 inch bolts to 150 to 160 foot pounds.

f. Torque converter must turn freely with transmission halted to crankcase, but before holding the drive plate to the flywheel.

g. End play of clutch pack on the input and output shafts is to be 0.012 to 0.024 inch between bearings.

h. End play on the idler shaft is to be 0.006 inch minimum.

i. After assembly is complete, check converter charging pressure by installing a gage in opening of plug (2, figure 1-27).

j. Check HIGH and LOW shifting charging pressure at points of plugs (1, figure 1-27). Gage should read 95 to 105 PSI.

k. Check FORWARD and REVERSE shifting charging pressure at plugs (4, figure 1-27). Pressure should be 95 to 105 PSI.

l. Check pump charging pressure at plug hole (3, figure 1-27) on top of transmission. Reading is to be 130 to 140 PSI.




Fig. 1-27. Pressure Testing Ports

1. HIGH and LOW check ports
2. Converter charging check port
3. Pump charging check port
4. FORWARD and REVERSE check ports

m. Pressures given above cannot be regulated. If gage readings do not fall in specified range, remove and clean valve and related parts, and reinstall. If readings still are not correct, install new components.

4-119. FUEL PUMP AND FUEL FILTER.

4-120. REMOVAL. (See figure 2-6).

- a. Disconnect fuel lines from pump and fuel filter.
- b. Remove the 2 capscrews that secure the pump to the engine side cover.

4-121. DISASSEMBLY. (See figure 2-6).

- a. Loosen the bail nut (16), swing the bail to one side, and withdraw the bowl (19).
- b. With retainers (8) removed, tap out arm pin (7). Pull clip (22), press out pin (21), and withdraw link (20).
- c. Remove cover and lift out remaining components within the body.

4-122. REPAIR. Repair of the fuel pump is limited to discarding damaged, bent, or ruptured (diaphragm) parts. Wash all parts in solvent and blow dry with compressed air. Check the spring for quick return action, when compressed and released.

4-123. REASSEMBLY. (See figure 2-6). Reassemble the fuel pump and filter in essentially the same order as disassembly, except that care must be taken not to damage or distort the diaphragm by not aligning the cover holes properly. Using a new gasket (23), secure the assembly to the engine, and connect the fuel lines.

4-124. CARBURETOR, (GASOLINE).

4-125. REMOVAL. (See figure 2-7).

- a. Loosen screw (39), remove clip (38), and pull the choke control cable out of the swivel (36).
- b. Remove the air intake hose and the fuel line. Remove the two capscrews that secure the carburetor to the manifold casting.

4-126. DISASSEMBLY. (See figure 2-7).

- a. Disassembly of the carburetor is complete upon removal of all attaching parts of each component. The following steps outline the various troubles and which components cause them.
- b. Some factors other than faulty operation of the carburetor that could contribute to improper operation of the engine are as follows: faulty ignition system, incorrect timing, air cleaner abnormally restricted, or air leaks. Check for and correct any of these conditions that may exist.
- c. If the engine is not idling properly, check the gas-

ket between the manifold and cylinder head and also the gasket between the carburetor and manifold. Air leaks at these points will cause erratic idling.

d. The principal parts subject to wear in the carburetor are the throttle shaft (2), the float valve and seat (15).

e. Wear of the throttle shaft results in more air entering the carburetor than is necessary. This condition results in too lean a gas mixture when the engine is idling. To compensate for the increased air supply, it is usually necessary to enrich the idle gas mixture; this in turn, affects fuel economy. In addition, this excess air is unfiltered and could cause serious damage to the engine.

f. Excessive wear of the float valve and seat will result in too high a fuel level in the carburetor bowl. This high fuel level causes excessive fuel consumption, crankcase dilution, and difficulty in maintaining satisfactory adjustment of the carburetor.

g. If the fuel level is too low, the engine will not respond quickly, and it will be very difficult to maintain a satisfactory carburetor adjustment. A sticking float valve or float arm could cause a low fuel level.

4-127. REPAIR. (See figure 2-9).

a. Inspect all parts taken from the carburetor. Replace any damaged or excessively worn parts. Discard all gaskets, the choke-shaft packing, and the throttle-shaft seal.

b. Using a cleaning solution, thoroughly clean the throttle body (1), the carburetor bowl (19), and all parts being used again.

4-128. REASSEMBLY. (See figure 2-7).

a. Assemble the carburetor in the numerical sequence as shown, with the following exception:

b. The float (12) controls the fuel level in the carburetor bowl. Turn the throttle body (1) upside down, and measure the distance between the float and the milled surface of the throttle body. This distance should be 5/16 inch. If necessary, bend the float arm in either direction to obtain the correct dimension.

c. Secure carburetor to exhaust manifold and intake hose, tube, and cable connections.

4-129. LP-GAS EQUIPMENT.

4-130. REMOVAL. (See figure 2-10).

a. Close fuel valve on tank.

b. Disconnect all hoses, wires, and linkage and remove the carburetor and vaporizer from the engine.

4-131. DISASSEMBLY AND REPAIR (CARBURETOR).

a. Remove main cover and diaphragm, clean thoroughly with solvent, blow dry with air hose, inspect for damage or wear. Clean inside carburetor, using small brush for orifice. Check for air leaks around outer edge of diaphragm, carburetor to manifold gasket, and vacuum pick-up openings in flange.

b. To replace diaphragm only, cut off diaphragm to remove from assembly. Carefully stretch new diaphragm over one backup plate; the diaphragm should float freely between the two plates.

4-132. DISASSEMBLY AND REPAIR (VAPORIZER).

a. Remove cover assembly. Check "power rain" operation by sucking on vacuum line connecting port. Turn and remove main vaporizer diaphragm assembly. Check seal in diaphragm stem. Clean or replace liquid seal pad. Clean chamber thoroughly. Remove lever assembly, check seat (there is a spare seat on the lever arm), check for bent lever or wear at the connecting slot. When replacing vaporizer seat, it is recommended to replace complete lever arm assembly.

4-133. REASSEMBLY.

a. Reassemble in reverse order of disassembly.

b. When installing diaphragm assembly in carburetor, be sure to allow sufficient slack in diaphragm so the fuel and air valve can move freely. Use guide pins if possible.

c. In vaporizer, to reconnect diaphragm assembly to lever: with liquid seal pad and cover installed, insert screw driver to hold seat in closed position, place diaphragm tab at 90°, rotate to position, check for connection.

4-134. OIL PUMP.

4-135. REMOVAL (See figure 2-13). To remove the oil pump, first drain the crankcase oil. Remove the four stud nuts and the cap screw which secure the oil pump body (1) to the crankcase, and then remove the oil pump.

4-136. DISASSEMBLY. (See figure 2-13).

a. Remove the gear (14) on the drive shaft, and the Woodruff keys.

b. Before removing the drive shaft for the oil pump, it will be necessary to remove the distributor. The drive shaft for the oil pump affects the engine timing. Turn the engine over until the No. 1 piston is at the top dead center of its compression stroke and the rotor is pointing toward the post for the No. 1 cylinder.

c. Mark the position of the distributor rotor and the distributor body. Notice that the slot in the distributor drive coupling is off-center.

d. To remove the drive shaft for the oil pump, loosen the lock nut, and back out the setscrew. Remove the oil pump drive shaft.

e. Check the condition of the bushings (17) for the oil pump drive shaft. Use a screw-type extractor to remove these bushings if they are damaged. Press the lower bushing in the crankcase until it is flush with the bottom of the crankcase. The upper bushing should be flush with the top of the bushing hole. These bushings are line-bored. The correct inside diameter of these bushings after they are line-bored is 0.625 to 0.626 inch.

f. To replace the grooved bushing (18), drive on the coupling roll pin, and slip both parts off the shaft.

g. Remove the check valve and the pressure regulator screw (8).

4-137. REPAIR. (See figure 2-13).

a. Check the condition of the drive shaft (15), the coupling for the drive shaft, the grooved bushing, and the pinion (18). Replace any excessively worn or damaged parts.

b. If any of the springs are broken or have taken a "set", install new ones.

c. Check the condition of the oil pump gears. Replace them if they are chipped, cracked, or worn excessively.

4-138. REASSEMBLY. (See figure 2-13).

a. Insert the oil pump drive shaft assembly in the crankcase. Make certain the slot in the coupling and the largest section of the coupling on the distributor are in alignment. After installing the oil pump drive shaft, turn the setscrew all the way in and secure the lock nut.

b. Install the Woodruff keys on the oil pump drive shaft, and reinstall the oil pump drive gear on the shaft.

c. Assemble the remaining components observing the following steps.

d. There must be 0.002 to 0.004-inch clearance between the end of the oil pump drive gear and the oil pump housing. To obtain this clearance, add or remove gaskets (20), between the bottom of the crankcase and the top of the oil pump housing. Insert a piece of Plastigage in the pump housing directly beneath the oil pump drive gear. Re-install the pump, and securely tighten the cap screw and four stud nuts. Remove the pump, and check the flattened Plastigage strip, using the scale printed on the Plastigage envelope. Add or remove gaskets as necessary to obtain the 0.002 to 0.004-inch clearance.

NOTE: When using Plastigage, make certain

that all the oil is off the pump body and gears. This is necessary as Plastigage will dissolve in oil.

e. When reassembling, be sure to align the coupling on the distributor and on the oil pump drive shaft. If the engine was not turned over while the drive shaft was removed, the parts can be installed in their original position and the engine timing will be correct. However, be sure to check the timing, after reassembling, using a noon timing light.

4-139. ENGINE

4-140. REMOVAL. Many of the overhaul procedures described below can be accomplished without removing the engine from the vehicle. For any major overhaul, however, such as replacing the camshaft or crankshaft, the engine must be removed. Remove the overhead guard. Remove the engine hood sections. Disconnect all wiring, tubing, hoses, linkages, etc., that are connected from the engine to the frame or other components. Remove the radiator as described in paragraph 4-42. Remove the battery and box. Remove the bolts from the engine mount (6, figure 2-28) and the bolts from the torque converter drive plate (see figure 1-26) and converter housing. When all parts are free, move the engine directly to the rear and raise the engine completely up and out. Lower the engine onto a suitable support, using wood blocks to avoid damage to the assembly.

4-141. DISASSEMBLY AND REPAIR.

a. Remove the cylinder head cover (18, figure 2-2), and the adapter (16). Remove the side cover (27, figure 2-1) as an assembly.

b. Disconnect the rocker arm oil line and the rocker arm assembly.




Fig. 1-28. Gear Timing Marks

1. Timing marks

c. Remove all cylinder head stud nuts. Withdraw push rod (28, figure 2-3), and remove the heads.

d. To replace the crankshaft, first turn the engine over until the timing mark on the crankshaft throw lines up with the mark on the camshaft gear. See figure 1-28.

e. Remove the cap screws from the camshaft bearing caps (figure 1-29). Remove the screws holding the oil lines to the crankshaft bearing caps. The center and the front bearing caps are not interchangeable. Before removing the center and the front bearing caps, be sure they are marked with a center punch. Remove the bearing caps, and keep them in their original order. Remove the camshaft. Keep the tappets in their original order.




Fig. 1-29. Bearing Caps

1. Camshaft bearing caps
2. Oil lines
3. Tappet

f. To service the pistons, rings, piston pins, or connecting rods, it is not necessary to remove the engine from its mounting base.

g. Remove the heads and side cover as explained previously. Disconnect the rods. If the cylinder has a ridge around the top, remove the ridge with a reamer BEFORE attempting to push out the piston. Failure to remove this ridge before removing the piston will invariably result in damage to the piston ring lands. Exercise extreme care when using the reamer. It is possible to cut so deeply into the cylinder wall or to turn out the metal so far down in the cylinder that it will ruin the cylinder, or it will be necessary to rebore the cylinder.

h. After removing the ridge, bring each piston to the top of its stroke and wipe the reamer cuttings from the top of the piston. Be very careful not to allow cuttings to drop into the water jacker opening or into the crankcase. After removing the pistons from the cylinder, place them in a sack to keep them in order and to prevent damaging the rod or piston.

i. Soak the pistons in a suitable liquid cleaning solu-

tion. After thoroughly soaking the pistons, clean all the carbon from the top of the piston with a suitable scraper. Clean the carbon from the ring grooves with a ring groove cleaner or a broken section of a ring. If using a broken ring, file one end of it to a sharp, square edge. Clean metal should be evident over the entire area of the ring groove. Use care to avoid removing metal from the bottom of the ring groove. Carefully clean the oil return holes in the oil ring groove, using a drill of the proper size held in a tap wrench. Never use a steel buffing brush to clean the ring lands or skirt of a piston. After thoroughly cleaning the pistons, carefully examine each piston. Be sure there are no cracks in the head or skirt of any of the pistons, and check the rings lands to be sure they are not bent or broken. Replace the piston if any of these defects are found.

j. Check the ring grooves for wear, using new rings. The top rings should have a clearance of 0.002 to 0.004 inch between the ring and ring grooves on the piston. An additional 0.001 inch allowable for worn pistons. The second ring should have a clearance of 0.0015 to 0.0035 inch with an additional 0.0015-inch clearance allowable for worn pistons. The third and fourth rings (single groove) should have a clearance of 0.002 to 0.0035 inch.

k. Check the cylinder bore with an inside micrometer to determine if the bore is out-of-round, tapered, scored, or worn excessively. The factory limit for a standard cylinder bore is 3.7522 to 3.7518 inches. Rehone or replace the cylinder blocks if the wear, taper, or out-of-round exceeds 0.008 inch.

l. Pistons are available in 0.020-inch and 0.040-inch oversize to correspond with the cylinder bore. The bore dimension limits for 0.020-inch oversize pistons are 3.7722 to 3.7718 inches. The bore dimension limits for 0.040-inch oversize pistons are 3.7922 to 3.7918 inches.

m. De-glaze the cylinder walls when servicing the rings and pistons. This will enable the rings to mate or seat more quickly and will control the oil better. However, be sure to thoroughly clean the cylinders after de-glazing them. Any abrasive material left in the engine after reassembling will cause rapid wearing of the rings, cylinder walls, and the bearing surfaces of all parts lubricated by the crankcase oil. Use a good, 280-grit, spring-loaded surface hone when de-glazing the cylinder walls. We recommend the following procedure to obtain a satisfactory de-glazing job. First remove any hard carbon deposits that might be present within the cylinders, then wipe the cylinder out with a clean cloth. With the piston and rod assemblies out of the engine, carefully pack a clean, dry rag or a paper dampened with water at the bottom of the cylinders. This prevents abrasives and dirt from getting into the crankshaft or into the crankcase. Dip a clean cotton spring mop in clean No. 20 motor oil, and wash the cylinder walls. Run the surface hone in each cylinder making 10 to 12 complete strokes. Move the hone up and down in each cylinder rapidly enough to ob-

tain a pattern with the cross-hatching intersecting at about 60°. Clean the loose abrasives from the hone with a clean cloth before using the hone in the next cylinder. Repeat the de-glazing procedure in each cylinder. After honing, wipe as much as possible of the abrasive deposits from the cylinder walls. Swab each cylinder with clean No. 10 oil. Carefully wipe each cylinder with a clean cloth. One swabbing-wiping operation is not sufficient. Continue the swabbing-wiping operation until a clean, white cotton cloth remains absolutely unsoiled when rubbing it on the cylinder wall.

NOTE

Do not use gasoline or kerosene to clean the cylinders after de-glazing them. Solvents of this nature will not remove the grit from the walls.

n. The recommended clearance between the cylinder walls and the skirt of pistons is 0.003 inch. To check this clearance, place a long 0.003-inch feeler strip 1/2-inch wide between the side of the piston and the cylinder wall, in line with the pin. The piston should enter the bore with this feeler in place, but should not do so when using a 0.004-inch feeler strip.

o. Carefully check the rods to make certain they are straight. A bent rod is likely to make the piston operate so the ring faces are not parallel to the surface of the cylinder wall; a bent rod will also cause premature bearing failure. Accurate alignment of connecting rods is necessary for correct ring and bearing operation. To check the rod for twist or parallelism, place it in a fixture. Using an aligning tool, make any adjustments necessary. Install a new rod if the old rod cannot be properly aligned.

p. Always check the end gap of each ring in the cylinder. Insert the ring in the bore, and push the ring down with the top of the piston. This squares the ring in relation to the cylinder bore. Push the rings down to the bottom section of the cylinder just below the normal travel distance of the rings. When checking the end gap of new rings in a new cylinder, the rings should have an end gap of 0.010 to 0.020 inch. The end gap of the rings may vary somewhat from these clearances, depending upon the amount of cylinder wear.

q. While disassembling, be sure to mark any parts being used again. During the original time the engine was run, each engine part works into its mating part and becomes especially suited for its own particular position in the engine. In addition to normal engine wear, other factors contribute to bearing failure. Therefore, during disassembly of an engine and before reassembling it, try to determine, analyze, and correct the original cause of bearing failure. It is just as important to correct the cause of bearing failure as it is to replace the worn bearings. Some other factors which could cause bearing failure in addition to normal wear are as follows: dirt, misalignment (including rods and caps), incorrect assembly, lubrication failure,

out-of-round bearing surfaces, fatigue, corrosion, and incorrect methods of engine operation (including overloading). Check for, and correct any of these causes which could have contributed to bearing failure before reassembling the engine.

r. It is extremely important to check the crankshaft for scored rod-bearing journals or main-bearing journals. If the journals show evidence of scoring, it will be necessary to replace the crankshaft. Using a micrometer, measure each rod-bearing journal and each main-bearing journal at various places around the journal to be sure it is not tapered or out-of-round. If the taper or out-of-round of any journal exceeds 0.002 inch, replace the crankshaft.

NOTE

When re-using a crankshaft which has slightly tapered or out-of-round journals (less than 0.003 inch), be sure to fit the bearing to the maximum diameter of the journal. If the bearing is fitted to the minimum diameter of a slightly out-of-round or tapered journal, interference between the bearing and journal will result in rapid bearing failure.

s. Remove the flywheel (19, figure 2-4). Remove the rear oil-seal retainer, and the pilot-bearing retainer. Remove the belts which secure the rear main-bearing housing to the crankcase. Remove the front main-bearing cap and the better main-bearing cap. Notice that the center main-bearing cap and the front main-bearing cap have different identification marks and are not interchangeable. Using a bearing removal plug, roll the inner inserts out of the crankcase (lip end of insert first). Turn the crankshaft so the number 2 and the number 3 rod journals are to the outside. If the rod and piston assemblies are in the engine, push them up out of the way. Using a lead hammer, or a wood block and a hammer, drive the crankshaft toward the rear of the engine until the rear bearing housing is out of the crankcase. Use extreme care to prevent damaging any of the rods or crankshaft journals while removing the crankshaft.

t. Remove one of the long dowel pins from the end of the crankshaft. Remove the top half of the rear-main bearing, and remove the insert from the lower section. Position the rear-bearing housing in relation to the dowel pin. Notice that the open section of the bearing housing is opposite the remaining long dowel pin. Move the open section of the housing out and over the end of the crankshaft.

u. Remove the crankshaft (1, figure 2-4) from the crankcase through the side cover opening in the crankcase. Remove and clean the oil strainer. Clean out all the oil passageways and the oil tubes in the crankcase.

4-12. REASSEMBLY.

a. When reassembling, do not install the rear main-bearing inserts until the crankshaft is in the crankcase and rear main-bearing housing is on the shaft. Install

new gaskets between the bearing housing and crankcase. Figure 1-30 shows the correct position of the bearing inserts in the cap and housing. Be sure to install the bearing cap so the locking lugs on the inserts are on the same side.

b. After cleaning the surface of the shaft and bearings, apply a liberal amount of S.A.E. 90 oil to the surface of both inserts. Install the bearing cap. Torque the bearing cap bolts evenly and gradually to 60 to 65 foot pounds.

c. Check the crankshaft end clearance. There must be 0.002 to 0.002-inch end play between the crankshaft thrust shoulder and the flange on the rear main-bearing insert. Make certain the fitting in the rear main-bearing housing is in line with the oil tube. Drive the crankshaft and rear main-bearing housing all the way forward into the crankcase. Using a bearing removal plug, turn the crankshaft and roll the center main-bearing insert and the front main-bearing insert in place in the crankcase. The smooth or plain end of the insert should enter the bearing seat first.




Fig. 1-30. Bearing Locking Lugs

1. Locking lugs

d. Before installing the center main or the front main-bearing cap, tighten the bolts in the rear bearing housing in the correct sequence and to the proper torque. Tighten these bolts a little at a time and in a crisscross manner until reaching the full torque value. Correct torque of these bolts is 55 to 60 foot-pounds. The proper torquing (figure 1-31) of this housing is very important as it will affect the alignment of the crankshaft. An incorrectly aligned crankshaft will cause premature bearing failure. Install a new dowel pin in the crankshaft.

e. Install new gaskets and seals when reassembling the engine. Install a new rear oil seal in the retainer. Use a new gasket between the retainer and the rear main-bearing housing when reinstalling the bearing caps. Torque the front and center main bearing cap bolts evenly and gradually to 30 to 100 foot pounds.




Fig. 1-31. Torquing Sequence

f. Before installing the front oil seal for the crankshaft, check the condition of the seal. Install a new seal in the cover if the old seal appears damaged or worn excessively. Use a new gasket between the cover and crankcase. Reinstall the oil seal cover, the key, the crankshaft pulley, the washer and cap screw, and the fan belt.

g. Before reinstalling the flywheel (29, figure 2-4), make certain the pilot-bearing retainer is in place on the end of the crankshaft. Turn the crankshaft to the number 1 cylinder and number 4 cylinder crankshaft journals are straight up. The DC-1 mark (figure 1-32) should be in line with the opening in the side of the crankcase.




Fig. 1-32. Flywheel Timing Mark

h. Reinstall the tappets, camshaft, and remainder of the valve train assembly (figure 2-3). Make certain to align the timing mark on the camshaft gear with the timing mark on the crankshaft throw.

i. Check the amount of crankshaft end play. With a small pry bar, move the shaft toward the rear of the engine. Using a feeler gage, check the amount of clearance between the thrust surface of the crankshaft and the thrust surface of the bearing. The correct crankshaft end clearance is 0.002 to 0.003 inch.

j. Before installing the oil pump drive shaft, make certain that the 180° mark on the flywheel is centered in the timing marking (figure 1-32), and that the number one piston is at the top dead center of its compression stroke.

k. Make certain the surfaces of the crankcase and blocks are absolutely clean before reinstalling the blocks. Use new gaskets when reinstalling the blocks. Tighten the block mounting bolts to 24 to 30 foot-pounds. After reassembling, be sure to correctly torque the heads and adjust the valves as explained below.




Fig. 1-32. Block Mounting Bolts

l. Mounting bolts

1. Always use new gaskets when reinstalling the heads. The copper sheet side of the gasket should be toward the top of the engine. When rightening the head nuts, tighten the nuts at 25 foot-pounds intervals and in the sequence shown in figure 1-34. Tightening the nuts in this manner smooths out the gasket and squares the head on the block. The correct torque of the head nuts is 70 to 75 foot-pounds.




Fig. 1-34. Head Torque Sequence

2. Adjust valves as follows: Cold---intake .016 inch; exhaust .018 inch. At operating temperature---intake .008 inch; exhaust .010 inch.

4-143. HYDRAULIC PUMP (MY 4C).

4-144. REMOVAL. (See figure 2-30).

a. Drain the hydraulic tank. Remove the suction strainer (42).

b. Remove the hoses from the pump (1) and remove the pump from the engine side cover.

4-145. DISASSEMBLY. (See figure 2-30).

a. Remove helical gear (3). Remove socket head screws, and remove bearing adapter (8).

b. Remove drive shaft (5). Remove snap rings (6) and bearing (7).

c. Remove flow divider assembly (24). Remove plug (27), piston (25), and spring (26).

d. Remove plug (22), spring (30), and valve (23).

e. Remove cover (3) and remaining components.

4-146. REPAIR. (See figure 2-30).

a. Replace all oil seals.

b. Check condition of all bearings and replace faulty components.

c. Check condition of gears (6, and 15) and drive shaft. Replace faulty components.

d. Replace body and pump wear plates (18 and 19).

4-147. REASSEMBLY. (See figure 2-30). Reassemble in reverse order of disassembly.

a. Torque cover-to-body bolts to 190-210 inch-pounds.

b. Torque flow divider assembly socket head bolts to 190-210 inch-pounds.

c. Torque mounting bolts to 13 to 20 foot-pounds.

d. If necessary, add or remove shims (31) to obtain relief pressure of 1250 PSI. Install gage in lower steering pressure line, and turn brake wheels against wall or other solid object to activate relief valve.

4-148. HYDRAULIC PUMP (MY 6C).

4-149. REMOVAL. (See figure 2-30A).

a. Drain the hydraulic tank. Remove the suction strainer (35).

b. Disconnect the hoses and tubing from the pump

(7). Loosen the set screw in the coupling (20), remove the pump mounting bolts, and remove the pump (1) from the support (30).

4-155. DISASSEMBLY. (See figure 2-55A.)

a. Remove the four socket head screws from the flow divider assembly (12) and remove the flow divider from the cover (3).

b. Mark the gear plate (13) and cover (3) so they can be reassembled in the same relative position. Remove the six cover-to-body bolts and separate the cover, gear plate, and body (2), and their components. Note the position of the idler gear (8). The gear is symmetrical, but any amount of wear requires that it be reassembled in the same position for proper mating with the drive shaft gear (5).

c. Remove the retainers (3), oil seal (7), and "O" ring (9).

d. If there is evidence of bearing damage, remove the bearings (4) from the body and cover.

e. Remove plug (21) and "O" ring (22), and withdraw piston (19) and spring (20).

f. Remove plug (25), and withdraw shaft (25), spring (24), and valve (23).

4-151. REPAIR.

a. Replace wear plates (2 and 13).

b. Replace oil seal (7) and "O" rings (9, 17, 22 and 27) and seals (14 and 15).

c. Examine all remaining parts carefully for wear or damage. Discard any faulty components.

4-152. REASSEMBLY. (See figure 2-55A.)

a. Assemble in reverse order of disassembly. Keep all parts immaculately clean during re-assembly. Dip seals and "O" rings in clean hydraulic oil before installing.

b. The wear plates (2 and 13) are not identical. They must be installed as shown in figure 2-55, with the plate with the slots toward the pump body (2) side of the gear plate (13).

c. The idler gear (8) must be installed in its original position. See 4-152b above.

d. Torque the cover-to-body and flow divider attaching bolts to 80 to 110 inch pounds.

e. Add or remove shims (23) to obtain relief pressure of 1250 PSI. Install gauge in cover steering pressure line and turn rear wheel against wall or other solid object to activate relief valve.

4-153. HYDRAULIC CONTROL VALVE.

4-154. REMOVAL. Remove all tubing and hoses from the control valve. Remove the control valve from the mounting.

4-155. DISASSEMBLY. (See figure 2-54.)

a. Remove ball check plug (10), "O" ring (11), and check valve plunger (13).

b. Remove cap (20), gasket (21), shims and washers (19 and 19A), spring and guide (16 and 17), remove ball (18). Remove valve seat (14), "O" ring (12), and plunger (15).

c. Remove rubber contact (10), snap ring (8), and disc (8).

d. Remove bolt (6), lock washer (7), and stop collar (5), centering spring (3), and stop washer (4).

e. Disconnect handles from spools by removing the cotter pin and handle pin.

f. Push spool into housing from front of valve (control handle end) until front seal (2) is exposed, then remove front seal. Pull spool out of housing from front end, being very careful that neither spool nor beam is damaged in any way. Remove rear seal (2).

4-156. REPAIR.

a. Thoroughly clean the seal grooves.

b. Install new seals, "O" ring, and gasket (21).

c. Examine all parts carefully and replace any damaged or faulty components. If a spool or the valve is damaged the entire assembly must be replaced.

4-157. REASSEMBLY. (See figure 2-54). Reassemble in reverse order of disassembly.

a. Wash all parts thoroughly in an approved solvent.

b. The spools must be installed in the ports from which they were removed (the spool with 2 grooves must be installed in the port nearest the inner side of the valve). Install the spool from the front of the valve, until the spool end reaches the rear seal groove.

c. Dip new seal in hydraulic fluid and place seal in rear groove, with the "U" cup of the seal toward the valve body. Straighten the seal by running a smooth rod around the exposed surface of the seal until it fits perfectly.

d. Push the spool further into the housing, with a seating movement, to ease the spool through the rear seal. Push the spool just far enough in to expose the front seal groove. Dip new seal in hydraulic fluid and install front seal with the "U" cup toward the valve body and straighten seal as explained previously.

e. Gently push spool forward with a rotating motion, to chase the spool through the front seal. Position spool with 1/4-inch of polished surface of the spool exposed in front of valve.

f. Install new rubber bonnets.

g. Install check valve assembly with new "O" ring (12). Tighten plug (11) to 36 foot pounds.

h. Install relief valve assembly, with new "O" ring (18). Tighten valve seat (14) securely. Install ball (19), guide (17), spring (16). Use sufficient washers (19) or shim (19A), or both, to obtain relief pressure of 1250 PSI for the MY 40; 1750 PSI for the MY 60. Each washer (19) affects the pressure approximately 500 PSI; each shim (19A) affects the pressure approximately 80 PSI. Test the pressure at either plug opening (1, figure 1-33).

i. Install new gasket (21). Tighten cap (20) to 45 foot pounds.



Fig. 1-35. Hydraulic Pressure Lines

1. Testing ports

4-158. HYDRAULIC STEERING BOOSTER.

4-159. REMOVAL. Disconnect the hoses. Disconnect the drag link from the hydraulic steering booster. Remove the booster and the rear section of the drag link.

4-160. DISASSEMBLY. (See figure 2-27).

a. Remove the rear section of drag link from the booster.

b. Drain the oil from the booster by moving the piston rod in and out from one extreme of travel to the other.

c. Remove slotted nut (18), cushion retainers (17), and cushions (11) and bearing. Remove end plate (19).

d. Remove retaining ring (11). Pull back sharply on piston rod to blow out seals and rings (8, 9, 10, 12, and 13).

e. Remove retaining ring (14) and bearing (5). Remove pin (7) and "O" ring (6). Remove the piston and rod assembly (1).

f. With slotted nut (53) removed from ball stud (31), remove dust seal cover (42) and dust seal (41).

g. Straighten out the 2 staked places and remove end cap (45). Remove lock pin (33) and narrow adjusting plug (37). Front inside plug, remove washer (36) and spring (35). Remove outer ball seat (34) and ball stud (31).

h. Unscrew lubricator fitting (44). Pull out ball socket housing (10) and remove 2 steel balls (52).

i. The valve sub-assembly - consisting of through ball closure, and shell (32) - can now be removed. Use care to avoid damage to the threads inside the end of the cylinder housing when pulling out this assembly. The 4 small "O" rings (20) may or may not remain in their counter-bored. If not, they should be found on the face of the cylinder head.

j. To simplify disassembly of flexure rod (29), socket shell (39), and valve body and spool subassembly, reassemble ball stud (31) against inner ball seat (34), install outer ball seat (34), and screw in adjusting plug (37) as tight as possible. This will tend to keep flexure rod (29) from twisting when unscrewing elastic stop nut (30).

k. After elastic nut has been removed, washer (24), retaining washers (22 and 22A), "O" ring (23), spring (21), socket shell (39), and flexure rod (29) can be disassembled. The spool may now be removed from the valve body; however, note the position of the valve spool as it is assembled in the valve body (19). To remove spool, push toward ball stud end of unit.

l. Remove bypass valve assembly (26, 27, and 28). The plug (28) is a fairly tight fit, but can be removed.

4-161. REPAIR. (See figure 2-27).

a. Reinstall all O-rings and "O" rings.

b. Wash all parts in an approved solvent.

c. Examine all parts carefully for scratches or nicks. If any of the polished surfaces are marred, discard the faulty component.

4-162. REASSEMBLY. (See figure 2-27).

a. Place "O" ring (23) at spool and insert spool in valve body from ball stud end.

b. Drop ball (27) into hole, place spring (25) over plug stem (28), and press in hole until flush with face of valve body.

c. Place flexure rod (29) in socket shell (39), insert inner ball seat (34), ball stud (31), outer ball seat (34), and adjusting plug (37). Tighten securely. Place this assembly in vise, holding at threaded end of socket shell.

DO NOT DAMAGE THE SHELL BY CLAMPING IT TOO TIGHTLY IN THE VISE.

d. Slide valve body and spool assembly over flexure rod (end of valve body with 4 holes counterbored for small "O" rings must be up).

e. Assemble washer (22), spring (21), washer (22A), "O" ring (23), another washer (22A), and retainer washer (24). Press carefully into valve body until elastic nut (32) can be started on flexure rod. Using box wrench, push down on top of washer (24), at same time rotating valve body (13) back and forth until "O" ring (23) and inner washer (22A) enter valve body completely.

f. Tighten elastic nut (12) to 10-12 foot-pounds.

g. Remove ball stud, seats, and adjusting plug from socket shell.

h. Assemble 4 "O" rings (20) to valve body. Slide valve body into cylinder housing. Roll pin assembly in valve body must fit in center hole in cone of cylinder head.

i. Assemble socket housing (40) over shell (39), aligning slotted opening in housing with rectangular opening in cylinder housing. Align socket shell with openings. Install inner ball seat (34).

j. Place small amount of heavy grease in small holes in socket shell, and install steel balls (32).

k. Install ball stud (31) in shell through opening in cylinder housing. Be sure balls remain in place. Install outer ball seat (34).

l. Place washer (36) and spring (35) in opening of adjusting plug (37). Screw plug into socket shell. Tighten plug finger tight, then back off to nearest hole for lock. Stud should be firm, but move freely.

m. Insert lock pin (38) and snap in place, screw in end cap (49) until tight. Clamp cylinder housing in 2 places as provided in end cap.

n. Assemble the remaining components in the reverse order of disassembly. Assemble "O" ring (12) over piston rod end, being careful not to cut "O" ring. Cushion retainers (17) must be installed with cup toward cushions (18), with locator between cushions.

4-163. TILT CYLINDERS.

4-164. REMOVAL.

a. Place forks on floor and tilt mast forward. Secure mast with hoist. Remove hydraulic hoses. Remove pins (38, figure 2-37) on Simplex upright. On Duplex, drive roll pin into cylinder pin (31, figure 2-36). Do not drive roll pin in so far as to embed it in pin bore.

4-165. DISASSEMBLY. (See figure 2-33).

a. Tilt cylinder by moving rod back and forth.

b. Unscrew threaded washer (16).

c. Pull piston rod (8) and remaining parts out of shell (2).

d. Remove nut (9). Pull remaining components off rod.

4-166. SERVICE. (See figure 2-33).

a. Replace all "O" ring seals and packing assembly (7 and 13).

b. Replace nylon rider (6). Replace back-up ring (15).

c. Replace wiper ring (19).

4-167. REASSEMBLY. (See figure 2-33).

a. Reassemble in reverse order of disassembly. Lubricate all "O" rings with clean hydraulic fluid to facilitate installation. Install all parts from piston end of rod.

b. If a new cylinder is installed, retract the tilt cylinders. Loosen bolt in rod end (1, figure 1-36), place a punch through the hole (2, figure 1-36) in the rod, and align the new cylinder with the other to square up the mast.




Fig. 1-36. Tilt Cylinder Adjustments

1. Rod end
2. Insert punch here

4-168. LEFT CYLINDER (DUPLEX). See figure 2-35.

4-169. REMOVAL.

a. Place forks on ground. Disconnect lift chains and hydraulic hose.

b. Remove snap ring and cylinder support (97 and 98, figure 2-36). Lift the cylinder up and out.

4-170. DISASSEMBLY. (See figure 2-33).

c. Remove retainer (7), "O" ring (8), wiper ring (9), and garter spring (10). Pull out intermediate tube (2) and components.

f. Remove retainer (11), "O" ring (12), and wiper ring (13). Remove sheave support as described in paragraph 4-130.

g. Remove snap ring (17 and 25), washers (18 and 19), and packing (14 and 19). Remove pin (21) and piston (14).

d. Remove threaded washer (20) and wiper ring (31), remove retainer (22), "O" ring (23), and ring (24), and intermediate tube (4). Remove snap ring (34) and bushing (55).

e. Remove items 25 through 28, inclusive, from piston retainer (22).

f. Remove straight fitting and "O" ring at base of cylinder, and remove spacer (37), spring (35), and washer (36).

4-171. REPAIR.

a. Replace all "O" rings, packings, wiper rings, and back-up rings.

b. Wash all parts in an approved solvent. Examine for wear, scratches, or blemishes. Discard faulty components.

4-172. REASSEMBLY. (See figure 2-35). Assemble in reverse order of disassembly.

a. Dip "O" rings and packing in hydraulic fluid to facilitate assembly to prevent damaging these parts.

b. Install "O" rings, packing, back-up rings to piston (14) and retainer (22) sub-assemblies.

c. Install lift cylinder on mast assembly, with locating pin on bottom of cylinder in small hole in bottom plate of outer rail assembly. Connect hose to fitting. Install chains and adjust as explained in paragraph 4-182.

d. Check fluid level in tank and replenish as necessary, according to lubrication instructions (figure 1-10). Start the engine and operate at an idle speed. Pull back on lift control lever to fill the cylinder. Operate cylinder several times, raising and lowering mast. With engine running at idle speed, loosen bleed screw (6) on top of cylinder, and pull back on lift control lever. Tighten screw when fluid with no bubbles runs out of bleed hole.

4-173. LIFT CYLINDER (SIMPLEX). See figure 2-34.

4-174. REMOVAL. (See figure 2-37).

a. Lower forks to floor. Disconnect tubing from upper end of cylinder.

b. Disconnect tube from lower end of cylinder. Re-

move spring, washer, and spacer (15, 16 and 17, figure 2-34).

c. Remove nuts from anchor stud (20) to disconnect chain. Remove cap screws holding cylinder flange to cross brace on outer rail assembly (1).

d. Remove nuts from piston rod guides (27). Lift the cylinder up and out of the guide hole in the base of the outer rail assembly.

4-175. DISASSEMBLY. (See figure 2-34).

a. Remove plunger retainer (13). Remove "O" ring (19), wiper ring (20), and garter spring (21). Pull plunger assembly (3) out of shell (2).

b. Remove roll pin (5), and remove spacer (6), and piston retainer (4). Remove snap ring (14) and remove piston (7) from retainer (4).

c. Remove "O" ring (10) and back-up ring (13). Remove packing assembly (8). Packing assembly (8) consists of V-rings (9), packing set (10), and adaptor (11).

d. Items 15, 16, and 17 have been removed previously in step 4-174b.

4-176. REPAIR.

a. Replace entire packing assembly (8). Replace both "O" rings (12 and 19). Replace wiper ring (20).

b. Examine all parts carefully for scratches, wear or other damage.

4-177. REASSEMBLY. (See figures 2-34). Reassemble in reverse order of disassembly.

a. Dip new "O" rings and packing in clean hydraulic fluid to facilitate assembly and to prevent damage to these parts.

b. Assemble piston (7), packing (8), "O" ring (12), back-up ring (13), to retainer (4), and secure with snap ring (14).

c. Install lift cylinder on mast assembly, with lower end of cylinder in guide hole in base of outer rail assembly. Attach flange and piston head assembly (22, figure 2-37) to rails. Connect upper and lower tubes with spring, washer, and spacer (15, 16, and 17) in place as shown. Install chains and adjust as explained in paragraph 4-182.

d. Check hydraulic fluid level in tank and replenish as necessary, according to lubrication instructions (figure 1-10). Start the engine and operate at an idle speed. Pull back on the lift control lever to fill the cylinder. Operate the cylinder several times, raising and lowering the mast assembly.

e. Bleed the system as follows: Jack up the forks enough to gain access to the lower tube; crack the flared nut on

this rule to allow the air in the cylinder to escape. Start the engine and move the lift control lever slowly to the rear. When pure fluid (with no bubbles) is being forced out around the nut, tighten the nut.

4-178. MAST AND RELATED PARTS. The simplex and duplex mast assemblies are similar. Refer to figure 2-36 or 2-37 for proper mast.

4-179. REMOVAL.

a. Remove forks by disengaging levers, and sliding forks to notch in lower carriage bar for removal.

b. Secure mast assembly with hoist. Disconnect hydraulic lines. Remove pins holding tilt cylinders to mast. Remove clamp block (7, figure 2-28). Remove mast assembly from truck.

4-180. DISASSEMBLY. (See figure 2-36 or 2-37).

a. Remove pins (20, figure 2-36 or 21, figure 2-37) and roll carriage assembly (13) out bottom of mast assembly. Remove lift cylinder as explained previously.

b. Slide inner rail assembly (2) out of outer rail assembly (1) until 2 sets of rollers (6) are exposed. Rotate inner rail assembly upward until center rollers are above outer rail. Support inner rail assembly in raised position to allow removal of four shoes (3) from upper end of outer rail assembly. Slide out inner rail assembly. Remove load back rest from carriage.

c. Remove roller assemblies from carriage and inner rail. Remove snap ring (9) and remove roller from pin (10). Remove snap ring (8) and remove bearing (7) from roller (6). Remove thrust roller pin (12) and roller (14).

d. On duplex mast (figure 2-36), remove snap ring (23) and remove chain sheave (25) from sheave support (20). Remove snap rings (16) and remove bearing (28) from sheave (25).

e. On simplex mast (figure 2-37), remove set screw and remove piston head (22) from cylinder. Drive roll pin into pin (20), just far enough to allow removal of pin. Do not drive roll pin in so far as to embed it in the casting. Remove sheave (24) and bushing (25).

4-181. REPAIR. Examine all parts carefully for wear or damage, and discard faulty components. Examine tie bushings in the lift truck frame.

4-182. REASSEMBLY. Reassemble in reverse order of disassembly.

a. Stake screws (11) in two places when rollers are re-installed. Stake thrust roller pins (12) from front side of carriage, at both ends of slot in pin.

b. Use shims (5) under mast shoes (3) as required to obtain minimum clearance between inner and outer rails.

c. To adjust lift chains, first move forks to the extreme

ends of fork bar and lower forks until left cylinder is completely collapsed. Adjusting is to be done with no load on forks. Set the upright in a vertical position.

d. Turn the chain anchor rods into chain anchors as far as threads will allow (at 1, figure 1-37).

e. Fork-to-floor clearance (at 2, figure 1-37) will range from 6 to 3/4 inch, depending on tire deflection and machine tolerances.

f. Attach tension scale as shown (3, figure 1-37), apply force, and measure the deflection in the chain. Attach scale at same height to opposite chain, apply same force and measure deflection in chain.

g. Adjust spherical nuts (4, figure 1-37) until deflection is equal on both chains with equal tension. Keep spherical nut and jam nut as close to end of anchor stud as possible and still obtain above adjustments. This will allow lowest possible position of forks. Tighten jam nuts.




Fig. 1-37. Adjusting Chains

1. Turn stud into anchor
2. Fork-to-floor clearance
3. Tension scale
4. Spherical nuts

FOREWORD

This catalog contains a complete list of parts for the MY 40 and MY 60 Lift Trucks. To assist in determining the part numbers and descriptions, the parts in this catalog are grouped according to their location on the Lift Truck. Reference numbers only are shown in each illustration. These numbers correspond to those in the reference number column in the list of parts which precedes each "exploded view."

TYPICAL PARTS ARE SHOWN, AND MAY NOT ALWAYS BE IDENTICAL WITH CURRENT PARTS. REFER TO THE TEXT.

To further assist in locating repair parts, the part numbers are arranged in numerical sequence and indexed on pages 57 - 96.

Component parts of assemblies are listed following the assembly itself and are identified as being part of the assembly by this notation following the description:

Consists of the following.....part:

or

Includes the following.....parts:

Part numbers only make up an assembly. Hardware items are not to be included.

Parts such as standard bolts, nuts, screws, washers, etc., are indented and listed under the respective individual parts with which they are used.

"Right or Left" is determined by facing the mast from the Mohlift seat.

When in need of repair parts always order the parts from your Mohlift dealer or from the branch house nearest you. All parts orders should plainly specify your name, post office address and whether shipment is to go by parcel post, express or freight.

Before returning repair parts it is necessary to secure written permission from the company authorizing the return of such parts. In the returning of repair parts be sure the package is tagged with your name and address. Prepay transportation charges.

Claims of shortage or breakage should be made to the transportation company on receipt of goods.

It is the policy of Minneapolis-Moline, Inc. to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements in the design or construction of parts at any time without incurring the obligation to install such changes on products previously delivered.



GROUP INDEX

Air Cleaner	10
Battery Box and Cables	28
Brakes	46-48-50
Breather	5
Camshaft	8
Carburetor	14
Coil, Ignition	26
Connecting rods	10
Control Valve, hydraulic	68-70
Control Valve, transmission	36
Converter, transmission case	32
Counterweight	60
Crankcase	4
Crankshaft	16
Cylinder Block	6
Cylinder Head	8
Decals and Instruction Plates	61
Differential	44
Distributor	26
Drive Axle	44
Fan	21
Floor Plate	66
Flywheel	10
Frame	60
Fuel Pump	13
Fuel Tank and Lines	20
Gas Manifolds	12
Generator	28
Governor	16
Head Lamps	28
Hood	62
Horn	23
Horn Button	55
Hydraulic Pump	64-66
Instrument Panel	50
Lamps	29
Lifting Eye	6
Lift Cylinder	74-76
LP Gas Equipment	13
Mast	78-82
Master Cylinder	50
Muffler	22

GROUP INDEX (CONT'D)

Oil Filler	4
Oil Filter, engine	22
Oil Filter, hydraulic	64
Oil Pump	22
Overhead Guard	60
Pistons and Rings	10
Power Steering Booster and Linkage	58
Push Rod	8
Radiator	24
Reel and Hoses	72
Rocker Arms	8
Seat	82
Splash Plugs	26
Starting Motor	25
Steering Axle	40-42
Steering Gear	64-66
Tappers	8
Tail Lamps	28
Thermostat	24
Throttle Controls	17
Tilt Cylinder	72
Transmission	34
Transmission Case	32
Valves	8
Voltage Regulator	28
Water Pump	21
Wheels, Front and Rear	52
Wiring Harness	30
NUMERICAL INDEX	87-95

MOELLIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
CRANKCASE			
1	11R65C3	Crankcase - assembly	1
Includes the following 10 parts:			
2		GM172699 - Plug, expansion, 2-1/2"	1
		GM444740 - Plug, pipe, square head, 3/8"	2
		GM444746 - Plug, pipe, square head, 1/2"	1
		GM241339 - Bushing, reducer, 1/4" to 1/8"	1
3	10A6348	Plug - slotted, 1/8"	1
4	10A6387	Cap - bearing, camshaft, front and center	2
5	10A6381	Cap - bearing, camshaft, rear	1
		GM179846 - Bolt, hex, head, 3/8"-16 x 2-3/4"	6
6	10A6380	Bushing - oil pump shaft	2
7	10A6378	Pin - down, oil pump	2
8	10A6025	Bushing - governor shaft, 1/2" long	2
9	10A6023	Seal - oil, governor shaft, 17/16" O.D.	1
10	10A10202	Tube - oil, front and center crankshaft bearing	2
		GM113953 - Screw, rd. head, 1/4"-20 x 1/2"	4
11	10A5373	Tube - oil, rear crankshaft bearing	1
12	10A6588	Connector - rear oil tube (in crankcase)	1
		GM114619 - Connector, 3/16" tube	1
14	11A599C	Bearing - crankshaft, front and center, standard	3
		GM340955 - Bolt, self locking, 1/2"-13 x 2-1/2"	4
15	10A6099	Washer - self locking bolt, 17/32" I.D.	4
16	11P6421	Housing - with rear crankshaft bearing	1
		GM17986A - Bolt, hex, head, 1/2" 13 x 1-1/2"	6
17	11A6873	Bearing - crankshaft, rear standard	1
18	10A5285	Washer - bearing cap bolt	2
19		GM4824 - Bolt, self locking, 3/16"-14 x 2-1/4"	5
20	10A6417	Gasket - rear bearing housing	2
21	11A6418	Retainer - with oil seal, rear	1
		GM113966 - Screw, rd. head, 1/4"-20 x 1/2"	6
22	10A6558	Seal - oil, rear retainer	1
23	10A7418	Gasket - oil seal retainer	1
24	10A2025	Strainer - oil (float & screen)	1
25	10A7484	Connector - float & screen	1
26	11A16004	Dip stick	1
27	10A16008	Cover - side	1
		GM179839 - Bolt, hex, head, 3/8"-16 x 1/2"	15
28	10A5838	Stud - side cover, 3/8"-16 x 1-1/16"	2
29	10A9850	Stud - side cover, 3/8" x 1-1/8"	4
30	10A9072	Stud - side cover, 3/8" x 1-3/8"	4
31	10A1549C	Washer - side cover, 1/32" thick	1
32	10A79491	Shim - side cover, .006 thick	1
33	10A9304	Cover - timing belt	1
		GM113955 - Screw, rd. head, 1/4"-20 x 1/2"	1
34	10A28633	Cover - front end of crankcase	1
		GM179912 - Bolt, hex., 5/16"-16 x 1/2"	2
35	10A76815	Stud - timing pointer, 5/16" x 2-3/4"	1
36	10A12361	Seal - oil, for cover	1
37	10A6020	Gasket - oil seal cover	1
38	10R675	Gasket Set - engine overhaul	1
39	0E174D	Adapter - fuel pump	1
40	10A9181	Gasket - adapter to side cover	1
41	11A16927	Pipe - extension, dipstick	1
		GM116331 - Nut, lock, 1/8"-27 N.P.T.	1
42	10A4538	"O" Ring - extension, 3/8" I.D., 1/2" O.D.	1
43	10A5087	Cover - fuel pump adapter	1
44	10A0843	Gasket - cover to adapter	1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
CRANKCASE (Cont'd)			
40	10A18060	Strap - pipe extension	1
42	10A18078	Support - pipe assembly	1
42	10A10461	Breather	1
48	30A2920	Tube - breather	1
44	10A18051	Adapter - breather tube	1
45	10A18090	Bolt - adapter attaching	1
46		GM18042P - Gasket, bolt and adapter	1
	10A18027	*Cover - side	1
	10A0836	*Gasket - side cover	1
	10A6381	*Cover - small, for large side cover	1
	10A0851	*Gasket - small cover	1
	10A10842	*Support - breather, and fuel pump	1
	10A18040	*Gasket - breather support	1
		*NOTE: Used on MY 60 Lift Trucks.	




Fig. 2-1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
CYLINDER BLOCK, CYLINDER HEAD, AND BREATHER			
1	11A196E2	Block - cylinder, with expansion plugs Includes the following part:	2
		GM444794 - Plug, pipe, slotted, 3/4"	2
		GM108647 - Valve, drain, 1/4"	2
		GM179828 - Bolt, hex., 1/2"-13 x 1-7/8"	6
		GM179806 - Bolt, hex., 1/2"-13 x 3-3/4"	6
		GM190276 - Bolt, hex., 1/2"-13 x 4-1/4"	4
2	10A4033	Plug - expansion, 1-1/4"	4
3	10A5962	Plug - rear cylinder block and head	2
4	10A10007	Tube - between cylinder blocks and heads	2
5	10A3056	Seal - "O" ring, rear plug and center tube	6
6	10A7252	Gasket - cylinder block to crankcase	2
7	10A826	Head - cylinder, with valves not assembled	2
7	11A5521A	Head - cylinder, with guides and inserts	2
		GM118666 - Plug, pipe, socket head, 1/2"	1
11	10A6103	Plug - expansion, 1-1/4"	4
12	10A13607	Gasket - cylinder head to cylinder block	2
	10A10756	Stud - cylinder block and head, 1/2" x 6-3/4"	1
13	10A5000	Stud - cylinder block and head, 1/2" x 6-7/16"	6
14	10A5036	Stud - cylinder block and head, 1/2" x 6-7/16"	5
15	10A5937	Stud - cylinder block and head, 1/2" x 5-13/16"	6
		GM100058 - Nut, hex., 1/2"-20	18
16	10A10045	Adapter - cylinder head to cover	1
		GM172816 - Bolt, hex., 3/8"-16 x 1-3/4"	2
17	10A8009	Gasket - adapter to cylinder head	1
18	10A19536	Cover - cylinder head	1
		GM114503 - Nut, hex., jam, 3/8"-16	4
19	10A6428	Washer - copper, cylinder head cover	4
20	10A8006	Gasket - cylinder head cover	1
21	10A5946	Stud - cylinder head cover, 3/8" x 5"	4
22	10A3020	Sparer - cylinder head cover, 7/16" x 1"	4
	10A10804	Eye - lifting, on cylinder head studs	1




Fig. 2-2

MORHIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		CAMSHAFT, ROCKER ARMS, VALVES, PUSH RODS AND TAPPETS	
1	10A14043	Camshaft	1
2	10A16945	Gear - timing, 60 teeth	1
3	10A6402	Gear - oil pump drive, 18 teeth	1
		GM102306 - Key, Woodruff, No. 5	2
4	10A6352	Washer - gear retainer	1
5		GM179839 - Ball, hex., 3/5" x 1"	1
6	10A6353	Arm - rocker, front intake and rear exhaust	4
7	10A6351	Arm - rocker, front exhaust and rear intake	4
8	10A19E79	Screw - adjusting rocker arms	8
		GM114484 - Nut, hex. jam, 3/8"-24	8
9	10B5973	Shaft - rocker arms, with rubber plugs	1
		Includes the following parts:	
		GM103385 - Pin, roller, 1/6" x 1"	2
10	10A7207	Plug - rubber, 1/2" dia.	2
12	10A7206	Spring - rocker arms, 1-9/16" long	2
13	10A7205	Spring - rocker arms, 2-9/16" long	1
14	10A5915	Bracket - rocker arms	4
15	10A5948	Stud - rocker arm bracket, 3/8" x 3"	4
		GM102695 - Nut, hex., 3/8"-10	4
		GM114503 - Nut, hex., jam, 3/8"-16	4
16	10A7202	Tube - oil rocker arms	1
17	10A6310	Pipe - supply, oil tube	1
18	10A6313	Nut - oil supply pipe	1
		50A2041 - Washer - plain, 1/2"	1
19	10A6315	Seal - oil supply pipe	1
	10A10040	Cup - seal retainer	1
20	10A6429	Valve - intake	4
21	10A6509	Valve - exhaust	4
22	10A6433	Spring - valve	8
23	10A6408	Seat - valve spring	4
24	10A6040	Rotocap - exhaust valve	4
25	10A6410	Lock - valve spring seat	10
26	10A6444	Lock - exhaust valve	4
27	10A6953	Guide - valve	8
28	10A6478	Push Rod	4
29	10A6385	Tappet (valve lifted)	8
	103372	Gasket Set - valve grinding overhaul	1




Fig. 2-2

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Qty. No.	Part No.	DESCRIPTION	No. Pcs.
CRANKSHAFT, CONNECTING RODS, PISTONS, RINGS AND FLYWHEEL			
1	1060E32	Crankshaft - with gear and dowel pins	1
2	10A5912	Plc - cover	2
3	10A18353	Gear - timing, 26 teeth,	1
4		GM106751 - Key, Woodruff, No. 9	1
5	11A6870	Bearing - rear, standard	1
5	11A6871	Bearing - rear, .0025 undersize	1
5	11A6872	Bearing - rear, .005 undersize	1
5	11A6873	Bearing - rear, .020 undersize	1
5	11A6874	Bearing - rear, .040 undersize	1
6	11A5980	Bearing - front and center, standard	2
6	11A5981	Bearing - front and center, .0025 undersize	2
6	11A5982	Bearing - front and center, .005 undersize	2
6	11A5983	Bearing - front and center, .020 undersize	2
6	11A5984	Bearing - front and center, .040 undersize	2
7	10A166E4	Pulley - fan drive	1
8		GM271560 - Bolt, hex., 5/8"-11 x 1-3/4"	1
9		GM10E237 - Washer, plain, 11/16"	1
10	10A8423	Key - fan drive pulley, 1/4" x 1/4" x 1-1/2"	1
11	11A4860	Piston - with pin and retainer, standard	4
11	11A17475	Piston - with pin and retainer, .020 O.S.	4
11	11A17476	Piston - with pin and retainer, .040 O.S.	4
12	10A4861	Pin - piston, standard	4
12	10A17477	Pin - piston, .005 oversize	4
13	10A4959	Retainer - piston pin	4
14	10R993	Rings - set for 2 pistons, standard	2
14	10R999	Rings - set for 2 pistons, .020 oversize	2
14	10R994	Rings - set for 2 pistons, .040 oversize	2
15	11R18863	rod - connecting, with bearing and bushing	4
16	10A18726	Bolt - self locking, connecting rod	8
17	10A4865	Bushing - piston pin, 1" I.D., 1-7/16" long	4
18	109420	Bearing - connecting rod, standard	4
18	109424	Bearing - connecting rod, .0025 undersize	4
18	104491	Bearing - connecting rod, .005 undersize	4
18	109423	Bearing - connecting rod, .020 undersize	4
18	109423	Bearing - connecting rod, .040 undersize	4
19	11A15555	Flywheel - with ring gear	1
20	10A7557	Gear - starting ring	1
21		GM9409049 - Bolt, locking, 7/16"-20 x 1-1/2"	4
22	10A5285	Washer - flywheel belt	4




Fig. 2-4

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Qty. No.	Part No.	DESCRIPTION	No. Pcs.
GAS MANIFOLD, AIR CLEANER AND MUFFLER			
1	10A7695	Manifold - exhaust	1
2	10A9227	Clamp - manifold	4
3	10A7447	Stud - manifold clamp	2
		50A1008 - Nut, hex., seaz-proof, 7/16"-14	4
1	10A5929	Gasket - exhaust manifold	2
2	35A2234	Connector - exhaust manifold to muffler	1
3	35A2238	Gasket - exhaust connector and cover	2
7	10A7921	Cover - exhaust manifold	1
8	10A7720	Manifold - intake	1
9	10A9027	Stud - intake to exhaust manifold	4
		GM102935 - Nut, hex., 3/8"-16	4
10	10A7613	Gasket - intake manifold to carburetor	1
11	10A16904	Air Cleaner	1
		Consists of the following 3 parts	
12	10P1372	Base - assembly	1
13	10P1373	Filter	1
14	10P1374	Cover	1
15		GM120240 - Nut, wing, 19-32 N.F.	1
16	35A1434	Support - air cleaner	1
17	35A1435	Base - cleaner to carburetor	1
		GM103482 - Clamp, hose, 1-1/4"	2
18	35A2400	Muffler - My 40	1
	35A2298	Muffler - My 60	1
19	36A743	Pipe - exhaust - My 40	1
	35A2307	Pipe - exhaust, My 60	1
		GM179339 - Bolt, hex., 3/8"-18 x 1"	2
		50A1000 - Nut, hex., seaz-proof, 3/8"-16	2
20		50A755 - Clamp, pipe to muffler	1
21		GM191536 - Gasket, exhaust pipe	2
22	35A2301	Clamp - assembly, muffler, on frame, My 40	1
		GM185124 - Bolt, hex., 3/8"-16 x 1-1/4"	4
	35A2392	Clamp - muffler, on frame, My 60	2
23	35A2330	Clamp - half, for muffler	2





Fig. 2-5

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
FUEL PUMP			
1	1A10338	Pump - fuel, assembly	1
		(includes the following 19 parts:	
		GM103886 - Plug, pipe, 1/8"	1
2	10P1875	Diaphragm and pull rod	1
3	10P186F	Spring - diaphragm	1
6	10P187G	Arm - rocker	1
7	10P188G	Pin - rocker arm	1
8	10P188T	Retainer - rocker arm pit	2
9	10P186B	Spring - rocker arm	1
10	10P187F	Cap - rocker arm spring	1
11	10P186D	Cover - bottom	1
		GM100650 - Screw - fill, hd. No. 10-32 x 3/8"	3
12	10P188I	Gasket - bottom cover	1
13	10P187Y	Bowl - fuel, metal	1
14	15P23	Gasket - fuel, bowl	1
15	15P24	Screen	1
16	10P247	Bail - assembly, fuel bowl	1
17	10P1889	Valve and cage	2
18	10P1882	Gasket - valve and cage	2
19	10P1883	Retainer - valve and cage	1
20	10P1883	Link	2
21	10P1884	Pin - link	2
22	10P187J	Clap - link pin	4
23	10A 664U	Gasket - fuel pump to adapter	1
		GM179517 - Bolt, fuel pump to adapter, 5/16"-18 x 7/8"	2
		GM103820 - Washer, lock, 5/16"	2
	11A16913	Tube - fuel pump to carburetor	1
		GM140281 - Nut, 5/16" flared tube	1
		GM142427 - Nut, 5/16" tube, inverted flange	1
		30A5481 - Elbow, steel, 1/8", 90°	1
		GM137422 - Elbow, 5/16" flared tube, 90°	1



MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs.
		CARBURETOR	
	10A16902	Carburetor - (Schobler Model 75X 325)	1
		GM215385 - Bolt, hex., 5/16"-18 x 1"	2
1	10P1892	Body - throttle, upper half	1
		Includes the following 3 parts:	
2	10P1203	*Shaft - throttle, assembly	1
3		GM100714 - Screw, fillister head, No. 8-32 x 3/4"	1
4	10P750	Spring - throttle lever screw	1
	10P1793	Spring - throttle lever stop	1
5	10P740	Disc - throttle	1
6		*GM192256 - Screw, pan hd., No. 6-32 x 1/4"	2
7	10P786	*Packing - throttle shaft	1
8	10P750	Retainer - throttle shaft packing	1
9	10P771	*Cup - throttle shaft	1
10	10P744	Bowl - fuel, lower half	1
11		GM100675 - Screw, fillister head, No. 12-24 x 3/4"	4
		GM114581 - Valve, drain	1
12	10P719	+Gasket - fuel bowl to body	1
13	10P1801	Float	1
14	10P759	*Shaft - float lever	1
	10P776	Bracket - float lever	1
15	10P775	*Valve - seat and gasket (matched)	1
16	10P747	+Gasket - seat	1
17	10P786	Venturi	1
18	10P760	*Needle - idle adjusting	1
19	10P751	*Spring - idle adjusting needle	1
20	10P769	*Jet - idle	1
21	10P767	Nozzle - main	1
22	10P74E	*Gasket - nozzle	1
23	10P762	Adjustment - main, assembly	1
		Includes the following 3 parts:	
24	10P761	Needle - main adjustment	1
25	10P772	Retainer - main adjustment needle packing	1
26	10P704	Packing - retainer	1
27	10P65	+Gasket - main adjustment assembly	1
	10P1891	Plug - power jet retainer	1
28	10P769	*Jet - power	1
29	10P1799	Shaft - choke, with lever	1
30	10P753	*Packing - choke shaft	1
31	10P754	Disc - choke	1
32		*GM192256 - Screw, pan hd., No. 6-32 x 1/4"	2
33	10P792	*Cup - choke shaft	1
	10P1800	Bracket - choke assembly	1
34	10P1747	Bracket - choke	1
35		GM121263 - Screw, fillister head, No. 8-32 x 3/8"	1
36	10P758	Clip - choke bracket	1
37		GM121958 - Screw, fillister head, No. 8-32 x 5/16"	1
38	10P755	Swivel - choke	1
39		GM113625 - Screw, fillister head, No. 8-32 x 5/16"	1
40	10P774	Pin - choke swivel	1
41	10P782	*Spring - choke return	1
	10P1830	*Repair Kit - carburetor	1
		NOTE: Repair Kit includes the above items identified with an asterisk ()	
	10P1832	+Gasket Set - carburetor	1
		+NOTE: Gasket Kit includes the above items identified with a cross (+).	






Fig. 1-7

MOELLER - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
GOVERNOR			
1	10A14877	Governor - assembly	1
		Includes the following 9 parts:	
2	10P1653	Carrier - assembly	1
3	10P1630	Riser and Sleeve - assembly	1
4	10P1637	Race - bearing	1
5	10P1641	Ring - retainer, bearing race	1
6	10P1642	Retainer - with steel balls	1
7	10P1638	Roller - weight, assembly	2
10	10A6818	Fork - governor control	1
11	10A10444	Screw - set, governor fork, 5/16" - 13 x 1/2"	1
12	10A10446	Shaft - with lever, governor fork	1
13	10A9025	Pushing, lever shaft, 1/2" I.D.	2
14	10A10655	Seal - oil, lever shaft, 1/2" I.D.	1
15	10A72186	Pin - lever shaft	1
		GM103373 - Pin - cover, 3/32" x 3/4"	1
16		GM103340 - Washer - plain, 5/16"	2
17	10A15485	Rod - control, lever shaft pin to carburetor	1
		GM108872 - Pin - cover, 3/32" x 1/2"	1
18	10A14878	Spring - with plunger assembly	1
19	10A10943	Rod - adjusting, spring to throttle rod, 1/4" x 6-7/8"	1
		GM114482 - Nut - adjusting rod, 1/4" - 28	4
20	10A16697	Guide - adjusting rod	1





Fig. 2-8

MODEL - MY 40 AND 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
THROTTLE CONTROLS			
1	10A10601	Pedal - foot accelerator	1
		GM180077 - Bolt, hex., 5/16"-28 x 3/4"	-
		GM120376 - Nut, hex., 5/16"-18	1
2	36A523	Shaft - cross, with supports	1
		GM180099 - Bolt, hex., 1/2"-20 x 3/4"	4
		GM120375 - Nut, hex., 1/4"-20	4
		GM120393 - Washer, plain, 11/32"	2
		GM121022 - Pin, cotter, 1/16" x 3/4"	2
3	36A122	Link - pedal to cross shaft, 5-1/2" long	1
		GM120409 - Pin, cotter, 3/16" x 1-1/2"	1
4	10A10949	Spacer - pedal link, 1/4" O.D. x 9/16"	1
5	36A1276	Rod - cross shaft to gov. rod, 1/4" x 31-3/8", MY 40	1
	36A1286	Rod - cross shaft to gov. rod., 5/16" x 30-1/8", MY 60	1
6	10A307	Spring - throttle rod	1
7	36A1275	Clip - spring anchor, L shape, 5" long	1



MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
LPG GAS EQUIPMENT			
1	D118E	Tank - fuel, with fittings	1
2	35P516	Strap - mounting, fuel tank, right hand	1
3	35P508	Strap - mounting, fuel tank, left hand	1
4	35P518	Plate - support, mounting straps, MY 40	1
	35P541	Plate - support, mounting straps, MY 60	1
5	35P506	Vaporizer	1
6	35P509	Elbow - vaporizer to hose	2
7	35P510	Connector - vaporizer to hose	1
8	35P511	Plate - support vaporizer	1
		GM179799 - Bolt, 1/4"-20 x 1"	2
		GM109084 - Nut, hex., 1/4"-20	2
9	35P507	Solenoid	1
10		GM144315 - Connector, solenoid to hose	1
11	35P513	Carburetor	1
12		GM144369 - Elbow, carburetor to hose	1
13	35P512	Hose - vacuum, 3/32" I.D. x 20"	1
14	35P514	Filter	1
15		GM144355 - Elbow, filter to hose	2
16	35P515	Valve - relief, filter	1
17	35P520	Hose - filter to tank coupling	1
18	35P519	Coupling - hose to tank, female	1
19	35P517	Coupling - hose to tank, male	1
20	35P527	Hose - filter to solenoid	1
21	35P521	Hose - vaporizer to carburetor	1
22	35P523	Hose - vaporizer to water pump	1
23	35P509	Elbow - hose, to water pump	1
24	35P527	Bracket - water pump hose, 1" x 3"	1
25	35P524	Hose - vaporizer to cylinder block	1
26	35P529	Elbow - hose, to cylinder block	1




Fig. 2-10

MOELLIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		FUEL TANK, LINES AND FITTINGS	
		Fuel Tank - see main frame on page	
1		GM103881 - Plug, pipe, sq. hd., 5/4"	1
2	56A1456	50A133 - Valve, shut-off, 1/8"-27	1
3		Hose - tank to pump, 37-1/2" long	1
4	56A178	50A2481 - Elbow, street, 1/8", 90°	1
		Filter - assembly	1
		Includes the following 8 parts:	
5	56F55	Cap - filter	1
6	55F488	Pin - cap, 5/32" x 22/32"	1
7	55F56	Arm - cap	1
8	55F487	Pin - arm, 3/16" x 1-3/8"	1
9	55F57	Spring - arm	1
10	55F58	Catch - arm	1
11	55F169	Pin - catch, 3/16" x 1-5/32"	1
12	56F59	Flange - cap	1
13	55F60	Screen - assembly	1
14	55A1059	Unit - sending, fuel gauge, MY 40	1
	56A1060	Unit - sending, fuel gauge, MY 60	1
		GM113002 - Screw, round head, No. 10-32 x 7/16"	6
15	10A8815	Gasket - sending unit	1
16		*GM 178425 - Cap, fuel tank, in frame, 2" dia.	1





Fig. 2-11

MOBILEE • MY 4E AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
WATER PUMP AND FAN			
-	10A996	Pump - water, assembly Includes the following 6 parts:	1
		GM143162 - Plug, pipe, socket head, 3/8"	1
2	10A5918	Shaft - with bearings	1
3	10A7903	Ring - oil slinger, 5/8" L.D.	1
4	10A7183	Lock - spring, shaft to housing	1
5	10A3046	Seal - water pump	1
6	10A6006	Impeller	1
7	11A9203	Pulley - fan and water pump	1
8	10A7894	Hub - fan	1
9	10A9596	Cover - water pump, also support GM179828 - Bolt, hex., 3/8"-18 x 1" GM179824 - Bolt, hex., 5/16"-18 x 3/4" GM179825 - Bolt, hex., 5/16"-18 x 1-1/8" GM179821 - Bolt, hex., 5/16"-18 x 1-3/8" GM102634 - Nut, hex., 5/16"-18	1 3 3 1 1 3
10	10A7201	Gasket - cover to pump housing	1
11	10A16423	Belt - water pump and fan	1
12	11A7890	Tube - water pump to cylinder block	1
13	10A5906	Seal - "O" ring, water pump tube, 1-3/64" L.D.	2
14	10A1290E	Bracket - water pump support GM179820 - Bolt, hex., 5/16"-18 x 1-1/4" GM102634 - Nut, hex., 5/16"-18 GM102343 - Washer - plate, 11/32" L.D.	1 3 1 1
15	10A16123	Blade - fan GM179820 - Bolt, hex., 5/16"-18 x 1-1/4"	1 4



MORILLIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No Pcs
OIL PUMP			
1	10A1183U	Body - oil pump, assembly	1
		50A2473 - Elbow, oil pump body, 1/4", 90°	1
2	10A6386	Plug - underside of oil pump body	1
3	10A6406	Shaft - idler gear	1
4	10A7802	Valve - check	1
5	10A525	Spring - check valve	1
6	10A1172	Retainer - check valve spring	1
7	10A6382	Cover - check valve	1
8		GM102396 - Screw-set, check valve cover, 5/16"-19 x 2"	1
9		50A1041 - Nut, set screw, 5/16"-19	1
10		GM124429 - Gasket, copper, 3"	1
11	10A6366	Gasket - lead, set screw	1
12	10A3397	Washer - copper, set screw	1
13	10A9375	Gear - idler	1
14	10A6400	Gear - drive	1
		GM103905 - Key, drive gear, Woodruff No. 5	2
15	13AE413	Shaft - drive oil pump, 5/8" x 15-3/4"	1
16	10A6314	Piston - drive shaft	1
		50A2832 - Pin, roll, 3/16" x 1"	1
17	10A6360	Bushing - drive shaft	2
18	10AE413	Bushing - grooved, above piston	1
		GM102730 - Screw, set, 3/8"-26 x 1-1/2"	1
		GM102835 - Nut, hex., 3/8"-16	1
19	10A6312	Coupling - drive shaft to distributor	1
		50A2843 - Pin, roll, 3/16" x 1-1/4"	1
20	10AC387	Gasket - body to crankcase	1
21	10A6431	Stud - body to crankcase, 3/8"-18 x 1-3/16"	4
		GM102635 - Nut, hex., 3/8"-16	4
22	10A6373	Pin - bushel, body to crankcase	2
		GM179939 - Bolt, 3/8"-16 x 1"	1
OIL FILTER			
27	10A14373	Filter - oil, spin-on	1
28	10A15E97	Base - oil filter	1
29	10A16009	Support - filter base	1
		GM179683 - Bolt, hex., 1/2"-10 x 1-1/4"	3
		GM173841 - Bolt, hex. head, 3/8"-16 x 1-1/4"	2
		GM102885 - Nut, hex., 3/8"-16	4
30	10A17879	Hose - with couplings	2




Fig. 2-13

MOBILE - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per
RADIATOR			
1	35A2931	Radiator, with pressure cap, MY 40	1
	35A810	Radiator, with pressure cap, MY 60	1
2	35P29	Cap - pressure, Perfox No. G-13594	1
3		GM103647 - Valve, drain, 1/4"	1
4		GM100126 - Bolt, hex., 3/8"-16 x 1-1/2"	4
5		GM106301 - Nut, lock, 3/8"-16	4
6		GM100394 - Washer, plain, 3/8"	6
7	10A1577	Washer - fabric, 7/16" I.D., 2" O.D.	4
HOSES - THERMOSTAT			
8	10A10387	Hose - inlet	1
9		GM105478 - Clamp, hose, 1-3/4"	1
9		GM105499 - Clamp, hose, 1-7/8"	1
10		GM100461 - Clamp, hose, 2-1/8"	1
11	10A10638	Hose - outlet, MY 40	1
	35A1247	Hose - outlet, MY 60	1
12		GM103463 - Clamp, hose, 2"	2
13	10A10688	Tube - metal, cyl. head to hose, MY 40	1
	35A2742	Tube - metal, cyl. head to hose, MY 60	1
14	10A2956	Seal - "O" ring, metal tube, 1-3/8" I.D.	1
15	10A10329	Clamp - tube retainer, on cyl. head bolt	1
16	10A16460	Thermostat - 180°, Dole Valve Co. No. 5V11-180	1




Fig. 2-14

MORILIFT - MY 40 AND MY 63 LIFT TRUCKS.

Ref. No	Part No.	DESCRIPTION	No. Pcs.
DISTRIBUTOR, IGNITION COIL, CABLES AND SPARK PLUGS			
1	10A1881E	▼ Distributor - with coupling (Delco-Remy No. 1112606)	1
2	10P635	Coupling - distributor shaft	1
3	10P636	Pin - coupling to shaft	1
▼ Note: Order replacement parts for Distributor direct from Delco-Remy Division or United Motor System.			
4	10A6485	Support - distributor	1
		GM179841 - Bolt, hex., 3/8" - 16 x 1-1/4"	2
5	10A6427	Gasket - support to crankcase	1
6	10A6399	Gasket - bracket to distributor	1
7	10A6390	Clamp - distributor hold-down	2
		GM179840 - Bolt, hex., 3/8" - 16 x 1-1/8"	2
9	10A7412	Coupling - oil pump shaft to distributor coupling	1
10		50A2643 - Pin, roll, 3/16" x 1-1/4"	1
11	10A1881T	Coil - ignition, Delco-Remy No. 1118068	1
12		GM431509 - Nipple, rubber, 3/4" I.D.	1
		GM179816 - Bolt, hex., 5/16" - 18 x 3/4"	2
		GM103340 - Washer, plain, 11/32"	2
		GM102674 - Nut, hex., 5/16" - 18	2
13	85A2105	Support - ignition coil	1
		GM179816 - Bolt, hex., 5/16" - 18 x 3/4"	1
14	10A12342	Cable - high tension, coil to distributor, 19" long	1
		GM431608 - Nipple, rubber, 9/16" I.D.	1
15	10A6505	Cable - low tension, 14" long	1
16	L1R3	Cables - ignition set, with nipples	-
17		GM431508 - Nipple, rubber, 3/16" I.D.	5
18	109319E	Clip - with grammet, 5/8"	1
19		GM120013 - Grammet, No. 9	1
	102385	Spark Plug - No. 9 comm. or D-16	4




Fig. 2-12

MOBILE - MY 40 AND MY 60 LIFT TRUCKS

Qty. No	Part No	DESCRIPTION	No. Pcs
		GENERATOR, VOLTAGE REGULATOR, STARTING MOTOR, HORN AND LAMPS	
1	10A18922	*Generator (Delco-Remy No. 1100305)	1
2	10A18297	Pulley - generator, with fan	1
2	10A18338	Support - generator	1
		GM179839 - Bolt, hex., 3/8"-18 x 1"	2
		GM179818 - Bolt, hex., 5/16"-18 x 1"	2
		GM102E34 - Nut, hex., 3/16"-19	2
4	10A9745	Bar - generator adjusting	1
		GM179816 - Bolt, hex., 5/16"-18 x 3/4"	1
		GM102E40 - Washer, plain, 11/32"	1
5	10A17540	*Regulator - voltage, (Delco-Remy No. 1118902E)	1
	35A2139	Harness - wiring, generator, to regulator	1
6	10A9758	*Motor - starting (Delco-Remy No. 1106167)	1
7	10A8959	Screw - lock starting motor	1
		GM145E7 - Nut, hex, jam, 5/8"-11	1
		*NOTE: Order replacement parts for Generator, Regulator and Starting Motor direct from Delco-Remy Division or United Motor System.	
8	10A10689	Horn - Delco-Remy No. 9030309	1
		GM4E4750 - Nut, grip, 1/4"-28	2
9	10A10730	Bracket - horn	1
10	35A403	Horn Relay	1
	10A9746	Wire - horn relay to horn, 12" long	1
	35A509	Wire - horn button wire to horn relay, 4" long	1
11	10A16321	Lamp - head, with sealed unit	1
12	10P1553	Unit - sealed	1
13	10P1552	Molding - sealed unit	1
14	38AE31	Support - head lamp	1
		GM190238 - Nut, hex, jam, 1/2"-16	1
15	35AE32	Plate - retainer, head lamp support	1
		GM1B0123 - Bolt, hex., 3/8" 16 x 1-1/8"	2
16	35A741	Disc - tension, lamp support, 1" dia.	1
	15A15007	Clip - head lamp wire	1
	35A3004	Wire - with ins., 56" long	1
	35A3008	Wire - extension, 84" long	1
17	35A3001	Lamp - stop or tail light	1
18	35P363	Lens	1
19	35P364	Gasket	1
20	35P36E	Retainer - lens	1
21	35P362	Connector	1
	35A1749	Bracket - tail lamp	1
		GM191652 - Bolt, hex., 3/8"-16 x 3"	1
		GM198377 - Nut, hex., 3/8"-16	1
	35A3007	Wire - tail lamp, 81" long	1
	35A387	Switch - stop light, on Master Cylinder	1
	35A3006	Wire - switch, 42" long	1
	35A3009	Wire - stop light to switch, 77" long	1
	10A7881	Clip - tail lamp wire	1
22	35A3307	Box - battery	1
		GM102E35 - Nut, hex., 3/8"-16	2
23	35A3983	Clamp - battery hold down	1
		GM102E33 - Nut, hex., 3/8"-18	2
24	35A2231	Pin - pivot, battery box, 3/8" x 8-1/4"	1
25	35A3302	Cable - battery to starting motor, 36" long	1
26	35A3301	Cable - ground, engine to frame, 9" long	1
27	35A3303	Cable - ground, battery to frame, 7" long	1




Fig. 2-16

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
INSTRUMENT PANEL			
1	35A2099	Panel - instrument	1
		GM156242 - Screw, round head, 1/4" -20 x 5/8"	12
		GM120373 - Nut, hex., 1/4" -20	19
2	35A214	Gauge - ammeter	1
	35A1068	Wire - ammeter to ignition switch, 8" long	1
3	35A411	Gauge - engine temperature	1
	35A1068	Wire - temperature gauge to oil gauge, 8" long	1
4	35A288	Unit - temperature sending	1
5	35A412	Gauge - oil pressure	1
6	35A368	Unit - sending, oil pressure	1
6A	35A1762	Support - oil pressure, sending unit	1
		GM127384 - Coupling, pipe, 1/8"	1
		GM9402860 - Connector, 1/8" N.T.T. to 7/16" -20	1
	35A1753	Tube - extension, sending unit support	1
7	35A212	Gauge - fuel	1
	35A1067	Wire - fuel gauge to temperature gauge	1
8	35A405	Switch - light	1
	35A1066	Wire - oil gauge to light switch, 3" long	1
	35A3004	Wire - with fuse, light switch, 36" long	1
9	10A1677	Switch - ignition	1
10	10P71	Key - ignition match, set of 2	1
	35A1068	Wire - ignition switch to starting switch, 5" long	1
11	35A406	Switch - starting motor	1
	35A2887	Hour Meter, MY 60	1
12	35A2880	Hour Meter, MY 40	1
13	10A3436	Dampener - vibration, hour meter	1
		GM103737 - Screw, round head, No. 6-32 x 3/8"	2
14	35A210	Light warning	1
15	35A47	Plate - warning light	1
16	35A303	Unit - transmission, warning light	1
	35A1761	Choke lid - with tube and knob, 28" long	1
		GM124823 - Nut, hex, jam, 3/8" -24	1
17	10A2296	Switch - pressure	1
18		GM106494 - Nipple, pipe, close, 1/8"	1
19		GM106416 - Tee, pipe, 1/8"	1
	35A2084	Harness - wiring, upper	1
	35A2080	Harness - wiring, lower	1
	35A1102	Wire - lower wiring harness to coil	1
20	35A30	Plate - brake warning	1
		GM107937 - Screw, drive, No. 6 x 3/8"	2
21	35A1707	Switch - neutral, starting	1
		GM182664 - Screw, round head, No. 4-40 x 1"	2
22	35A2480	Bracket - mounting neutral switch	1
23	35A1754	Cover - switch bracket	1
		GM132900 - Screw, round head, No. 10-32 x 3/8"	1
24	35P525	*Switch - oil pressure	1
25	35P531	*Nut - mounting, oil pressure switch	1
	35P528	*Wire - oil pressure switch, 22" long	1
	35P527	*Wire - oil pressure switch, 31" long	1
26	35P530	*Plug - stop, panel opening	1
		*NOTE: Used on lift trucks equipped for using LP gas.	





Fig. 2-11

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No Pcs
TRANSMISSION CASE, CONVERTER AND PUMP			
1	35A9	Case - transmission.....	1
		GM103865 - Plug, pipe, 1/8"-27.....	3
		GM145649 - Ball, steel, 3/8".....	2
		GM180202 - Bolt, hex., 9/16"-12 x 1-1/4".....	10
		GM180219 - Bolt, hex., 9/16"-12 x 2".....	1
		GM124382 - Nut, hex., 9/16"-12 cad.....	1
2	10A2297	Plug - drain, magnetic, 1/2"-14.....	1
3	35A1260	Valve - relief, 3/4" O.D., 1-1/8" long.....	1
4	35A1549	Piston - relief valve.....	1
5	35A1248	Spring - relief valve, 1" long, 10 coils.....	1
6	10A8329	Seal - "O" ring, relief valve, 3/4" O.D.....	1
7	35A324	Tube - relief valve, 5/16" x 4-55/64", with clip.....	1
8	35A873	Support - angle, tube clip.....	1
		GM160016 - Bolt, hex., 1/4"-20 x 1/2" cad.....	3
		GM120075 - Nut, hex., 1/4"-20.....	3
10	35A1487	Dipstick.....	3
10A	35A1488	Clamp - dipstick.....	1
11	35A989	Sleeve - dipstick, pressed in case.....	1
11A	35A2168	Bracket - filler tube.....	1
11B		GM140535 - Clip - filler tube.....	1
		GM190116 - Bolt, hex., 3/8"-16 x 1/2" cad.....	1
		GM120077 - Nut, hex., 3/8"-16 cad.....	1
12	35A389	Housing - priority valve, 1-1/8" x 2-3/4".....	1
13	35A302	Spool - priority valve, 3/4" O.D. x 12/16" long.....	1
14	35A306	Spring - priority valve, 2-3/8" long.....	1
15	35A391	Guide - valve spring, 3/4" O.D. x 15/16" long.....	1
16	10A9808	Seal - "O" ring, priority valve housing.....	2
	35A709	Washer - priority valve spring, 1/4" I.D., 1" O.D.....	1
17	10A4	Cover - transmission case.....	1
		GM145637 - Ball, steel, 1/2".....	1
		GM145641 - Ball, steel, 5/16".....	1
18	35A8263	Plug - pipe, 1/2".....	2
19		GM144720 - Plug, pipe, 3/8"-18.....	1
		GM160129 - Bolt, hex., 5/8"-16 x 1-7/8" cad.....	10
		GM120082 - Washer, lock, 3/8" cad.....	13
20	10A11540	Pin - dowel, cover to case, 3/8" x 3/4".....	2
21	35A370	Gasket - transmission case cover.....	1
22	35A102	Manifold - on transmission case cover, with orifice and steel ball.....	1
23		GM103865 - Plug, pipe, 1/8".....	2
24		GM147485 - Ball, steel, 1/4".....	1
		GM180123 - Bolt, hex., 3/8"-16 x 1-1/8".....	3
25	35A321	Gasket - manifold to trans. case cover, 4-7/8" dia.....	1
26	35A106	Flange - filter mounting.....	1
		GM180079 - Bolt, hex., 3/16"-19 x 1".....	8
27	35A717	Gasket - filter flange.....	1
28	35A313	Shell - filter, 1-1/8" I.D., 3-17/16" long.....	1
	35A2413	Cover - filter shell.....	1
		35A440 - Bolt, hex., 3/8"-16 x 5-1/4".....	1
29	35A318	Screen - filter shell, 1-3/32" O.D., 3-9/16" long.....	1
30	35A851	Cover - reverse idler gear.....	1
		GM180078 - Bolt, cover, 5/16"-18 x 3/8".....	8
31	35A852	Gasket - reverse gear cover.....	1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs
		TRANSMISSION CASE, CONVERTER AND PUMP (Continued)	
32	35A109	Ball housing	1
		GM189125 - Bolt, hex., 3/8"-18 x 1-1/8", cad.	4
		GM189132 - Bolt, hex., 3/8"-18 x 1-1/4", cad.	5
		GM120362 - Washer, lock, 3/8", cad.	2
		GM271722 - Bolt, hex., 5/8"-11 x 2", cad.	13
		GM121514 - Washer, lock, 5/8", cad.	13
		GM124389 - Nut, hex., 3/8"-11	12
33	10A11543	Pin - dowel, ball housing, 3/8" x 3/4"	2
34	35A693	Pin - dowel, ball housing, 1/2" x 1"	2
35	35A311	Pump - converter, Long Mfg. Div. No. 17-F-60.	1
		GM180090 - Bolt, hex., 3/16"-18 x 1-1/8", cad.	8
	10A9997	Washer - copper, converter bolt, 11/32" I.D., 3/3" O.D.	8
36	35A312	Gasket - pump to cover	1
38	35A313	Converter - Long Mfg. Div. No. F-40-C-20.	1
		GM3409013 - Bolt, hex., 3/16"-18 x 5/8"	6
		GM103320 - Washer, lock, 5/16"	6
39	31A322	Kit - drive plate, converter to flywheel	1



MOBILEFORK MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Per
TRANSMISSION			
1	95A928	Shaft - input, 15-5/8" long	1
		GM145641 - Ball, steel, 5/16"	2
2	55E243	Shaft - output, with pinion and dog gear (matched)	1
3	35A341	Ring - oil seal, input and output shafts, 1-7/4" O.D.	2
3A		35A766 - Ring - quad, shaft to housing	2
		GM145641 - Ball, steel, 5/16"	2
4	35A2132	Housing - driving plates	2
5	35A355	Ring - oil seal, 2-3/8" O.D.	4
6	35A330	Piston - input shaft housing, 7-3/8" O.D., 58 teeth	2
7	35A336	Piston - output shaft housing, 7-3/8" O.D., 58 teeth	2
9		GM145637 - Ball, steel, 3/16" dia.	2
		35A2262 - Pin, roll, 3/64" x 3/8"	2
9	10A15E39	Ring - input and output pistons, 7" dia.	4
10	35A327	Washer - thrust, plate housing, 1-17/32" I.D., 2-3/8" O.D.	4
11	35A321	Spring - piston, 2-1/32" long	4
12	35A322	Retainer - spring, 2-21/32" O.D.	4
13	35A343	Ring - snap, spring retainer, 2-1/8"	4
14	35A233	Plate - friction, 7" O.D., 36 internal teeth	10
15	35A304	Plate - backing, 7-1/8" O.D., 58 external teeth	12
16	35A235	Ring - backup, 3/8" wide, 58 external teeth	4
17	35A236	Ring - retainer, backup ring, 7-1/2" O.D.	4
18	35A338	Carrier - assembly with bushing, input shaft, 36 and 45 teeth	1
19	35A339	Bushing - carrier, 1-1/2" I.D., 1-1/2" long	1
20	35A344	Carrier - assembly with bushing, output shaft, 39 teeth	1
21	35A339	Bushing - carrier, 1-1/2" I.D., 1-1/2" long	1
22	35A319	Washer - thrust, carrier to bearings	2
23-24	35A342	Bearing - ball, input shaft	2
25	35A361	Ring - collector, ball bearing	1
25A		35A367 - O-ring, collector ring	1
26E	35A993	Ring - piston	1
26C	35A363	Retainer - piston dog	1
26D		35A768 - Ring, retainer	1
28	35A266	Carrier - assembly with bushing, output shaft, 35 teeth	1
27	35A373	Bushing - carrier assembly	1
28	35A262	Spacer - carrier to bearing, 1-15/16" I.D., 1-5/16" wide	1
29	35A264	Carrier - assembly with bushing, output shaft, 44 teeth	1
30	35A330	Bushing - carrier assembly, 1-1/2" I.D., 1-1/2" long	1
31	35A265	Spacer - carrier to bearing, 1-32/64", 2-3/8" O.D.	1
32	35A357	Cone - bearing	1
33	35A327	Cup - bearing	1
34	35A365	Cone - bearing	1
35	35A368	Cup - bearing	1
36	35A359	Washer - thrust, spacer to carrier	1
37	35A366	Nut - lock, bearing, 19 N.A.	2
38	35A967	Washer - lock nut	1
39	35A352	Gear - reverse, with bearing, 41 teeth	1
40	35A353	Bearing - needle	2
41	35A356	Shaft - reverse, 1" x 3"	1
42		GM223092 - Screw, sec half dog point, 3/8" - 10 x 3/4"	1
43	35A351	Washer - thrust, reverse gear, 1-1/32" I.D., 1-3/4" O.D.	2
44	35A347	Shaft - idler, with gears, 50 and 25 teeth	1
45	35A340	Bearing - roller, 1-1/2" I.D.	2
46	35A369	Washer - thrust, reverse gear, 1-1/32" I.D., 1-3/4" O.D.	1
47	35A348	Bearing - roller, 1-27/32" I.D.	1
48	35A346	Washer - thrust, 1-15/16" I.D., 2-7/8" O.D.	1




Fig. 2-19

MORILLIST - MY 40 AND MY 60 LIFT TRUCKS

Kit No.	Part No.	DESCRIPTION	No. Pcs.
CONTROL VALVE AND OIL FILTER			
1	35A9	Block - porting	1
2	36A279	Gasket - porting block to trans. case cover	1
3	35A7	Body - valve, w/ latching feature	1
4	35A379	Gasket - valve body to porting block	1
		GM180180 - Bolt, hex., 1/2"-13 x 1-7/8"	4
		GM180188 - Bolt, hex., 1/2"-13 x 2-2/4"	6
		GM192046 - Screw, flbster head, No. 10-24 x 5/8"	4
		GM120217 - Washer, lock, No. 10	3
5	35A372	Spool - lever control, 3/4" x 1-9/32"	2
6		GM145641 - Ball, steel, lever spool, 5/16"	2
8	35A379	Spring - steel ball, 28/32" long, 10 coils	2
9	10A15329	Seal - oil, lever spool, 3/4" I.D., 1/4" wide	4
10	10A6320	Seal - "O" ring, valve body	5
11	10A15752	Plug - valve body seal, 3/4" O.D., 3/8" wide	6
12	10A6320	Ring - snap, plug retainer	6
13	35A373	Spool - pressure regulator, 3/4" O.D., 2" long	1
14	35A374	Spring - pressure spool, 1-3/4" long, 12 coils	1
15	35A377	Valve - relief, 3/4" O.D., 1-1/3" long	1
16		GM145643 - Ball, steel, relief valve, 3/8"	1
17	35A376	Spring - relief valve, 1" long, 9 coils	1
18	35A653	Spool - inching, 1-5/8" long	1
19	35A699	Spring - centering inching spool, 3/4" long, 14 coils	1
20	35A651	Spring - inching spool, 1-3/8" long, 11-1/4" coils	1
20A	36A1771	Spacer - inching spool spring	1
21	35A653	Piston - inching, 2-5/8" long	1
22	35A692	Spacer - inching piston	1
23	35A11	Cylinder - inching	1
		GM122056 - Screw, fill, head, No. 10-24 x 7/8"	2
24	35A694	Gasket - inching cylinder to valve body, 1-3/4" x 2-1/4"	1
25	10A4536	Seal - "O" Ring, cylinder to valve body	2
26	35A695	Packing - Vee Block, cylinder, Chicago No. 100BV40	1
27	36A688	Washer - backup, cylinder packing, 3/4" I.D.	1
28		50A2602 - Washer, inching piston	1
29	35A690	Spring - cylinder, 2-1/2" long, 11 coils	1
30	35A697	Plug - cylinder spring	1
31	35A1770	Spring - end of plug	1
32		50A196 - Ring, snap, plug, Tru-Arc, No. 5070-109	1
		GM138200 - Screw, socket head, 1/4"-20 x 1"	1
33	36A571	Lever - hand, with sleeve and bushing, high and low range, inner	1
34	35A288	Bushing - 1/2" I.D., 1" long, Chrysler Corp, No. AA 850-2	1
35	10A5955	Collar - tube, 1-1/64" I.D., 1-5/8" O.D.	1
		50A1838 - Screw, set, 3/8"-16 x 1/2"	1
36	36A575	Lever - hand, with shaft, forward and reverse, outer	1
37	36A574	Arm - hand lever tube	1
		GM106743 - Key, woodruff, No. 3	1
		GM180128 - Bolt, hex., 3/8"-16 x 1-3/4" cad.	1
38	35A377	Arm - hand lever shaft	1
		50A2623 - Pin, coll, 3/16" x 1"	1
		50A2082 - Washer, plain, 17/32"	2
39	35A573	Clamp - hand lever	1
		GM180133 - Bolt, hex., 3/8"-16 x 2" cad.	2
40	35A387	Bushing - hand lever clamp, 1" I.D., 1-1/4" O.D.	2
	36A1844	Bearing - assembly arm to clamp	1
		GM180376 - Bolt, hex., 9/16"-18 x 7/8"	3
	35A1945	Support - bearing assembly	1
		GM180122 - Bolt, hex., 5/16"-18 x 7/8"	2
		GM123304 - Washer, plain, 13/32"	2
41	35A353	Bell Crank - connecting links	1
42	36A578	Support - bell crank	2
		GM151370 - Screw, set, sq. hd., 3/8"-16 x 1-1/2" cad.	2




Fig. 2-20

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		CONTROL VALVE AND OIL FILTER (Cont'd)	
		50A2052 - Washer, plain, 17/32"	1
		GM103335 - Pin, cotter, 1/8" x 1"	1
43	35A582	Spacer - bell crank, 13/32" thick, inner	1
44	15A14814	Spacer - bell crank, 3/8" thick, between cranks	1
46	35A585	Rod - hand lever to bell crank	2
47		GM442720 - Joint, ball, hand lever rods, 5/16" dia.	4
		GM120968 - Nut, hex., 5/16"-24	4
		GM124820 - Nut, hex. jam, 5/16"-24	4
48	35A586	Link - valve to bell crank, 3/8" x 4-3/4"	1
48 A	36A2495	Link - valve to bell crank, with clip for neutral starting switch	1
		GM103373 - Pin, cotter, 3/32" x 3/4"	2
49	35A6	Filter - oil, Fram No. 2468	1
50	35P21	Body - Fram No. 8715	1
51		GM444914 - Plug, drain, 1/8"-27 N.P.T.	1
52	35P32	Cartridge - Fram No. 118106	1
53	35P35	Spring - assembly, Fram No. 118940	1
54	35P34	Cover - Fram No. 103226	1
55	35P38	Gasket - cover, No. 102027	1
56	35P36	Bolt - cover, with valve, Fram No. 2563	1
57	35P37	Gasket - bell, Fram No. 101979	1
58	35P38	Strap - mounting, Fram No. 10768	1
		GM183421 - Screw, round head, 1/4"-20 x 3-1/4"	1
		GM120372 - Nut, square, 1/4"-20	1
		GM131268 - Washer, lock, 1/4"	1
59	35A1282	Tube - filter to transmission case, 1/2" O.D.	1
		50A600 - Clip, tube to frame	1
60		GM9402866 - Elbow, filter inlet	1
61		GM9410977 - Elbow, transmission outlet	1
62	10A-2012	Seat - "O" ring, connector, 2-1/2" I.D.	1
63	35A562	Hose - cooler, inlet and outlet, 12-1/2" long	2
64	35A1283	Tube - filter to cooler inlet	1
65		GM9402700 - Connector, filter outlet	1
66	35A1284	Tube - valve to cooler hose, 1/2" O.D.	1
67		GM9410979 - Elbow, valve inlet	1
68	10A12612	Seal - "O" ring, valve elbow, 2-1/2" I.D.	1
69	RL886D	Clip - support cooler tube	6
		GM180088 - Bolt, hex., 5/16"-18 x 3/4" dia.	2
		GM120376 Nut, hex., 5/16"-18	2




Fig. 2-20

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Kit No	Part No	DESCRIPTION	No. Pcs
		MY 40 STEERING AXLE	
1	35A1795	Axle - steel	1
1A		GM135509 - Screw, set, 1/2"-13 x 1-1/4", cone point	2
		GM110084 - Screw, set, 1/2"-13 x 1-1/2", oval point	2
		GM120238 - Nut, hex, jam, 1/2"-13	5
		GM172578 - Plug, expansion, 1-3/4"	4
2	35A1847	Bearing - needle, in axle, Torrington No. 352029 CH	4
3	35A1796	Spindle - wheel hub, right hand	1
4	35A1797	Spindle - wheel hub, left hand	1
5	35A1799	Pin - spindle to axle, 1-3/4" x 6-13/16"	2
6	15A6448	Bearing - thrust, for spindle pin, Timken No. T126	2
7	35A1803	Seal - dust, on spindle, National Seal No. 60426	2
8	35A549	Bearing - axle pivot	2
9	35A551	Bushing - bearing box	2
		GM189180 - Bolt, hex., 1/2"-13 x 1-7/8"	9
		GM120378 - Nut, hex., 1/2"-13	8
10	35A1801	Shaft - axle to pivot bearing, 1 1/4" dia, x 13-1/2" long	1
11	35A1483	Housing - steering, tie rods	1
12	35A1809	Pin - pivot, steer housing to axle	1
		35A2143 - Washer, plain, 25/32" x 1-3/4"	1
		GM487640 - Nut, hex, slotted, 3/4"-16	1
		GM103409 - Pin, cotter, 3/16" x 1-1/2"	1
13	35A1802	Pin - lock, pivot pin to axle, 3/8" x 2"	1
14	20H4700	Cone - bearing, steering housing, Timken No. LM67906L	2
15	15A10709	Cup - bearing, steering housing, Timken No. LM67910	2
16	35A565	Socket - tie rod, long, Thompson Products No. L-14-SV-642-A-11	2
17	35A561	Socket - tie rod, short, Thompson Products No. L-14-SV-640-A-11	2
		GM143385 - Pin, cotter, 1/8" x 1"	5
18	35A885	Sleeve - adjusting, tie rod ends, 3/8" O.D., x 5-3/8" long	2
19	35A887	Clamp - adjusting sleeve	4

20-7380020




Fig. 2-81

MOBILITY - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	Qty.
		MY 60 STEERING AXLE	
	35A2996	Axle - steering, assembly Includes the following 34 parts	1
1	35P114	Axle - center	1
2	35P118	Shaft - steering arm	1
3	35P111	Bearing - steering knuckle pin	4
4	35P113	Cap - bearing mounting	2
5		GM27136E - Bolt, bearing cap, 5/8"-11 x 3"	8
7	35P112	Knuckle - steering, right hand	1
8	35P114	Knuckle - steering, left hand	1
9	16A6143	Bearing - thrust, steering knuckle	2
10	35P113	Shaft - steering knuckle	as req'd
11		GM192826 - Plug, expansion, 1-5/8" <i>23 for 2 V</i>	4
12	35P117	Key - draw, knuckle pin	2
		GM10392E - Nut, draw key, 3/8"-24	2
13		GM137634 - Screw, stop, steering knuckle, 7/16"-14 x 2-3/4"	2
		GM271120 - Nut, stop screw, 7/16"-14	2
14	35P113	Pin - steering knuckle	2
15	13P122	Arm - steering, center	1
15A	35P342	Wash - ball, center steering arm GM192849 - Nut, stored, 1/2"-18	1
18	VT924	Nut - steering arm end shaft	1
19	35P 63	Washer - steering arm nut	1
18	VT927	Cap - grease, steering arm	1
19	35P121	Cone - bearing, center steering arm	4
20	16A 699	Cup - bearing, center steering arm	4
21	35P120	Seal - felt, steering arm bearing	1
22	35P119	Cup - left seal	1
	35P113	Tie rod - assembly	2
23	35P24	End - tie rod, left hand	2
24	35P25	End - tie rod, right hand	2
25	35P24	Cover - tie rod end, rubber	4
26		GM112249 - Nut, lock, slotted, 3/8"-16	4
27	35P109	Sleeve - tie rod	2
28	16P20	Clamp - tie rod	4
29		GM161400 - Bolt, tie rod clamp, 7/16"-20 x 1-1/2"	4
		GM271506 - Nut, clamp bolt, 7/16"-20	4
30		GM111296 - Fitting, grease, straight	2
30		GM112310 - Fitting, grease, 45°	2
31	35P126	Hub - wheel, with bearing cups	2
32	35P127	Cup - bearing, outer	2
33	35P127	Cup - bearing, inner	2
34	35P124	Cone - bearing, wheel hub, outer	2
35	35P128	Cone - bearing, wheel hub, inner	2
36	35P126	Seal - oil, wheel hub	2
37	VT924	Nut - spindle bearings	2
38	35P138	Washer - bearing retainer GM103938 - Cover, spindle nut, 1-3" x 1-3/4"	2
39	35P123	Cup - hub GM199947 - Bolt, hub cap, 3/8"-10 x 3/4"	8
40	3-A734	Bushing - bearing caps	2
41	36A766	Shaft - with bracket, axle support GM271723 - Bolt, support bracket, 5/8"-11 x 2" GM124583 - Nut, support bolt, 5/8"-11	2




Fig. 2-21A

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Kit No.	Part No.	DESCRIPTION	No. Pcs.
DRIVE AXLE AND DIFFERENTIAL			
1	35A2152	Housing - drive axle, MY 40	2
	35A2807	Housing - drive axle, MY 60	2
	36A2700	Stud - housing to diff. case, 5/8"-11 x 2-9/8"	16
		36A162 - Nut, Nylock, 5/8"-11, MY 60	
		GM124589 - Nut, hex., 5/8"-11 cad.	14 or 16
13	35A2187	Breather - in drive axle housing, MY 40	2
	36A2518	Breather - in drive axle housing, MY 60	2
2	35A231	Shim - axle housing to diff. case, .030 thick	4
2	35A421	Shim - axle housing to diff. case, .005 thick	4
2	35A209	Shim - axle housing to diff. case, .002 thick	4
2	35A239	Seal - "O" ring, axle housing, 6-1/4" O.D.	2
4	35A1751	Axle - drive, with 19 tooth gear, 2" x 12"	2
5	35A2158	Cup - roller bearing, drive axle	1
5A	35A2159	Cone - roller bearing, drive axle	1
6	16A16471	Ring - retainer, roller bearing	2
7	35A2154	Retainer - roller bearing	2
		GM189079 - Bolt, hex., 5/16"-18 x 1/2", cad.	8
7A	35A2155	Shim - roller bearing retainer, .600 thick	Var.
7A	36A2156	Shim - roller bearing retainer, .605 thick	Var.
7A	35A2157	Shim - roller bearing retainer, .620 thick	Var.
8	35A1252	Housing - wheel shaft, MY 40	2
		GM180669 - Bolt, hex., 7/16"-20 x 1-3/8" cad.	24
		GM271306 - Nut, hex., 7/16"-20, cad.	24
	35A423	Housing - wheel shaft, MY 60	2
		36A1870 - Bolt, wrench head, 1/2"-20 x 1-3/4", MY 60	16
		GM181702 - Bolt, hex., 1/2"-20 x 1-3/4", MY 60	6
		GM222887 - Nut, hex., 1/2"-20, MY 60	22
		36A1371 - Bolt, wrench head, 3/8"-18 x 1-1/2", MY 60	
9	35A242	Gasket - wheel shaft housing, 12" dia., MY 40	2
	35A3909	Gasket - wheel shaft housing, MY 60	2
10	36A235	Shaft - wheel, with bolting flange and oil shield, MY 40	2
	36A380	Shaft - wheel, with bolting flange and oil shield, MY 60	2
11	35A1750	Gear - wheel shaft, 26 teeth	2
12		36A331 - Nut, lock, wheel shaft gear, 1-1/4"-12	2
13	35A1850	Washer - wheel shaft nut	2
14	35A425	Cone - bearing, wheel shaft, inner	2
15	16A11469	Cup - bearing, wheel shaft, inner	2
16	35A239	Cone - bearing, wheel shaft, outer	2
17	35A238	Cup - bearing, wheel shaft, outer	2
18	35A237	Seal - oil, wheel shaft	2
19	35A236	Sleeve - oil seal	2
20	35A234	Case - differential	1
		GM105869 - Plug, pipe, 1/8"-27	1
	35A683	Pin - dowel, differential case, 1/2" x 1"	2
21	35A227	Gasket - differential case	1
22	35A044	Cage - differential, left hand	1
22A	35A1948	Cage - differential, right hand	1
23	16A731	Bolt - differential cage, 1/2" x 5-3/4"	8
		GM119224 - Nut, hex., slotted, 1/2"-20	6
24	16A6712	Cone - bearing, cage	2
25	16A1637	Cup - bearing, cage	2
26	35A1427	Ring - retainer, roller bearing, 7-3/4" O.D.	2
27	553242	Gear - ring, 40 teeth (matched with pinion)	1
28	16A756	Gear - bevel, 26 teeth	2
29	16A109	Washer - thrust, 4-1/4" O.D.	2
30	11A5559	Pinion - bevel, with bushing, 14 teeth	4
31	16A5689	Bushing - bevel pinion	4
32	16A1584	Shaft - bevel pinions	2
	35A2112	Plug - magnetic, 1/2"-14 N.F.T., drain	1

MODULIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs.
		BRAKES	
	35A1241	Brake - assembly, right hand	1
	35A1242	Brake - assembly, left hand	1
		5CA594 - Screw, cap, 9/16"-32 x 1-3/8"	14
		GM178434 - Screw, hex, sheet metal, 1/4"-14 x 1/2"	4
1	35P317	Plate - backing, L.H. brake	1
1	35P318	Plate - backing, R.H. brake	1
2	35P319	Spacer	2
3		GM179614 - Bolt, hex., 5/16"-18 x 5/8"	4
5	35P320	Pin - anchor	4
6	35P321	Shoe - brake, with lining	4
7	35P322	Pin - shoe, guide	4
8	35P323	Clip - shoe guide spring	4
9	35P324	Spring - shoe return	4
10	35P325	Spring - adjusting wheel	2
11	35P326	Guide - star wheel adjusting	2
12	35P327	Screw - adjusting	2
13	35P328	Nut - adjusting	2
14	35P329	Cylinder - wheel, assembly	2
15		GM179617 - Bolt, hex., 5/16"-18 x 7/8"	4
16		GM193320 - Washer, lock, 5/16"	4
	35P330	Plug - adjusting	2
17	35P331	Lever and Pin - assembly, L.H., parking brake	1
17	35P332	Lever and Pin - assembly, R.H., parking brake	1
18	35P333	Clip - "C" spring	2
19	35P334	Link and Pin - assembly, L.H., parking brake	1
19	35P335	Link and Pin - assembly, R.H., parking brake	1
	35P336	Clamp - L.H. emergency cable	1
	35P337	Clamp - R.H. emergency cable	1
20	35P339	Body - wheel cylinder	2
21	35P340	Spring - with retainer	2
22	35P341	*Cup - piston	4
23	35P342	Piston	4
24	35P343	*Bore	4
25	35P344	Push Rod	4
	35P345	Screw - bleeder	2
	35P338	*Kit - repair, includes items with an asterisk (*)	--




Fig. 2-23

MOBILEFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs
BRAKE AND INCHING PEDALS WITH LINKAGE			
1	36A2250	Pedal - brake	1
2	36A2238	Pedal - inching	1
3	35A2120	Bushing - in hub of brake and inching pedal	4
4	35A1811	Shaft - pedals to bracket 50A2838 - Pin, roll, 1/8" x 5/8"	1
5	35A1810	Bracket - on shroud, for pedals GM180122 - Bolt, hex., 3/8"-18 x 1" GM120375 - Nut, hex., 3/8"-16	1 3 3
6	35A2200	Pad - foot and inching pedals GM120369 - Nut, hex., 3/8"-24	2 2
7	36A2237	Arm - brake, MY 40	1
	36A1813	Arm - brake, MY 60	1
8	8455	Bearing - needle, in arm	2
9	35A2001	Shaft - pivot, brake arm to frame 36A2627 - Pin, roll, 1/4" x 1-1/2" GM273552 - Fitting, grease, 1/8"-27 x 90°	1 1 1
10	36A2152	Bushing - in brakes, brake arm and inching pedals, 1/2" long	3
11	35A1812	Link - brake pedal to brake arm GM274583 - Pin, connector, 7/16" GM121222 - Pin, roller, 3/32" x 3/4" 35A2024 - Washer, plain, 15/32"	1 2 2 1
12			
13	35A2231	Bushing - in ends of brake link	2
14	36A2453	Shaft - pivot, on frame, for bell crank, MY 40	1
	36A2243	Shaft - pivot, on frame, for bell crank, MY 60 GM180122 - Bolt, hex., 3/8"-18 x 1" GM120375 - Nut, hex., 3/8"-16 36A306 - Ring, snap	1 2 1 1
15			
16	35A2242	Crank - bell, on pivot shaft	1
17	35A2058	Clevis - 7/16"-20, for bell crank GM274583 - Pin, connector, 7/16" GM109436 - Pin, roller, 3/16" x 3/4" GM200123 - Nut, hex., s/n, 7/16"-20 GM120325 - Washer, plain, 15/32"	1 2 1 1 2
18			
19	35A2123	Bushing - in bell crank	2
20	35A2232	Bushing - in bell crank	1
21	35A2002	Spring - brake arm return	1
22	35A169	Bolt - eye, brake arm spring GM124829 - Nut, hex., 3/8"-16	1 2
23			
24	35A2285	Clevis - with rod, MY 40	1
	15A2248	Rod - brake arm to master cylinder, 7/16"-20 x 10, MY 60 GM144244 - Clevis, 7/16"-20, MY 60	1 1
25	35A2230	Link - inching pedal to bell crank GM274583 - Pin, clevis, 7/16" GM121222 - Pin, roller, 3/32" x 3/4" 35A2024 - Washer, plain, 15/32"	1 2 2 2
26			
27	36A2231	Bushing - in inching link, 3/8" long	2
28	10A2282	Sleeve - on bell crank clevis, MY 40	1
	35A2246	Sleeve - on bell crank clevis, MY 60	1
29	35A2245	Rod - between sleeve and inching cylinder, 4-5/16" long	1
30	35A2247	Spring - over rod GM120394 - Washer, plain, 13/32" GM124829 - Nut, hex., 3/8"-16	1 1 1
31A			
31	35A2364	Spring - inching pedal return	1
32	35A209	Bolt - eye, for inching pedal return spring GM124829 - Nut, hex. jam, 3/8"-16 GM120369 - Nut, hex., 3/8"-16	1 1 1




Fig. 2-24

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
PARKING BRAKE			
33	35A185	Lever - hand, parking brake	1
		GM180887 - Bolt, hex., 5/16" - 18 x 2	2
		GM120976 - Nut, hex., 5/16" - 18	2
34	35A1020	Spacer - hand lever, 5/8" O.D. x 15/16" long	2
35	35A1271	Cable - hand lever to right hand brake, MY 40	1
36	35A1272	Cable - hand lever to left hand brake, MY 40	1
	35A1790	Cable - hand lever to right hand brake, MY 60	1
	35A1779	Cable - hand lever to left hand brake, MY 60	1
	10A3978	Clip - left hand brake cable, MY 60	1
37	35A188	Pin - cable to hand lever, 7/16" x 13/16"	2
		GM121222 - Pin, cotter, 3/32" x 3/4"	2
38	35A190	Clamp - cable	2
39	35A191	Spacer - cable clamp	2
MASTER CYLINDER AND OIL LINES			
40	35A1834	Cylinder - master, left hand, MY 40	1
	35A1834	Cylinder - master, right or left hand, MY 60	2
	35P376	Kit - repair, left hand master cylinder, 35A1834	1
41	35A388	Cylinder - master, right hand MY 40	1
		GM103877 - Plug, pipe, square head, 1/8"	1
	35P387	Kit - repair, right hand master cylinder, 35P388, MY 40	1
		GM180138 - Bolt, hex., 3/8" - 16 x 3'	4
		GM120377 - Nut, hex., 3/8" - 16	2
42	35A1880	Tube - with nuts, right hand brake line, MY 40	1
	35A3266	Tube - with nuts, right hand brake line, MY 60	1
43	35A1861	Tube - with nuts, left hand brake line, MY 40	1
	35A3267	Tube - with nuts, left hand brake line, MY 60	1
44	35A1968	Tube - master cylinder to tee, MY 40	1
	35A3265	Tube - with nuts, master cylinder to tee, MY 60	1
45		GM940953 - Tee, 3-way, 7/16" - 20	1
46	35A1855	Tube - inching cylinder to inching valve, MY 40	1
	35A2481	Tube - inching cylinder to inching valve, MY 60	1
47		50A590 - Tee, inching	1
48		GM44688 - Plug, hex. socket, 1/8" - 27	1
49		50A595 - Bolt, inching cylinder	1
50		50A840 - Bolt, brake cylinder	2
51		50A835 - Swivel, connector	3
52		50A836 - Gasket, bolt	2
53		50A837 - Gasket	3
54		50A841 - Gasket	2
55		50A834 - Bolt, Master cylinder	1
56	35A387	Switch - stop light	1
	35A2468	Clip - inching to bell housing	1




Fig. 2-24

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		WHEELS, FRONT AND REAR	
1	35A1799	+Hub - rear wheel	2
2	13A574	+Cone - bearing, rear wheel hub outer	2
3	10A638	+Cup - bearing, rear wheel hub outer	2
2A	15A12648	+Cone - bearing, rear wheel hub inner	2
3A	15A12647	+Cup - bearing, rear wheel hub inner	2
		GM131018 - Washer, plain, 1"	2
		GM451343 - Nut, hex., slotted, 7/8"-14	2
4	35A1803	+Seal - oil, rear wheel hub	2
5	35A555	-Rim - rear wheel, inner half	2
6	35A556	-Rim - rear wheel, outer half	2
		GM181688 - Bolt, hex., 1/2"-20 x 1" cad.	16
		GM180120 - Bolt, hex., 3/8"-16 x 3/4" cad.	16
		GM120377 - Nut, hex., 3/8"-16 cad.	16
7	35A358	+Cap - rear wheel hub	2
		+NOTE: For MY 40 Lift Trucks.	
	35P126	+Hub - rear wheel, with bearing cups	2
	35P126	+Cup - bearing, outer	2
	35P127	+Cup - bearing, inner	2
	35P124	+Cone - bearing, outer	2
	35P128	+Cone - bearing, inner	2
	35P129	+Seal - oil, wheel hub	2
	VT324	-Nut - spindle bearings	2
	35P128	+Washer - bearing retainer	2
	35P123	+Cap - hub	2
		+GM179837 - Bolt, hex., 3/8"-18 x 3/4"	8
	35A557	+Wheel - inner, rear half	2
	35A558	+Wheel - outer, rear half	2
		+35A582 - Bolt, hex., 5/8"-11	10
	35A839	+Bolt - in outer wheel	10
		+GM121358 - Nut, hex., 5/8"-18	10
		+NOTE: For MY 60 Lift Trucks, see illustration page 45	
8	35A2520	*Center - drive wheel	2
9	35A146E	*Bolt - hub, drive wheel	16
10	35A639	*Rim - drive wheel, MY 40	2
	35A2775	*Rim - drive wheel, MY 60	2
10A	35P972	*Ring - retainer, for rim	2
11	35A1299	*Clamp - rim	12
12	35A1300	*Stud - rim clamp, 5/8"-11 N.C. x 2-1/4"	12
		GM124380 - Nut, rim clamp stud, 5/8"-11	12
		*NOTE: Used on lift trucks with single drive wheel	
	35A413	**Center - drive wheel	2
	35A146E	**Bolt - hub, drive wheel	16
	35A639	**Rim - drive wheel	4
	35P972	**Ring - retainer, for rim	4
	35A852	**Clamp - rim	12
	35A1300	**Stud - rim clamp	12
		GM124380 - Nut, hex., 5/8"-11	12
	35A1012	**Spacer - between rims	2
		**NOTE: Used on lift trucks with dual drive wheels	




Fig. 2-26

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		MY 40 STEERING GEAR	
	35A532	Gear - steering, with arm	1
		Includes the following 21 parts:	
1	35P79	Housing - with oil seal, bushing and end cover	1
2	35P86	Seal - oil, cross shaft	1
3	35P89	Bushing - cross shaft	2
4	35P87	Cover - end, lower section	1
5	35P80	Gain and Tube	1
6	34P569	Cup - ball	2
7		GM145031 - Ball, steel, 5/16" dia.	22
8	30P500	Ring - contact	2
9	35P51	Nut - steering wheel	1
10	35P64	Tube - jacket, with bearing	1
11	35P973	Bearing - jacket tube	1
12	35P47	Spring - bearing	1
13	35P48	Seat - spring	1
14	35P49	Clamp - assembly, jacket tube	1
		GM261347 - Bolt, hex., 5/16"-18 x 2"	1
		GM103026 - Nut, hex., 5/16"-18	1
		GM215546 - Washer, lock, int. and ext., 5/16"	1
15	35P63	Cover - upper	1
		GM178816 - Bolt, upper cover, 5/16"-18 x 3/4"	3
		GM103340 - Washer, plain, 11/32"	8
16	VT223	Shim - upper cover, .002	Var.
16	VT224	Shim - upper cover, .003	Var.
16	VT225	Shim - upper cover, .010	Var.
17	35P81	Shaft - cross, with nut	1
18		GM114489 - Nut, hex. jam, 3/4"-16	1
19		GM231046 - Washer, lock, 3/4"	1
20	35P92	Cover - side, with adjusting screw	1
21	35P83	Screw - adjusting	1
22		GM214486 - Nut, lock, adjusting screw	1
		GM178818 - Bolt, hex., 5/16"-18 x 1"	4
		GM103340 - Washer, plain, 11/32"	4
23	30P56E	Gasket - side cover	1
24	35A3001	Arm - steering	1
25	35A182	Wheel - steering	1
		GM180478 - Bolt, hex., gear to support, 1/2"-13 x 1-3/4" rad.	2
		GM120378 - Nut, hex., 1/3"-13	2
26	36A589	Drag link, front, 42-1/2" long	1
		Includes the following 5 parts:	
27	35P311	Bearing - ball socket	2
28	35P240	Seat - spring	1
29	35P28E	Spring - socket	1
30	35P289	Bumper - spring	1
31	35P242	Plug - socket	1
32	35A1040	Drag link, rear, 29-5/16" long	1
33	35P302	Seal - dust, rubber	1
34	35A535	Clamp - rear drag link	1
		GM180163 - Bolt, clamp, 1/2"-13 x 2-1/4" rad.	1
		GM120378 - Nut, hex., 1/2"-13 rad.	1
		GM231288 - Fitting, lubricator, 1/8"-27 straight	8
	35A2614	Washer - drag link to booster, 45/64" I.D., 2-1/8" O.D.	2

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
		HORN BUTTON	
	35A1066	Button - horn, with wire Includes the following 11 parts:	1
36	35P446	Cover - horn button	1
37	35P447	Button	1
38	35P448	Cap - contact	1
39	35P449	Spring - horn button	1
40	35P450	Cap - contact	1
41	35P451	Ferrule - insulating	1
42	35P452	Washer - contact	1
43	35P453	Spring - contact	1
44	35P454	Plate - base, assembly	1
45	35P455	Screw - base plate, No. 10 x 5/8"	8
46	35P470	Wire - with connector	1




Fig. 3-26

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		MY 60 STEERING GEAR	
	35A811	Gear - steering, less arm	1
		Includes the following 21 parts:	
1	35P79	Housing - with seal, bushings and cover	1
2	35P86	Seal - oil, cross shaft	1
3	35P88	Bushing - cross shaft	2
4	35P87	Cover - end, lower section	1
5	35P238	Cam and Tube	1
6	30P559	Cup - ball	2
7		GM145631 - Ball, steel, 5/16" dia.	22
9	30P560	Ring - retainer	2
9	35P51	Nut - steering wheel	1
10	35P84	Tube - jacket, with bearing	1
11	30P562	Bearing - jacket tube	1
12	35P47	Spring - bearing	1
13	35P49	Seat - spring	1
14	35P48	Clamp - assembly, jacket tube	1
		GM182347 - Bolt, hex., 5/16"-18 x 2"	1
		GM193025 - Nut, hex., 5/16"-18	1
		GM115548 - Washer, lock, ext. & int. 5/16"	1
15	35P83	Cover - upper	1
		GM179816 - Bolt, upper cover, 5/16"-18 x 3/4"	3
16	VT223	Shim - upper cover, .002	Var.
18	VT224	Shim - upper cover, .003	Var.
16	VT225	Shim - upper cover, .010	Var.
17	35P81	Shaft - cross, with nut	1
18		GM114498 - Nut, hex, jam, 3/4"-18	1
19		GM131046 - Washer, lock, 3/4"	1
20	35P82	Cover - side, with adjusting screw	1
21	35P88	Screw - adjusting	1
22		GM114498 - Nut, lock, adjusting screw	1
		GM179818 - Bolt, hex., 5/16"-18 x 1"	4
23	30P566	Gasket - side cover	1
24	35A3001	Arm - steering	1
25	35A182	Wheel - steering	1
26	35A312	Drag Link - front	1
		Includes the following 5 parts:	
27	35P241	Bearing - ball socket	2
28	35P240	Seat - spring	1
29	35P238	Spring - socket	1
30	35P239	Bumper - spring	1
31	35P242	Plug - socket	1
32	35A314	Drag link - rear	1
		Includes the following 6 parts:	
33	35P367	Bearing - ball socket	2
34	35P368	Seat - spring	1
35	35P369	Spring - socket	1
36	35P370	Bumper - spring	1
37	35P371	Plug - socket	1
38	10P1345	Clamp - rear drag link	1
		GM271284 - Fitting, lubrication, 1/3" x 87-1/2" front drag link	1
		GM271285 - Fitting - lubrication, 1/3" x 90", rear drag link	1
	15A2514	Washer - drag link to bracket, 49/64" I.D., 2-7/8" O.D.	2

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
		35 TO 35A135 NLA POWER STEERING BOOSTER	
	35A2136	Cylinder - hydraulic, complete	1
	35P349	Includes the following 40 parts:	
1	30P93	Piston - with rod and seal	1
2		GM103026 - Nut, hex., 1/2" - 20	1
3	10P472	Ring - piston	2
4	35P350	Seal - piston	3
5	85P351	Gland - piston rod	1
6	10P1033	Seal - "O" ring	2
7	10P1597	Ring - backup	1
8	10P1598	Ring - retainer	1
9	10P1599	Ring - retainer	2
10	10P610	Seal - oil	1
11	10P1600	Ring - retainer	1
12	35P352	Seal - "O" ring	1
13	35P353	Ring - backup	1
14	35P354	Ring - retainer	1
15	35P355	Plate - end GM170783 - Screw, end plate, 1/4" - 20 x 5/8" GM103319 - Washer, lock, 1/4"	3 3
16	35P356	Cushion - piston rod	2
17	35P357	Retainer - cushion GM102649 - Nut, hex. slotted, 5/8" - 18	2 1
18		Body - valve, with "O" rings	1
19	35P358	Seal - "O" ring, valve body	4
20	10P1738	50A2359 - Pin, roll, 1/4" x 3/4"	1
21	35P359	Spring - valve spool	1
22	35P360	Washer - centering, valve spring	1
22A	35P361	Washer - centering, valve spring	2
23	35P362	Seal - "O" ring	1
24	10P1614	Washer - retainer	1
25	10P1609	Seal - "O" ring	1
26	10P1606	Spring - body GM145645 - Ball, steel, 7/16"	1 1
27		GM145645 - Ball, steel, 7/16"	1
28	10P1607	Plug - with pin	1
	10P1608	Seal - "O" ring, body plug	1
29	10P1813	Flexure - assembly 30A1043 - Nut, hex., elastic stop, 5/16" - 24	1 1
30		30A1043 - Nut, hex., elastic stop, 5/16" - 24	1
31	10P1812	Stud - ball	1
32		GM145645 - Ball, steel, 7/16"	2
33		GM102649 - Nut, hex., slotted, 5/8" - 18	1
34	10P1621	Seat - ball	2
35	10P1622	Spring - ball seat	1
36	35P130	Washer - ball stud spring	1
37	10P1623	Plug - adjusting	1
38	10P1624	Pin - lock, adjusting plug	1
39	10P1617	Shell - ball stud assembly	1
40	35P108	Housing - ball stud shell	1
41	10P1620	Shield - dust	1
42	10P1015	Retainer - dust shield	1
43	10P1618	Cap - end	1
44	35P200	Fitting - lubrication	1




Fig. 2-27

Seal kit use?
10R1777

35A534
\$287

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		FRAME, OVERHEAD GUARD, FLOOR PLATE AND COUNTERWEIGHT	
1	36A2925	Frame - main, with fuel and hyd. fluid compartments, MY 40 single drive wheels	1
	36A2910	Frame - main, with fuel and hyd. fluid compartment, MY 40 Dual drive wheels	1
	36A4065	Frame - main, with fuel and hyd. fluid compartment, MY 60 single drive wheels	1
	36A4275	Frame - main, with fuel and hyd. fluid compartment, MY 60 Dual drive wheels	1
2		GM444879 - Plug, pipe, 3/4" drain	2
3	36A476	Breather - with dipstick, hydraulic fluid tank	1
4	36A537	Guard - overhead, assembly, MY 40	1
	36A532	Guard - overhead, assembly, MY 60	1
		GM180123 - Bolt, hex., 3/8"-16 x 1-1/8" cad.	8
5	35A182	Pad - fabreka, frame to engine	2
		50A942 - Bolt, hex., 5/8"-11 x 1-1/2", Nylock	2
6	36A469	Bracket - frame to engine, MY 40	1
	35A802	Bracket - frame to engine, MY 60	1
		GM180181 - Bolt, hex., 1/2"-13 x 3-1/4" cad.	2
		GM435567 - Nut, lock, 1/2"-13	2
7	36A473	Support - differential case to frame, MY 40	2
7	35A800	Support - differential case to frame, MY 60	2
		GM271731 - Bolt, hex., 5/8"-11 x 4"	4
		GM121374 - Washer, lock, 3/8"	4
7A	35A2181	Block - clamp, MY 40	2
7B	36A2181	Block - clamp, MY 60	2
	35A588	Bushing - mast pivot, MY 60	2
		GM180185 - Bolt, hex., 1/2"-13 x 2-1/2"	4
8	35A1835	Plate - floor, front, MY 40	1
	35A1810	Plate - floor, front, MY 60	1
		GM180120 - Bolt, hex., 3/8"-16 x 3/4" cad.	2
9	36A1831	Plate - floor, rear, MY 40	1
	36A820	Plate - floor, rear, MY 60	1
		GM180122 - Bolt, hex., 3/8"-16 x 1" cad.	2
10	35A433	Clip - floor plate, on front bar	2
	35A501	Safety Walk, on rear floor plate, 12" x 24", MY 40	1
	35A502	Safety Walk, on R.H. fender step, 6" x 8", MY 40	1
	36A503	Safety Walk, on L.H. fender step, 6" x 8", MY 40	1
	36A504	Safety Walk, on frame, R.H. 8" x 12", MY 40	1
	36A505	Safety Walk, on frame, L.H. 8" x 12", MY 40	1
	35A827	Safety Walk, on floor plate, MY 60	1
	36A830	Safety Walk, on frame, MY 60	2
11	35A9145	Counterweight, MY 40	1
		GM271748 - Bolt, hex., head, 3/4"-16 x 8", MY 40	1
		GM446257 - Washer, plain, 13/16", MY 40	1
		GM426099 - Nut, hex., 3/4"-16, MY 40	1
	35A2413	Counterweight - MY 60	1
		GM271731 - Bolt, hex., 5/8"-11 x 4", MY 60	1
		36A2602 - Washer, plain, 21/32", MY 60	1
		GM124553 - Nut, hex., 5/8"-11, MY 60	1
12	36A752	Pin - hitch	1
		50A284E - Pin, roll, 3/16" x 1-3/4"	1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
DETAILS AND INSTRUCTION PLATES			
	35A2107	Decal - MOBIL-MATIC, on dash	1
	35A382	Decal - MOBILIFT, on uprights	2
	35A384	Decal - MOBILIFT, on side panel	2
	35A626	Plate - instruction, transmission control	1
	35A627	Plate - instruction, hfr control	1
		GM427590 - Rivet, button head, 3/32" x 1/4"	4
	35A56	Plate - brake warning	1
		GM167837 - Screw, 4100, No. 6 x 3/8"	2




Fig. 2-28

MORILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
HOOD AND SEAT			
1	36A3300	Hood - MY 40	1
	36A3372	Hood - front section, MY 60	1
	36A3373	Hood - rear section, MY 60	1
		GM180120 - Bolt, hex., 3/8"-16 x 3/4"	7
		GM120377 - Nut, hex., 3/8"-16	7
2	35A2297	Insulation - center hood section	1
3	10A15467	Grommet - rubber, center hood section	2
4	36A3326	Panel - side, right hand, MY 40	1
	36A3375	Panel - side, right hand, MY 60	1
5	36A3298	Panel - side, left hand, MY 40	1
	36A3374	Panel - side, left hand, MY 60	1
		GM180120 - Bolt, hex., 3/8"-16 x 3/4"	7
		GM120374 - Nut, square, 3/8"-16	7
		GM120324 - Washer, plain, 13/32"	4
6	36A2178	Support - rear, hood, right hand, MY 40	1
7	35A2178	Support - rear, hood, left hand, MY 40	1
	36A823	Frame - angle, rear, MY 60	1
8	36A3569	Panel - drain, MY 40	1
	36A824	Panel - drain, MY 60	1
		GM180118 - Bolt, hex., 3/8"-16 x 3/4"	2
		GM120377 - Nut, hex., 3/8"-16	2
9	35A499	Hinge - hood	2
10	35A499	Pin - hood hinge, 3/8" x 2-1/4"	2
11	35A499	Bracket - hood hinge, MY 40	4
		GM180198 - Bolt, hex., 1/2"-13 x 3-1/2"	4
		GM120372 - Nut, hex., 1/2"-13	4
12	36A1484	Spacer - between hinge brackets, 1-1/8" long, MY 40	4
13	35A3297	Rod - side panel support, 3/8" x 17-3/2" long	2
		GM120394 - Washer, plain, 13/32"	2
		GM100373 - Pin, center, 3/32" x 9/4"	2
14	35A2176	Bracket - side panel rod, 1-1/2" x 3-1/2", MY 40	2
15	36A2176	Clip - for panel support rod, left hand side, MY 40	2
16	35A1814	Strand - front	1
		GM180124 - Bolt, hex., 3/8"-16 x 1-1/4"	4
		GM180128 - Bolt, hex., 3/8"-16 x 1-3/4"	1
17	35A481	Support - steering column	1
		GM180121 - Bolt, hex., 3/8"-16 x 7/8"	2
18	35A482	Clamp - steering column to support	1
		GM180121 - Bolt, hex., 3/8"-16 x 7/8"	2
		GM120377 - Nut, hex., 3/8"-16	2
19	36A2607	Support - hood, front, MY 40	1
	36A2743	Support - hood, front, MY 60	1
	35A1759	Cover - hood support, MY 60	1
		GM180122 - Bolt, hex., 3/8"-16 x 1"	9
		GM120377 - Nut, hex., 3/8"-16	9
20	35A480	Brace - angle, 28" long, MY 40	1
	36A2223	Brace - angle, 35-3/8" long, MY 60	1
21	36A1907	Catch - on support, for panels	2
		GM180018 - Bolt, hex., 1/4"-20 x 1/2"	2
		GM120375 - Nut, hex., 1/4"-20	2
	36A1485	Seat - complete with cushions	1
		Includes the following 7 parts:	
		GM103025 - Nut, hex., 5/16"-24	4
22	35P491	Frame	1
23	36P492	Cushion - back rest	1
24	35P493	Cushion - seat	1
25	35P494	Hinge - back rest	2
26	36P497	Button - end, frame, tail	2
27	35P49E	Slide - seat frame, right hand	1
28	35P495	Slide - seat frame, left hand	1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No.	DESCRIPTION	No. Pcs.
MY 40 HYDRAULIC PUMP			
1	36A867	Pump - hydraulic, with flow divider Includes the following 32 parts.	1
2	35P269	Body - pump, with bearings	1
3	35P270	Cover - pump, with bearings	1
4	35P297	Bearing - needle, Torrington No. 81416	4
5	35P271	Shaft - drive	1
6	35P280	Gear - drive shaft	1
7	35P276	Bearing - ball, drive shaft, New Dep. No. 9206	1
8	35P279	Ring - bearing retainer, Truarc No. 6109-118	2
9	35P275	Adapter - bearing GM147103 - Screw, adapter, hex, socket, No. 8132 x 1"	1 2
10	35P277	Seal - "O" ring, adapter, 3-1/4" I.D.	1
11	35P276	Washer - thrust, bearing, 2" I.D., 1-3/16" O.D.	1
12	35P299	Retainer - with oil seal	1
13	10P1772	Seal - oil, Chicago Rawhide No. 501391 Screw - retainer, pan. hd. tld, cutting, 10-24 x 3/8"	1 4
14	35P286	Seal - "O" ring, retainer, 1-3/4" I.D., 1-16/16" O.D.	1
15	35P274	Gear - filler	1
16	35P271	Plate - gear, 1-7/64" thick	1
17	35P272	Pin - Cotter, gear plate, 5/16" x 1-3/4" GM179829 - Bolt, hex, hd., 5/16"-18 x 2-3/4"	2 6
18	35P255	Plate - wear, pump body	1
19	35P282	Plate - wear, pump cover	1
20	35P283	Seal - wear plate, outer, rubber	2
21	35P284	Seal - wear plate, liner, rubber	2
22	35P281	Plug - backup, wear plate seal, ivory	2
23	35P287	Seal - "O" ring, 5/8" I.D., 3/4" O.D.	2
24	35P285	Flow Divider - assembly	1
25	35P289	Piston	1
26	10P1595	Spring - piston, 32 coils	1
27	10P1590	Plug - piston and spring, 3/4"-16 N.F.	1
28	35P294	Seal - "O" ring, plug, 7/8" O.D.	1
29	35P290	Valve	1
30	35P291	Spring - valve, 9 coils	1
31	35P293	Shim - valve spring	as req.
32	35P292	Plug - valve, 1/3"-20 N.F.	1
33	35P296	Seal - "O" ring, flow divider to pump GM138226 - Screw, hex socket, 5/16"-18 x 1" GM127792 - Elbow, pump inlet, 1"-90°	2 4 1
34		Gear - helical, on pump shaft	1
35	10A19932	Key - gear	1
36	10A3648	Washer - lock, gear to shaft GM179846 - Bolt, lockwasher, 5/16"-18 x 3/4" 50A446 - Bolt, pump to housing, 3/8"-18 x 5-1/4"	1 1 2
37	11A5647	Washer - pump bolt	2
38	10A10224	Gasket - pump to side cover	1
39	35A705	Hose - suction strainer to pump GM105478 - Clamp, hose, 1-3/4"	1 4
40	35A1285	Nipple - pipe, 1" x 2"	2
41	35A3524	Strainer - suction	1
42	35A696	Flange - mounting, on hyd. oil tank GM160121 - Bolt, hex., 3/8"-16 x 7/8" cad.	1 6
43	36A690	GM157793 - Elbow, pipe, 1", 90°	1
44		Gasket - flange to tank	1
45	35A700		
46			




Fig. 2-30

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Pcs
MY 60 HYDRAULIC PUMP			
1	35A856	Pump - hydraulic, with flow divider	1
		Includes the following 28 parts:	
2	35P299	Body - pump, with bearings	1
3	35P300	Cover - pump, with bearings	1
4	35P297	Bearing - needle, Torrington No. R1413	4
5	35P301	Shaft - drive, with gear	1
6	35P265	Retainer - with oil seal	1
7	19P1772	Seal - oil, Chicago Rawhide No. 501391	1
		GM144901 - Screw, retainer, pan hd. ind. cutting, No. 10-24 x 3/8"	4
8	35P266	Seal - "O" ring, retainer, 1 3/4" I.D., 1-13/16" O.D.	1
9	35P271	Gear - idler	1
10	35P271	Plate - gear, 1-7/8" thick	1
11	35P272	Pin - dowel, gear plate, 3/16" x 1-3/4"	2
		GM179809 - Bolt, hex., head, 5/16"-18 x 2-5/4"	6
12	35P295	Plate - wear, pump body	1
13	35P282	Plate - wear, pump cover	1
14	35P283	Seal - wear plate, outer, rubber	2
15	35P284	Seal - wear plate, inner, rubber	2
16	35P281	Ring - backup, wear plate seal, ivory	2
17	35P287	Seal - "O" ring, 5/8" I.D., 3/4" O.D.	2
18	35P295	Flow Divider, see body	1
19	35P289	Piston	1
20	10P1592	Spring - piston, 32 coils	1
21	10P1595	Plug - piston and spring, 3/4"-18 N.F.	1
22	35P294	Seal - "O" ring, plug, 1/8" O.D.	1
23	35P290	Valve	1
24	35P291	Spring - valve, 9 coils	1
25	35P293	Shim - valve spring	28 req.
26	35P292	Plug - valve, 1/2"-20 N.F.	1
27	35P296	Seal - "O" ring, flow divider on pump	2
		GM18622E - Screw, hex., socket, 5/16"-18 x 2"	4
28		GM127782 - Elbow, pump inlet, 1", 90°	1
29	35A804	Coupling - hyd. pump shaft to fan pulley	1
		GM180977 - Bolt, hex., 5/16"-18 x 3/4" coupling to pulley	3
30	35A800	Support - hyd. pump	1
		GM169290 - Bolt, pump to support, hex. head, 3/8"-16 x 4-1/2"	2
		GM120277 - Nut, hex., 3-5"-16, cad.	2
		GM27151E - Bolt, hex., 5/8"-11 x 1-1/4" cad.	3
31	10A1543	Pin - dowel, support to crankcase	2
32	35A1449	Hose - suction, strainer to pump	1
33		GM103473 - Clamp, hose, 1-7/8"	4
34	35A2524	Nipple - pipe, 1" x 2"	2
35	35A899	Strainer - suction	1
36	35A839	Flange - mounting, on hyd. oil tank	1
		GM180121 - Bolt, hex., 3-8"-16 x 7/8"	6
37		GM144329 - Elbow, pipe, 1" N.P.T., 45°	1
38	35A700	Gasket - flange to tank	1




Fig. 2-30A

MOBILIFT • MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No Pcs
CONTROL VALVE			
	35A3033	Valve - control, standard, MY 60	1
1	35A3078	Valve - control, standard, MY 40	1
	35A3032	Valve - control, one spool aux. special	1
1	35A2034	Valve - control, two spool aux. special	1
2	15P660	Seal - spool	2 or 4
3	15P656	Spring - spool centering	1 or 2
4	10P1632	Washer - stop, centering spring	1 or 2
5	15P654	Collar - stop, centering spring	1 or 2
6	15P652	Bolt - stop collar	1 or 2
7	10P1630	Washer - lock, stop collar bolt	1 or 2
8	15P655	Disk - stop collar	1 or 2
9	15P657	Ring - snap, stop disk	1 or 2
10	15P658	Donnet - rubber, spool opening	1 or 2
11	35P215	Plug - ball check	1
12	10A1829	"O" Ring - ball check plug	1
13	35P218	Plinger - check and relief valve	2
14	35P216	Seat - relief valve	1
15	10A12072	"O" Ring - relief valve seat	1
16	35P221	Spring - relief	1
17	35P222	Guide - relief spring	1
18	35P223	Ball - relief guide	1
19	10A18469	Washer - spacer, relief spring	Var.
19A	10A16480	Shim - relief spring	Var.
20	35P220	Cap - relief spring	1
21	10A16487	Gasket - relief spring cap	1
22	35P217	*Plug - port	1
23	35P225	*"O" Ring - port plug	1
*NOTE: Used with standard (35A3078) valve.			




Fig. 2-31

MORILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
HYDRAULIC CONTROL VALVE			
1	-----	Valve - control, see page 68 for complete listing.....	1
		GM180134 - Bolt, hex., 3/8"-16 x 2-1/2".....	2
		GM120877 - Nut, hex., 3/8"-16.....	2
2	36A3321	Lever - hand control, inner, standard.....	1
3	36A3322	Lever - hand control, outer, standard.....	1
4	36A3328	Lever - hand control, aux. rear, inner.....	1
5	36A3327	Lever - hand control, aux. rear, outer.....	1
6	36A1257	Shaft - hand levers, 3/8" x 6-7/16".....	1
7	25A1257	Shaft - aux. levers, 3/8" x 6-7/16".....	1
		GM103562 - Pin, cotter, 1/16" x 3/4".....	2
8	35A546	Link - roller, lever to valve spool.....	A.R.
9	26A3223	Support - valve, on frame.....	1
10	36A3228	Support - aux. valve, rear.....	1
11	16A12008	Spacer - single aux. valve.....	1
12	35A3119	Elbow - valve, side outlet.....	1
13		50A946 - Nipple, pipe, 3/4" x 1-3/4".....	1
14		50A2480 - Nipple, pipe, 3/4" x 2".....	1
15		50A946 - Nipple, pipe, 3/4" x 3-3/4".....	1
16	50A3120	Plug - adapter, 7/8"-14 to 1-2/8"-12.....	1
17		50A1866 - Ring, quad.....	1
18	36A3117	Gasket - adapter plug.....	1
19	10A14730	Elbow - rubber, connecting valves.....	1
20	35A3010	Hose - connecting valves.....	1
		GM105475 - Clamp, hose, 1-3/8".....	2
21	35A3118	Plug - hex. head, 1-3/8"-12.....	1
22	36A3119	Gasket - hex. head plug, copper.....	1
23	35A3036	Hose - valve to tank.....	1
		GM105475 - Clamp, hose, 1-3/8".....	2
24		50A2330 - Nipple, pipe, 3/4" x 1-3/8".....	1
25		GM144113 - Elbow, steel, 3/4" N.P.T., 90°.....	1
	35A4076	Tube - hyd. pump hose to valve, MY 60.....	1
26	35A1289	Hose - Hyd. pump to valve, MY 40.....	1
27		GM9410978 - Elbow, hose, 7/8"-14, 90°.....	2
28	10A3256	"O" Ring - hose elbow.....	2
29	36A1291	Hose - valve to lift cylinder.....	1
30	35A1292	Tube - hose to lift cylinder, MY 40.....	1
	36A3719	Tube - valve hose to lift cylinder, MY 60.....	1
31		GM9410978 - Elbow, valve port, 7/8"-14.....	2
32		GM9410204 - Connector, lift cylinder, 7/8" x 14.....	1
33	10A18255	Seal - "O" ring, elbow and connector.....	2
34	36A1293	Tube - control valve port "A".....	1
35	35A1294	Tube - control valve port "B".....	1
36	10A18265	"O" Ring - control valve tube.....	2
37	35A1297	Tee - with orifice, valve tube.....	2
		GM444699 - Plug, pipe, 1/8" N.P.T.....	2
38	35A1295	Hose - port "A" tube to lift cylinder.....	2
39	35A1384	Hose - port "B" tube to lift cylinder.....	2
40		GM9410976 - Elbow, lift cylinder, 90°, 9/16"-18, rod end.....	2
41		GM9411104 - Elbow, lift cylinder, 45°, 9/16"-18, piston end.....	2
42	10A16405	"O" Ring - lift cylinder elbow.....	4
43	16A16577	Clip - valve tubes.....	1
		GM130024 - Bolt, hex., 1/4"-20 x 1-1/4".....	1
		GM130376 - Nut, hex., 1/4"-20.....	1
44	35A1296	Tube - hyd. pump to steering booster, MY 40.....	1
	35A1462	Tube - hyd. pump to steering booster, MY 60.....	1
45	35A1588	Tube - steering booster to hyd. oil tank, MY 40.....	1
	35A3506	Tube - steering booster to hyd. oil tank, MY 60.....	1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
HYDRAULIC CONTROL VALVE (Cont'd)			
46	35A1287	Hose - tube to booster	2
47		GM9410976 - Elbow, 90°, 9/16"-18, MY 40	3
		GM9410280 - Elbow, swivel, 3/8", 90°, MY 60	2
		GM9410202 - Connector, 3/8", 37°, MY 60	2
48	1CA16405	Seal - "O" ring, pump and booster elbow	3
49	RTS86D	Clip - tubes	4
		GM180171 - Bolt, hex., 1/2"-10 x 3/4"	2
50		GM9402709 - Connector, tube to hyd. tank, 1/4" NPT, 5/16"-18	1
51	1CA14576	Clamp - tube to tank	1
		GM150081 - Bolt, hex., 5/16"-18 x 1-3/4"	1
		GM120476 - Nut, hex., 5/16"-18	1
52	85A1438	Bracket - tube clamp	1
		GM1F0677 - Bolt, hex., 5/16"-18 x 3/4"	1
		GM150376 - Nut, hex., 5/16"-18	1
		*Hose - drain	1
		*50A1156 - Fitting, hose, 1/4"-18	1
		*GM119911 - Bushing, reducer, 3/8" to 1/4"	1
		*GM145616 - Clamp, hose, 5/8"	1
*NOTE: For use with Simplex Mast only, see chart on page 66.			



Fig. 2-32

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs
TILT CYLINDER			
1	35A2746	Cylinder - assembly Includes the following 19 parts:	2
2	35P485	Shell - assembly	2
3	35P306	Piston - half	2
4	35P313	Piston - half	2
5	35P310	Seal - "O" ring, piston to rod	2
6	35P307	Rider - nylon, piston	4
7	35P309	Packing - assembly	2
8	35P313	Rod - piston, 18-5/8" long	2
9	35P305	Nut - piston rod	2
10	35P209	Retainer - piston rod seals	2
11	35P314	Bushing - piston rod retainer	2
12	35P315	Seal - "O" ring, retainer to bushing	2
13	35P304	Packing - assembly, retainer bushing	2
14	35P308	Seal - "O" ring, retainer to outer shell	2
15	35P316	Ring - back-up, outer retainer seal	2
16	35P210	Washer - threaded, with nylon pellet	2
17	35P135	Pellet - nylon	2
18	35P203	Ring - wiper, piston rod	2
19	35P211	End - piston rod, with bushing	2
20	35P212	Bushing - piston rod end, also head end	4
		Bolt - hex. head, 3/8"-24 x 1-1/2"	2
		Nut, hex., 3/8"-24	2
21	35A702	Pin - with end plate, cyl. to frame, 1-1/4" x 3"	2
		GM191758 - Fitting, grease, 1/8"-27 straight	2
		GM180677 - Bolt, hex., 5/16"-18 x 3/4"	2
22	35A750	Pin - tilt cylinder, 2-1/4" x 3-3/4"	2
REEL AND HOSES			
	35A1469	Reel - hose, left hand	1
	35A9344	Reel - hose, right hand	1
		GM180173 - Bolt, hex., 1/2"-13 x 1"	2 or 4
	35A1482	Block - junction	1 or 2
		GM180128 - Bolt, hex., 3/8"-16 x 1-3/4"	1 or 2
	35A2181	Clip - hose, on tie bar	1 or 2
	35A9180	Hose - reel to junction box, 114" long	2 or 4
	35A3183	Hose - reel to junction box, 138" long	2 or 4
	35A9184	Hose - reel to junction box, 156" long	2 or 4
	35A1474	Hose - reel to valve, 89" long	2 or 4
	35A1477	Hose - reel to valve, 110" long	2 or 4
	35A1479	Hose - reel to valve, 124" long	2 or 4




Fig. 2-23

MOBILIFT - M³ 40 AND M³ 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		SIMPLEX LIFT CYLINDER	
1	-----	Cylinder - assembly, see chart on pages 84-85 Includes the following parts:	1
2	-----	*Shell	1
3	-----	*Plunger	1
4	33P486	Retainer - piston	1
5	33P180	Pin - roll, retainer to plunger	2
6	-----	*Spacer - plunger to shell	1
7	33P485	Piston - cylinder	1
8	33P176	Packing - piston retainer, assembly	1
9	33P178	Washer	2
10	33P177	Packing - set	1
11	33P179	Adaptor - female	1
12	33P174	Seal - "O" ring, retainer to piston	1
13	33P173	Ring - backup, retainer seal	1
14	33P175	Ring - snap, piston to retainer	1
15	33P147	Spring - cylinder spud	1
16	33P374	Washer - spud spring	1
17	33P373	Spacer - spud spring	1
18	33P172	Retainer - plunger, elbow end	1
19	33P191	Seal - "O" ring retainer to shell	1
20	33P189	Ring - taper, plunger to retainer	1
21	33P188	Spring - garter, taper ring	1
	33P497	Pin - dowel, spud end of cylinder	1
		*NOTE: Shell, Plunger and Spacer must be ordered by size, see chart for complete cylinder on page 84-85.	




Fig. 9-24

MODULIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No Pcs.
DUPLEX LIFT CYLINDER			
1	-----	Cylinder - lift, see chart page B4 Includes the following 85 parts:	1
2	-----	*Shell	1
3	-----	*Tube - intermediate stage	1
4	-----	*Tube - intermediate stage, inner	1
5	35P163	Screw - inner tube plate, 3/16"-24 x 3/8"	1
6	35P164	Seal - tube plate screw	1
7	35P480	Retainer - outer shell	1
8	35P152	Seal - "O" ring, retainer	1
9	35P481	Ring - wiper, retainer	1
10	35P150	Spring - garter, wiper ring, 4-9/32"	3
11	35P483	Retainer - intermediate tube	1
12	35P482	Ring - felt retainer	1
13	35P484	Ring - wiper, retainer	1
13A	35P478	Spring - garter, wiper ring	3
14	35P478	Piston	1
15	35P475	Packing - piston, outer	1
17	35P157	Ring - snap, piston packing	1
18	35P477	Packing - piston, inner	1
19	35P153	Ring - snap, piston packing	1
21	35P479	Pin - roll, piston	2
22	35P474	Retainer - piston	1
23	35P152	Seal - "O" ring, piston retainer	1
24	35P154	Ring - backup, "O" ring	1
25	35P470	Bushing - piston retainer	1
26	35P160	Seal - "O" ring, bushing to retainer	1
27	35P161	Ring - backup, bushing "O" ring	1
28	35P478	Packing - retainer bushing	1
29	35P471	Washer - threaded, piston retainer	1
30	-----	GM135692 - Screw, set, socket, 1 1/4"-28 x 1"	2
31	35P158	Ring - wiper, plunger to threaded washer	1
32	-----	*Plunger - cylinder	1
33	35P143	Bushing - plunger to inner tube	1
34	35P152	Ring - snap, plunger bushing	1
35	35P147	Spring - plunger, piston end	1
36	35P146	Washer - plunger spring	1
37	35P148	Socket - plunger spring	1
37	35P166	Pin - roll, plunger spring, 3/16" x 3/4"	1
*NOTE: Shell, tubes and plunger must be ordered by size, see chart for complete cylinder on page B4			




Fig. 2-35

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Qty. No	Part No.	DESCRIPTION	No. Per
MY 40 DUFLEX UPRIGHT			
1	-----	Roll - outer assembly, see chart on page 84	1
2	-----	Roll - inner assembly, see chart on page 84	1
3	D496	Shoe - mast	6
4	-----	50A648 - Screw, hex, socket, 3/8"-16 x 3/4"	12
5	D497	Shim - mast shoe	12
6	35A708	Roller - mast	10
7	D317	Bearing - mast roller	10
8	-----	50A577 - Ring, snap, 3-5/32" I.D.	10
9	-----	50A578 - Ring, snap, 1-3/9" I.D.	10
10	D297	Pin - with flange, mast roller	10
11	-----	50A647 - Screw, flat head, hex, socket, 1/2"-16 x 7/8"	54
12	-----	GM138290 - Screw, hex, socket, 1/2"-10 x 1"	10
13	-----	GM163029 - Washer, lock, 1/2"	16
14	-----	Carriage - see chart on page 84	1
15	35A622	Roller - thrust, Roller Brg. Corp. 74444	4
16	35A623	Pin - thrust roller, 3/4" x 1-28/32"	4
17	-----	Chain - see chart on page	2
18	35A934	Anchor - chain, 3"	2
19	35A937	Pin - chain anchor, 5/16" x 1-1/8"	2
20	-----	GM147666 - Pin, cotter, 3/16" x 1-1/4"	2
21	35A938	Anchor - chain	2
22	35A844	Pin - chain anchor, 5/8" x 2"	2
23	35A28	Roll - chain anchor, 5/4" x 12"	2
24	-----	50A197 - Nut, spherical, anchor rod	5
25	-----	GM219798 - Nut, hex, jam 3/4"-16	4
26	-----	*Cylinder - assembly, lift, see chart on page 84	1
27	-----	*NOTE: See page 79 for common component parts.	
28	35A31	Support - cylinder, upper	1
29	-----	50A222 - Bolt, hex, socket, 1/2"-18 x 1-1/2"	3
30	35A3285	Sheave - chain	2
31	35A32	Support - sheave	1
32	-----	50A243 - Ring, snap, cylinder support	1
33	-----	GM103384 - Screw, set, hex, socket, 5/16"-16 x 3/4"	1
34	D322	Bearing - ball, sheave support	2
35	D316	Ring - stop	2
36	D319	Ring - snap, spherulex, ball bearing	4
37	35A303	Pin - ball, cylinder, 1-1/4" x 3 1/8"	2
38	-----	50A282b - Pin, roll, 1/4" x 1-1/8"	2
39	-----	GM111596 - Fitting, grease, 1/8"	4
40	35A690	Pin - with plate, outer rail pivot	2
41	-----	GM271285 - Fitting, grease, 1/8", 90°	2
42	-----	GM193077 - Bolt, hex, hd, 5/16"-16 x 3/4"	2
43	-----	GM123214 - Washer, lock, 5/16"	2
44	35A538	Shim - pivot pin, 1-1/2" I.D., 1-1/4" long	2
45	-----	Roll - assembly, see chart on page 84	1
46	35A698	Pin - fork stop, 5/8" x 2-1/16", Clark Equip. Co. No. 756447	2
47	35A680	Roll - fork stop pin, Clark Equip. Co. No. 756448	2
48	-----	50A882 - Pin, roll, 5/16" x 1"	2
49	35A687	Spring - stop pin, 1-3/32" long	1
50	-----	GM150378 - Nut, hex., 1/2"-13	6
51	35A643	Rack Rest - load	1
52	-----	GM180199 - Bolt, hex., 1/2"-13 x 1-3/4"	6
53	-----	GM120384 - Washer, lock, 1/2"	6
54	35A215	Clip - light wire holding, on mast	4
55	35A313	Block - stop, outer rail	1
56	-----	GM271546 - Bolt, hex., 5/8"-18 x 1-3/4"	1




Fig. 2-36

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
MY 40 SIMPLEX UPRIGHT			
1	-----	Rail - outer assembly, see chart on page 84	1
2	-----	Rail - inner assembly, see chart on page 84	1
3	D476	Shoe - mast	6
4	-----	50A643 - Screw, hex., socket, 3/8"-16 x 3/4"	12
5	D467	Shim - mast shoe	12
6	35A708	Roller - mast	10
7	D317	Bearing - mast roller	10
8	-----	50A577 - Ring, snap, mast bearing, 3-5/32" I.D.	10
9	-----	50A576 - Ring, snap, mast bearing, 1-3/8" I.D.	10
10	D-297	Pin - with flange, mast rollers	10
11	-----	50A647 - Screw, flat head, hex. socket, 1/2"-13 x 7/3"	24
12	-----	GM136290 - Screw, hex. socket, 1/2"-13 x 7	16
12	-----	GM103369 - Washer, lock, 1/2"	16
13	-----	C-Straps - see chart on page 88	2
14	36A622	Roller - thrust, Roller Brg. Corp. #74444	4
15	35A923	Pin - thrust roller, 3/4" x 1-22/32"	4
16	-----	Chain - see chart on page 76	2
17	36A933	Anchor - chain, lower	2
18	35A934	Anchor - chain, upper	2
19	35A837	Pin - chain anchors, 5/16" x 1-1/8"	4
		GM133370 - Pin, center, 3/32" x 1/2"	6
20	35A200	Stud - chain anchor, 3/4"-20"	2
21	35A644	Pin - anchor, 5/8" x 2"	2
		36A787 - Nut, spherical	2
22	-----	*Cylinder - assembly, upright, see chart on page 84	1
		*NOTE: See page 74 for common component parts.	
23	36A724	Head - piston	1
		GM102586 - Screw, ser. piston head, 5/16"-16 x 1"	2
24	35A95	Sheave - piston head	2
25	35A417	Bushing - sheave	2
26	35A96	Pin - sheave, 1-1/2" x 3-7/8"	2
		50A2825 - Pin, roll, 1/4" x 1-1/4"	2
		GM271285 - Fitting, grease, 1/8"	2
27	36A920	Guide - platen head, 2" x 3"	2
		GM130149 - Belt, hex., 7/16"-14 x 1-1/2"	4
		GM271501 - Nut, hex., 7/16"-14	4
28	-----	Fork - lifting, see chart on page 88	2
29	35A628	Pin - fork stop	2
30	35A669	Lever - stop pin	2
31	35A667	Spring - stop pin	2
		50A2832 - Pin, roll, stop pin, 3/16" x 1"	2
32	36A750	Pin - assembly, outer rail pivot	2
		GM180077 - Bolt, hex., 5/16"-18 x 3/4"	2
33	36A706	Pin - assembly, til. cylinder	2
		GM180073 - Bolt, hex., 5/16"-18 x 1/2"	2
		GM103570 - Washer, lock, 5/16"	4
		GM271285 - Fitting, grease, 1/8"	4
34	-----	Back Rest - assembly, see chart on page 86	1
		GM180176 - Bolt, hex. head, 1/2"-13 x 1-3/3"	8
		GM120375 - Nut, hex., 1/2"-18	8
		GM120384 - Washer, lock, 1/2"	8
35	35A1463	Vent - strap	1
		GM133053 - Screw, 1/4"-20 x 1-1/4"	1
		GM120376 - Nut, hex., 1/4"-20	1
		GM120385 - Washer, lock, 1/4"	1
36	35A1464	Spacer	1
37	35A3513	Block - stop, outer rail	1
		GM27154E - Bolt, hex., 5/8"-18 x 1-1/4"	1




Fig. 2-37

MOBILITY - MY 40 AND MY 60 LIFT TRUCKS

Ref. No	Part No	DESCRIPTION	No. Per
MY 60 SIMPLEX UPRIGIT			
1	-----	Rail - outer assembly, see chart on page 85	1
2	-----	Rail - inner assembly, see chart on page 85	1
3	D476	Shoe - mast	8
4		50A848 - Screw, hex. socket, 5/8"-18 x 3/4"	12
5	D467	Shim - mast shoe	12
6	35A708	Roller - mast	10
7	D317	Bearing - mast roller	10
8		50A877 - Ring, snap, mast bearing	10
9		50A876 - Ring, snap, mast bearing	10
10	D-237	Pin - with flange, mast rollers	10
11		50A847 - Screw, flat head, hex. socket, 1/2"-13 x 7/8"	24
12		GM139090 - Screw, hex. socket, 1/2"-13 x 1	16
13	36A2015	Carriage - assembly, 36"	1
14	85A622	Roller - thrust, Roller Brg. Corp. #74444	4
15	85A624	Pin - thrust roller, 3/4" x 1-29/32"	4
16	-----	Chain - see chart on page 90	2
17	35A725	Anchor - chain, lower	2
18	35A726	Anchor - chain, upper	2
19	35A728	Pin - chain anchors, 1-5/16" x 2"	4
		GM138472 - Pin, corner, 3/32" x 1/2"	8
20	35A133	Stud - chain anchor, 3/4"-18 x 3-1/4"	2
21	35A738	Pin - anchor, 7/8" x 3-3/16"	2
		50A187 - Nut, spherical	2
22	-----	*Cylinder - assembly, upright, see chart on page 65	1
		*NOTE: See page 24 for common component parts.	
23	35A1877	Head - piston	1
		GM102588 - Screw, set, piston, head, 5/16"-18 x 1"	1
24	35A85	Sheave - piston head	2
25	35A417	Bushing - sheave	2
26	35A96	Pin - sheave, 1-1/2" x 3-1/8"	2
		50A262E - Pin, roll, 1/4" x 1-1/4"	2
		GM271285 - Fitting, grease, 1/8"	2
27	35A1879	Gulch - piston head	1
		GM271248 - Bolt, hex., 5/8"-18 x 1-3/4"	4
		GM138987 - Screw, cap, hex. socket, 5/8"-11 x 2"	2
28		Pin - fitting, assembly, see chart on page 85	2
29	35A668	Pin - fork stop	1
30	35A669	Lever - stop pin	2
31	35A667	Spring - stop pin	2
		50A2832 - Pin, roll, stop pin, 3/16" x 1"	2
32	35A759	Pin - assembly, outer rail pivot	2
		GM180377 - Bolt, hex., 5/16"-18 x 3/4"	2
33	36A1881	Pin - assembly, oil cylinder	2
		GM179780 - Bolt, hex., 1/4"-20 x 3/4"	2
		GM271285 - Fitting, grease, 1/8"	4
34	-----	Back Rest - assembly, see chart on page 85	1
		GM130176 - Bolt, hex. head, 1/2"-13 x 1-3/8"	8
		GM130378 - Nut, hex., 1/2"-13	8
35	35A1483	Vest - strap	1
		GM189355 - Screw, 1/4"-20 x 1-1/4"	1
		GM120370 - Nut, hex., 1/4"-20	1
36	35A1464	Spacer	1
37	35A3515	Block - stop, outer rail	1
		GM271346 - Bolt, hex., 5/8"-18 x 1-1/4"	1

MOBILIFT - MY 40 AND MY 60 LIFT TRUCKS

VARIEBLE PARTS CHART
FOR MY 40 SIMPLEX AND DUPLEX MASTE

OUTER RAIL		DUPLEX INNER RAIL		SIMPLEX INNER RAIL		DUPLEX LIFT CYLINDER		SIMPLEX LIFT CYLINDER		3/4" PITCH CHAIN	
Part No.	*Length	Part No.	*Length	Part No.	*Length	Part No.	Stroke	Part No.	Stroke	Part No.	Pitches Length
36A148E	60-1/2	36A2832	80-1/2	36A1546	60-1/2	35A2655	22-1/4	35A1675	44-3/4	35A2638	57 42-3/4
36A1487	62	36A2833	82	36A1547	62	35A2656	23	35A1676	46 1/4	35A2639	59 44-1/4
36A1488	63-1/2	36A2834	83-1/2	36A1548	63-1/2	35A2657	23-3/4	35A1677	47-3/4	35A2640	61 45-3/4
36A1489	65	36A2835	85	36A1549	65	35A2658	24-1/2	35A1678	49-1/4	35A2641	63 47-1/4
36A1490	66-1/2	36A2836	86-1/2	36A1550	66-1/2	35A2659	25-1/4	35A1679	50-3/4	35A2642	65 48-3/4
36A1491	68	36A2837	88	36A1551	68	35A2660	26	35A1680	52-1/4	35A2643	67 50-1/4
36A1492	69-1/2	36A2838	89-1/2	36A1552	69-1/2	35A2661	26-3/4	35A1681	53-3/4	36A2644	69 51-3/4
36A1493	71	36A2839	91	36A1553	71	35A2662	27-1/2	35A1682	55-1/4	35A2645	71 53-1/4
36A1494	72-1/2	36A2840	92-1/2	36A1554	72-1/2	35A2663	28-1/4	35A1683	56-3/4	35A2646	73 54-3/4
36A1495	74	36A2841	94	36A1555	74	35A2664	29	35A1684	58-1/4	35A2647	75 56-1/4
36A1496	75-1/2	36A2842	95-1/2	36A1556	75-1/2	35A2665	29-3/4	35A1685	59 3/4	36A2648	77 57-3/4
36A1497	77	36A2843	97	36A1557	77	35A2666	30-1/2	35A1686	61-1/4	35A2649	79 59-1/4
36A1498	78-1/2	36A2844	98-1/2	36A1558	78-1/2	35A2667	31-1/4	35A1687	62-3/4	35A2650	81 60-3/4
36A1499	80	36A2845	100	36A1559	80	35A2668	32	35A1688	64-1/4	35A2651	83 62-1/4
36A1500	81-1/2	36A2846	101-1/2	36A1560	81-1/2	35A2669	32-3/4	35A1689	65-3/4	35A2652	85 63-3/4
36A1501	83	36A2847	103	36A1561	83	35A2670	33-1/2	35A1690	67-1/4	35A2653	87 65-1/4
36A1502	84-1/2	36A2848	104-1/2	36A1562	84-1/2	35A2671	34-1/4	35A1691	68-3/4	35A2654	89 66-3/4
36A1503	86	36A2849	106	36A1563	86	35A2672	35	35A1692	70-1/4	35A1703	91 68-1/4
36A1504	87-1/2	36A2850	107-1/2	36A1564	87-1/2	35A2673	35-3/4	35A1693	72-3/4	35A1706	93 69-3/4
36A1505	89-1/2	36A2851	109	36A1565	89-1/2	35A2674	36-1/2	35A1694	73-1/4	35A1707	95 71-1/4
36A1506	90	36A2852	110	36A1566	90	35A2675	37-1/4	36A1695	74-3/4	35A1708	97 72-3/4
36A1507	91	36A2853	111	36A1567	91	35A2676	38	35A1696	76-1/4	36A1709	99 74-1/4
36A1508	91-1/2	36A2854	111-1/2	36A1568	91-1/2	35A2677	38-3/4	36A1697	77-3/4	36A1710	101 75-3/4
36A1509	92-1/2	36A2855	112-1/2	36A1569	92-1/2	35A2678	39-1/2	36A1698	78-1/4	36A1711	103 77-1/4
36A1510	93	36A2856	113	36A1570	93-1/2	35A2679	40-1/4	36A1699	80-3/4	36A1712	105 78-3/4
36A1511	94	36A2857	114	36A1571	94	36A2680	41	36A1700	82-1/4	36A1713	107 80-1/4
36A1512	94-1/2	36A2858	114-1/2	36A1572	94-1/2	36A2681	41-3/4	36A1701	83-3/4	36A1714	109 81-3/4
36A1513	95-1/2	36A2859	115-1/2	36A1573	95	36A2682	42-1/2	36A1702	85-1/4	36A1715	111 83-1/4
36A1514	96	36A2860	116	36A1574	96-1/2	36A2683	43-1/4	36A1703	86-3/4	36A1716	113 84-3/4
36A1515	97-1/2	36A2861	117	36A1575	97-1/2	36A2684	44	36A1704	88-1/4	36A1717	115 86-1/4
36A1516	98-1/2	36A2862	118-1/2			36A2685	44-3/4			36A1718	117 87-3/4
36A1517	99	36A2863	119			36A2686	45-1/2			36A1719	119 89-1/4
36A1518	100	36A2864	120			36A2687	46-1/4			36A1720	121 90-3/4
36A1519	100-1/2	36A2865	120-1/2			36A2688	47			36A1721	123 92-1/4
36A1520	101-1/2	36A2866	121-1/2			36A2689	47-3/4			36A1722	125 93-3/4
36A1521	102	36A2867	122			36A2690	48-1/2			36A1723	127 95-1/4
36A1522	103	36A2868	123-1/2			36A2691	49-1/4			36A1724	129 96-3/4
36A1523	103-1/2	36A2869	124			36A2692	50			36A1725	131 98-1/4
36A1524	104-1/2									36A1726	133 99-3/4
36A1525	105-1/2									36A1727	135 100-1/4
36A1526	107									36A1728	137 102-3/4
36A1527	108-1/2									36A1729	139 104-1/4
36A1528	110									36A1730	141 105-3/4
36A1529	111-1/2									36A1731	143 107-1/4
36A1530	113									36A1732	145 108-3/4
36A1531	115-1/2									36A1733	147 110-1/4
36A1532	117									36A1734	149 111-3/4
36A1533	118-1/2										
36A1534	120										

*NOTE: Figures in length column denotes actual length of rails,
for overall height lowered add 5 inches to lengths shown.

MOBILIFT - MY 40 AND MY 69 LIFT TRUCKS

VARIABLE PARTS CHART
FOR MY 60 SIMPLEX MAST

Max. Fork Height"	Overall Height Lowered"	OUTER RAIL		INNER RAIL		LIFT CYLINDER		CHAIN		
		Part No.	Length"	Part No.	Length"	Part No.	Stroke"	Part No.	Pitches	Length"
91	79	36A1882	85	36A1922	86	35A1878	44-3/4	35A2083	91	88-1/4
94	71-1/2	36A1883	86-1/2	36A1923	86-1/2	35A1876	46-1/4	35A2084	98	69-3/4
97	73	36A1884	88	36A1924	88	35A1877	47-3/4	35A2085	95	71-1/4
100	74-1/2	36A1885	89-1/2	36A1925	89-1/2	35A1878	49-1/4	35A2086	97	72-3/4
103	75	36A1886	91	36A1926	91	35A1879	50-3/4	35A2087	99	74-1/4
106	77-1/2	36A1887	92-1/2	36A1927	92-1/2	35A1880	52-1/4	35A2088	101	75-3/4
109	79	36A1888	94	36A1928	94	35A1881	53-3/4	35A2089	103	77-1/4
112	80-1/2	36A1889	95-1/2	36A1929	95-1/2	35A1882	55-1/4	35A2090	106	78-3/4
115	82	36A1890	97	36A1930	97	35A1883	56-3/4	35A2091	107	80-1/4
118	83-1/2	36A1891	99-1/2	36A1931	98-1/2	35A1884	58-1/4	35A2092	109	81-3/4
121	85	36A1892	100	36A1932	100	35A1885	59-3/4	35A2093	111	83-1/4
124	86-1/2	36A1893	101-1/2	36A1933	101-1/2	35A1886	61-1/4	35A2094	113	84-3/4
127	88	36A1894	103	36A1934	103	35A1887	63-3/4	35A2095	115	86-1/4
130	89-1/2	36A1895	104-1/2	36A1935	104-1/2	35A1888	64-1/4	35A2096	117	87-3/4
133	91	36A1896	106	36A1936	106	35A1889	65-3/4	35A2097	119	89-1/4
136	92-1/2	36A1897	107-1/2	36A1937	107-1/2	35A1890	67-1/4	35A2098	121	90-3/4
139	94	36A1898	109	36A1938	109	35A1891	68-3/4	35A2099	123	92-1/4
142	95-1/2	36A1899	110-1/2	36A1939	110-1/2	35A1892	70-1/4	35A2080	126	93-3/4
145	97	36A1900	112	36A1940	112	35A1893	71-3/4	35A2081	127	95-1/4
148	99	36A1901	114	36A1941	114	35A1894	73-1/4	35A2082	129	96-3/4
151	100-1/2	36A1902	115-1/2	36A1942	115-1/2	35A1895	74-3/4	35A2083	131	98-1/4
154	102	36A1903	117	36A1943	117	35A1896	76-1/4	35A2084	133	99-3/4
157	103-1/2	36A1904	118-1/2	36A1944	118-1/2	35A1897	77-3/4	35A2085	135	101-1/4
160	105	36A1905	120	36A1945	120	35A1898	79-1/4	35A2086	137	102-3/4
163	107	36A1906	122	36A1946	122	35A1899	80-3/4	35A2087	139	104-1/4
166	108-1/2	36A1907	123-1/2	36A1947	123-1/2	35A1900	82-1/4	35A2088	141	106-3/4
169	110	36A1908	125	36A1948	125	35A1901	83-3/4	35A2089	143	107-1/4
172	111-1/2	36A1909	126-1/2	36A1949	126-1/2	35A1902	85-1/4	35A2090	145	109-3/4
175	113	36A1910	128	36A1950	128	35A1903	86-3/4	35A2091	147	110-1/4
178	115	36A1911	130	36A1951	130	35A1904	88-1/4	35A2092	149	111-3/4

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
6435	48	10A 5935	6	10A 6479	8	10A10343	16
		10A 5936	6	10A 6505	26	10A10401	5
D 297	78-80	10A 5937	6	10A 6581	5	10A10444	16
D 313	78	10A 5946	6-8	10A 6587	4	10A10445	16
O 316	78	10A 5956	6-21	10A 6588	4	10A10471	44
O 317	78-80	10A 5966	8	10A 6712	44	10A10601	17
O 322	78	10A 5969	6	10A 6849	4-13	10A10686	24
U 467	78-80	10A 5988	6	10A 6958	4	10A10689	24
D 476	78-80	10A 6005	6	10A 6959	28	10A10699	28
D 1186	18	10A 6006	21	10A 6999	4	10A10700	28
		10A 6009	6	10A 7183	21	10A10749	17
RE 1746	4	10A 6010	8	10A 7201	21	10A10758	6
		10A 6015	8	10A 7202	8	10A10804	6
RT 886D	38-71	10A 6016	6	10A 7203	21	10A11489	44
		10A 6018	16	10A 7205	8	10A11543	32-33
VT 223	54-56	10A 6020	4	10A 7206	6	10A12012	38-68
VT 224	54-56	10A 6025	4-16	10A 7207	6	10A12051	4
VT 225	54-56	10A 6285	70	10A 7213	12	10A12198	16
VT 897	42	10A 6329	32-36	10A 7252	6	10A12342	26
VT 924	42-52	10A 6330	36	10A 7302	22	10A12699	4
		10A 6350	8	10A 7313	4	10A12906	21
10A 256	44	10A 6351	6	10A 7447	12	10A13490	4
10A 307	17	10A 6376	4-22	10A 7484	4	10A13491	4
10A 405	44	10A 6378	4	10A 7537	10	10A13667	6
10A 525	22	10A 6380	4-22	10A 7581	28	10A13679	8
10A 574	52	10A 6381	4	10A 7695	12	10A13726	10
10A 693	42-52	10A 6383	22	10A 7723	12	10A13922	28
10A 781	44	10A 6385	22	10A 7894	21	10A13923	28
10A 1173	22	10A 6386	22	10A 7896	21	10A14043	8
10A 1504	44	10A 6387	22	10A 7931	12	10A14373	22
10A 1677	30	10A 6392	8	10A 8745	28	10A14720	70
10A 1697	44	10A 6395	26	10A 8853	36	10A14877	16
10A 2015	4	10A 6397	8	10A 8973	22	10A14878	16
10A 2040	8	10A 6398	26	10A 9020	6	10A15467	62
10A 2296	30	10A 6400	22	10A 9025	4-16	10A15485	16
10A 2297	32	10A 6402	8	10A 9027	12	10A15577	24
10A 2382	48	10A 6403	6	10A 9072	4	10A15639	34
10A 3046	21	10A 6405	26	10A 9146	28	10A15697	22
10A 3397	22-33	10A 6406	22	10A 9161	4	10A15752	36
10A 3436	30	10A 6408	8	10A 9227	12	10A16003	5
10A 3978	50	10A 6412	22-26	10A 9304	4	10A16123	21
10A 4538	4-36	10A 6413	22	10A 9758	28	10A16285	70
10A 4859	10	10A 6414	22	10A 9808	32	10A16297	28
10A 4861	10	10A 6415	22	10A 9818	20	10A16321	28
10A 4865	10	10A 6417	4	10A 9835	5	10A16329	36
10A 5097	4	10A 6418	4	10A 9838	4	10A16338	28
10A 5285	4-10	10A 6423	10	10A 9850	4	10A16387	24
10A 5560	44	10A 6425	6	10A 9851	5	10A16405	70-71
10A 5648	64	10A 6427	26	10A10007	6	10A16423	21
10A 5844	8	10A 6429	8	10A10040	8	10A16469	24
10A 5912	10	10A 6431	22	10A10045	6	10A16487	68
10A 5915	8	10A 6435	8	10A10202	4	10A16489	68
10A 5916	21	10A 6440	8	10A10224	64	10A16490	68
10A 5929	12	10A 6448	40-42	10A10329	24	10A16576	71

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
10A16577	70	10P 763	14	10P 1803	14	11A16837	5
10A16587	16	10P 764	14	10P 1872	12	11A16913	13
10A16654	10	10P 765	14	10P 1873	12	11A16927	4
10A16815	4	10P 766	14	10P 1874	12	11A17475	10
10A16816	26	10P 767	14	10P 1875	13	11A17476	10
10A16817	26	10P 768	14	10P 1876	13		
10A16836	6	10P 769	14	10P 1877	13	11B 3	26
10A16838	13	10P 770	14	10P 1878	13	11B 6421	4
10A16840	5	10P 771	14	10P 1879	13	11B 6500	4
10A16842	5	10P 772	14	10P 1880	13	11B16863	10
10A16868	4	10P 773	14	10P 1881	13		
10A16890	5	10P 774	14	10P 1882	13	15A10703	40
10A16891	5	10P 776	14	10P 1883	13	15A12647	52
10A16902	14	10P 778	14	10P 1884	13	15A12648	52
10A16904	12	10P 1033	58	10P 1885	13	15A13908	70
10A16909	22	10P 1345	56	10P 1886	13	15A14814	38
10A16945	8	10P 1552	28	10P 1887	13	15A15557	28
10A16952	64	10P 1553	28	10P 1888	13		
10A16953	10	10P 1592	66	10P 1889	13	15P 23	13
10A16978	5	10P 1595	64-66	10P 1890	14	15P 24	13
10A17477	10	10P 1597	58	10P 1891	14	15P 652	68
10A17879	22	10P 1598	58	10P 1892	14	15P 654	68
		10P 1599	58	10P 1893	14	15P 655	68
10B 420	10	10P 1600	58			15P 656	68
10B 421	10	10P 1606	58	10R 71	30	15P 657	68
10B 422	10	10P 1607	58	10R 385	26	15P 660	68
10B 423	10	10P 1608	58	10R 826	6	15P 663	68
10B 424	10	10P 1609	58	10R 972	8		
10B 6032	10	10P 1613	58	10R 973	4	20H 4700	40
10B 6973	8	10P 1614	58	10R 986	21		
10B 9198	26	10P 1615	58	10R 992	10	30A 1807	62
10B11839	22	10P 1617	58	10R 993	10		
		10P 1618	58	10R 994	10	30P 559	54-56
10P 68	14	10P 1619	58			30P 560	54-56
10P 347	13	10P 1620	58	11A 4860	10	30P 562	56
10P 472	58	10P 1621	58	11A 5559	44	30P 566	54-56
10P 519	58	10P 1622	58	11A 5647	64		
10P 635	26	10P 1623	58	11A 5851A	6	35A 3	32
10P 636	26	10P 1624	58	11A 5980	4-10	35A 6	38
10P 744	14	10P 1635	16	11A 5981	10	35A 7	36
10P 746	14	10P 1636	16	11A 5982	10	35A 9	36
10P 747	14	10P 1637	16	11A 5983	10	35A 10	36
10P 748	14	10P 1638	16	11A 5984	10	35A 28	78
10P 749	14	10P 1641	16	11A 6416	4	35A 31	78
10P 750	14	10P 1642	16	11A 6870	4-10	35A 56	30
10P 751	14	10P 1650	68	11A 6871	10	35A 56	61
10P 752	14	10P 1652	68	11A 6872	10	35A 57	30
10P 754	14	10P 1738	58	11A 6873	10	35A 95	80-82
10P 755	14	10P 1747	14	11A 6874	10	35A 96	80-82
10P 756	14	10P 1772	64-66	11A 7253	21	35A 100	80-82
10P 759	14	10P 1798	14	11A 7890	21	35A 103	33
10P 760	14	10P 1799	14	11A13662	6	35A 105	32
10P 761	14	10P 1800	14	11A15555	10	35A 152	60
10P 762	14	10P 1801	14	11A16004	4	35A 178	20

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
35A 182	54-56	35A 358	34	35A 573	36	35A 827	60
35A 185	50	35A 359	34	35A 574	36	35A 830	60
35A 189	50	35A 363	34	35A 577	36	35A 837	78-80
35A 190	50	35A 365	34	35A 582	38	35A 839	52
35A 191	50	35A 366	34	35A 583	36	35A 846	70
35A 200	48	35A 367	34	35A 585	36	35A 849	34
35A 201	48	35A 368	34	35A 586	38	35A 851	32
35A 202	48	35A 369	34	35A 587	36	35A 852	32
35A 203	48	35A 372	36	35A 588	78	35A 862	38
35A 210	30	35A 373	36	35A 588	60	35A 866	66
35A 212	30	35A 374	36	35A 609	78	35A 867	64
35A 214	30	35A 375	36	35A 622	78-80	35A 869	44
35A 226	44	35A 376	36	35A 623	78-80	35A 873	32
35A 227	44	35A 377	36	35A 626	61	35A 886	40
35A 230	44	35A 379	36	35A 627	61	35A 887	40
35A 231	44	35A 382	61	35A 632	28	35A 909	28
35A 236	44	35A 384	61	35A 639	52	35A 920	80
35A 237	44	35A 387	28-50	35A 641	28	35A 933	78-80
35A 238	44	35A 388	50	35A 644	78-80	35A 934	78-80
35A 239	44	35A 389	32	35A 652	52	35A 980	34
35A 242	44	35A 390	32	35A 667	78-80	35A 981	34
35A 244	44	35A 391	32	35A 668	78-80	35A 988	30
35A 278	36	35A 392	32	35A 669	78-80	35A 993	34
35A 283	36	35A 405	28	35A 676	34	35A 996	30
35A 309	30	35A 406	30	35A 683	33-44	35A 1012	52
35A 310	32	35A 408	30	35A 688	36	35A 1020	50
35A 311	33	35A 411	30	35A 689	36	35A 1040	54
35A 312	33	35A 412	30	35A 690	36	35A 1059	20
35A 314	33	35A 417	80-82	35A 691	36	35A 1065	20
35A 317	32	35A 419	32	35A 692	36	35A 1066	55
35A 318	32	35A 420	44	35A 693	36	35A 1067	30
35A 321	32	35A 421	44	35A 694	36	35A 1068	30
35A 322	33	35A 425	44	35A 695	36	35A 1102	30
35A 327	34	35A 475	60	35A 696	36	35A 1241	46
35A 330	34	35A 481	62	35A 697	36	35A 1242	46
35A 331	34	35A 482	62	35A 698	64-66	35A 1247	24
35A 332	34	35A 483	60	35A 700	64-66	35A 1248	32
35A 333	34	35A 497	62	35A 705	64	35A 1249	32
35A 334	34	35A 498	62	35A 708	78-80	35A 1250	32
35A 335	34	35A 499	62	35A 709	32	35A 1252	44
35A 336	34	35A 501	60	35A 735	82	35A 1257	70
35A 337	34	35A 502	60	35A 736	82	35A 1271	50
35A 339	34	35A 503	60	35A 738	82	35A 1272	50
35A 341	34	35A 504	60	35A 739	82	35A 1275	17
35A 342	34	35A 505	60	35A 752	60	35A 1276	17
35A 346	34	35A 522	17	35A 754	42	35A 1280	17
35A 347	34	35A 532	54	35A 757	52	35A 1282	38
35A 348	34	35A 535	54	35A 758	52	35A 1283	38
35A 349	34	35A 551	40	35A 802	60	35A 1284	38
35A 350	34	35A 555	52	35A 803	60	35A 1285	64
35A 351	34	35A 556	52	35A 804	66	35A 1286	70
35A 353	34	35A 558	52	35A 810	24	35A 1287	71
35A 355	34	35A 564	40	35A 811	56	35A 1288	70
35A 357	34	35A 565	40	35A 814	56	35A 1289	70

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
35A 1291	70	35A 1702	84-85	35A 1770	36	35A 2087	85
35A 1292	70	35A 1703	84-85	35A 1771	36	35A 2088	85
35A 1293	70	35A 1704	84-85	35A 1779	50	35A 2089	85
35A 1294	70	35A 1705	84	35A 1780	50	35A 2090	85
35A 1295	70	35A 1706	84	35A 1795	40	35A 2091	85
35A 1297	70	35A 1707	84	35A 1796	40	35A 2092	85
35A 1299	52	35A 1708	84	35A 1797	40	35A 2107	61
35A 1300	52	35A 1709	84	35A 1798	52	35A 2108	26
35A 1426	20	35A 1710	84	35A 1799	40	35A 2109	28
35A 1427	44	35A 1711	84	35A 1800	40	35A 2112	44
35A 1433	71	35A 1712	84	35A 1801	40	35A 2120	48
35A 1435	12	35A 1713	84	35A 1802	40	35A 2120	48
35A 1448	32	35A 1714	84	35A 1803	40-52	35A 2133	34
35A 1449	66	35A 1715	84	35A 1810	48	35A 2136	58
35A 1452	70	35A 1716	84	35A 1811	48	35A 2145	60
35A 1463	80-82	35A 1717	84	35A 1812	48	35A 2151	76
35A 1464	80-82	35A 1718	84	35A 1814	62	35A 2153	44
35A 1466	52	35A 1719	84	35A 1815	60	35A 2154	44
35A 1467	32	35A 1720	84	35A 1832	60	35A 2155	44
35A 1469	72	35A 1721	84	35A 1834	50	35A 2156	44
35A 1474	72	35A 1722	84	35A 1845	36	35A 2157	44
35A 1477	72	35A 1723	84	35A 1847	40	35A 2158	44
35A 1479	72	35A 1724	84	35A 1848	44	35A 2159	44
35A 1482	72	35A 1725	84	35A 1850	44	35A 2167	44
35A 1483	40	35A 1726	84	35A 1855	50	35A 2168	32
35A 1484	62	35A 1727	84	35A 1860	50	35A 2176	62
35A 1485	62	35A 1728	84	35A 1861	50	35A 2178	62
35A 1675	84-85	35A 1729	84	35A 1862	50	35A 2179	62
35A 1676	84-85	35A 1730	84	35A 1864	70	35A 2181	60
35A 1677	84-85	35A 1731	84	35A 1879	82	35A 2231	28
35A 1678	84-85	35A 1732	84	35A 2063	85	35A 2234	12
35A 1679	84-85	35A 1733	84	35A 2064	85	35A 2237	62
35A 1680	84-85	35A 1734	84	35A 2065	85	35A 2242	48
35A 1681	84-85	35A 1735	86	35A 2066	85	35A 2245	48
35A 1682	84-85	35A 1736	86	35A 2067	85	35A 2246	48
35A 1683	84-85	35A 1737	86	35A 2068	85	35A 2247	48
35A 1684	84-85	35A 1738	86	35A 2069	85	35A 2248	48
35A 1685	84-85	35A 1739	86	35A 2070	85	35A 2250	46
35A 1686	84-85	35A 1740	86	35A 2071	85	35A 2251	48
35A 1687	84-85	35A 1741	86	35A 2072	85	35A 2252	48
35A 1688	84-85	35A 1742	86	35A 2073	85	35A 2253	48
35A 1689	84-85	35A 1743	86	35A 2074	85	35A 2258	12
35A 1690	84-85	35A 1744	86	35A 2075	85	35A 2384	48
35A 1691	84-85	35A 1745	86	35A 2076	85	35A 2385	48
35A 1692	84-85	35A 1746	86	35A 2077	85	35A 2392	12
35A 1693	84-85	35A 1747	86	35A 2078	85	35A 2393	12
35A 1694	84-85	35A 1749	28	35A 2079	85	35A 2396	12
35A 1695	84-85	35A 1750	44	35A 2080	85	35A 2400	12
35A 1696	84-85	35A 1751	44	35A 2081	85	35A 2415	60
35A 1697	84-85	35A 1754	30	35A 2082	85	35A 2419	32
35A 1698	84-85	35A 1757	30	35A 2083	85	35A 2461	50
35A 1699	84-85	35A 1758	62	35A 2084	85	35A 2468	50
35A 1700	84-85	35A 1759	30	35A 2085	85	35A 2496	30
35A 1701	84-85	35A 1765	30	35A 2086	85	35A 2514	54-56

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
35A 2520	52	35A 2690	84	35A 3032	68	35P 17	42
35A 2524	64-66	35A 2691	84	35A 3033	68	35P 23	42
35A 2638	84	35A 2692	84	35A 3034	68	35P 24	42
35A 2639	84	35A 2693	30	35A 3035	70	35P 25	42
35A 2640	84	35A 2694	30	35A 3078	68	35P 26	42
35A 2641	84	35A 2699	30	35A 3079	86	35P 31	38
35A 2642	84	35A 2742	24	35A 3080	86	35P 32	38
35A 2643	84	35A 2746	72	35A 3081	86	35P 33	38
35A 2644	84	35A 2775	52	35A 3082	86	35P 34	38
35A 2645	84	35A 2776	86	35A 3083	86	35P 35	38
35A 2646	84	35A 2777	86	35A 3084	86	35P 36	38
35A 2647	84	35A 2778	86	35A 3085	86	35P 37	38
35A 2648	84	35A 2779	86	35A 3086	86	35P 38	38
35A 2649	84	35A 2780	86	35A 3087	86	35P 39	24
35A 2650	84	35A 2781	86	35A 3088	86	35P 47	54-56
35A 2651	84	35A 2782	86	35A 3089	86	35P 48	54-56
35A 2652	84	35A 2783	86	35A 3090	86	35P 49	54-56
35A 2653	84	35A 2784	86	35A 3091	86	35P 49	58
35A 2654	84	35A 2785	86	35A 3092	86	35P 51	54-56
35A 2655	84	35A 2786	86	35A 3093	86	35P 55	20
35A 2656	84	35A 2787	86	35A 3096	86	35P 56	20
35A 2657	84	35A 2788	86	35A 3099	86	35P 57	20
35A 2658	84	35A 2789	86	35A 3102	86	35P 58	20
35A 2659	84	35A 2790	86	35A 3103	86	35P 59	20
35A 2660	84	35A 2791	86	35A 3104	86	35P 60	20
35A 2661	84	35A 2792	86	35A 3106	86	35P 79	54-56
35A 2662	84	35A 2793	86	35A 3117	70	35P 60	54
35A 2663	84	35A 2794	86	35A 3118	70	35P 81	54-56
35A 2664	84	35A 2795	86	35A 3119	70	35P 82	54-56
35A 2665	84	35A 2796	86	35A 3120	70	35P 83	54-56
35A 2666	84	35A 2797	86	35A 3161	72	35P 84	54-56
35A 2667	84	35A 2798	86	35A 3162	72	35P 86	54-56
35A 2668	54	35A 2799	86	35A 3183	72	35P 87	54-56
35A 2669	84	35A 2800	86	35A 3184	72	35P 88	54-56
35A 2670	84	35A 2801	86	35A 3244	72	35P 89	54-56
35A 2671	84	35A 2802	86	35A 3265	50	35P 108	42-52
35A 2672	84	35A 2803	86	35A 3266	50	35P 109	42
35A 2673	84	35A 2804	86	35A 3267	50	35P 110	42
35A 2674	84	35A 2805	86	35A 3268	32	35P 111	42
35A 2675	84	35A 2890	30	35A 3282	78	35P 112	42
35A 2676	84	35A 2891	30	35A 3297	62	35P 113	42
35A 2677	84	35A 2907	44	35A 3301	28	35P 114	42
35A 2678	84	35A 2909	44	35A 3302	28	35P 115	42
35A 2679	84	35A 2934	24	35A 3303	28	35P 116	42
35A 2680	84	35A 2935	5	35A 3367	86	35P 117	42
35A 2681	84	35A 2995	42	35A 3373	62	35P 118	42
35A 2682	84	35A 3001	54-56	35A 3383	28	35P 119	42
35A 2683	84	35A 3004	28-30	35A 3506	70	35P 120	42
35A 2684	84	35A 3006	28	35A 3513	78-80	35P 121	42
35A 2685	84	35A 3007	28	35A 3719	70	35P 122	42
35A 2686	84	35A 3008	28	35A 4076	70	35P 123	42-52
35A 2687	84	35A 3009	28			35P 124	42-52
35A 2688	84	35A 3010	70	35B 243	34-44	35P 125	42-52
35A 2689	84	35A 3031	28			35P 126	42-52

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
35P 127	42-52	35P 241	54-56	35P 324	46	35P 450	55
35P 128	42-52	35P 242	54-56	35P 325	46	35P 451	55
35P 129	42-52	35P 269	64	35P 326	46	35P 452	55
35P 135	72	35P 270	64	35P 327	46	35P 453	55
35P 143	76	35P 271	64-66	35P 328	46	35P 454	55
35P 147	74-76	35P 272	64-66	35P 329	46	35P 455	55
35P 148	76	35P 273	64	35P 330	46	35P 467	20
35P 149	76	35P 274	64-66	35P 331	46	35P 468	20
35P 150	76	35P 275	64	35P 332	46	35P 469	20
35P 152	76	35P 276	64	35P 333	46	35P 470	55
35P 153	76	35P 277	64	35P 334	46	35P 471	76
35P 154	76	35P 278	64	35P 335	46	35P 472	76
35P 156	76	35P 279	64	35P 336	46	35P 473	76
35P 157	76	35P 280	64	35P 337	46	35P 474	76
35P 158	76	35P 281	64-66	35P 338	46	35P 475	76
35P 160	76	35P 282	64-66	35P 339	46	35P 476	76
35P 161	76	35P 283	64-66	35P 340	46	35P 477	76
35P 162	76	35P 284	64-66	35P 341	46	35P 478	76
35P 164	76	35P 285	64-66	35P 342	46	35P 479	76
35P 165	76	35P 286	64-66	35P 343	46	35P 480	76
35P 166	76	35P 287	64-66	35P 344	46	35P 481	76
35P 172	74	35P 288	64-66	35P 345	46	35P 482	76
35P 173	74	35P 289	64-66	35P 350	58	35P 483	76
35P 174	74	35P 290	64-66	35P 351	58	35P 484	76
35P 175	74	35P 291	64-66	35P 352	58	35P 485	74
35P 176	74	35P 292	64-66	35P 353	58	35P 486	74
35P 177	74	35P 293	64-66	35P 354	58	35P 487	74
35P 178	74	35P 294	64-66	35P 355	58	35P 488	72
35P 179	74	35P 295	64-66	35P 356	58	35P 491	62
35P 180	74	35P 296	64-66	35P 357	58	35P 492	62
35P 181	74	35P 297	64-66	35P 358	58	35P 493	62
35P 182	74	35P 298	66	35P 359	58	35P 494	62
35P 183	74	35P 299	66	35P 360	58	35P 495	62
35P 198	58	35P 300	66	35P 361	58	35P 496	62
35P 199	58	35P 301	66	35P 362	58	35P 497	62
35P 200	58	35P 302	54	35P 363	28	35P 506	18
35P 204	72	35P 305	72	35P 364	28	35P 507	18
35P 208	72	35P 306	72	35P 365	28	35P 508	18
35P 209	72	35P 307	72	35P 366	28	35P 509	18
35P 210	72	35P 308	72	35P 367	56	35P 510	18
35P 211	72	35P 309	72	35P 368	56	35P 511	18
35P 212	72	35P 310	72	35P 369	56	35P 512	18
35P 213	68	35P 311	72	35P 370	56	35P 513	18
35P 215	68	35P 313	72	35P 371	56	35P 514	18
35P 216	68	35P 314	72	35P 372	52	35P 515	18
35P 217	68	35P 315	72	35P 373	54	35P 516	18
35P 218	68	35P 316	72	35P 374	74	35P 517	18
35P 220	68	35P 317	46	35P 375	74	35P 518	18
35P 221	68	35P 318	46	35P 376	50	35P 519	18
35P 222	68	35P 319	46	35P 387	50	35P 520	18
35P 225	68	35P 320	46	35P 446	55	35P 523	18
35P 238	54-56	35P 321	46	35P 447	55	35P 524	18
35P 239	54-56	35P 322	46	35P 448	55	35P 525	30
35P 240	54-56	35P 323	46	35P 449	55	35P 526	30

N U M E R I C A L I N D E X


Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
35P 527	18	36A 1491	84	36A 1575	84	36A 1926	85
35P 528	30	36A 1492	84	36A 1636	86	36A 1927	85
35P 529	18	36A 1493	84	36A 1637	86	36A 1928	85
35P 530	30	36A 1494	84	36A 1638	86	36A 1929	85
35P 531	30	36A 1495	84	36A 1639	86	36A 1930	85
35P 541	18	36A 1496	84	36A 1640	86	36A 1931	85
35P 542	42	36A 1497	84	36A 1641	86	36A 1932	85
		36A 1498	84	36A 1642	86	36A 1933	85
36A 4	32	36A 1499	84	36A 1643	86	36A 1934	85
36A 29	78	36A 1500	84	36A 1644	86	36A 1935	85
36A 102	32	36A 1501	84	36A 1645	86	36A 1936	85
36A 235	44	36A 1502	84	36A 1646	86	36A 1937	85
36A 317	32	36A 1503	84	36A 1647	86	36A 1938	85
36A 324	32	36A 1504	84	36A 1648	86	36A 1939	85
36A 328	34	36A 1505	84	36A 1762	30	36A 1940	85
36A 338	34	36A 1506	84	36A 1813	48	36A 1941	85
36A 343	34	36A 1507	84	36A 1831	60	36A 1942	85
36A 352	34	36A 1508	84	36A 1844	36	36A 1943	85
36A 356	34	36A 1509	84	36A 1877	82	36A 1944	85
36A 360	34	36A 1510	84	36A 1881	82	36A 1945	85
36A 364	34	36A 1511	84	36A 1882	85	36A 1946	85
36A 463	60	36A 1512	84	36A 1883	85	36A 1947	85
36A 476	60	36A 1513	84	36A 1884	85	36A 1948	85
36A 490	62	36A 1514	84	36A 1885	85	36A 1949	85
36A 523	17	36A 1515	84	36A 1886	85	36A 1950	85
36A 537	60	36A 1546	84	36A 1887	85	36A 1951	85
36A 549	40	36A 1547	84	36A 1888	85	36A 2012	86
36A 569	54	36A 1548	84	36A 1889	85	36A 2013	86
36A 571	36	36A 1549	84	36A 1890	85	36A 2014	86
36A 575	36	36A 1550	84	36A 1891	85	36A 2015	82-86
36A 578	36	36A 1551	84	36A 1892	85	36A 2016	86
36A 631	28	36A 1552	84	36A 1893	85	36A 2017	86
36A 649	78	36A 1553	84	36A 1894	85	36A 2018	86
36A 682	78	36A 1554	84	36A 1895	85	36A 2019	86
36A 699	64-66	36A 1555	84	36A 1896	85	36A 2020	86
36A 706	72-80	36A 1556	84	36A 1897	85	36A 2021	86
36A 743	12	36A 1557	84	36A 1898	85	36A 2022	86
36A 750	72-80	36A 1558	84	36A 1899	85	36A 2023	86
36A 755	42	36A 1559	84	36A 1900	85	36A 2024	86
36A 806	66	36A 1560	84	36A 1901	85	36A 2025	86
36A 812	56	36A 1561	84	36A 1902	85	36A 2026	86
36A 820	60	36A 1562	84	36A 1903	85	36A 2027	86
36A 824	62	36A 1563	84	36A 1904	85	36A 2028	86
36A 825	62	36A 1564	84	36A 1905	85	36A 2175	62
36A 832	60	36A 1565	84	36A 1906	85	36A 2223	62
36A 880	44	36A 1566	84	36A 1907	85	36A 2243	48
36A 924	80	36A 1567	84	36A 1908	85	36A 2255	48
36A 999	32	36A 1568	84	36A 1909	85	36A 2256	48
36A 1434	12	36A 1569	84	36A 1910	85	36A 2257	48
36A 1486	84	36A 1570	84	36A 1911	85	36A 2391	12
36A 1487	84	36A 1571	84	36A 1922	85	36A 2397	12
36A 1488	84	36A 1572	84	36A 1923	85	36A 2423	48
36A 1489	84	36A 1573	84	36A 1924	85	36A 2495	38
36A 1490	84	36A 1574	84	36A 1925	85	36A 2515	60

N U M E R I C A L I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
36A 2516	44	36A 2863	84	50A 162	44	50A 2827	48
36A 2697	62	36A 2864	84	50A 193	20	50A 2832	22-78
36A 2700	44	36A 2865	84	50A 196	36	50A 2836	48
36A 2743	62	36A 2866	84	50A 197	78-80	50A 2843	22-26
36A 2813	84	36A 2867	84	50A 232	78	50A 2846	60
36A 2814	84	36A 2868	84	50A 245	78	50A 2859	58
36A 2815	84	36A 2869	84	50A 446	32-64	50A 2862	34
36A 2816	84	36A 2870	86	50A 577	78-80	50A 3602	36
36A 2817	84	36A 2871	86	50A 578	78-80	GM 100659	13
36A 2818	84	36A 2872	86	50A 581	44	GM 100675	14
36A 2819	84	36A 2873	86	50A 582	52	GM 100714	14
36A 2820	84	36A 2874	86	50A 594	46	GM 100737	30
36A 2821	84	36A 2875	86	50A 595	50	GM 102396	22
36A 2822	84	36A 2876	86	50A 596	48	GM 102584	78
36A 2823	84	36A 2877	86	50A 599	50	GM 102585	80-82
36A 2824	84	36A 2878	86	50A 600	38	GM 102634	21-26
36A 2825	84	36A 2879	86	50A 647	78-80	GM 102635	8-12
36A 2826	84	36A 2880	86	50A 648	78-80	GM 102649	42-56
36A 2827	84	36A 2881	86	50A 765	12	GM 102735	22
36A 2828	84	36A 2882	86	50A 766	34	GM 103025	54-56
36A 2829	84	36A 2925	60	50A 767	34	GM 103026	42
36A 2830	84	36A 3026	86	50A 768	34	GM 103028	6-58
36A 2831	84	36A 3027	86	50A 824	4	GM 103319	58
36A 2832	84	36A 3028	86	50A 934	50	GM 103320	13-33
36A 2833	84	36A 3029	86	50A 935	50	GM 103329	78-80
36A 2834	84	36A 3030	86	50A 936	50	GM 103340	16-21
36A 2835	84	36A 3053	86	50A 937	50	GM 103362	70
36A 2836	84	36A 3054	86	50A 940	50	GM 103372	16-80
36A 2837	84	36A 3055	86	50A 941	50	GM 103373	16-38
36A 2838	84	36A 3056	86	50A 942	60	GM 103385	8-38
36A 2839	84	36A 3057	86	50A 946	70	GM 103388	42
36A 2840	84	36A 3058	86	50A 948	70	GM 103406	48
36A 2841	84	36A 3065	86	50A 1000	12	GM 103409	17-40
36A 2842	84	36A 3066	86	50A 1008	12	GM 103647	6-24
36A 2843	84	36A 3067	86	50A 1041	22	GM 103865	13-32
36A 2844	84	36A 3068	86	50A 1043	58	GM 103877	50
36A 2845	84	36A 3069	86	50A 1156	71	GM 103881	20
36A 2846	84	36A 3070	86	50A 1370	44	GM 103905	22
36A 2847	84	36A 3298	62	50A 1371	44	GM 103906	8
36A 2848	84	36A 3300	62	50A 1666	70	GM 105404	30
36A 2849	84	36A 3307	28	50A 1858	36	GM 105416	30
36A 2850	84	36A 3321	70	50A 2024	48	GM 105475	70
36A 2851	84	36A 3322	70	50A 2032	36-38	GM 105478	24-64
36A 2852	84	36A 3323	70	50A 2041	8	GM 105479	24-66
36A 2853	84	36A 3325	62	50A 2143	40	GM 105480	24
36A 2854	84	36A 3326	70	50A 2330	70	GM 105481	24
36A 2855	84	36A 3327	70	50A 2473	22	GM 105482	12
36A 2856	84	36A 3329	70	50A 2480	70	GM 106267	10
36A 2857	84	36A 3368	62	50A 2481	13-20	GM 106749	36
36A 2858	84	36A 3372	62	50A 2602	60	GM 106751	10
36A 2859	84	36A 3374	62	50A 2823	36	GM 107837	30-61
36A 2860	84	36A 3375	62	50A 2825	78	GM 108574	80
36A 2861	84	36A 4065	60	50A 2826	80-82	GM 109084	18
36A 2862	84	36A 4275	60				

P A R T I C U L A R I N D E X

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
GM 110094	40	GM 132046	36	GM 179833	4	GM 219758	78
GM 111296	42-78	GM 132056	36	GM 179837	42-52	GM 223092	34
GM 113625	14	GM 132664	30	GM 179839	8-12	GM 225857	44
GM 113902	70	GM 132900	30	GM 179840	26	GM 271284	56
GM 113955	4	GM 133053	80-82	GM 179841	22-26	GM 271285	54-56
GM 114492	16	GM 137422	13	GM 179845	4-6	GM 271501	80
GM 114494	8	GM 137634	42	GM 179846	64	GM 271505	42
GM 114496	54-56	GM 138202	36	GM 179883	22	GM 271506	44
GM 114499	54-56	GM 138226	64-66	GM 179885	4	GM 271546	66-76
GM 114503	6-8	GM 138290	78-80	GM 179888	6	GM 271548	82
GM 114507	28	GM 138357	82	GM 179896	6	GM 271560	10
GM 114640	4	GM 138652	76	GM 180016	32-62	GM 271566	42
GM 114981	14	GM 139502	40	GM 180020	17	GM 271723	33-42
GM 115548	54-56	GM 140381	13	GM 180024	70	GM 271731	60
GM 116391	4	GM 140585	32	GM 180073	44-80	GM 272120	42
GM 116566	6	GM 141539	4	GM 180077	17-66	GM 272123	48
GM 119254	44	GM 142427	13	GM 180078	32-36	GM 273148	60
GM 119931	71	GM 143162	21	GM 180079	32	GM 273352	48
GM 120013	26	GM 144113	70	GM 180080	33	GM 274563	48
GM 120214	76	GM 144138	66	GM 180081	71	GM 426099	60
GM 120217	36	GM 144244	48	GM 180087	50	GM 427590	61
GM 120236	28-40	GM 144315	18	GM 180088	38	GM 427640	40
GM 120240	12	GM 144355	18	GM 180116	32	GM 431508	26
GM 120368	38	GM 144801	66	GM 180118	62	GM 431509	26
GM 120369	48	GM 145619	72	GM 180120	52-60	GM 435507	60
GM 120372	36	GM 145629	58	GM 180121	62-64	GM 442720	30
GM 120374	62	GM 145631	54-56	GM 180122	48-60	GM 444688	50-70
GM 120375	17-30	GM 145637	34	GM 180123	28-32	GM 444740	4
GM 120376	17-38	GM 145641	32-34	GM 180124	12-62	GM 444746	4
GM 120377	26-32	GM 145643	32-36	GM 180126	24	GM 444780	32
GM 120378	40-54	GM 145645	58	GM 180128	36-62	GM 444794	6
GM 120382	32-33	GM 145657	32	GM 180129	32	GM 444814	38
GM 120384	78-80	GM 147105	64	GM 180130	36	GM 444879	60
GM 120385	80	GM 147485	32	GM 180132	33	GM 446257	60
GM 120393	17	GM 155343	30	GM 180134	70	GM 451343	52
GM 120394	24-36	GM 172576	42	GM 180138	50	GM 454750	28
GM 120395	48	GM 172578	40	GM 180149	60	GM 456004	24
GM 120428	5-22	GM 172600	4	GM 180171	72	GM9402680	30
GM 121222	48-50	GM 173102	42	GM 180173	72	GM9402708	71
GM 121223	17	GM 178434	46	GM 180176	80-82	GM9402709	38
GM 121358	52	GM 178458	20	GM 180179	78	GM9402865	36
GM 121574	33-60	GM 179793	58	GM 180180	36-40	GM9402953	50
GM 124583	32	GM 179795	82	GM 180183	54	GM9409010	33
GM 124589	33-42	GM 179797	18	GM 180185	60	GM9409049	10
GM 124829	48	GM 179812	4	GM 180188	36	GM9409055	4
GM 124920	38	GM 179814	46	GM 180191	60	GM9410202	71
GM 124925	30	GM 179816	26-28	GM 180192	62	GM9410204	70
GM 127792	64-66	GM 179817	13-46	GM 180201	32	GM9410280	71
GM 127793	64	GM 179818	28-34	GM 180218	32	GM9410976	70-71
GM 131018	52	GM 179820	21	GM 180479	54	GM9410977	38
GM 131046	54-56	GM 179821	21	GM 181347	54-56	GM9410978	70
GM 131200	38	GM 179824	21	GM 181400	42	GM9411154	70
GM 131958	14	GM 179825	21	GM 181652	28		
GM 131963	14	GM 179829	64-66	GM 181669	44		





SUPPLEMENT "A"

TO MY 40 AND MY 60 LIFT TRUCKS

PARTS, OPERATION AND MAINTENANCE MANUAL S-292

MINNEAPOLIS-MOLINE, INC.
HOPKINS, MINNESOTA 

(

(

(

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		Supplement "A" to Parts, Operation and Maintenance Manual S-292	
		This supplement is to be used in conjunction with repair section of the S-292 manual. Changes and additions are listed in this supplement.	
Page 4		Omit 10A6958 seal, ref. #22 Change 11A16004 dipstick to 11A19552 Change GM179833 to GM179839 and length to 2/8"-12 x 1".....	9 5
		Add GM179841 Bolt - hex. head, 3/8"-18 x 1-1/4".....	5
		Change quantity on 10A9836 from 3 to 1.....	2
		Add 15A15558 Clip - wire, on screw.....	2
		Add 10A8140 Stud - for adapter.....	2
		Add GM102634 Nut - hex., 5/16"-18.....	2
		Add 11A17006 Cover - on large side cover (MY 60).....	1
		Add 35A708 Gasket - cover.....	1
Page 5		Change 35A2935 to 10A16337 and size to 1-1/2" O.D. x 7-1/4"	
		Add 14R281 Gasket Set - engine overhaul.....	1
		Add 10R972 Gasket Set - valve grinding.....	1
Page 8		Change quantity on 10A10758 from 1 to 6 Omit 10A5936 stud Change 10A5933 stud to 10A1989, 3 used Change quantity on 10A5937 stud from 6 to 4 Change GM103028 nut to GM214442 Add 10A6999 Washer - stud.....	15
Page 9		Change 10A7202 tube to 10A16333 Change 10A6016 nut to 10A19162 Add 10A16332 Rod - metering, oil pipe.....	1
Page 10		Change 11A4860 piston (ref. # 11) to 11B4860 Change 11A17475 piston (ref. # 11) to 11B17475 Change 11A17476 piston (ref. #11) to 11B17476 Change 10R992 rings (ref. # 14) to 10R1047, with expanders Change 10R996 rings (ref. # 14) to 10R1048, with expanders Change 10R994 rings (ref. # 14) to 10R1049, with expanders	
Page 12		Change 10A7729 manifold to 10A19613 Change 10A9027 stud to 10A9072 correction Change GM102685 nut to 50A1000 (see=proof)	
Page 18		Add 35P631 Repair Kit - vaporizer.....	1
		Change 35P507 solenoid to 35P1084 Add 35P1037 Diaphragm - assembly, for carburetor.....	1
Page 22	10A5063	Change 10A17879 hose (ref. # 30) quantity from 2 to 1 and length to 14" Add to follow: Hose - with coupling, 12-5/8" long.....	1


Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 24		Add single asterisk to parts listed under Hoses and Thermostat *NOTE: Used on MY40 Lift Truck to No. 20100250, Inc. *NOTE: Used on MY60 Lift Truck to No. 20200123, Inc. Add the following:	
	35A6678	**Hose - inlet	1
		**GM106480 - Clamp, hose, 2"	2
	10A10689	**Hose - outlet	1
		**GM106480 - Clamp, hose, 2"	2
	10A5736	**Thermostat - 170°	1
	10A6810	**Housing - thermostat	1
		**GM179841 - Bolt, hex., 3/8"-18 x 1-1/4"	3
	10A6829	**Gasket - housing	1
	10A19482	**Support - housing	1
		**GM179818 - Bolt, hex., 5/16"-18 x 3/4"	1
		**GM179826 - Bolt, hex., 5/16"-18 x 2"	1
		**GM103340 - Washer, plain, 11/32" I.D., 11/16" O.D.	1
	10A10758	**Stud - in adapter for support	1
		**NOTE: Used on MY40 Lift Truck No. 20100251 and after. **NOTE: Used on MY60 Lift Truck No. 20200123 and after.	
Page 28		Change 10A16398 support (ref. #3) to 10A17829 Change 10A8754 bar (ref. #4) to 10A18084 Change 10A9758 starting motor (ref. #6) to 10A19196 Add to follow 35A3807 wire:	
	35A3011	Wire - tail lamp extension	1
		Add to description on 35A3307, for MY40	
	35A3778	Box - battery, MY60	1
	10P2338	Battery - dry, 12 volt, Model 5 SN	1
	10P2367	Electrode - 3 - 2 qt. package	1
	10P2368	Electrode - 5 gallon	-
	10P2369	Hose - electrode dispenser for 5 gallon container	-
		Add to description on 35A3383 for MY 40	
	35A2147	Clamp - battery hold down, for MY 60	1
		Change 35A2231 pin (ref. # 24) to 35A6868.	
Page 30		Change 35A1762 support (ref. # 6) to 35A5188 Change 35A1759 tube to 35A5187 Change 35A2691 and 35A2690 hourmeter (ref. # 12) to 35A4277	
	35A4274	Wire - hour meter, positive	1
	35A4280	Wire - hour meter, negative	1
		Add a single asterisk (*) to 35A1757, 35A2496, and 35A1754 *NOTE: Used on MY 40 Lift Truck to No. 20100125, Inc. *NOTE: Used on MY 60 Lift Truck to No. 20200098, Inc.	
	35A3253	Switch - neutral starting, in control valve	1
		**NOTE: Used on MY 40 Lift Trucks No. 20100126 and after. **NOTE: Used on MY 60 Lift Trucks No. 20200099 and after.	

Ref No	Part No	DESCRIPTION	No Pcs
Page 32		Change GM103866 plug to 50A954 twice Change 10A2297 plug (ref. # 3) to 35A3236 Change 35A1467 dipstick (ref. # 10) 35A2521 Change 35A899 sleeve (ref. # 11) to 35A999 and add to follow 50A1768 "O" Ring - dipstick sleeve	1
	35A6958	Change GM180116 bolt to GM180120 and size to 3/4" long Add to follow GM120377 Washer - filler tube bracket	1
		Change 35A3268 plug to 50A955 Change GM180076 bolt to GM180021 following ref. # 30.	
Page 33		Add the following seals for converter pump Seal - converter pump	1
	35P613	"O" Ring - converter pump, 1/2" I.D., 11/16" O.D.	1
	10A27	"O" Ring - converter pump, 5-1/2" I.D., 5-3/4" O.D.	1
	M536		
Page 34		Add the following housing assemblies prior to line 4 Housing - assembly, input, complete	1
	35R29	Housing - assembly, output, complete	1
	35R30	Change description on 35A2133 housing (ref. # 4) to read, Housing - less plates, pistons, rings, springs and seals Add to follow GM223092 screw (ref. # 42)	
	35A7724	Pin - screw, 1/4" x 25/82" long	1
Page 36		Change 35A278 gasket (ref. # 2) to 35A378 (curr.) Change 35A7 body (ref. # 3) to 35A6079 and add the following Plug - housing, 3/4"-16 N.P., on unit less neutral starting switch	1
	10P1595	"O" Ring - plug	1
	35P294	Switch - neutral starting	1
	35A6283	Add to follow GM132046 50A1879 Screw - 12 pt. cap., 1/4"-20 x 1"	1
		Change 35A372 spool (ref. # 5) to 35A5348 Change 35A691 spring (ref. # 20) to 35A1770 and coils to 12-1/2 Change 35A10 cylinder (ref. # 39) to 35R24 housing assembly Includes 1 - 35A10, 1 - 35A693, 1 - 35A698, 1 - 35A5184, 1 - 35A695, 1 - 35A698, 2 - 10A4538, 1 - 50A196, 1 - 35A5185, 1 - 35A6828, 1 - 35A669, 1 - 10A136, and 1-50A3692. Change 35A697 plug (ref. # 30) to 35A5184 plug with vent hole, add the following parts that work in 35A5184	
	35A5185	Vent - valve	1
	35A6838	Disc - filter, latching plug, 1/16" x 5/16" O.D.	1
	35A689	Spring - disc, inside of plug, 9/16" O.D., 14-1/2 coils x 3/4" long	1
		Change GM180128 bolt to GM180130 and length to 2" Change 50A2829 pin to 50A2832 (curr.) Change 35A578 support (ref. # 42) to 35A5584	

Ref. No	Part No	DESCRIPTION	No. Pcs.
Page 38	35A1443 35A1444 35A1445	Change quantity on 35A586 link (ref. #48) from 1 to 2 and add note to follow, 2 used when neutral starting switch is mounted in control valve housing. Change 36A2495 link (ref. #48A) to 36A5772 link, used on earlier lift trucks on which neutral starting switch is not mounted in control valve housing. Add a single asterisk (*) to 35A1282, 35A1288 and 35A1284 *NOTE: Used on MY40 lift trucks. *Tube - filter to transmission case *Tube - filter to cooler inlet *Tube - filter to transmission case *NOTE: Used on MY60 lift trucks. Change GM9410977 elbow (ref. #61) to GM9410208 connector. Change quantity on GM9410977 (ref. #67) from 1 to 2.	1 1 1
Page 40		Change 35A1483 housing (ref. #11) to 35A5066.	
Page 42		Change 35P123 cone (ref. #19) to 10A574 (same as).	
Page 44		Change GM102865 to 50A954 following ref. #20. Change 35A2112 plug to 35A3256.	
Page 46	35A5665	Change the description on the following parts from right hand to left hand: 35A1241, 35P318, 35P332 and 35P335. Change the description on the following parts from left hand to right hand: 35A1242, 35P317, 35P331 and 35P334. Add to follow 35A1242: Screw - cap (special), 9/16" -12 x 1-5/8" Change quantity on 50A694 screw from 14 to 4.	10
Page 48		Change 36A2256 pedal (ref. #1) to 36A6066. Add GM271283 - Fitting - freeze, 1/8"-27 x 45° Change 36A2255 pedal (ref. #2) to 36A5064. Add GM124824 Nut - hex., jam, 5/16"-16 GM102445 - Set Screw - oval point, 5/16"-18 x 1" GM271283 - Fitting, grease, 1/8"-27 x 45° Change 35A1811 shaft (ref. #4) to 35A5916. Change 50A2836 Pin - roll, 3/16" x 1-1/2". Change 35A1810 bracket (ref. #5) to 35A5914. Change quantity on GM120377 nut from 1 to 2 and add: 50A1033 - Nut, hex. (gripco), 3/8"-16 Change 35A2385 clevis (ref. #24) to 36A6452 and add: GM117883 - Clevis - rod GM274663 - Pin, clevis GM121822 - Pin, cotter GM272123 - Nut, hex. jam, 7/16"-20 Change 10A2382 sleeve (ref. #28) to 35A2882.	1 1 1 1 2 1 1 1 1
Page 52		Add to follow GM180120 bolt, GM181894 Bolt, hex., 1/2"-20 x 7/8" Add to follow GM120377 nut, GM120371 Nut, hex., 1/2"-20, Add to follow ref. #7, 35A558 cap. *Tire and Tube, 6:00 - 6:90 x 8", 10 ply, MY40 Add to follow 35P123 cap; *Tire and Tube, 7:50 x 10, 10 ply, MY60 Change 35A146E bolt (ref. #9) to 35A6398. Add to follow 35A1300 stud, ref. #12 hardware; *Tire and Tube, 7:50 x 15, 12 ply, MY40 *Tire and Tube, 8:25 x 15, 12 ply, MY60 Change 35A419 center to 35A6145. Change 35A146E bolt to 35A6399. Change 35A1300 stud to 35A2700. Add to follow 35A1012 spacer; *Tire and Tube, 7:50 x 15, 12 ply, MY40 and MY60	16 16 2 2 2 2 4

Rei. No.	Part No.	DESCRIPTION	No. Pcs.
Page 54	10P2061 10P2060	Change description on 86A582 to Gear - steering, leaf arm and change includes the following 23 parts; Omit GM114486 nut (ref. #22) and use: Nut - lock, adjusting screw..... Washer - lead, lock nut..... Change 35A3001 arm (ref. #24) to 35A2888. Add to description on 35A588 (ref. #28) booster stud to steering arm. Change 35A1040 drag link (ref. #32) to 35A6492 and add to description booster rod to axle housing. Change 35P302 seal (ref. #93) to 10P1881 and add: GM102648 - Nut, hex., locked, 9/16"-18.....	1 1 3
Page 56	10P2061 10P2060	Omit GM114486 - Nut, (ref. #22) and add: Nut - lock, adjusting screw..... Washer - lead, lock nut.....	1 1
Page 58		Change 35P49 piston (ref. #1) to 35P349 (cont.) Change GM103028 nut (ref. #2) to 30A1010 lock nut.	
Page 60	35A8700 35A5315 35A5600	Change 36A2825 frame (ref. #1) to 36A2892. Change 36A4065 frame to 36A7598. Change 36A4275 frame to 36A3376. Add new mounting pad Pad - bonded, engine to frame (MY40)..... Change 36A463 bracket (ref. #8) to 36A6782. Change 35A802 bracket to 36A6572. Change GM180181 bolt to GM180182 and: Add to description on 35A470 support (ref. #7) with 2 holes used on support. Add to description on 35A803 support (ref. #7) with 2 holes used on support Add new supports for frames with 4 bolt support mounting Support - differential case to frame, MY 40..... Support - differential case to frame, MY 60..... 30A1730 - Bolt, hex., 5/8"-11 x 4"..... Change 36A501 safety walk to 35A6068 and size to 12" x 20" Change GM448257 washer to 30A2888, 25/32" I.D., 1-5/8" O.D.	2 2 2 8
Page 61	35A5773 35A6381 35A6454 35A6455	Change 35A382 decal to 35A8089. Change 36A364 decal to 30A4969 and add the following decals: Decal - starting caution..... Decal - strap..... Decal - spear, R.H..... Decal - spear, L.H.....	1 2 1 1
Page 62		Change 35A2178 support (ref. #6) to 35A2178. Change 35A2179 support (ref. #7) to 35A2179.	
Page 64		Add note to heading (Used on MY 40 lift trucks to No. 20100175 Inc.) Change 35P278 bearing to 30A164 (same as). Change 10P1595 spring (ref. #28) to 10P1592. Add new group for hydraulic pump on MY40.	


Ref. No	Part No	DESCRIPTION	No. Pcs
		HYDRAULIC PUMP	
		Used on MY40 Lift Truck No. 20100176 and after.	
1	86A3014	Pump - hydraulic, with flow divider	1
		Includes the following 23 parts:	
2	35P263	Body - pump, with bearings	1
3	85P270	Cover - pump, with bearings	1
4	35P287	Bearing - needle, Torrington No. B1416	4
5	10P1860	Shaft - drive	1
6	10P1864	Gear - drive shaft	1
7	30A164	Bearing - ball, drive shaft, New Dep. No. 3206	1
8	35P279	Ring - bearing retainer, Truarc No. 5100-118	2
9	10P1863	Adapter - bearing	1
		GM147105 - Screw, adapter, No. 8-22 x 1	2
10	35P277	"O" Ring - adaptor	1
11	35P276	Washer - thrust, ball bearing	1
12	35P283	Retainer - with oil seal	1
13	10P1772	Seal - oil, Chicago Rawhide No. 601391	1
	10P1966	Screw - retainer, std. cutting, No. 10-24 x 3/8"	4
14	35P286	"O" Ring - retainer, 1-15/16" O.D.	1
15	10P1568	Gear - idler	1
16	10P1862	Plate - gear	1
17	10P1861	Pin - cover, gear plate	2
		GM175829 - Bolt, hex., cover to body, 5/16"-18 x 2-3/4"	0
18	35P285	Plate - wear, pump body	1
19	35P288	Plate - wear, pump cover	1
20	35P288	Seal - wear plate, outer, rubber	2
21	35P284	Seal - wear plate, inner, rubber	2
22	35P281	Ring - back-up, wear plate seal	2
23	35P287	"O" Ring - 5/8" I.D., 3/4" O.D.	2
24	10P1859	Flow Divider, assembly	1
25	10P1591	Piston	1
26	10P1590	Spring - piston	1
27	10P1595	Plug - piston and spring	1
28	35P294	"O" Ring - piston plug	1
29	35P290	Valve	1
30	10P1406	Spring - valve	1
31	35P293	Shim - valve spring	A.R.
32	35P292	Plug - valve spring	1
33	35P296	"O" Ring - flow divider to pump	2
		GM135226 - Screw - flow divider to pump, 5/16"-19 x 2"	4
34		GM127782 - Elbow - pump inlet, 1"-90°	1
35	10A16952	Gear - helical, on pump shaft	1
36	10A5648	Key - gear	1
37	11A5647	Washer - lock, gear to shaft	1
		GM179818 - Bolt, hex., 5/16" x 18 x 3/4"	1
		GM186283 - Bolt, pump to housing, 3/8"-18 x 5"	2
38	10A10234	Washer - pump holt	2
39	35A705	Gasket - pump to side cover	1
40	35A1285	Hose - suction strainer to pump	1
41		GM105487 - Clamp, hose, 1-3/4"	2
42	35A2524	Nipple - pipe, 1" x 2"	2
43	35A698	Strainer - suction	1
44	3EAB89	Flange - mounting, on hydraulic oil tank	1
		GM190121 - Bolt, hex., 3/8"-16 x 7/8", cad.	6
45		GM127793 - Elbow, pipe, 1", 90°	1
46	35A700	Gasket - flange to tank	1



HYDRAULIC PUMP

Ref. No	Part No	DESCRIPTION	No. Pcs
Page 66		Change GM105479 clamp to GM105478 and also to 2-3/4".	
Page 68		Add a single cross (+) to 35A3078 valve. +NOTE: Used on MY40 Lift Trucks to No. 20100175 Inc.	
	35A6739	+ Valve - control, MY40	1
	35P227	+NOTE: Used on MY40 lift trucks, No. 20100178 and after, Add note to 35P221 spring, (ref. #16) for 35A3078 valve.	
	35A3118	Spring - relief, for 35A6739 valve	1
	15P747	Plug - valve, power beyond	1
		Gasket - plug, power beyond	1
Page 70		Change 50A948 nipple (ref. #13) to GM128067 and size to 1-1/2". Change 10A1473D elbow (ref. #19) to 10A12470. Change 35A9039 hose (ref. #23) to 50A3863. Change 10A6285 "O" ring (ref. #28) to 10A16285. Add to follow 10A16405 "O" ring, ref. #42: 50A603 - Clip, hose, on upright pin	1
	35A8300	Clip - hose, tilt cylinder, left hand	1
Page 71		Add new fitting to replace 50A1256 on late model trucks. Fitting - hose, 1/4"-15 x 90°	1
Page 72		Change 35A2746 cylinder (ref. #2) to use the following: Cylinder - assembly for MY40 Lift Trucks	1
	35A6686	Rod - piston, for 35A6686 cylinder, 18-7/8" long	1
	35P1280	Cylinder assembly, for MY60 Lift Trucks	1
	35A7710	Rod - piston, for 35A7710 cylinder, 13-5/8" long	1
	35P1063	Add to description on 35P313 rod, for 35A2746 cylinder. Change 35P305 nut (ref. #9) to 50A1140, 1-1/8"-22. Change 35P816 ring (ref. #16) to 10A7848 (same as) Change 35P211 and (ref. #18) to 35G5223. Change 35P212 bushing (ref. #21) to 15A13163. Change 36A706 pin (ref. #21) to 36A4925 and length to 3-3/8" long. Pin - tilt cylinder, 2-1/4" x 3-1/4"	2
	35A5301	50A2831 - Pin, roll, 1/4" x 2-1/4"	2
	25A32	Repair Kit - tilt cylinders, consists of items 5, 6, 7, 12, 13, 14, 15 and 18.	
Page 74		Change 35P486 retainer (ref. #4) to 35P169. Change 35P486 piston (ref. #7) to 35P168. Add to description of 35P176 (ref. #8) packing set, includes V-rings, packing and adapter. Omit 35P178 V-ring, 35P177 packing, and 35P179 adapter. Repair Kit - lift cylinder, consists of items 8, 12, 13, 14, 20, and 21.	
	35R35		
Page 76		Add to heading: <p style="text-align: center;">Group I</p> Used on MY40 Lift Truck to No. 20100175 Inc.	
	35P156	Washer - piston packing	1
Page 77A		Add new Duplex Lift Cylinder	


Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 77A (Cont'd)		Duplex Lift Cylinder Group II Used on MY 40 Lift Trucks No. 20100176 and after.	
1	35A5237	Cylinder - lift, complete, 35-1/2" long	1
1	35A5246	Cylinder - lift, complete, 40-1/2" long	1
1	35A5250	Cylinder - lift, complete, 44" long	1
		Each includes the following 34 parts:	
3	35P1120	Shell - for 35-1/2" cylinder	1
2	35P1121	Shell - for 40-1/2" cylinder	1
2	35P842	Shell - for 44" cylinder	1
8	35P883	Screw - button head, cylinder shell	1
4	35P832	*Seal - button head screw	1
5	35P1122	Tube - intermediate, for 35-1/2" cylinder	1
5	35P1123	Tube - intermediate, for 40-1/2" cylinder	1
5	35P844	Tube - intermediate, for 44" cylinder	1
6	35P1124	Plunger - for 35-1/2" cylinder	1
6	35P1125	Plunger - for 40-1/2" cylinder	1
6	35P848	Plunger - for 44" cylinder	1
7	35P822	*Ring - wiper, intermediate tube	1
8	35P829	Spring - garter, wiper ring	1
9	35P834	Retainer - wiper ring	1
10	10P1241	*"O" Ring - retainer, 4-1/2" I.D., 4-3/4" O.D.	1
11	35P836	Bushing - intermediate tube	1
12	10A13782	*"O" Ring - intermediate tube bushing, 4-1/8" O.D., 4-3/8" O.D.	1
13	35P835	*Ring - back-up, "O" ring	1
14	35P837	*Packing - tube bushing	1
15	35P840	*Ring - wiper, plunger	1
16	35P829	*Spring - garter, wiper ring	1
17	35P838	Retainer - plunger wiper ring	1
19	10A13447	*"O" Ring - wiper ring retainer, 3-1/4" I.D., 3-1/2" O.D.	1
19	35P820	Piston	1
20	35P824	*Packing - piston	1
21	10A4729	*"O" Ring - piston, inner, 2-1/4" I.D., 2-1/2" O.D.	1
22	35P821	*Ring - back-up, "O" ring	1
23	35P823	Ring - snap, piston retainer	1
24	35P826	Bearing - intermediate tube	1
25	35P825	Ring - bearing retainer	1
26	35P827	Ring - snap, bearing	1
27	35P828	Head - cylinder	1
28	10A13135	*"O" Ring - cylinder head, 4-5/8" I.D., 4-7/8" O.D.	1
29	35P830	*Ring - back-up, head "O" ring	1
30	35P821	Nut - lock, cylinder head	1
31	35A5530	Spacer - intermediate tube, 1/4" x 4-5/32" O.D., for 35-1/2" and 40-1/2" cylinders	1
31	35A5532	Spacer - intermediate tube, 1" x 4-5/32", for 35-1/2" cylinder	1
32	35A5532	Spacer - plunger, 1/4" x 3-5/32", for 35-1/2" and 40-1/2" cylinders	1
32	35A5534	Spacer - plunger, 1" x 3-5/32", for 35-1/2" cylinders	1
33	35P1025	Spring - oil restrictor	1
34	35P140	Washer - perforated, oil restrictor	1
35	35P146	Spacer - oil restrictor	1
	35R37	*Repair Kit - lift cylinder	1
		NOTE: Repair Kit consists of the above items identified by an asterisk ()	
Page 78		Add to heading on MY 40 Duplex Upright Group III Used on MY 40 Lift Trucks to No. 20100175 inc. Change 35A523 pin (ref. # 15) to 35A5459 and size to 1-25/32" Change ref. # 16 description to read, see chart on page 54 Change ref. # 34 description to read, see chart on page 55	



DUPLEX LIFT CYLINDER

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
Page 79A		Add new MY 40 Duplex Upright MY 40 Duplex Upright Group IV	
1	-----	Rail - outer assembly, see page 84 additions	1
2	86A5918	Pin - upright to frame, 1-1/2" x 2-3/4" long	2
3	50A1771	Pin - roll, 1/4" x 3"	2
		GM271287 - Fitting, grease, 1/4" -28	2
	35A588	Bushing - pivot pin, 1-1/2" I.D. x 1-1/4" long	2
4	-----	Rail - inner assembly, see page 84 additions	1
5	35A5535	Shoe - mast	8
		50A267E - Screw, hex, socket, 3/8"-16 x 5/8"	12
6	35A5538	Shim - mast shoe	A.R.
7	35A706	Roller - mast	10
8	D817	Bearing - mast roller	10
9		50A577 - Ring - snap, mast bearing, 3-5/32" I.D.	10
10		50A578 - Ring - snap, mast bearing, 1-3/8" I.D.	10
11	-----	Carriage - assembly, see page 86 additions	1
12	36A5317	Bearing - thrust, carriage	4
13	85A5756	Pin - thrust bearing	4
14	-----	Rack - load safety, see page 86	1
		GM271772 - Bolt, hex., 3/4"-18 x 2-1/4" cad.	8
		GM131046 - Washer, lock, cad., 3/4"	6
15	-----	Chain - 3 x 4 lacing, see page 84	2
16	3EP600	Chain - 3/4" pitch, 3 x 4 lacing, 10 foot roll	-
16	35A5041	Link - connecting, 7 links with 2 pins	-
17	35A5042	Link - connecting, 3 links with 2 pins	-
18	35A0562	Anchor - chain, lower, 2-1/2" long	2
19	35A5768	Pin - chain anchor, 2-1/3" long	2
		50A2753 - Ring, retainer, anchor pin	2
20	35A6583	Anchor - chain, upper, 4-1/2" long	2
21	85A887	Pin - chain anchor, 5/16" x 1-1/2"	4
		GM109372 - Cotter, 3/32" x 1/2"	4
22	-----	Rod - chain anchor, see page 84 additions	2
		GM219758 - Nut, hex., jam, 3/4"-16	4
		50A197 - Nut, spherical, 3/4"-16	2
23	-----	Cylinder - lift, see page 77A for component parts and listing on page 84 additions	1
		GM180130 - Bolt, hex., 3/8"-16 x 2", cad.	1
		GM124829 - Nut, hex., jam, 3/8"-16, cad.	1
24	36A9266	Head - piston	1
		GM102589 - Screw, set, cup point, 3/8"-16 x 1 1/2	1
25	35A920	Guide - piston head	2
		GM180179 - Bolt, hex., 1/2"-13 x 1-3/4" cad.	4
		GM120378 - Nut, hex, jam, 1/2"-13, cad.	4
26	86A5320	Block - stop, outer rail	2
		GM271715 - Bolt, hex., 5/8"-11 x 1"	4
27	36A6740	Sheave - chain, 8-1/8" dia.	4
28	35A5750	Sheave - chain, 6-1/4" dia.	2
29	86A531E	Bearing - sheave	6
30	35A5760	Pin - sheave bearing, 1" x 2-3/4"	4
30	85A8362	Pin - sheave bearing, 1" x 3-1/8"	2
		50A2848 - Pin, roll, 5/32" x 3/4"	6
31	-----	Fork - lifting, see page 86	2
32	35A668	Pin - fork stop, 2-1/6" long	2
33	35A669	Lever - stop pin	2
34	35A667	Spring - stop pin	2
		50A2832 - Pin, roll, 3/16" x 1"	2
35	36A3707	Latch - with bushing	1
36	10A12028	Bushing - latch, 5/8" I.D., 5/8" long	1
37	85A4084	Pin - latch, 5/8" x 1-7/8"	1
		50A2543 - Pin, roll, 3/16" x 1-1/4"	1

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
MY 40 DUPLEX UPRIGHT (Cont'd)			
38	35A3688	Cap - latch dog.....	1
39	35A3097	Plunger - latch dog.....	1
40	35A3696	Spring - latch dog.....	1
41	35A7830	Tube - vent, 1/4" and 3/3" O.D.	1
42	-----	Flange - vent tube, see page 84 additional 50A3378 - Clamp, hose, 7/16"	1 2
43	35A7307	Elbow - vent hose, 90°, 1/4"-18	1
44	35A3660	Strap - vent hose	1
		GM133056 - Screw, 3/4"-20 x 3-1/2".....	1
		GM320376 - Nut, hex., 1/4"-20.....	1
45	35A1464	Spacer - vent hose.....	1
		50A739 - Strap, hose	2
		GM102594 - Set screw, cup pt., 3/8"-16 x 1/8"	2



Ref. No	Part No.	DESCRIPTION	No. Pcs
Page 82		Add a single cross (+) to D287 plus, 56A647 screw and GM158290 screw +NOTE: Used on MY 60 Lift Trucks to No. 20200098 Inc.	
14	35A5317	+Roller - thrust, 1-1/4" I.D., 3-1/4" O.D.,	4
15	85A5755	+Pin - thrust roller, 1-1/4" x 2-1/16" long	4
		+GM102594 - Set Screw, hex. socket, 3/8"-16 x 5/8"	2
		+NOTE: Used on MY 60 Lift Trucks No. 20200099 and after.	
	35A5039	Link - connecting, 10 Hnks with 2 pins,	-
	25A5040	Link - connecting, 4 Hnks with 2 pins,	-
Page 54		Add new duplex outer rails chain anchor rod and vent hose for MY 40 Lift Trucks starting with No. 20100176 and after	

Duplex Outer Rail	Duplex Inner Rail	Duplex Cylinder Assy.	Duplex Chain Anchor Rod	Duplex Vent Hose	Mast
35A6607 - 60-1/2"	35A5606 - 60-1/2"	35A5232 - 33"	35A5780 - 14"	35A7327 - 16"	91"
35A6608 - 62"	35A5607 - 62"	35A5233 - 33"	35A5780 - 14"	35A7327 - 16"	94"
35A6609 - 63-1/2"	35A5608 - 63-1/2"	35A5234 - 33"	35A5780 - 14"	35A7327 - 16"	97"
35A6610 - 65"	35A5609 - 65"	35A5235 - 33"	35A5780 - 14"	35A7327 - 16"	100"
35A6611 - 66-1/2"	35A5670 - 66-1/2"	35A5236 - 35-1/2"	35A5781 - 16-1/2"	35A7328 - 19"	103"
35A6612 - 68"	35A5672 - 68"	35A5237 - 35-1/2"	35A5781 - 16-1/2"	35A7328 - 19"	106"
35A6613 - 69-1/2"	35A5673 - 69-1/2"	35A5238 - 35-1/2"	35A5781 - 16-1/2"	35A7328 - 19"	109"
35A6614 - 71"	35A5674 - 71"	35A5239 - 38"	35A5782 - 18"	35A7329 - 21-1/2"	112"
35A6615 - 72-1/2"	35A5674 - 72-1/2"	35A5240 - 38"	35A5782 - 18"	35A7329 - 21-1/2"	115"
35A6616 - 74"	35A5675 - 74"	35A5241 - 38"	35A5782 - 18"	35A7329 - 21-1/2"	118"
35A6617 - 75-1/2"	35A5676 - 75-1/2"	35A5242 - 38"	35A5782 - 18"	35A7329 - 21-1/2"	121"
35A6618 - 77"	35A5677 - 77"	35A5243 - 40-1/2"	35A5783 - 21"	35A7330 - 24"	124"
35A6619 - 78-1/2"	35A5678 - 78-1/2"	35A5244 - 40-1/2"	35A5783 - 21"	35A7330 - 24"	127"
35A6620 - 80"	35A5679 - 80"	35A5245 - 40-1/2"	35A5783 - 21"	35A7330 - 24"	130"
35A6621 - 82-1/2"	35A5680 - 81-1/2"	35A5246 - 44"	35A5784 - 24"	35A7331 - 26-1/8"	133"
35A6622 - 88"	35A5682 - 83"	35A5247 - 44"	35A5784 - 24"	35A7331 - 26-1/2"	136"
35A6623 - 84-1/2"	35A5682 - 84-1/2"	35A5248 - 44"	35A5784 - 24"	35A7331 - 26-1/2"	139"
35A6624 - 86"	35A5683 - 86"	35A5249 - 44"	35A5784 - 24"	35A7331 - 26-1/2"	142"
35A6625 - 87-1/2"	35A5684 - 87-1/2"	35A5250 - 44"	35A5784 - 24"	35A7331 - 26-1/2"	145"
35A6626 - 89-1/2"	35A5685 - 89-1/2"	35A5251 - 47"	35A5785 - 28"	35A7332 - 30"	148"
35A6627 - 91"	35A5686 - 91"	35A5252 - 47"	35A5785 - 28"	35A7332 - 30"	151"
35A6628 - 92-1/2"	35A5687 - 92-1/2"	35A5253 - 47"	35A5785 - 28"	35A7332 - 30"	154"
35A6629 - 94"	35A5688 - 94"	35A5254 - 47"	35A5785 - 28"	35A7332 - 30"	157"
35A6630 - 95-1/2"	35A5689 - 95-1/2"	35A5255 - 50"	35A5786 - 32-1/2"	35A7333 - 33"	160"
35A6631 - 97-1/2"	35A5690 - 97-1/2"	35A5256 - 50"	35A5786 - 32-1/2"	35A7333 - 33"	163"
35A6632 - 99"	35A5692 - 99"	35A5257 - 50"	35A5786 - 32-1/2"	35A7333 - 33"	166"
35A6633 - 100-1/2"	35A5692 - 100-1/2"	35A5258 - 50"	35A5786 - 32-1/2"	35A7333 - 33"	169"
35A6634 - 102"	35A5693 - 102"	35A5259 - 53"	35A5787 - 33-1/8"	35A7334 - 36"	172"
35A6635 - 103-1/2"	35A5694 - 103-1/2"	35A5260 - 53"	35A5787 - 33-1/8"	35A7334 - 36"	175"
35A6636 - 105-1/2"	35A5695 - 105-1/2"	35A5261 - 53"	35A5787 - 33-1/2"	35A7334 - 36"	178"

Add 35A660 for 10 ft roll of 3/4" pitch 3 x 4

